GM UPFITTER INTEGRATION

BODY BUILDER MANUAL

FOR

2017 CHEVROLET COLORADO/GMC CANYON

ELECTRICAL SECTION

Revision 1.0 *www.gmupfitter.com* *October 26, 2016*

GM UPFITTER INTEGRATION

Note to User:
As part of our mission to provide an up-to-date website that includes detailed Body Builder Manuals, Technical Bulletins, and Best Practice Manuals, we are now using sectional excerpts directly from the General Motors Service Information publications for our Electrical Body Builder Manuals.

You will note that the section numbers are non-sequential as we have provided only those that are believed to be the most pertinent to the Upfitter community and best suited to their needs.*

This new usage of the Service Information provides the opportunity for us to remain consistent with the changes that take place throughout the model year and to provide you updated information in a more timely fashion.

**** If you would like to have access to all of the electrical Service Information, please apply for a subscription from ACDelco at http://acdelcotechconnect.com/html/tss_tech_esi.jsp***

General Information

General Information

Introduction

Vehicle, Engine and Transmission ID and VIN Location, Derivative and Usage



The VIN plate is the legal identifier of the vehicle. The VIN plate is located on the upper left corner of the instrument panel (I/P) and can be seen through the windshield from the outside of the vehicle:

Vehicle Identification Number (VIN) System

Position	Definition	Character	Description
1	Country of Origin	1	United States
2	Manufacturer	G	General Motors
3	Vehicle Brand/Type	B	Chevrolet Incomplete Truck
		C	Chevrolet Truck
		D	GMC Incomplete Truck
		T	GMC Truck
4	GVWR/Brake System/Body Style	G	5001–6000/Hydraulic – Crew Cab (43)
		H	5001–6000/Hydraulic – Extended Cab (53)
		P	6001–7000/Hydraulic – Extended Cab (43)
		R	6001–7000/Hydraulic – Extended Cab (53)
5–6	Chassis/Series	S/A	Chevrolet Colorado, Base 2WD
		S/B	Chevrolet Colorado, Work Truck 2WD
		S/C	Chevrolet Colorado, LT 2WD
		S/D	Chevrolet Colorado, Z71 2WD
		S/9	Chevrolet Colorado, (Non-US, Non-Canada) 2WD
		T/B	Chevrolet Colorado, Work Truck 4WD

		T/C	Chevrolet Colorado, LT 4WD
		T/D	Chevrolet Colorado, Z71 4WD
		T/9	Chevrolet Colorado, (Non-US, Non-Canada) 4WD
		5/A	GMC Canyon, Base 2WD
		5/B	GMC Canyon, Work Truck 2WD
		5/C	GMC Canyon, SLE 2WD
		5/D	GMC Canyon, SLT 2WD
		6/B	GMC Canyon, Work Truck 4WD
		6/C	GMC Canyon, SLE 4WD
		6/D	GMC Canyon, SLT 4WD
7	Restraint System	E	Active Manual Belts, Airbags – Driver and Passenger Front (1st row), Front Seat Side (1st row), Roof Side (All seating rows)
8	Engine Type	A	RPO LCV, Engine Gas, 4 Cylinder, 2.5L, L4, SIDI, DOHC, DCVCP, VVT, E85 MAX, E0–E100, Aluminum
		N	RPO LGZ, Engine Gas, 6 Cylinder, 3.6L, V6, DI, DOHC, VVT, Aluminum, VAR2, GEN 2
		1	RPO LWN, Engine Diesel, 2.8L, DI, L4, DOHC, Turbo, XLDE
9	Check Digit	—	Check Digit
10	Model Year	H	2017
11	Plant Location	1	Wentzville, MO
12–17	Plant Sequence Number	—	Plant Sequence Number

2.5L LCV Engine ID and VIN Derivative Location

Refer to CELL Link Error - Link target cell (cell ID 220437) is invalid for this publication..

3.6L LGZ Engine ID and VIN Derivative Location

Refer to CELL Link Error - Link target cell (cell ID 72279) is invalid for this publication..

2.8L LWN Diesel Engine ID and VIN Derivative Location

Refer to CELL Link Error - Link target cell (cell ID 197081) is invalid for this publication..

6L50 MYB Transmission ID and VIN Derivative Location

Refer to CELL Link Error - Link target cell (cell ID 135940) is invalid for this publication..

8L45 M5T Transmission ID and VIN Derivative Location

Refer to CELL Link Error - Link target cell (cell ID 260620) is invalid for this publication..

Eaton 6–Speed (N8D) Manual Transmission ID and VIN Derivative Location

Refer to CELL Link Error - Link target cell (cell ID 254385) is invalid for this publication..

Vehicle Certification, Tire Placard, Anti-Theft, and Service Parts ID Label


1
2
3
4
5
6
GVWR
GAWR FRT
GAWR RR
7
15
14
8
9
MODEL:
PAYLOAD =
TIRE SIZE
SPEED
RIM
COLD TIRE PRESSURE
FRT
RR
SPA
10
SEE OWNER'S MANUAL FOR ADDITIONAL INFORMATION
13
12
11

Vehicle Certification Label

Callout	Description
1	Logo
2	Name of Manufacturer
3	Maximum Gross Vehicle Weight Rating (GVWR)
4	Maximum Gross Axle Weight Rating (GAWR) - Front
5	Final Date of Manufacture (Month and Year MM/YY) Date of manufacture callout C is to reflect the date that the vehicle is counted as built. In those cases where a replacement label is needed, the replacement label should reflect the actual build date not the date of replacement.
6	Maximum Gross Axle Weight Rating (GAWR) - Rear
7	Certification Statement
8	Vehicle Class Type (Pass Car, etc.)
9	Payload
10	Tire Pressure, Front, Rear, and Spare (Cold)
11	Original Tire Rim Size
12	Tire Speed Rating
13	Original Equipment Tire Size
14	Engineering Model Number
15	Vehicle Identification Number (VIN)


1
2
TIRE AND LOADING INFORMATION
SEATING CAPACITY
TOTAL
FRONT
REAR
The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs.
TIRE
ORGINAL SIZE
COLD TIRE PRESSURE
FRONT
REAR
SPARE
SEE OWNER'S MANUAL FOR ADDITIONAL INFORMATION
XXXXXXXXXXXXXXXX
4
3

Tire Placard

Callout	Description
1	Specified Occupant Seating Positions
2	Maximum Vehicle Capacity Weight
3	Tire Pressure, Front, Rear, and Spare (Cold)
4	Original Equipment Tire Size


1
GM
INVALIDTAG000005

Anti-Theft Label

Callout	Description
1	The Federal law requires that General Motors label certain body parts on this vehicle with the VIN. The purpose of the law is to reduce the number of motor vehicle thefts by helping in the tracing and recovery of parts from stolen vehicles. Labels are permanently affixed to an interior surface of the part. The label on the replacement part contains the letter R, the manufacturer's logo, and the DOT symbol. The anti-theft label must be covered before any painting, rustproofing procedures, and uncovered after the procedures. Failure to follow the precautionary steps may result in liability for violation of the Federal Vehicle Theft Prevention Standard and possible suspicion to the owner that the part was stolen.

RPO Code List

The following table provides the description of the Regular Production Option (RPO) codes that are available on the vehicle. The vehicle's RPO list is printed on the Service Parts Identification Label.

RPO	Description
01U	PRIMARY COLOR-EXTERIOR, SPECIAL (02)
4AA	INTERIOR TRIM-JET BLACK
4D7	INTERIOR TRIM-JET BLACK/DK ASH
4DP	INTERIOR TRIM-COCOA / DUNE
4EE	INTERIOR TRIM-JET BLACK/DK GALVANIZED WITH ICED BLUE ACCENT
4GB	INTERIOR TRIM-JET BLACK/ COBALT RED
51F	ACCESSORY-FLOOR LINER - CONTOURED - FRONT ONLY
5AZ	ACCESSORY-SAFETY KIT - UNIVERSAL
5G8	CALIBRATION-ACTIVATION 'ON', TOW/HAUL MODE
5JR	ACCESSORY-MIRROR COVERS - ALTERNATE FINISH 1
5JY	ACCESSORY-TONNEAU - RR COMPT - SOFT FOLDING
5K2	ACCESSORY-DECAL PACKAGE - BODY SIDE, DESIGN 1
5V5	ACCESSORY-SPOILER DESIGN 1
5VI	ACCESSORY-TIE DOWN RINGS - CARGO AREA
5VQ	ACCESSORY-PUBX BEDLINER - W/INTEGRAL STORAGE COMPARTMENTS
5W7	ACCESSORY-AIR FILTER - PERFORMANCE
5WI	ACCESSORY-TIE DOWN RINGS - CARGO AREA, MOVEABLE
5Y3	ACCESSORY-TOW BALL - TRAILER HITCH
5Y4	ACCESSORY-COVER - TRAILER HITCH TOW BALL
5YN	ACCESSORY-BADGE - INTERIOR TRIM, DESIGN 1
5YO	ACCESSORY-DATA RECORDER INTERFACE - VEHICLE PERFORMANCE
9B7	MIRROR AUX-O/S SPOT, CONVEX
9H3	FUEL TANK-76L, 20 GAL
9J4	BUMPER RR-(NONE)

A28	WINDOW RR-FULL WIDTH, SLIDING
AAK	ACCESSORY-FLOOR LINER - CONTOURED - ALT DESIGN 1
AAQ	ADJUSTER PASS ST-POWER, 4 WAY (DO NOT USE ON NEW PROGRAMS AFTER MY18)
ACO	IDENTIFICATION-ACCESSORY CATALOG OFFERING
AH6	ADJUSTER FRT ST-SEAT, POWER, 4 WAY, VERT, DRIVER (DO NOT USE ON NEW PROGRAMS AFTER MY18)
AJ2	SEAT RR-FOLDING, JUMPSEAT
AKJ	WINDSHIELD STYLE-SHADE BAND
AL9	LUMBAR DRIVER-SEAT, POWER, 2 WAY
AM7	SEAT RR-FOLDING
AR7	SEAT-FRT BKT, STANDARD
AT9	LUMBAR PASSENGER-SEAT, POWER, 2 WAY
ATG	LOCK CONTROL, ENTRY-REMOTE ENTRY, STANDARD RANGE
ATZ	SEAT RR-NONE
AXG	WINDOW REG DRVR DR-POWER OPERATED, EXPRESS UP/DOWN
AY0	RESTRAINT SYSTEM-SEAT, INFLATABLE, DRIVER & PASS FRT, SEAT SIDE, ROOF SIDE
B30	COVERING FLOOR-CARPET
B34	COVERING FRT-FLOOR MATS, CARPETED INSERT
B35	COVERING REAR-FLOOR MATS, CARPETED INSERT
B38	COVERING FLOOR-VINYL, FRT & RR, FULL WIDTH
BAE	EQUIPMENT-SECURITY SYSTEM, IMMOBILIZATION
BJA	PARTS PKG-TRUCK APPLICATION VAR.1
BPH	APPEARANCE PACKAGE-CHEVROLET "OFF ROAD"
BTV	REMOTE START-ENGINE
BW4	MOLDING B/S (OPEL)-EXTR, MLDG, SIDE WINDOW REVEAL, CHROME
BW5	MOLDING B/S (OPEL)-EXTR, MLDG, SIDE WINDOW REVEAL, BLACK

BW7	ORNAMENTATION-EXTR, PLR APLQ
BWN	STEPS-CORNER ASSIST, BUMPER
BYH	FOOT REST-DRIVER
C49	DEFOGGER-RR WINDOW, ELECTRIC
C67	HVAC SYSTEM-AIR CONDITIONER FRT, ELECTRONIC CONTROLS
C68	HVAC SYSTEM-AIR CONDITIONER FRT, AUTO, ELECTRONIC CONTROLS
C74	LAMP-INTR, ROOF, DUAL READING
CAV	ACCESSORY-TRAY - TRUNK/CARGO AREA
CG6	ORNAMENTATION-EXTR, NAMEPLATE, VAR 1
CGN	LINER-PUBX, SPRAY ON
D07	CONSOLE-FRT COMPT, FLOOR, CUSTOM
D31	MIRROR I/S R/V-TILT
D72	HANDLE O/S DOOR-BLACK
D75	HANDLE O/S DOOR-BODY COLOR
D87	HANDLE, REAR CLOSURE-O/S, L/GATE, R/CMPT, BLACK
DBI	MIRROR O/S-LH & RH, MANUAL CONTROL, MANUAL FOLDING
DD8	MIRROR I/S R/V-LT SENSITIVE
DEG	SUNSHADE-DRIVER, W/MIRROR, COVER, ILLUM, SLIDING, PASS, W/MIRROR, COVER, ILLUM,SLIDING
DK6	CONSOLE ROOF-INTERIOR
DL6	MIRROR O/S-LH & RH, REMOTE CONTROL, ELECTRIC, MANUAL FOLDING,COLOR
DL9	MIRROR O/S-LH & RH, REMOTE CONTROL, ELECTRIC, HEATED, CHROME
DLU	MIRROR I/S FRT VAN-SUNSHADE, DRIVER, W/O MIRROR, PASS, W/MIRROR & COVER
DNS	EQUIPMENT-SUPPLIER INSTALLED
E15	STEPS-ASSIST, CHROME
E20	HANDLE O/S DOOR-CHROME
E25	ACCESSORY-ASSIST STEPS - TUBULAR - CHROME
E33	HANDLE-I/S, DR, GLOSSY CHROME

E49	HANDLE-I/S, DR, JET BLACK
E63	BODY EQUIPMENT-FLEETSIDE PICK-UP BOX
EF7	COUNTRY-UNITED STATES OF AMERICA (USA)
EN5	END GATE--LOCKING-
FE9	CERTIFICATION-EMISSION, FEDERAL
FHX	VEHICLE FUEL-DIESEL B20
FJW	VEHICLE FUEL-GASOLINE E15
FX3	RIDE AND HANDLING-AUTOMATIC ELECTRONIC CONTROLLED
G7C	PRIMARY COLOR-EXTERIOR, PULL ME OVER RED SOLID (130X)
G7Z	PRIMARY COLOR-EXTERIOR, LASER BLUE MET (218M)
G80	AXLE POSITRACTION-LIMITED SLIP
G93	AXLE-FRT ELECTRONIC LOCKING DIFFERENTIAL, DRIVER SELECT
G94	AXLE-RR ELECTRONIC LOCKING DIFFERENTIAL, DRIVER SELECT
GAN	PRIMARY COLOR-EXTERIOR, SWITCHBLADE SILVER MET (G) 636R
GAT	APPEARANCE PACKAGE-GMC "ALL TERRAIN"
GAZ	PRIMARY COLOR-EXTERIOR, SUMMIT WHITE (G) 8624
GBA	PRIMARY COLOR-EXTERIOR, BLACK (G) 8555
GBV	PRIMARY COLOR-EXTERIOR, CYBER GRAY MET (G) 637R
GGQ	PRIMARY COLOR-BURNING HOT MET(425B)
GJB	PRIMARY COLOR-EXTERIOR, MINERAL MET (433B)
GMW	PRIMARY COLOR-DEEPWOOD GREEN MET-2 (449B)
GPA	PRIMARY COLOR-EXTERIOR, GASOLINE MET-2 (457B)
GPJ	PRIMARY COLOR-GLORY RED TINT-2 (434B)
GT5	AXLE REAR-4.10 RATIO
GU6	AXLE REAR-3.42 RATIO
GWX	PRIMARY COLOR-EXTERIOR, SUBTERRANEAN MET (105V)

H0K	INTERIOR TRIM CONFIG-LEATHER, LEVEL 3, COCOA / DUNE
H0U	INTERIOR TRIM CONFIG-CLOTH, LEVEL 2, JET BLACK
H2Q	INTERIOR TRIM CONFIG-VINYL, LEVEL 1, JET BLACK /DK ASH
H2R	INTERIOR TRIM CONFIG-CLOTH, LEVEL 1, JET BLACK/ DK ASH
H2S	INTERIOR TRIM CONFIG-CLOTH, LEVEL 2, JET BLACK / DK ASH
H2T	INTERIOR TRIM CONFIG-CLOTH, LEVEL 2, COCOA / DUNE
H2U	INTERIOR TRIM CONFIG-LEATHER, LEVEL 3, JET BLACK
H2V	INTERIOR TRIM CONFIG-LEATHER, LEVEL 3, JET BLACK / DK ASH
H2X	INTERIOR TRIM CONFIG-LEATHER, LEVEL 4, JET BLACK
HH1	INTERIOR TRIM CONFIG-CLOTH, LEVEL 4, JET BLACK / DK GALVANIZED WITH ICED BLUE ACCENT
HJX	INTERIOR TRIM CONFIG-CLOTH, LEVEL 4, JET BLACK / COBALT RED
I17	ENGINEERING YEAR-2017
IO3	RADIO-INFOTAINMENT SYSTEM - BASE HMI
IO5	RADIO-INFOTAINMENT SYSTEM - UPLEVEL HMI, ENHANCED CONNECTIVITY
IO6	RADIO-INFOTAINMENT SYSTEM - UPLEVEL HMI, ENHANCED CONNECTIVITY, EMBEDDED NAVIGATION
IOB	RADIO-INFOTAINMENT SYSTEM - MIDLEVEL HMI, MIDLEVEL CONNECTIVITY
JHD	CONTROL-HILL DESCENT, GEAR HOLD
JL1	CONTROL-INTEGRATED TRAILER BRAKE
JL9	BRAKE SYSTEM-PWR, FRT & RR DISC, ANTILOCK, FRT & RR WHL
K05	HEATER ENG-BLOCK
K34	CRUISE CONTROL-AUTOMATIC, ELECTRONIC
K40	ENGINE BRAKE-EXHAUST
K4C	CHARGER-INDUCTIVE PORTABLE WIRELESS DEVICE

KA1	HEATER SEAT FRT-DRVR & PASS
KG4	GENERATOR-150 AMP
KG9	GENERATOR-140 AMP
KU1	VENTILATED SEAT DRVR-FRONT
KU3	VENTILATED SEAT PASS-FRONT
LCV	ENGINE-GAS, 4 CYL, 2.5L, L4, SIDI, DOHC, DCVCP, VVT, E85 MAX, E0-E100, ALUM
LGZ	ENGINE-GAS, 6CYL, 3.6L, V6, DI, DOHC, VVT, ALUM, VAR2, GEN 2
LHD	VEHICLE DRIVE-LEFTHAND DRIVE
LWN	ENGINE-DIESEL, 2.8L, DI, L4, DOHC, TURBO, XLDE
M5T	TRANSMISSION-AUTO 8 SPD, 8L45
MCY	PORT, ELEK DEVICE-USB ONLY
MCZ	PORT, MULTI ELEK DEV-USB
MYB	TRANSMISSION-AUTO 6 SPD, 6L50
N30	STEERING WHEEL-DELUXE
N33	STEERING COLUMN-TILT TYPE
N37	STEERING COLUMN-TILT, TELESCOPING
N8D	TRANSMISSION-MAN 6 SPD, 85MM, 4.45 1ST, 2.56 2ND, 1.53 3RD, 1.00 4TH, 0.87 5TH, 0.76 6TH
NE1	CERTIFICATION-EMISSION, GEOGRAPHICALLY RESTRICTED REGISTRATION FOR VEHICLES UP TO 14,000 LBS GVW (USE 2003 MDL YR
NE8	EVAPORATIVE SYSTEM-LEVEL 3 EMISSIONS
NP5	STEERING WHEEL-LEATHER WRAPPED
NQ6	TRANSFER CASE-2 SPD, ACTIVE, PART TIME 4WD, L/H DROP, LOW RATIO 2.72:1
NQ7	TRANSFER CASE-2 SPD, SWITCH ACTIVATED, PART TIME 4WD, L/H DROP, LOW RATIO 2.72:1
NT7	EMISSION SYSTEM-FEDERAL, TIER 2
NTB	EMISSION SYSTEM-FEDERAL, TIER 3
NU5	EMISSION SYSTEM-CALIFORNIA, BIN 4
NUB	EMISSION SYSTEM-CALIFORNIA, ULEV70
NUF	EMISSION SYSTEM-CALIFORNIA, ULEV125

NW9	TRACTION CONTROL-ELECTRONIC
NY7	SHIELD-TRANSFER CASE
PPA	EQUIPMENT-ASSIST, OPEN & CLOSE, TAILGATE
PZX	WHEEL-18 X 8.5, J, ALUMINUM, DESIGN 2
Q5U	WHEEL-17 X 8.0, J, ALUMINUM, DESIGN 2
Q5W	WHEEL-17 X 8.0, J, ALUMINUM, DESIGN 1
QDC	TIRE SPARE-T175/90D18 LL 111M BW SPR
QHE	TIRE ALL-255/65R17 SL 110T BW AT
QHR	TIRE ALL-255/65R17 SL 110T BW ALS
QIA	TIRE ALL-265/60R18 SL 110T BW AL2
QJ2	TIRE ALL-265/65R17 SL 112S BW AT VAR1
QJJ	TIRE ALL-265/70R16 SL 112T BW ALS
QQD	TIRE ALL-P255/55R20 SL 107H BW AL3
R1U	WHEEL-17 X 8.0, J, ALUMINUM, DESIGN 3
R28	WHEEL-17 X 8.0, J, ALUMINUM, DESIGN 4
R34	WHEEL-17 X 8.0, J, ALUMINUM, DESIGN 5
R5O	ACCESSORY-TIRE - 215/60R17 SL 96H BW AL3
R88	ACCESSORY-ILLUMINATED EMBLEM - EXTERIOR - DESIGN 2
RDI	ACCESSORY-KEYLESS ENTRY
RGO	ACCESSORY-TIRE ALL - 265/65R17 SL 112S BSL MT VAR 1
RIA	ACCESSORY-FLOOR LINER - CONTOURED
RIF	WHEEL-17 X 8.0, J, ALUMINUM, DESIGN 7
RIK	ACCESSORY-BADGE - EXTERIOR, PACKAGE, DESIGN 1
RN2	ACCESSORY-ILLUMINATED EMBLEM - EXTERIOR - DESIGN 1
RQ9	WHEEL-20 X 8.5, J, ALUMINUM, DESIGN 1
RS1	WHEEL-16 X 7.0, J, ALUMINUM, DESIGN 1
RS2	WHEEL-16 X 7.0, J, STEEL, DESIGN 1
RSZ	WHEEL-18 X 7.5, J, ALUMINUM, DESIGN 1
RT5	WHEEL-18 X 8.5, J, ALUMINUM, DESIGN 1

RTX	WHEEL SPARE-18 X 4.5, B, ALUMINUM, DESIGN 1
RVG	ACCESSORY-ADAPTER - TRAILER HARNESS
RVP	ACCESSORY-ASSIST STEPS - REMOVABLE
RVS	ACCESSORY-ASSIST STEPS - TUBULAR - ROUND - BLACK
RVX	ACCESSORY-BALL MOUNT - TRAILER HITCH
RVY	ACCESSORY-PUBX CARGO DIVIDER
RW2	ACCESSORY-BED RAILS - BLACK
RW3	ACCESSORY-BED RAILS - CHROME
RW6	ACCESSORY-BED STORAGE BOX - FIXED FULL WIDTH - METAL
RWI	ACCESSORY-BODY SIDE MOLDINGS - CHROME
RWR	ACCESSORY-CAMERA - REAR VISION
RWS	ACCESSORY-FLOOR MATS - CARPET
RXH	ACCESSORY-CENTER CAP - WHEEL - DESIGN 1
RXJ	ACCESSORY-CENTER CAP - WHEEL - DESIGN 2
RXQ	ACCESSORY-CONVENIENCE NET - BED MOUNTED
RYT	ACCESSORY-FIRST AID KIT
RYV	ACCESSORY-FLOOR MATS - ECONOMY CARPET
RZ9	ACCESSORY-GRILLES/GRILLE INSERT - ALTERNATE DESIGN 1
RZO	ACCESSORY-WHEEL - 20" - ALUMINUM - DESIGN 9
RZR	ACCESSORY-WHEEL - 20" - ALUMINUM - DESIGN 8
RZW	ACCESSORY-HARNESS - TRAILER HITCH
S08	ACCESSORY-HIGHWAY SAFETY KIT
S0M	ACCESSORY-ILLUMINATED DOOR SILLS
S0Y	ACCESSORY-LAMPS - CARGO AREA
S1K	WHEEL SPARE-16 X 7.0, J, STEEL, DESIGN 1
S3U	ACCESSORY-LAMP KIT - FRONT FOG

S3X	ACCESSORY-LAMPS - FRONT ROOF MOUNTED - OFF-ROAD
S41	ACCESSORY-LINER - WHEEL HOUSE
S42	ACCESSORY-LOAD STOPS - UTILITY RACK
S44	ACCESSORY-LOCKING PIN - TRAILER HITCH
S47	ACCESSORY-LUG NUTS
S4P	WHEEL SPARE-17 X 8.0, J, ALUMINUM, DESIGN 1
S52	ACCESSORY-MOLDED HOOD PROTECTOR - SMOKED
S53	ACCESSORY-MOLDING - UPPER ACCENT
S5O	ACCESSORY-LAMP KIT - FRONT PROJECTOR FOG
S5W	ACCESSORY-ORGANIZER - PANEL - SEAT BACK
S6L	ACCESSORY-PROTECTOR - ROCKER PANEL
S6P	ACCESSORY-REMOTE START KIT
S6W	ACCESSORY-SEAT COVER - MUDDER (PROTECTIVE)
SA5	ACCESSORY-SHIELD - UNDERBODY
SAI	ACCESSORY-SILL PLATES - STAINLESS
SAO	ACCESSORY-SMOKERS PACKAGE
SAS	ACCESSORY-SPARE TIRE CARRIER - REAR
SB2	ACCESSORY-SPOILER - DECKLID - FLUSH MOUNT
SB7	ACCESSORY-DECAL PACKAGE - DESIGN 1
SB8	ACCESSORY-SPOILER/MOLDING/PROTECTOR - TAILGATE
SBY	ACCESSORY-SPORT BAR - BED MOUNTED - DESIGN 1
SBZ	ACCESSORY-SPORT PEDAL KIT
SCJ	ACCESSORY-SUSPENSION LOWERING KIT
SCZ	ACCESSORY-TAILGATE HANDLE - ALTERNATE FINISH - CHROME
SD5	ACCESSORY-TIRE PRESSURE MONITOR
SDE	ACCESSORY-TRAILER HITCH - REMOVABLE
SDI	ACCESSORY-TRIANGLE - REFLECTIVE

SDS	ACCESSORY-WEATHER DEFLECTORS - SIDE WINDOW - SMOKED
SE4	ACCESSORY-WHEEL - 18" - ALUMINUM - DESIGN 1
SE5	ACCESSORY-WHEEL - 18" - ALUMINUM - DESIGN 2
SE6	ACCESSORY-WHEEL - 18" - ALUMINUM - DESIGN 3
SE7	ACCESSORY-WHEEL - 18" - ALUMINUM - DESIGN 4
SF5	ACCESSORY-WHEEL FLARES - ALTERNATE DESIGN - MOLDED COLOR
SF6	ACCESSORY-WHEEL FLARES - ALTERNATE DESIGN - PAINTED
SFE	ACCESSORY-WHEEL LOCKS
SFZ	ACCESSORY-EMBLEM - EXTERIOR - DESIGN 1
SG1	ACCESSORY-EMBLEM - EXTERIOR - DESIGN 2
SGZ	ACCESSORY-WHEEL - 19 X 8.5 - J - ALUMINUM - DESIGN 2
SIE	ACCESSORY-PUBX TIERED STORAGE
SIF	ACCESSORY-RSE - PORTABLE MEDIA CONNECTIVITY PACKAGE
SIZ	ACCESSORY-PUBX CARGO DIVIDER - ALTERNATE DESIGN
SJ8	ACCESSORY-ILLUMINATION PACKAGE - INTERIOR AMBIENT
SJH	ACCESSORY-WHEEL - 17 X 7.0 - J - ALUMINUM - DESIGN 1
SKY	ACCESSORY-WHEEL - 18 X 8.5 - J - ALUMINUM - DESIGN 1
SKZ	ACCESSORY-WHEEL - 18 X 8.5 - J - ALUMINUM - DESIGN 2
SL7	ACCESSORY-PUBX LADDER / UTILITY RACK STANCHIONS
SLG	ACCESSORY-WHEEL - 18 X 7.5 - J - ALUMINUM - DESIGN 1
SLN	ACCESSORY-STRUT TOWER BRACE
SMY	ACCESSORY-WHEEL - 17 X 8.0 - J - ALUMINUM - DESIGN 1

T3C	HEADLAMP FUNCTION-PROJECTOR, LOW/HIGH BEAM (DO NOT USE AFTER '09 MAJOR PROGRAMS, USE HDL&HDL CONT&VCS FAM AS NEEDED)
T3U	LAMP FRT FOG-FRT FOG
T4A	HEADLAMPS-HALOGEN
T4Z	SHIFTER INTERLOCK-SEAT BELT ASSURANCE SYSTEM
TCA	LAMP-DOME, CENTER
TCK	DEFLECTOR-RR TIRE, AIR
TDM	MODE-TEEN DRIVER SETTINGS
TR0	LAMP-INTR, ROOF, RR, COURTESY & DUAL READING
U19	SPEEDOMETER-INST, KILO & MILES, KILO ODOMETER
U2K	DIGITAL AUDIO SYSTEM-S-BAND
U73	ANTENNA-FIXED, RADIO
UDC	DISPLAY INSTRUMENT-DRIVER INFO ENHANCED (ONE COLOR GRAPHIC)
UDD	DISPLAY INSTRUMENT-DRIVER INFO ENHANCED (MULTI COLOR STANDARD GRAPHIC)
UE1	COMMUNICATION SYSTEM-VEHICLE, ONSTAR
UEU	SENSOR INDICATOR-FORWARD COLLISION ALERT
UF2	LAMP-CARGO
UFL	LANE ACTIVE SAFETY-DEPARTURE WARNING
UG0	LAMP-CARGO, BED RAIL
UGA	HOOK-TOW, RED
UHN	WHEEL-18 X 8.5, J, ALUMINUM, DESIGN 3
UMN	SPEEDOMETER-INST, MILES & KILO, MILES ODOMETER
UQ3	SPEAKER SYSTEM-ENHANCED AUDIO
UQA	SPEAKER SYSTEM-PREMIUM AUDIO, BRANDED AMPLIFIER
US2	VEHICLE VIN-NON-SALEABLE, 0777 SERIES (DO NOT USE UNLESS AUTHORIZED BY DN)
USR	RECEPTACLE-USB

UTJ	THEFT DETERENT-ELECTRICAL, UNAUTHORIZED ENTRY
UVC	VISION-REAR VIEW, MONO, ANALOG
UVD	STEERING WHEEL HEAT-MANUAL
V3L	GRILLE-RADIATOR, BRIGHT CHROME
V8X	ACCESSORY-SILL PLATES - ALTERNATE DESIGN 2
VAS	ACCESSORY-GRILLE / GRILLE INSERTS - ALTERNATE FINISH - BODY COLOR
VAT	ACCESSORY-GRILLE / GRILLE INSERTS - ALTERNATE FINISH - CHROME
VAV	ACCESSORY-FLOOR MATS - ALL WEATHER
VBR	ACCESSORY-PUBX RUBBER MAT
VJG	BUMPER RR-BLACK
VJH	BUMPER RR-CHROME
VJQ	HOOK-TOW, FRT
VK3	LICENSE PLATE FRONT-FRT MOUNTING PKG
VKU	ACCESSORY-MIRROR CAPS - CHROME
VKY	ACCESSORY-DOOR HANDLES - ALTERNATE FINISH - CHROME
VLI	ACCESSORY-MAT - TRUNK / CARGO AREA
VPB	ACCESSORY-TONNEAU - RR COMPT - VINYL W/ INTEGRAL CROSSBOW SUPPORTS
VQK	ACCESSORY-SPLASH GUARDS - CUSTOM MOLDED
VQL	ACCESSORY-FUEL DOOR - DESIGN 1
VQY	ACCESSORY-TOW HOOKS - CHROME
VQZ	ACCESSORY-EXHAUST TIP - DESIGN 1
VRV	ACCESSORY-SPLASH GUARDS - CUSTOM MOLDED - PAINTED
VST	ACCESSORY-SILL PLATES - ALTERNATE DESIGN 1
VT5	BUMPER RR-COLOR KEYED
VT7	OWNERS MANUAL-ENGLISH LANGUAGE
VTD	ACCESSORY-GROUND EFFECTS PACKAGE
VTG	ACCESSORY-INTERIOR TRIM KIT

VUK	ACCESSORY-TAILGATE LINER - PUBX
VV4	COMMUNICATION EQUIP-MOBILE INTERNET CONNECTIVITY
VYQ	ACCESSORY-STRIPE PACKAGE - HOOD AND FENDER - BLACK
VYW	ACCESSORY-FLOOR MATS - PREMIUM CARPET - DESIGN 1
VZ3	LABEL-MERCURY DISPOSAL NOTIFICATION
VZX	ACCESSORY-PUBX BEDLINER
W0H	ACCESSORY-TOW HOOKS - ALT FINISH
W1Y	CONTROL-STEERING WHEEL, RADIO, REDUNDANT CONTROLS
W2A	ACCESSORY-WEATHER DEFLECTORS - SIDE WINDOW - CLEAR
W2D	ACCESSORY-CARGO NET
WBC	ACCESSORY-EXHAUST UPGRADE - DUAL MODE
WEN	PLANT CODE-WENTZVILLE, MO, USA
WGQ	SALES PACKAGE-REDLINE
WJP	SALES PACKAGE-MIDNIGHT EDITION
WMH	VIN MODEL YEAR-2017
WPD	SALES PACKAGE-SAFETY
WPK	SALES PACKAGE-SPORT PACK
X88	MARKET BRAND-CHEVROLET
XAE	ACCESSORY-TIRE ALL-P255/55R20 SL 107H BW AL3 VAR 1
XAJ	ACCESSORY-TIRE-265/60R18 SL 110T BW AL2 - VAR1
XBC	ACCESSORY-TIRE ALL-P245/40R20 SL 95V BW AL3 VAR 1
XCA	ACCESSORY-TIRE ALL-245/40R19 SL 94W BW AL3 VAR1
XCC	ACCESSORY-TIRE ALL-245/45R18 SL 96H BW AL3 VAR 1
Y91	MERCHANDISED PKG-LUXURY EDITION
YF5	CERTIFICATION-EMISSION, CALIFORNIA
YM8	IDENTIFICATION-LIMITED PERSONALIZATION OPTION (LPO)

Z49	COUNTRY-CANADA
Z6X	SALES PACKAGE-OFF ROAD PERFORMANCE
Z71	CHASSIS PACKAGE-"OFF ROAD"
Z82	TRAILER PROVISIONS-SPECIAL EQUIPMENT, H.D.
Z85	CHASSIS PACKAGE-INCREASED CAPACITY
Z88	MARKET BRAND-GMC
ZJJ	TIRE SPARE-265/70R16 SL 112T BW ALS
ZJP	TIRE SPARE-265/65R17 SL 112S BW AT VAR1
ZQ9	APPEARANCE PACKAGE-EXTERIOR TRIM, BLACK OUT
ZW9	BODY EQUIPMENT-BASE BODY OR CHASSIS
ZY1	COLOR COMBINATION-SOLID

Body Systems

Fixed and Moveable Windows

Schematic and Routing Diagrams

Moveable Window Schematics

Driver Door



B+
X51A
Fuse
Block -
Instrument
Panel
F8DA
5A
F42DA
30A
X1
16
25
1940
RD/VT
1240
RD/L-BU
X700
A
1240
RD/L-BU
J213
1240
RD/L-BU
X500
16
1
1940
RD/VT
1240
RD/L-BU
2
M74D
Window
Motor -
Driver
A90
Logic
B+
M
K9
Body
Control
Module
4
6
3
5
7
1
6134
L-GN/YE
745
GY
1300
L-GN/WH
7628
L-GN/VT
1136
GY
3550
BK
J501
DL6/DL9
1940
RD/VT
Outside
Rearview
Mirror
Schematics
1940
RD/VT
6134
L-GN/YE
Door Lock/
Indicator
Schematics
4
5
6
2
3
S79D
Window
Switch -
Driver
B+
A90
Logic
1
3550
BK
G303

Passenger Door


B+
X51A
Fuse
Block -
Instrument
Panel
F45DA
30A
X1
35
1340
RD/WH
J300
1340
RD/WH
1340
RD/WH
B
X800
X600
1
1340
RD/WH
X1
4
S79D
Window
Switch -
Driver
A90
Logic
1
6134
L-GN/YE
5
S79P
Window
Switch -
Passenger
B+
A90
Logic
3550
BK
X1
2
3
1
8
3387
L-GN/GY
3388
YE/L-BU
3650
BK
746
GY
Door Lock/
Indicator
Schematics
2
M74P
Window
Motor -
Passenger
M
1
G304
G303


S79D Window Switch - Driver
A90 Logic
5
6134 L-GN/YE
J213
A
K9 Body Control Module
J300
B
1240 RD/L-BU
1340 RD/WH
X700 1
X800 1
1240 RD/L-BU
8
6135 L-GN/GY
1
6135 L-GN/GY
1
1340 RD/WH
8
S79LR Window Switch - Left Rear
A90 Logic
B+
S79RR Window Switch - Right Rear
A90 Logic
B+
6
7
2
3
5
668 L-BU/VT
669 YE/L-BU
747 GY
3350 BK
3350 BK
6
7
2
5
670 L-BU/GY
671 L-GN/BK
748 GY
3450 BK
1
M74LR Window Motor - Left Rear
M
2
Door Lock/ Indicator Schematics
1
M74RR Window Motor - Right Rear
M
2
Door Lock/ Indicator Schematics
G303
G304

Defogger Schematics

Defogger (C49)


K33
HVAC
Control
Module
A90
Logic
X2 19
193
BN/VT
X200 45
193
BN/VT
B+
X2 61
X50A
Fuse Block -
Underhood
86
30
KR5
Rear
Defogger
Relay
85
87
F28UA
40A
F60UA
7.5A
X1 71
X2 39
62
1150
BK
2267
BN/YE
Outside
Rearview
Mirror
Schematics
293
BN/VT
X1 A
E18
Rear
Defogger
Grid
X2 A
3950
BK
G103
G306

Description and Operation

Power Windows Description and Operation

Power Windows System Components

The power window system consists of the following components:

- Driver window switch
- Passenger window switch
- Left rear window switch
- Right rear window switch
- Right rear door latch
- Left rear door latch
- Window motors in each of the doors
- 30A Fuse
- Body control module (BCM)


S79D Window Switch - Driver
M74D Window Motor - Driver
K9 Body Control Module
S79P Window Switch - Passenger
S79LR Window Switch - Left Rear
S79RR Window Switch - Right Rear
M74P Window Motor - Passenger
M74LR Window Motor - Left Rear
M74RR Window Motor - Right Rear

Driver Express Up and Express Down Power Window Motor

The driver door contains a window motor is smart motor that will detect excessive resistance while performing the express up function and automatically reverse direction to prevent injury to any occupants that may become trapped between the closing window and the door frame. The automatic reverse safety feature can be overridden by pulling and holding the window switch.

The logic circuit within the window motor monitors the up, down and express signal circuits which are normally equal to B+ voltage. When a switch is used on the driver window switch, the contacts close causing a voltage drop within the appropriate signal circuit. The driver window motor will detect the voltage drop and will command the window to move in the direction requested.

Passenger, Left Rear and Right Rear Express Down Window Motors

For the passenger, right rear and left rear doors, when their window switch is pressed in the down position, battery positive voltage is applied to their respective window motor control circuit and ground to the other window motor control circuit causing that window to open. When the individual window switch is pulled in the up position, voltage and ground is applied to the window motor in the opposite direction causing that window to close. The return path to ground is supplied through the inactive control circuit being normally grounded through the window switch.

Each passenger and rear window switch communicates to the BCM by a serial data circuit. When the driver wishes to control the passenger, left rear or right rear window, the driver will use the appropriate switch on the driver window switch. When this switch is used, a serial data message is sent to the BCM requesting a window motor command, the BCM will then send a serial data message to the appropriate door window switch which will then command that window to move in the direction requested.

Lockout Switch Feature

The driver window switch contains a window lockout switch, when the driver presses the window lockout switch, a serial data message is sent to the BCM which will send a disable command to the rear window switches, the rear window switches will then ignore all functions when a passenger uses the rear window switch. The rear window motor commands will still function normally when the driver uses the appropriate switches on the driver window switch.

Rear Window Defogger Description and Operation

Rear Window Defogger System Components

The rear window defogger system consists of the following components:

- HVAC control module
- Rear defogger relay
- Rear defogger grid
- 40A fuse

Rear Window Defogger Block Diagram



Rear Window Defogger Operation

The rear defog control system utilizes a single zone backlight design, driven with a single relay configuration. Additionally, up to two outside rear view mirrors can be heated if equipped. A switch for the customer to control the system is provided within the HVAC control module, also included in the HVAC control module is an indicator to inform the customer with the current state of the system. The system is only operational when engine is running or during remote start.

Pressing the heated rear window switch on the HVAC control module causes the HVAC control module to provide voltage to the coil side of the rear defogger relay, this will energize the relay causing the relay switch contacts to close allowing B+ voltage to flow through the rear defogger grid control circuit to the rear defogger grid.

When the rear heated window switch is pressed and the engine is running, the rear defog control system will remain active for 10 minutes. After the initial cycle has lapsed, pressing the switch again will continue rear window defogger operation, but the cycle will only last 5 minutes.

Body Systems

Horns and Pedestrian Alerts

Schematic and Routing Diagrams

Horn Schematics

Horns


B+
X50A
Fuse Block -
Underhood
KR3
Horn
Relay
F51UA
15A
X2
25
X1
11
28
BN/WH
29
BN/GY
X5
19
K9
Body
Control
Module
X3
18
3287
L-GN/WH
X2
1
X85
Steering Wheel Air
Bag Coil
X1
10
3287
L-GN/WH
2
P13
Horn
Assembly
BK
BK
1
X1
1
S33
Horn
Switch
X2
1
2050
BK
1150
BK
G300
G103

Description and Operation

Horns System Description and Operation

System Description

The horn system consists of the following components:

- HORN fuse
- Horn relay
- Horn switch
- Horn assembly
- Body control module (BCM)



System Operation

The vehicle horn system is activated under the following conditions:

- When the horn switch is depressed
- The BCM commands the horns ON under any of the following conditions:
  - When the content theft deterrent system detects a vehicle intrusion—For further information refer to CELL Link Error - Link target cell (cell ID 149050) is invalid for this publication..
  - When the panic button is depressed on the remote control door lock transmitter—For further information refer to Keyless Entry System Description and Operation.
  - When the keyless entry system is used to lock the vehicle, a horn chirp may sound to notify the driver that the vehicle has been locked. The notification feature may be enabled or disabled through personalization. For further information refer to Keyless Entry System Description and Operation.
  - When the OnStar® system is used to sound the horns if equipped—For further information, refer to CELL Link Error - Link target cell (cell ID 149754) is invalid for this publication..

Circuit Operation

Battery positive voltage is applied at all times to the horn relay coil and the horn relay switch. Pressing either of the horn switches applies ground to the horn relay control circuit. The BCM may also apply ground to the horn relay control circuit as described above. When the horn relay control circuit is grounded, the horn relay is energized and battery positive voltage is applied to the horns through the horn control circuit. The horns sound as long as ground is applied to the horn relay control circuit.

Body Systems

Lighting

Schematic and Routing Diagrams

Headlights/Daytime Running Lights (DRL) Schematics

Controls


B+
X50A
Fuse Block - Underhood
KR48
Headlamp
High Beam
Relay
X2 58
1969
BN/VT
X5 18
K9
Body
Control
Module
5V
X2 10
X3 11 17
X1 22 11 16
278
WH/L-BU
524
WH
307
YE/BN
13
L-GN/GY
306
L-GN/BN
103
WH/VT
5
B10B
Ambient
Light/Sunload
Sensor
HVAC Schematics
6
1791
BK/YE
X2 18
K33
HVAC
Control
Module
A90
Logic
2 4
S78
Turn Signal/
Multifunction
Switch
FTP
3
5 3 1
S30
Headlamp
Switch
AUTO
AUTO
8
2151
BK/WH
2151
BK/WH
P16
Instrument
Cluster
A90
Logic
G307


K9
Body
Control
Module
F5DA
F33UA
X4 2
X5 18
X4 1
712
YE
1969
BN/VT
312
YE
B+
X2 58
X50A
Fuse Block -
Underhood
KR48
Headlamp
High Beam
Relay
X102 37
X102 19
F38UA
10A
F37UA
10A
X1 14
13
712
YE
711
WH
311
WH
312
YE
X110 2
3
X120 3
2
E13LA
Headlamp
Assembly -
Left
E13RA
Headlamp
Assembly -
Right
BK
1
E4G
Headlamp -
Left Low
Beam
2
BK
A
E4E
Headlamp -
Left High
Beam
B
BK
J121
E4F
Headlamp -
Right High
Beam
E4H
Headlamp -
Right Low
Beam
J122
X110 1
X120 1
1150
BK
1250
BK
G103
G105

Fog Lights Schematics

Fog Lamps (T3U)

LOC
DESC


B+
X50A
Fuse Block - Underhood
KR46
Front Fog Lamp Relay
F48UA
15A
X1 31
X2 19
2234
BN/VT
1317
BN/WH
X5 13
K9
Body Control Module
J118
X1 15
2234
BN/VT
2234
BN/VT
192
L-BU/GY
A
E29LF
Fog Lamp - Left Front
B
A
E29RF
Fog Lamp - Right Front
B
10
S30
Headlamp Switch
8
1150
BK
1250
BK
2151
BK/WH
G103
G105
G307

Controls and Indicators


K9
Body
Control
Module
X2 26
111
L-BU/GY
X7 14
158
GY
X200 18
158
GY
X1 22
13
L-GN/GY
X3 17
307
YE/BN
11
524
WH
12
663
WH/L-GN
24
664
VT/L-BU
4
2
1
7
FTP
S78
Turn Signal/
Multifunction Switch
3
10
18
S48A
Multifunction
Switch -
Instrument
Panel
14
5
AUTO
S30
Headlamp
Switch
3
2050
BK
2151
BK/WH
2151
BK/WH
G300
G307
X2 13
5360
BK/BN
5V
X1 19
5359
WH
X1 7
5361
L-BU/YE
N8D
N8D
MYB
MYB
C
B
B22
Brake
Pedal
Position
Sensor
A
N8D
MYB
K20
Engine
Control
Module
X3 67
N8D
5007
L-GN/WH
A
B16
Backup
Lamp
Switch
B
451
BK/WH
G102
Engine
Controls
Schematics
5380
WH/L-GN
5381
WH/RD
5382
BK/YE
2
3
4
5
B22
Brake
Pedal
Position
Sensor
1
6
P16
Instrument
Cluster
A90
Logic

Park, Side Marker and Front Turn Lamps


F5DA
F17DA
F33UA
F17DA
K9 Body Control Module
X4 6
X5 2
X4 5
3
709 VT/GY
1314 L-BU/WH
309 GY/BN
1315 L-GN/VT
X102 6
47
8
29
709 VT/GY
1314 L-BU/WH
309 GY/BN
1315 L-GN/VT
X110 4
5
X120 4
5
E13LA Headlamp Assembly - Left
E13RA Headlamp Assembly - Right
RD
BK
YE
X88
Z88
E4AC Park/ Daytime Running Lamp - Left
A
E4J Park Lamp - Left Front
B
A90 Logic
B
A
E4N Park/Turn Signal Lamp - Left
G
E4AL Park/ Daytime Running Lamp - Left Lower
BK
BK
BK
J121
BK
X110 1
1150 BK
G103
RD
BK
YE
X88
Z88
E4AD Park/ Daytime Running Lamp - Right
A
E4K Park Lamp - Right Front
B
A90 Logic
B
A
E4P Park/Turn Signal Lamp - Right
G
E4AM Park/ Daytime Running Lamp - Right Lower
BK
BK
BK
J122
BK
X120 1
1250 BK
G105

LOC
DESC

Tail Lamps


K9
Body
Control
Module
F17DA
F17DA
F15DA
F33UA
F17DA
X4
7
X5
1
X7
3
X5
7
X4
4
2509
BN/L-BU
7542
GY/YE
24
L-GN/WH
2609
BN/GY
7541
WH/YE
J200
24
L-GN/WH
24
L-GN/WH
Inside
Rearview
Mirror
Schematics
X106
14
12
7
6
15
24
L-GN/WH
J402
2509
BN/L-BU
7542
GY/YE
24
L-GN/WH
24
L-GN/WH
24
L-GN/WH
2609
BN/GY
7541
WH/YE
Object
Detection
Schematics
X410
2
3
1
X420
1
2
3
E42L
Tail Lamp
Assembly -
Left
E42R
Tail Lamp
Assembly -
Right
OG
GY
YE
YE
OG
GY
B
A
B
A
A
A
B
A
B
A
E5U
Tail/Stop and
Turn Signal
Lamp - Left
Lower
E5AG
Tail/Stop and
Turn Signal
Lamp - Left
Upper
E5A
Backup
Lamp -
Left
E5B
Backup
Lamp -
Right
E5AH
Tail/Stop
and Turn
Signal Lamp
- Right
Upper
E5V
Tail/Stop
and Turn
Signal Lamp
- Right
Lower
G
G
B
B
G
G
BK
BK
BK
BK
BK
BK
X410
4
750
BK
X420
4
850
BK
G401
G402

CHMSL, Cargo, License Plate Lamps and Accessory Bed Lighting (S0Y)


K9 Body Control Module
F15DA
F15DA
X4 13
6846 L-GN/YE
X7 7
1429 BN/WH
J235
1429 BN/WH
1429 BN/WH
Interior Lights Dimming Schematics
8
5065 VT/WH
B+
X2 47
X2 46
X50A Fuse Block - Underhood
F7UA 15A
F36UA 10A
86
30
30
85
KR112 Cargo Lamp Relay
KR41 Center High Mounted Stop Lamp Relay
85
87
87
86
X2 43
X1 80
X1 37 (Not Used)
X1 75
71
X106 8
47
6846 L-GN/YE
1430 WH/VT
X400 1
X401 1
6846 L-GN/YE
1430 WH/VT
1430 WH/VT
1054 VT/GY
X102 3
17
J408
J413
1430 WH/VT
1430 WH/VT
J123
6846 L-GN/YE
6846 L-GN/YE
1430 WH/VT
1430 WH/VT
1430 WH/VT
1054 VT/GY
X303 1
2
A
A
A (S0Y)
A (S0Y)
E7L License Plate Lamp - Left
E7R License Plate Lamp - Right
E33L Cargo Lamp - Left
E33R Cargo Lamp - Right
W26 Blunt Cut - Cargo Lamp Provision
B
B
B
B
1430 BN
1054 RD
E6 Center High Mounted Stop Lamp
A
A
A
E33L Cargo Lamp - Left
E33R Cargo Lamp - Right
B
B
B
750 BK
750 BK
751 BK/WH
751 BK/WH
3150 BK
1150 BK
X303 3
3150 BK
3150 BK
G401
G301
G103
LOC
DESC

Interior Lights Schematics

Dome Lamps (Except C74)


K9
Body
Control
Module
F1DA
X7 19
X1 14
X2 5
156
GY
328
GY/L-GN
157
GY
X202 20
21
328
GY/L-GN
157
GY
X301 9
8
7
156
GY
328
GY/L-GN
157
GY
J307
157
GY
157
GY
5
4
2
E36AH
Dome
Lamp
2
E37R
Dome/
Reading
Lamps -
Rear
6
6
3150
BK
3150
BK
G301


K9 Body Control Module
F1DA
F1DA
X7 19
X1 14
X2 5
X7 2
C74
C74
C74
156 GY
328 GY/L-GN
157 GY
6815 WH/BN
X202
20
21
328 GY/L-GN
157 GY
X301
9
8
7
6
156 GY
328 GY/L-GN
157 GY
6815 WH/BN
C74 -D6I-TR0
C74 +D6I+TR0
J306
TR0
D6I
D6I
157 GY
J307
TR0
6815 WH/BN
6815 WH/BN
A3L Sunshade - Left
A
A
RD
RD
157 GY
6815 WH/BN
157 GY
6815 WH/BN
5
4
2
1
2
1
E37F Dome/Reading Lamps - Front
E37R Dome/ Reading Lamps - Rear
E31L Sunshade Mirror Lamp - Left
A3L Sunshade - Left
E31R Sunshade Mirror Lamp - Right
A3R Sunshade - Right
6
6
BK
BK
B
B
3150 BK
3150 BK
3150 BK
3150 BK
G301

Interior Lights Dimming Schematics

Dimming Control (1 of 3)


K9
Body
Control
Module
F15DA
B+
X1 13
X2 9
X1 7
X7 9
(Not Used)
X2 8
1688
L-BU/RD
44
YE/GY
5005
BK/YE
6817
YE
J214
X203 9
JL1
NQ6/NQ7
X202 22
X200 22
X2 3
X51A
Fuse
Block -
Instrument
Panel
F32DA
2A
X2 4
-W1Y
6136
BN
X2 6
X85
Steering
Wheel Air
Bag Coil
X1 5
12
11
7
2
S30
Headlamp
Switch
5K Ω
470K Ω
8
S76
Trailer
Brake
Control
Switch
J206
X500 26
X600 26
X301 5
7631
BK/BN
S48A
Multifunction
Switch -
Instrument
Panel
14
E37F
Dome/Reading
Lamps - Front
3
6
X202 35
DL6/DL9
-ATG
ATG+
DL6/DL9
ATG-
DL6/DL9
J503
S77
Transfer
Case Shift
Control
Switch
5
J233
X106 9
S52
Outside
Rearview
Mirror
Switch
1
11
S13D
Door Lock
Switch -
Driver
S13P
Door Lock
Switch -
Passenger
S70L
Steering
Wheel
Controls
Switch -
Left
S70R
Steering
Wheel
Controls
Switch -
Right
2151
BK/WH
3150
BK
3550
BK
3650
BK
2050
BK
19
K38
Chassis
Control
Module
G203
G301
G303
G304
G300
6817

Dimming Control (2 of 3)


K9
Body
Control
Module
P16
Instrument
Cluster
A90
Logic
A26
HVAC
Controls
A90
Logic
P17
Info
Display
Module
A90
Logic
S79D
Window
Switch -
Driver
A90
Logic
S79P
Window
Switch -
Passenger
A90
Logic
W1Y
S70R
Steering
Wheel
Controls
Switch -
Right
A90
Logic
6
1
6817
BN
6
S70L
Steering
Wheel
Controls
Switch -
Left
1
2050
BK
2050
BK
G300
KA1
KA1
A22
Radio
Controls
A90
Logic
S32D
Seat
Heating
Switch -
Driver
A90
Logic
S32P
Seat
Heating
Switch -
Passenger
A90
Logic
S79LR
Window
Switch -
Left
Rear
A90
Logic
S79RR
Window
Switch -
Right Rear
A90
Logic

Dimming Control (3 of 3)

LOC
DESC


K9
Body
Control
Module
F15DA
F15DA
X2
6
X1
5
X7
7
5697
GY
6816
WH
1429
BN/WH
J220
NQ6/NQ7
6816
WH
X200
24
21
J235
5697
GY
6816
WH
1429
BN/WH
Exterior
Lights
Schematics
1429
BN/WH
6816
WH
6816
WH
X500
32
12
5697
GY
6816
WH
11
S79D
Window
Switch -
Driver
12
7
2
S48A
Multifunction
Switch -
Instrument
Panel
14
4
S77
Transfer
Case Shift
Control
Switch
NQ6
AUTO
4WD
4⬇
4⬆
2⬆
7
10
9
8
1561
GY/L-GN
1565
VT/WH
1566
BN/BK
1563
GN/BK
X202
29
31
30
28
2050
BK
1561
GY/L-GN
1565
VT/WH
1566
BN/BK
1563
GN/BK
X2
11
3
14
13
K69
Transfer
Case
Control
Module
G300

Description and Operation

Exterior Lighting Systems Description and Operation

The exterior lighting system consist of the following lamps:

- Backup lamps
- Daytime running lamps
- Front fog lamps
- Hazard warning lamps
- Headlamps
- Park, tail, license, and marker lamps
- Stop lamps
- Turn signal lamps
- Trailer lighting

Low Beam Headlamps

The headlamps may be turned ON in 3 different ways:

- When the headlamp switch is placed in the ON position, for normal operation
- When the headlamp switch is placed in the AUTO position, for automatic lamp control
- When the headlamp switch is placed in the AUTO position, with the windshield wipers ON in daylight conditions, after a 6 second delay

The BCM will also command the low beam headlamps ON during daylight conditions when the following conditions are met:

- Headlamp switch in the AUTO position
- Windshield wipers ON
- Vehicle in any gear but PARK

When the BCM commands the low beam headlamps ON, the vehicle operator will notice the interior backlighting for the instrument cluster and the various switches with backlighting control will dim to the level of brightness selected by the instrument panel dimmer switch.

The body control module (BCM) monitors three signal circuits from the headlamp switch. When the headlamp switch is in the AUTO position, all three signal circuits are open. When placed in the AUTO position, the BCM monitors inputs from the ambient light sensor to determine if headlamps are required or if daytime running lamps will be activated based on outside lighting conditions. When the headlamp switch is placed in the OFF position, the headlamp switch headlamps OFF signal circuit is grounded, indicating to the BCM that the exterior lamps should be turned OFF. With the headlamp switch in the PARK position, the headlamp switch park lamps ON signal circuit is grounded, indicating that the park lamps have been requested. When the headlamp switch is placed in the HEADLAMP position, both the headlamp switch park lamps ON signal circuit and the headlamp switch headlamps ON signal circuit are grounded. The BCM responds to the inputs by illuminating the park lamps and headlamps. When the low beam headlamps are requested, the BCM applies B+ to both low beam headlamp control circuits illuminating the low beam headlamps.

High Beam Headlamps

When the low beam headlamps are ON and the turn signal/multifunction switch is placed in the high beam position, ground is applied to the BCM through the high beam signal circuit. The BCM responds to the high beam request by applying ground to the high beam relay control circuit which energizes the high beam relay. With the high beam relay energized, the switch contacts close allowing battery voltage to flow through the left and right high beam fuses to the high beam control circuits illuminating the left and right high beam headlamps.

Daytime Running Lamps

The daytime running lamps will illuminate continuously when the following conditions are met:

- The ignition is in the RUN or CRANK position
- The shift lever is out of the PARK position for vehicles equipped with automatic transmissions or the parking brake is released for vehicles with manual transmissions
- The low and high beam headlamps are OFF

The ambient light sensor is used to monitor outside lighting conditions. The ambient light sensor provides a voltage signal that will vary between 0.2 and 4.9 volts depending on outside lighting conditions. The body control module (BCM) provides a 5 V reference signal to the ambient light sensor and the HVAC control module provides a low reference ground. The BCM monitors the ambient light sensor signal circuit to determine if outside lighting conditions are correct for either daytime running lights or automatic lamp control when the headlamp switch is in the AUTO position. In daylight conditions the BCM will command the low beam headlamps ON. Any function or condition that turns on the headlamps will cancel daytime running lamps operation.

Flash to Pass

When the turn signal/multifunction switch is momentarily placed in the flash to pass position, ground is applied to the turn signal/multifunction switch. The turn signal/multifunction switch applies ground to the body control module (BCM) through the flash to pass switch signal circuit. The BCM responds to the flash to pass request by applying ground to the high beam relay control circuit. This energizes the high beam relay, closing the switch side contacts of the high beam relay, applying battery voltage to the left and right high beam fuses. Battery voltage is applied from the high beam fuses through the high beam control circuit to the high beam headlamp assemblies. This causes the high beam headlamps to illuminate at full brightness momentarily.

Backup Lamps

Automatic Transmission

With the engine ON and the transmission in the REVERSE position, the transmission control module (TCM) sends a serial data message to the body control module (BCM). The message indicates that the gear selector is in the REVERSE position. The BCM applies battery voltage to the backup lamps control circuit illuminating the backup lamps. Once the driver moves the gear selector out of the REVERSE position, a message is sent by the TCM via serial data requesting the BCM to remove battery voltage from the backup lamps control circuit. The engine must be ON for the backup lamps to operate.

Manual Transmission

The engine control module (ECM) provides a signal circuit to the backup lamp switch which is permanently grounded. With the engine running and the transmission in the reverse position, the backup lamp switch signal circuit is pulled low and the ECM responds by sending a serial data message to the body control module (BCM). The message indicates that the gear selector is in the reverse position. The BCM applies battery voltage to the backup lamps control circuit illuminating the backup lamps. Once the driver moves the gear selector out of the reverse position, a message is sent by the ECM via serial data requesting the BCM to remove battery voltage from the backup lamps control circuit. The engine must be running for the backup lamps to operate. The engine must be running for the backup lamps to operate.

Front Fog Lamps

The front fog lamp switch is an input to the body control module (BCM) and is contained in the headlamp switch assembly. The BCM supplies voltage to the front fog lamp switch via the front fog lamp and instrument panel dimmer switch B+ circuit. When the front fog lamp switch is pressed, voltage from the B+ circuit is pulled down through the front fog lamp switch resistor. The front fog lamp resistor is part of the resistor ladder that also provides the dimming signals for the instrument panel dimmer switches. The BCM receives the voltage signal through the front fog lamp and instrument panel dimmer switch signal circuit.

The front fog lamp relay is supplied with battery voltage at all times. The front fog lamp switch signal circuit is grounded momentarily by pressing the front fog lamp switch. The body control module (BCM) energizes the front fog lamp relay by applying ground to the front fog lamp relay control circuit. When the front fog lamp relay is energized, the relay switch contacts close and battery voltage is applied through the front fog lamp fuse to the front fog lamp control circuit which illuminates the front fog lamps.

Hazard Lamps

The hazard flashers may be activated in any power mode. The hazard switch signal circuit is momentarily grounded when the hazard switch is pressed. The body control module (BCM) responds to the hazard switch signal input by supplying battery voltage to all four turn signal lamps in an ON and OFF duty cycle. When the hazard switch is activated, the BCM sends a serial data message to the instrument panel cluster requesting both turn signal indicators to be cycled ON and OFF.

The instrument panel dimmer switch controls the brightness of the interior backlighting components. When the instrument panel dimmer switch is placed in a desired brightness position, the body control module (BCM) receives a signal from the instrument panel dimmer switch and responds by applying a pulse width modulated voltage to the hazard switch light emitting diode (LED) backlighting control circuit illuminating the LED to the desired level of brightness.

Park, Tail, and License Lamps

When the headlamp switch is placed in the HEAD or PARK position, ground is applied to the park lamp switch ON signal circuit to the body control module (BCM). The BCM responds by applying voltage to the park lamps, tail lamps, and license lamps control circuits illuminating the park, tail, and license lamps.

Stop Lamps

The brake pedal position sensor is used to sense the action of the driver application of the brake pedal. The brake pedal position sensor provides an analog voltage signal that will increase as the brake pedal is applied. The body control module (BCM) provides a low reference signal and a 5 V reference voltage to the brake pedal position sensor. When the variable signal reaches a voltage threshold indicating the brakes have been applied, the BCM will apply battery voltage to the left and right stop lamp control circuits as well as the center high mounted stop lamp control circuit illuminating the left and right stop lamps and the center high mounted stop lamp.

Turn Signal Lamps

Ground is applied at all times to the turn signal/multifunction switch. The turn signal lamps may only be activated with the ignition switch in the ON or START positions. When the turn signal/multifunction switch is placed in either the TURN RIGHT or TURN LEFT position, ground is applied to the body control module (BCM) through either the right turn or left turn signal switch signal circuit. The BCM responds to the turn signal switch input by applying a pulsating voltage to the front and rear turn signal lamps through there respective control circuits. When a turn signal request is received by the BCM, a serial data message is sent to the instrument cluster requesting the respective turn signal indicator be pulsed ON and OFF.

Trailer Lighting

Backup Lamps

For backup lamp operation, the trailer backup lamps relay is supplied with battery voltage at all times. With the engine running and the transmission in the reverse position, the transmission control module (TCM) sends a serial data message to the body control module (BCM). The message indicates that the gear selector is in the reverse position. The BCM responds to the backup lamp request by energizing the trailer backup lamps relay by applying battery voltage to the trailer backup lamps relay control circuit. When the trailer backup lamps relay is energized, the relay switch contacts close and battery voltage is applied through the backup lamp fuse to the trailer backup lamps control circuit which illuminates the trailer backup lamps. Once the driver moves the gear selector out of the reverse position, a message is sent by the TCM via serial data requesting the BCM to remove battery voltage from the trailer backup lamps relay control circuit.

Park Lamps

For trailer park lamp operation, the trailer park lamps relay is supplied with battery voltage at all times. When the headlamp switch is placed in the HEAD or PARK position, ground is applied to the park lamp switch ON signal circuit to the body control module (BCM). The BCM responds to the park lamp request by energizing the trailer park lamps relay by applying ground to the trailer park lamps relay control circuit. When the trailer park lamps relay is energized, the relay switch contacts close and battery voltage is applied through the trailer parks lamp fuse to the trailer park lamp control circuit which illuminates the trailer park lamps.

Stop Lamps

For trailer stop lamp operation, the left and right trailer stop/turn signal lamp relay’s are supplied with battery voltage at all times. The brake pedal position sensor is used to sense the action of the driver application of the brake pedal. The brake pedal position sensor provides an analog voltage signal that will increase as the brake pedal is applied. The body control module (BCM) provides a low reference signal and a 5 V reference voltage to the brake pedal position sensor. When the variable signal reaches a voltage threshold indicating the brakes have been applied, the BCM energizes the left and right trailer stop/turn signal lamp relay’s by applying ground to the left and right trailer stop/turn signal lamp relay control circuits. With the left and right trailer stop/turn signal lamp relay’s energized, the relay switch contacts close and battery voltage is applied through the left and right trailer stop/turn signal fuse’s to the trailer stop lamp control circuits which illuminates the trailer stop lamps.

Turn Signal Lamps

For trailer turn signal lamp operation, the left and right trailer stop/turn signal lamp relay’s are supplied with battery voltage at all times. Ground is applied at all times to the turn signal/multifunction switch. The turn signal lamps may only be activated with the ignition switch in the ON or START positions. When the turn signal/multifunction switch is placed in either the TURN RIGHT or TURN LEFT position, ground is applied to the body control module (BCM) through either the right turn or left turn signal switch signal circuit. The BCM responds to the turn signal switch input by applying a pulsating ground to the left and right trailer stop/turn signal lamp relay control circuits energizing the relay’s in an ON and OFF cycle. With the left and right trailer stop/turn signal lamp relay’s energized, the relay switch contacts cycle ON and OFF applying battery voltage through the left and right trailer stop/turn signal fuse’s to the trailer turn signal lamp control circuits which illuminates the trailer turn signal lamps in an ON and OFF cycle.

Battery Run Down Protection/Inadvertent Power

To provide battery run down protection, the exterior lamps will be deactivated automatically under certain conditions. The BCM monitors the state of the headlamp switch. If the park or headlamp switch is ON when the ignition switch is placed in either the CRANK or RUN position and then placed in the OFF position, the BCM initiates a 10 minute timer. At the end of the 10 minutes, the BCM will turn off the control power output to the park lamp controls as well as the headlamp relay coils, deactivating the exterior lamps. This feature will be cancelled if any power mode other than OFF becomes active. The BCM will disable battery run down protection if any of the following conditions exist. The park or headlamp switch is placed in the ON to OFF position, and back to the ON position during battery run down protection. The BCM determined that the park or headlamp switch was not active when the ignition was turned OFF.

Interior Lighting Systems Description and Operation

Interior Lamps

The interior lighting system consist of two groups. This first group includes lamps that may not be dimmed.

- Dome lamps
- Reading lamps
- Sunshade mirror lamps

Dome Lamps

The dome lamp switch has 3 positions: DOOR, OFF, and ON. The ON position provides a ground for continuous operation and the dome lamps will remain illuminated until the switch is placed in either the DOOR or OFF position. When in the DOOR position, the dome lamps operation is controlled by the body control module (BCM). When any door is opened, the door ajar switch contacts close and the BCM receives a door-open input. The BCM illuminates the dome lamps when any door is opened or a door lock/unlock request is activated with the key fob. After all doors have been closed, the dome lamps will remain illuminated approximately 3 seconds after the last door closes. When the driver places the dome lamp switch in the OFF position, the dome lamps will be disabled. In the event that the dome lamps were to remain illuminated for more than 10 minutes with the ignition switch in the OFF position and no doors opened, the BCM will deactivate the dome lamps control circuit to prevent total battery discharge. The dome lamps will turn OFF using the theater dimming feature when controlled by the BCM.

Reading Lamps

The inadvertent power supply voltage circuit from the BCM provides battery positive voltage to each reading lamp. When a reading lamp switch is activated, the switch contacts close providing a path to ground and the reading lamp illuminates. If the operator inadvertently leaves a reading lamp ON, the BCM will turn all interior lamps OFF after 10 minutes has passed since any switch activation has been detected by the BCM.

Sunshade Mirror Lamps

The inadvertent power supply voltage circuit from the BCM provides battery voltage to each set of sunshade mirror lamps. When the sunshade mirror cover is opened, a switch closes providing ground and the sunshade lamps illuminate. If the operator inadvertently leaves a sunshade mirror cover open with the lamps ON, the BCM will turn all interior lamps OFF after 10 minutes has passed since any switch activation has been detected by the BCM.

Keyless Entry Interior Illumination

When the operator uses the keyless entry transmitter in order to unlock the doors, the BCM receives a door-unlock signal. The BCM must receive inputs from various systems that indicate that the ignition switch is OFF, the courtesy lamp switch is OFF, and all doors are closed before the BCM will activate the interior lamps. After all doors have been closed, the courtesy lamps will turn OFF immediately if the ignition switch is turned to the ON position, the door locks are LOCKED, or approximately 20 seconds after the last door closes. The BCM will turn off the courtesy lamps through the theater dimming feature. The BCM keeps the courtesy lamps on for 40 seconds after an alarm event is completed.

Interior Lamps Dimming

The second group includes lamps which may be dimmed. This group may use a combination of light emitting diodes (LED), incandescent lamps, and pulse width modulation (PWM) illumination.

- Dome/reading lamps – front
- Dome/reading lamps – rear
- Door lock switch – driver
- Door lock switch – passenger
- Hazard switch
- Headlamp switch
- HVAC control head assembly
- Multifunction switch – instrument panel
- Outside rearview mirror switch
- Radio
- Steering wheel control switch – left
- Steering wheel control switch – right
- Sun roof switch
- Sun roof tilt switch
- Window switch – passenger

With the headlamp switch in the PARK or HEAD position, the park lamp switch signal circuit provides an input to the body control module (BCM). The BCM responds by applying voltage to the park lamps as well as the backlight dimming control circuits illuminating all components with interior backlighting. All interior backlighting turns ON at the dimming level indicated by the instrument panel dimmer switch. The instrument panel dimmer switch is a momentary type switch and utilizes a resistor ladder to increase and decrease the brightness of the interior backlighting components. The instrument panel dimmer switch provides a voltage signal to the BCM that will increase as the brightness of the lights are increased and decrease as the brightness of the lights are decreased. The BCM provides a low reference signal and a B+ circuit to the switch. When the instrument panel dimmer switch is held in the desired position, the dimmed voltage setting is applied from the instrument panel dimmer switch through the instrument panel dimmer switch signal circuit to the BCM. The BCM interprets the signal and applies a pulse width modulated (PWM) voltage through the backlighting control circuits illuminating the interior backlighting to the requested level of brightness.

The backlighting for the HVAC controls, instrument cluster, and radio controls are controlled by the BCM via serial data. When the instrument panel dimmer switch is operated to the desired backlighting setting, the BCM sends a serial data message to the HVAC control module, radio, and instrument cluster requesting the backlighting be adjusted to the desired level.

Battery Rundown Protection/Inadvertent Power

The BCM inadvertent power supply voltage circuit provides battery voltage to all of the interior courtesy lamps. In the event that any of these lamps were to remain illuminated for a period of more than 10 minutes with the ignition switch in the OFF position, the BCM will deactivate the inadvertent power supply voltage circuit to prevent total battery discharge. If the ignition switch is turned to any position other than OFF, or if a lamp switch is activated during this 10 minute period, the timer resets for another 10 minutes.

Body Systems

Mirrors

Schematic and Routing Diagrams

Inside Rearview Mirror Schematics

Auto-Dimming Mirror (DD8)


KR73
Ignition
Main
Relay
X51A
Fuse
Block -
Instrument
Panel
F29DA
10A
X3
13
1739
VT/L-GN
F15DA
K9
Body
Control
Module
X7
3
24
L-GN/WH
J200
24
L-GN/WH
24
L-GN/WH
Exterior
Lights
Schematics
OnStar/Telematics
Schematics
2516
YE/VT
2517
BN/WH
2514
L-GN/WH
2515
L-GN/BK
X301
10
11
X300
4
5
3
2
1739
VT/L-GN
24
L-GN/WH
2516
YE/VT
2517
BN/WH
2514
L-GN/WH
2515
L-GN/BK
UE1
UE1
UE1
UE1
2
1
6
7
3
4
A10
Inside
Rearview
Mirror
IGN
R
A90
Logic
S51
Telematics
Button
Assembly
1.5K Ω
1.5K Ω
10K Ω
SOS
A1
Mirror Dimming
5
3150
BK
G301

Outside Rearview Mirror Schematics

Driver and Passenger Position


B+
X51A
Fuse
Block -
Instrument
Panel
F8DA
5A
X1
16
1940
RD/VT
X500
16
1940
RD/VT
J501
1940
RD/VT
12
S52
Outside
Rearview
Mirror
Switch
L
o
R
L
o
R
8
3390
VT/L-BU
6
3391
YE/BN
10
3389
BN/BK
7
3397
YE/VT
5
3398
WH
9
3396
L-GN/BK
11
X500
5
3397
YE/VT
3
3398
WH
6
3396
L-GN/BK
X600
5
3397
YE/VT
3
3398
WH
6
3396
L-GN/BK
3550
BK
X510
2
1
3
X610
2
1
3
3390
D-BU/WH
3391
WH
3389
GN/WH
M77D
Outside Rearview
Mirror Motor -
Driver
A9A
Outside
Rearview
Mirror -
Driver
M
M
3397
D-BU/WH
3398
WH
3396
GN/WH
M77P
Outside Rearview
Mirror Motor -
Passenger
A9B
Outside
Rearview
Mirror -
Passenger
M
M
G303

Heating (DL9)


X50A
Fuse Block - Underhood
KR5
Rear Defogger Relay
F60UA
7.5A
X2
62
2267
BN/YE
J207
2267
BN/YE
2267
BN/YE
X500
4
X600
4
2267
BN/YE
2267
BN/YE
X510
4
X610
4
A9A
Outside Rearview Mirror - Driver
2267
BK
X1
A
E17D
Outside Rearview Mirror Glass - Driver
X2
A
850
BK
A9B
Outside Rearview Mirror - Passenger
2267
BK
X1
A
E17P
Outside Rearview Mirror Glass - Passenger
X2
A
2050
BK
X510
5
X610
5
3550
BK
3650
BK
G203
G302

Description and Operation

Automatic Day-Night Mirror Description and Operation

Inside Rearview Mirror with the Automatic Day-Night Feature System Operation

The inside rearview mirror uses 2 photocell sensors. One sensor is the headlight sensor, located on the face side of the mirror. The headlight sensor is used to determine light conditions present at the mirror face. The other sensor is the ambient light sensor, located on the rear of the mirror or windshield side. The ambient light sensor is used to determine the exterior light conditions. With a low exterior light condition detected, and a high light condition from behind of the car, at the headlight sensor, the inside rearview mirror will automatically darken the face of the mirror.

In the daytime, the mirror is in a normal state because of the high exterior light condition that is indicated by the ambient light sensor. With the gear selector lever in the REVERSE position, backup lamp supply voltage is supplied as an input to the inside rearview mirror. The mirror monitors this input to disable the automatic day-night feature. This allows the driver to see objects in the mirror clearly when backing up, even during the night.

Outside Mirror Description and Operation

Power Mirror System Components

The power mirror system consists of the following components:

- Outside rearview mirror switch
- Mirror selector switch
- Driver outside rearview mirror
- Passenger outside rearview mirror

Each of the outside rearview mirror contains two motors. The vertical motor operates the mirror in the up and down directions, and the horizontal motor operates the mirror in the left and right directions.

Power Mirrors Without A45 Block Diagram



Power Mirror System Controls

The outside rearview mirror switch is a four position directional switch: Up, Down, Left and Right.

The mirror select switch is a three position switch: left, neutral/fold, and right.

Power Mirror System Operation

The outside rearview mirror switch receives battery voltage from the underhood fuse block The power mirror switch also receives a constant ground.

The four positions of the direction switch have dual switch contacts. Each of the contacts are connected to opposing sides of the appropriate power mirror motors through the selector switch. The selector switch completes these circuits depending on the position of the selector switch, L or R.

If the selector switch is placed in the L position and the up switch is pressed, battery voltage will be supplied to the left outside rearview mirror vertical motor through the left mirror motor vertical control circuit and ground through the left mirror motor common control circuit. If the down switch is pressed, battery voltage will be supplied to the left outside rearview mirror vertical motor through the left mirror motor common control circuit and ground through the left mirror motor vertical control circuit.

The remainder of the mirror functions operate in the same manner as described above. Placing the power mirror switch in opposing positions, left/right or up/down, will reverse the polarity to the mirror motor, reversing the direction of movement.

Heated Mirrors (If Equipped)

The heated mirrors are controlled through the rear defog relay. Whenever the rear window defogger is turned on battery voltage is supplied to the mirror heater elements through the left and right mirror heater element control circuits.

Body Systems

Vehicle Access

Schematic and Routing Diagrams

Door Lock/Indicator Schematics

Controls


K9 Body Control Module
X2
19
15
18
X7
21
24
X7
12
18
780 BN/YE
781 BN/WH
3265 YE/BN
244 YE/VT
245 BN/VT
3269 BN/WH
3268 GY/BK
X200
31
32
23
X600
18
17
X700
19
X800
19
X500
18
17
34
10
S79D Window Switch - Driver
A90 Logic
4
3
S13D Door Lock Switch - Driver
5
1
7
8
3270 WH/VT
1124 L-BU/VT
4
5
A23D Door Latch Assembly - Driver
3
S13P Door Lock Switch - Passenger
2
A23LR Door Latch Assembly - Left Rear
3
4
A23RR Door Latch Assembly - Right Rear
3
3550 BK
3550 BK
3550 BK
3650 BK
3550 BK
3450 BK
G303
G304


K9
Body
Control
Module
X6 27
747
GY
X700 5
747
GY
J700
X7 11
748
GY
X800 5
748
GY
J800
M74D
Window
Motor -
Driver
6
745
GY
S79LR
Window
Switch -
Left Rear
2
747
GY
S79RR
Window
Switch -
Right Rear
2
748
GY
S79P
Window
Switch -
Passenger
8
746
GY
1
A23D
Door
Latch
Assembly
- Driver
3
3550
BK
1
A23LR
Door
Latch
Assembly
- Left
Rear
3
3350
BK
5
A23RR
Door Latch
Assembly -
Right Rear
3
3450
BK
5
A23P
Door Latch
Assembly -
Passenger
3
3650
BK
747
GY
2
A23H
Door Latch
Assembly -
Left Rear
Upper
1
3350
BK
747
GY
2
A23G
Door Latch
Assembly -
Left Rear
Lower
1
3350
BK
748
GY
2
A23K
Door Latch
Assembly -
Right Rear
Upper
1
3450
BK
748
GY
2
A23J
Door Latch
Assembly -
Right Rear
Lower
1
3450
BK
G303
G304
LOC
DESC


K9 Body Control Module
F11DA F25DA
F25DA
F11DA
X6 4
1
2
X5 16
294 BN/YE
J209
294 BN/YE
X600 19
294 BN/YE
8
A23P Door Latch Assembly - Passenger
9
295 GY
X600 20
295 GY
294 BN/YE
X700 10
294 BN/YE
8
A23LR Door Latch Assembly - Left Rear
7
9
295 GY
3266 WH/L-BU
X700 11
9
295 GY
3266 WH/L-BU
294 BN/YE
X800 10
294 BN/YE
8
A23RR Door Latch Assembly - Right Rear
9
7
295 GY
3266 WH/L-BU
X800 11
9
295 GY
3266 WH/L-BU
294 BN/YE
5911 GY
X500 19
20
294 BN/YE
5911 GY
8
7
A23D Door Latch Assembly - Driver
M
3271 GY/L-GN
3267 VT/YE
X2 12
13
X50A Fuse Block - Underhood
TP18
KR113 Child Security Lock Disable Relay
X2 4
5
X1 71
295 GY
3266 WH/L-BU
1150 BK
J211 (43)
J210 (43)
G103

Description and Operation

Door Ajar Indicator Description and Operation

Door Ajar Indicator System Components

The door ajar indicator system consists of the following components:

- Body control module
- Instrument cluster
- Driver door latch
- Passenger door latch
- Left rear door latch
- Right rear door latch
- Driver window motor (AXG)
- Passenger window switch (AED)
- Left rear window switch (AEQ)
- Right rear window switch (AEQ)

Door Ajar System

Depending upon if the vehicle is a standard cab, extended cab or crew cab and/or is equipped with express up/down power windows or standard express down power windows or manual crank windows affects how the driver and passenger door ajar signal circuits are configured and monitored.

Door Ajar Indicator With AXG/AED/AEQ Block Diagram


P16
Instrument
Cluster
K9
Body
Control
Module
M74D
Window
Motor -
Driver
S79P
Window
Switch -
Passenger
S79LR
Window
Switch -
Left Rear
S79RR
Window
Switch -
Right
Rear
A23D
Door
Latch
Assembly
- Driver
A23P
Door Latch
Assembly -
Passenger
A23LR
Door
Latch
Assembly
- Left
Rear
A23RR
Door Latch
Assembly -
Right Rear

Driver Door Ajar (With AXG)

The driver window motor will provide a 12V signal to the driver door ajar switch within the door latch to indicate the status of the door. When the driver door is open, the contract within the ajar switch closes providing a ground part for the signal circuit. The driver window motor will detect the voltage drop in the ajar signal circuit and will send a serial data message to the body control module. The body control module will then send a message to the instrument cluster which will illuminate the door ajar icon.

Passenger and Rear Doors Ajar (With AED and AEQ)

The passenger and rear window switches provide a 12V signal to the respective door ajar switch within the door latch to indicate the status of the door. When the door is open, the contract within the ajar switch closes providing a ground part for the signal circuit. The window switch will detect the voltage drop in the ajar signal circuit and will send a serial data message to the body control module. The body control module will then send a message to the instrument cluster which will illuminate the door ajar icon.

Door Ajar Indicator Block Diagram


P16 Instrument Cluster
K9 Body Control Module
A23D Door Latch Assembly - Driver
A23P Door Latch Assembly - Passenger
A23LR Door Latch Assembly - Left Rear
A23RR Door Latch Assembly - Right Rear

Driver, Passenger and Rear Doors Ajar (Without AXG, AED or AEQ)

The body control module provides a 12V signal to each door ajar switch within the door latch to indicate the status of the door. When the door is open, the contract within the ajar switch closes providing a ground part for the signal circuit. The body control module will detect the voltage drop in the ajar signal circuit and will send a message to the instrument cluster which will illuminate the door ajar icon

Power Door Locks Description and Operation

Door Lock System Components

The power door lock system consists of the following components:

- Driver door lock switch
- Driver door key cylinder switch (Part of the driver door latch assembly)
- Child door lockout switch (Part of the driver window switch)
- Passenger door lock switch
- Front door lock actuators
- Rear door lock actuators (Extended and crew cab models)
- Body control module (BCM)
- Remote control door lock receiver
- Keyless entry transmitter
- Underhood fuse block (Contains child security lock disable PCB relay)

Door Lock System Controls

The power door lock system can be controlled by any of the following:

- A door lock switch LOCK or UNLOCK activation
- A key cylinder switch unlock activation
- A keyless entry transmitter activation
- Pressing the driver door lock plunger flush with the door panel will lock all doors

Door Lock Operation

The BCM supplies a 12 volt signal to the lock and unlock signal circuits of the driver and passenger door lock switches. When the appropriate switch is pressed, a contact within the door lock switch closes providing a ground path for the signal circuit. The BCM will detect the voltage drop in the signal and will command the doors to perform the lock or unlock functions.

The driver door latch contains 2 internal switches and 2 signal circuits that are monitored by the BCM. One switch is controlled by the driver key cylinder switch, when the key is turned to the unlock position, a switch will close and the BCM will command the remaining doors to UNLOCK. The other switch is controlled by the driver door lock plunger, pressing the plunger flush with the door panel will close the switch, the switch will close and the BCM will command the remaining doors to LOCK

The BCM may also receive a LOCK or UNLOCK command from the remote control door lock receiver, refer to Keyless Entry System Description and Operation for information on the keyless entry system

The BCM, upon receipt of a lock switch lock or unlock signal, will supply voltage to the door lock actuator lock or unlock control circuits and ground to the other lock actuator control circuit, the doors will then lock or unlock as commanded.

The following three circuits are used to operate the lock:

- Driver door unlock
- Passenger doors unlock
- All doors lock

Power Door Child Lock Block Diagram


S79D Window Switch - Driver
S79LR Window Switch - Left Rear
S79RR Window Switch - Right Rear
K9 Body Control Module
A23LR Door Latch Assembly - Left Rear
A23RR Door Latch Assembly - Right Rear
A23LR Door Latch Assembly - Left Rear
A23RR Door Latch Assembly - Right Rear
X50A Fuse Block - Underhood

Child Security Lockout System Operation

The child door lockout switch on the driver window switch controls the child locks on the rear doors. The lockout switch is an input to the body control module and the body control module controls the door lock security relay. When the body control module receives a command from the child door lockout switch, it will apply voltage to the child security lock disable relay coil, this will energize the relay and the contact within the relay will then direct the voltage to activate the left rear and right rear child locks and then isolate them from the normal door lock system to prevent the rear doors from being opened by using the interior rear door handles. An indicator will also illuminate to alert the driver that the child lockout system has been activated. Pushing the switch again will return normal function to the rear interior door handles and the indicator will go out.

The body control module monitors the voltage level of the child security motor status signal circuit, when the child locks have been activated, the contacts of the child security motor status switch (internal to the rear door latch) will close providing a ground path for the signal circuit pulling the voltage low. It is in this manner that the body control module is able to determine if the rear door latch has been successfully been locked out.

The body control module monitors the status of the child security lockout system, when the body control module detects a fault in the system, it will command the child lockout indicator to flash ON and OFF for 30 seconds to alert the driver that the child security lockout system may not be functioning properly.

The body control module will command the child lockout indicator to flash ON and OFF for the following reasons:

- An open/high resistance in either child security motor status signal circuit
- The body control module detects that one or both rear door latches have not activated and are not locked out
- The body control module detects a short to ground or an open/high resistance in the child security lock disable relay control circuit
- A malfunctioning child security lock disable relay
- An open/high resistance in the child security lock motor control circuit

Body Systems

Wipers and Washers

Schematic and Routing Diagrams

Wiper/Washer Schematics

Wiper/Washer Control


B+
F6UA
30A
X50A
Fuse Block - Underhood
30
85
KR12C
Windshield
Wiper
Speed
Control
Relay
87A
87
86
86
30
KR12B
Windshield
Wiper Relay
85
87
87A
X1
73
72
X2
45
22
X1
74
71
860
WH/VT
91
GY
X5
24
X4
16
F15DA
K9
Body
Control
Module
P
X4
17
X3
13
20
25
10
95
YE/BN
92
WH
196
BN/L-GN
1714
YE/L-BU
1715
GY
94
WH/BK
6009
BK/GY
3150
BK
1150
BK
3
1
5
2
S82
Windshield
Wiper/Washer
Switch
332 Ω
442 Ω
536 Ω
665 Ω
825 Ω
1070 Ω
X102
11
10
95
YE/BN
92
WH
2
4
1
M75
Windshield
Wiper Motor
M
3
3150
BK
1
2
1
2
G301
G103

Washer Pump


F15DA
K9
Body
Control
Module
X4 14
2268
BN/GY
B+
X2 60
X50A
Fuse Block -
Underhood
KR11
Windshield
Washer
Pump Relay
F56UA
15A
X1 30
71
228
GY/VT
1150
BK
1
M
G24
Windshield
Washer
Pump
2
1150
BK
G103

Description and Operation

Wiper/Washer System Description and Operation

Wiper/Washer System Components

The wiper/washer system consists of the following electrical components:

- Windshield Wiper Relay
- Windshield Wiper Speed Control Relay
- Windshield Washer Pump
- Windshield Washer Pump Relay
- Windshield Wiper Motor
- Windshield Wiper/Washer Switch
- Body Control Module (BCM)
- Underhood Fuse Block

Windshield Wiper System

The body control module (BCM) controls the wiper motor via two removable relays (Windshield Wiper Relay and Windshield Wiper Speed Control Relay). The BCM determines the wipe/wash system mode of operation by monitoring several signals from the Windshield Wiper/Washer Switch.

The BCM has 3 signal circuits, the first signal circuit is the Windshield Wiper Switch Low Reference, where the BCM provides a low reference signal to the Windshield Wiper/Washer Switch. Each input of the BCM provides a switched battery pull-up for each Windshield Wiper/Washer Switch output signal it receives.

The second signal circuit is the Windshield Wiper Switch Low Signal, and it consists of 6 resistors in the windshield wiper/washer switch configured as a resistor ladder network. The BCM monitors the voltage, and when high speed windshield wiper operation is requested, the windshield wiper control switch is connected to a different set of resistors into the circuit resulting in different voltages appearing on the BCM A/D input. To initiate low speed operation, the BCM only energizes the front wiper motor on/off relay. This allows battery voltage from the wiper fuse to be applied through the switched contacts of the wiper motor on/off relay, through the normally closed contacts of the wiper high/low speed relay, to the low speed control circuit of the windshield wiper motor.

The third signal circuit is the Windshield Wiper Switch High Signal, the BCM monitors the voltage, and when high speed windshield wiper operation is requested, the BCM continues to apply voltages to the windshield wiper relay control circuit and also applies ground to the windshield wiper speed control relay control circuit. This will cause the contacts in the windshield wiper speed control relay to close and apply B+ to the windshield wiper motor through the windshield wiper high speed control circuit, enabling high speed wiper operation.

Parking the wiper motor, the BCM monitors the park circuit until the park switch pulls the park circuit to ground. At this time, the BCM will immediately deactivate the wiper motor on/off relay. The relay contacts will switch back to their normally closed position and will apply ground to the wiper motor power inputs through the normally closed contacts of the wiper high/low relay. This deactivates and dynamically brakes the wiper motor in the park position. When the wiper switch is turned to the OFF position while the wiper motor is somewhere in mid-cycle, the BCM will continue to operate the motor until the wipers reach the park position. If the BCM is running the wiper motor and does not see a state transition of the park switch after 8 s, the wipers will stop immediately when the wiper switch is turned to OFF. If the ignition is turned OFF while the wipers are in mid-cycle, the wipers will stop immediately, regardless of position. The BCM will park the wipers next time the ignition is turned ON.

The windshield wiper system MIST operation is identical to LOW speed operation, except that the MIST switch is a press and release type switch. When the wiper switch is moved to the MIST position and released, low speed wiper motor operation is started and will continue until 1 cycle is complete. If the wiper switch is moved to the MIST position and held, the wiper motor will operate in the LOW speed mode until the switch is released.

Windshield wiper intermittent operation is a low speed wiper motor function with a variable delay interval between the wiper motor cycles. The duration of the delay is controlled by the front wiper control switch's intermittent 1 thru intermittent 5 settings. The wiper operation is as follows

1. The BCM will initiate a single wipe by activating its front wiper ON/OFF relay output.
2. At the completion of a single wipe, the BCM will park the wipers as described above.
3. The BCM will then pause the wipers in their park position for the time duration associated with intermittent delay switch setting.
4. When the delay time expires repeat Steps 1 and 3 until the system is turned off or taken out of intermittent mode. If the wiper switch is moved from a longer delay interval to a shorter delay interval, the BCM will command an immediate wipe cycle and reset the delay timer to the shorter delay interval.

Front Wiper Block Diagram


S82
Windshield
Wiper/
Washer
Switch
K9
Body
Control
Module
M75
Windshield
Wiper Motor

Windshield Washer System

The windshield washer system contains a windshield washer pump, a windshield washer pump relay, windshield wiper/washer switch. the windshield washer pump is controlled by the body control module (BCM) via a removable relay. When the washer switch is depressed, the BCM monitors the signal circuit by the washer request circuit. The BCM then applies voltage through a control circuit to the removable windshield washer pump relay. With the relay energized, fused battery voltage is applied through the switch contacts of the relay and the control circuit to activate the windshield washer pump.

Washers System Block Diagram


S82
Windshield
Wiper/
Washer
Switch
K9
Body
Control
Module
G24
Windshield
Washer
Pump

Engine/Propulsion

12 V Starting and Charging

Schematic and Routing Diagrams

Starting and Charging Schematics

Starting


K20
Engine
Control
Module
X7 1
X50D
Fuse
Block -
Battery
F6UB
300A
X6 1
1
RD
2
RD/YE
IGN
X1 63
X1 44
X1 66
51 (LFX)
14 (LCV)
22 (LWN)
6386
VT/GY
139
VT/GY
5V
X1 47
48
68
N8D
N8D
N8D
6109
GY/RD
6111
YE
6110
BK/GY
Manual Transmission
Schematics
P/N
X2 58 (LFX)
X1 49 (LCV)
X1 24 (LWN)
1786
WH/GY
B+
X3 11
X50A
Fuse Block -
Underhood
F12UA
30A
30
85
KR27
Starter
Relay
KR73
Ignition
Main
Relay
F5UA
10A
J110
87
86
X3 5
21
20
139
VT/GY
X1 3
Q8
Control
Solenoid
Valve
Assembly
T12
Automatic
Transmission
Assembly
X2 F
WH
B15
Transmission
Internal
Mode Switch
Automatic
Transmission
Controls
Schematics
GY
X2 A
K71
Transmission
Control
Module
X1 5
6
S39
Ignition
Switch
III
I
II
1.3K Ω
4
+
C1
Battery
–
6
YE
1450
BK
1073
WH/BK
1020
WH/VT
250
BK
1451
BK/WH
X3 22
15
5V
K9
Body
Control
Module
X2 A
X1 1
M64
Starter
Motor
M
G102
G107 (LWN)
G108 (LCV/LFX)
G107

Charging


B+
X50A
Fuse Block -
Underhood
F69UA
5A
X2 72
440
RD/BN
X4 20
B+
K9
Body
Control
Module
5V
X5 6
X4 18
21
26
1650
BK
5077
BK/PU
5075
WH/YE
5076
D-BU/VT
B
C
A
B18
Battery
Current
Sensor
1
RD
+
C1
Battery
−
250
BK
250
BK
G102
X7 1
X50D
Fuse
Block -
Battery
F6UB
300A
X4 A
2
RD
X4 A
X50A
Fuse Block -
Underhood
F74UA
200A
X5 A
2
RD/YE
P9
Driver Information
Center Display
P16
Instrument
Cluster
A90
Logic
K20
Engine
Control
Module
X2 55
53 (LFX)
X3 19
18 (LCV)
X2 67
34 (LWN)
LCV/LFX
LWN
23
GY
225
L-BU/WH
25
BN
X2 A
X1 2
1
B
S
F
L
P
G13
Generator

Description and Operation

Charging System Description and Operation

Electrical Power Management Overview

The electrical power management system is designed to monitor and control the charging system and send diagnostic messages to alert the driver of possible problems with the battery and generator. This electrical power management system primarily utilizes existing on-board computer capability to maximize the effectiveness of the generator, to manage the load, improve battery state-of-charge and life, and minimize the system's impact on fuel economy. The electrical power management system performs 3 functions:

- It monitors the battery voltage and estimates the battery condition.
- It takes corrective actions by boosting idle speeds, and adjusting the regulated voltage.
- It performs diagnostics and driver notification.

The battery condition is estimated during ignition-off and during ignition-on. During ignition-off the state-of-charge of the battery is determined by measuring the open-circuit voltage. The state-of-charge is a function of the acid concentration and the internal resistance of the battery, and is estimated by reading the battery open circuit voltage when the battery has been at rest for several hours.

The state-of-charge can be used as a diagnostic tool to tell the customer or the dealer the condition of the battery. Throughout ignition-on, the algorithm continuously estimates state-of-charge based on adjusted net amp hours, battery capacity, initial state-of-charge, and temperature.

While running, the battery degree of discharge is primarily determined by a battery current sensor, which is integrated to obtain net amp hours.

In addition, the electrical power management function is designed to perform regulated voltage control to improve battery state-of-charge, battery life, and fuel economy. This is accomplished by using knowledge of the battery state-of-charge and temperature to set the charging voltage to an optimum battery voltage level for recharging without detriment to battery life.

The Charging System Description and Operation is divided into 3 sections. The first section describes the charging system components and their integration into the electrical power management. The second section describes charging system operation. The third section describes the instrument panel cluster operation of the charge indicator, driver information center messages, and voltmeter operation.

Charging System Components

Generator

The generator is a serviceable component. If there is a diagnosed failure of the generator it must be replaced as an assembly. The engine drive belt drives the generator. When the rotor is spun it induces an alternating current (AC) into the stator windings. The AC voltage is then sent through a series of diodes for rectification. The rectified voltage has been converted into a direct current (DC) for use by the vehicles electrical system to maintain electrical loads and the battery charge. The voltage regulator integral to the generator controls the output of the generator. It is not serviceable. The voltage regulator controls the amount of current provided to the rotor. If the generator has field control circuit failure, the generator defaults to an output voltage of 13.8 V.

Body Control Module (BCM)

The body control module (BCM) is a GMLAN device. It communicates with the engine control module (ECM) and the instrument panel cluster for electrical power management (electrical power management) operation. The BCM determines the output of the generator and sends the information to the ECM for control of the generator turn on signal circuit. It monitors the generator field duty cycle signal circuit information sent from the ECM for control of the generator. It monitors a battery current sensor, the battery positive voltage circuit, and estimated battery temperature to determine battery state of charge. The BCM performs idle boost.

Battery Current Sensor

The battery current sensor is a serviceable component that is connected to the negative battery cable at the battery. The battery current sensor is a 3-wire hall effect current sensor. The battery current sensor monitors the battery current. It directly inputs to the BCM. It creates a 5 volt pulse width modulation (PWM) signal of 128 Hz with a duty cycle of 0–100 percent. Normal duty cycle is between 5–95 percent. Between 0–5 percent and 95–100 percent are for diagnostic purposes.

Engine Control Module (ECM)

When the engine is running, the generator turn-on signal is sent to the generator from the ECM, turning on the regulator. The generator's voltage regulator controls current to the rotor, thereby controlling the output voltage. The rotor current is proportional to the electrical pulse width supplied by the regulator. When the engine is started, the regulator senses generator rotation by detecting AC voltage at the stator through an internal wire. Once the engine is running, the regulator varies the field current by controlling the pulse width. This regulates the generator output voltage for proper battery charging and electrical system operation. The generator field duty terminal is connected internally to the voltage regulator and externally to the ECM. When the voltage regulator detects a charging system problem, it grounds this circuit to signal the ECM that a problem exists. The ECM monitors the generator field duty cycle signal circuit, and receives control decisions based on information from the BCM.

Instrument Panel Cluster

The instrument panel cluster provides the customer notification in case a concern with the charging system. There are 2 means of notification, a charge indicator and a driver information center message of SERVICE BATTERY CHARGING SYSTEM if equipped.

Charging System Block Diagram


P16
Instrument
Cluster
K20
Engine
Control
Module
G13
Generator
M64
Starter
Motor
C1
Battery
K9
Body
Control
Module
B18
Battery
Current
Sensor

Charging System Operation

The purpose of the charging system is to maintain the battery charge and vehicle loads. There are 6 modes of operation and they include:

- Battery Sulfation Mode
- Charge Mode
- Fuel Economy Mode
- Head lamp Mode
- Start Up Mode
- Voltage Reduction Mode

The engine control module (ECM) controls the generator through the generator turn ON signal circuit. The ECM monitors the generator performance though the generator field duty cycle signal circuit. The signal is a pulse width modulation (PWM) signal of 128 Hz with a duty cycle of 0–100 percent. Normal duty cycle is between 5–95 percent. Between 0–5 percent and 95–100 percent are for diagnostic purposes. The following table shows the commanded duty cycle and output voltage of the generator:

Commanded Duty Cycle	Generator Output Voltage
10%	11 V
20%	11.56 V
30%	12.12 V

40%	12.68 V
50%	13.25 V
60%	13.81 V
70%	14.37 V
80%	14.94 V
90%	15.5 V

The generator provides a feedback signal of the generator voltage output through the generator field duty cycle signal circuit to the ECM. This information is sent to the body control module (BCM). The signal is PWM signal of 128 Hz with a duty cycle of 0–100 percent. Normal duty cycle is between 5–99 percent. Between 0–5 percent and 100 percent are for diagnostic purposes.

Battery Sulfation Mode

The BCM will enter this mode when the interpreted generator output voltage is less than 13.2 V for 45 minutes. When this condition exists the BCM will enter Charge Mode for 2–3 minutes. The BCM will then determine which mode to enter depending on voltage requirements.

Charge Mode

The BCM will enter Charge Mode when ever one of the following conditions are met.

- The wipers are ON for more than 3 seconds.
- GMLAN (Climate Control Voltage Boost Mode Request) is true, as sensed by the HVAC control head. High speed cooling fan, rear defogger and HVAC high speed blower operation can cause the BCM to enter the Charge Mode.
- The estimated battery temperature is less than 0°C (32°F).
- Battery State of Charge is less than 80 percent.
- Vehicle speed is greater than 145 km/h (90 mph)
- Current sensor fault exists.
- System voltage was determined to be below 12.56 V

When any one of these conditions is met, the system will set targeted generator output voltage to a charging voltage between 13.9–15.5 V, depending on the battery state of charge and estimated battery temperature.

Fuel Economy Mode

The BCM will enter Fuel Economy Mode when the estimated battery temperature is at least 0°C (32°F) but less than or equal to 80°C (176°F), the calculated battery current is less than 15 amperes and greater than −8 amperes, and the battery state-of-charge is greater than or equal to 80 percent. Its targeted generator output voltage is the open circuit voltage of the battery and can be between 12.5–13.1 V. The BCM will exit this mode and enter Charge Mode when any of the conditions described above are present.

Head lamp Mode

The BCM will enter Head lamp Mode when ever the head lamps are ON (high or low beams). Voltage will be regulated between 13.9–14.5 V.

Start Up Mode

When the engine is started the BCM sets a targeted generator output voltage of 14.5 V for 30 seconds.

Tow/Haul Mode

Pressing the Tow/Haul Mode button located on the center stack, the vehicle system voltage is raised and the remote(non-vehicle) battery will be charged. Having the headlights on will raise the system voltage and if the Tow/Haul button is applied it will not serve any purpose. The voltage is regulated between 13.9-14.5 V.

Instrument Panel Cluster Operation

Charge Indicator Operation

The instrument panel cluster illuminates the charge indicator and displays a warning message in the driver information center if equipped, when the one or more of the following occurs:

- The engine control module (ECM) detects that the generator output is less than 11 V or greater than 16 V. The instrument panel cluster receives a GMLAN message from the ECM requesting illumination.
- The instrument panel cluster determines that the system voltage is less than 11 V or greater than 16 V for more than 30 seconds. The instrument panel cluster receives a GMLAN message from the body control module (BCM) indicating there is a system voltage range concern.
- The instrument panel cluster performs the displays test at the start of each ignition cycle. The indicator illuminates for approximately 3 seconds.

Display Message: BATTERY NOT CHARGING SERVICE CHARGING SYSTEM or SERVICE BATTERY CHARGING SYSTEM

The BCM and the ECM will send a serial data message to the driver information center for the BATTERY NOT CHARGING SERVICE CHARGING SYSTEM or SERVICE BATTERY CHARGING SYSTEM message to be displayed. It is commanded ON when a charging system DTC is a current DTC. The message is turned OFF when the conditions for clearing the DTC have been met.

Electrical Power Management Description and Operation

Electrical Power Management

The electrical power management is used to monitor and control the charging system and alert the driver of possible problems within the charging system. The electrical power management system makes the most efficient use of the generator output, improves the battery state-of-charge, extends battery life, and manages system electrical loads.

The load shed operation is a means of reducing electrical loads during a low voltage or low battery state-of-charge condition.

The idle boost operation is a means of improving generator performance during a low voltage or low battery state-of-charge condition.

Each electrical power management function, either idle boost or load shed, is activated in incremental steps. For example, idle boost 1 must be active before idle boost 2 can be active. The criteria used by the body control module (BCM) to regulate electrical power management are outlined below:

Electrical Power Management Block Diagram



Idle Boost and Load Shed With Current Sensor

Function	Battery Temperature Calculation	Battery Voltage Calculation	Amp-Hour Calculation	Action Taken
Idle Boost 1 Start	Less Than −15°C (5°F)	Less Than 13 V	—	First level Idle boost requested
Idle Boost 1 Start	—	—	Battery has a net loss greater than 0.6 Ah	First level Idle boost requested
Idle Boost 1 Start	—	Less Than 11 V	—	First level Idle boost requested
Idle Boost 1 End	Greater Than −10°C (14°F)	Greater Than 12 V	Battery has a net loss less than 0.2 Ah	First level Idle boost request cancelled
Idle Boost 2 Start	—	—	Battery has a net loss greater than 1.6 Ah	Second level Idle boost requested
Idle Boost 2 Start	—	Less Than 11 V	—	Second level Idle boost requested

Idle Boost 2 End	—	Greater Than 12 V	Battery has a net loss less than 0.8 Ah	Second level Idle boost request cancelled
Load Shed 1 Start	—	—	Battery has a net loss of 4 Ah	Rear Defrost, Heated Mirrors, Heated Seats, HVAC cycled OFF for 20% of their cycle
Load Shed 1 Start	—	Less Than 11 V	—	Rear Defrost, Heated Mirrors, Heated Seats, HVAC cycled OFF for 20% of their cycle
Load Shed 1 End	—	Greater Than 12 V	Battery has a net loss of less than 2 Ah	Clear Load Shed 1
Idle Boost 3 Start	—	—	Battery has a net loss of 10 Ah	Third level Idle boost requested
Idle Boost 3 Start	—	Less Than 11 V	—	Third level Idle boost requested
Idle Boost 3 End	—	Greater Than 12 V	Battery has a net loss of less than 6.0 Ah	Third level Idle boost request cancelled
Load Shed 2 Start	—	—	Battery has a net loss greater than 12 Ah	Rear Defrost, Heated Mirrors, Heated Seats, HVAC cycled OFF for 50% of their cycle. The BATTERY SAVER ACTIVE message will be displayed on the DIC
Load Shed 2 Start	—	Less Than 11 V	—	Rear Defrost, Heated Mirrors, Heated Seats, HVAC cycled OFF for 50% of their cycle. The BATTERY SAVER ACTIVE message will be displayed on the DIC
Load Shed 2 End	—	Greater Than 12 V	Battery has a net loss of less than 8 Ah	Clear Load Shed 2
Load Shed 3 Start	—	Less Than 11.9 V	Battery has a net loss greater than 20 Ah	Rear Defrost, Heated Mirrors, Heated Seats, HVAC cycled OFF for 100% of their cycle. The BATTERY SAVER ACTIVE message will be displayed on the DIC
Load Shed 3 Start	—	Less Than 11 V	—	Rear Defrost, Heated Mirrors, Heated Seats, HVAC cycled OFF for 100% of their cycle. The BATTERY SAVER ACTIVE message will be displayed on the DIC
Load Shed 3 End	—	Greater Than 12.6 V	Battery has a net loss of less than 13 Ah	Clear Load Shed 3

Idle Boost and Load Shed Without Current Sensor (based on battery voltage)

Function	Battery Temperature Calculation	Battery Voltage Calculation	Action Taken
Idle Boost 1 Start	Less Than −15°C (5°F)	Less Than 13 V	First level Idle boost requested
Idle Boost 1 Start	—	Less Than 12.6 V	First level Idle boost requested
Idle Boost 1 End	Greater Than −15°C (5°F)	—	First level Idle boost request cancelled
Idle Boost 1 End	—	Greater Than 13 V	First level Idle boost request cancelled
Idle Boost 2 Start	—	Less Than 12.4 V	Second level Idle boost requested
Idle Boost 2 End	—	Greater Than 12.5 V	Second level Idle boost request cancelled
Load Shed 1 Start	—	Less Than 12.3 V	Rear Defrost, Heated Mirrors, Heated Seats, HVAC cycled OFF for 20% of their cycle
Load Shed 1 End	—	Greater Than 12.4 V	Clear Load Shed 1
Idle Boost 3 Start	—	Less Than 10 V	Third level Idle boost requested
Idle Boost 3 End	—	Greater Than 12.3 V	Third level Idle boost request cancelled
Load Shed 2 Start	—	Less Than 12.1 V	Rear Defrost, Heated Mirrors, Heated Seats, HVAC cycled OFF for 50% of their cycle. The BATTERY SAVER ACTIVE message will be displayed on the DIC
Load Shed 2 End	—	Greater Than 12.2 V	Clear Load Shed 2
Load Shed 3 Start	—	Less Than 11.9 V	Rear Defrost, Heated Mirrors, Heated Seats, HVAC cycled OFF for 100% of their cycle. The BATTERY SAVER ACTIVE message will be displayed on the DIC
Load Shed 3 End	—	Greater Than 12.0 V	Clear Load Shed 3

Starting System Description and Operation

The starter motors are non-repairable starter motors. They have pole pieces that are arranged around the armature. Both solenoid windings are energized. The pull-in winding circuit is completed to the ground through the starter motor. The windings work together magnetically to pull and hold in the plunger. The plunger moves the shift lever. This action causes the starter drive assembly to rotate on the armature shaft spline as it engages with the flywheel ring gear on the engine. Moving at the same time, the plunger also closes the solenoid switch contacts in the starter solenoid. Full battery voltage is applied directly to the starter motor and it cranks the engine.

As soon as the solenoid switch contacts close, current stops flowing thorough the pull-in winding because battery voltage is applied to both ends of the windings. The hold-in winding remains energized. Its magnetic field is strong enough to hold the plunger, shift lever, starter drive assembly, and solenoid switch contacts in place to continue cranking the engine. When the engine starts, pinion overrun protects the armature from excessive speed until the switch is opened.

When the ignition switch is released from the START position, the START relay opens and battery voltage is removed from the starter solenoid S terminal. Current flows from the motor contacts through both windings to the ground at the end of the hold-in winding. However, the direction of the current flow through the pull-in winding is now opposite the direction of the current flow when the winding was first energized.

The magnetic fields of the pull-in and hold-in windings now oppose one another. This action of the windings, along with the help of the return spring, causes the starter drive assembly to disengage and the solenoid switch contacts to open simultaneously. As soon as the contacts open, the starter circuit is turned off.

Circuit Description (Key Start)

When the ignition switch is placed in the Start position, a discrete signal is supplied to the body control module (BCM) notifying it that the ignition is in the Start position. The BCM then sends a message to the engine control module (ECM) notifying it that CRANK has been requested. The ECM verifies that the transmission is in Park or Neutral. If it is, the ECM then supplies 12 V to the control circuit of the crank relay. When this occurs, battery positive voltage is supplied through the switch side of the crank relay to the S terminal of the starter solenoid.

Starting System Block Diagram



Engine/Propulsion

Cruise Control

Schematic and Routing Diagrams

Cruise Control Schematics

Cruise Control


B+
X51A Fuse Block - Instrument Panel
F4DA 5A
X1 3
3040 RD/YE
X202 6
3040 RD/YE
S70L Steering Wheel Controls Switch - Left
3400 Ω
1740 Ω
1050 Ω
698 Ω
499 Ω
1400 Ω
Object Detection Schematics
RES+
SET-
B+
10
1
4
9
3040 RD/YE
2050 BK
1884 BN/YE
1444 WH
Steering Wheel Secondary/ Configurable Control Schematics
J250
3040 RD/YE
J234
1444 WH
J232
Steering Wheel Secondary/ Configurable Control Schematics
3040 RD/YE
2050 BK
1444 WH
X1 1
9
8
6
X85 Steering Wheel Air Bag Coil
X2 10
2
3
5
2050 BK
1884 BN/L-GN
1444 WH/RD
X3 9
4
IGN
G300
P16 Instrument Cluster
A90 Logic
K20 Engine Control Module
X1 23 (LWN)
X1 50 (LCV)
X1 57 (LFX)
6311 WH/L-BU
X101 5
6311 WH/L-BU
X5 12
12V
K9 Body Control Module
L O C
D E S C

HVAC

HVAC - Automatic

Schematic and Routing Diagrams

HVAC Schematics

Power, Ground, Serial Data, HVAC and Blower Controls


B+
X50A
Fuse Block - Underhood
F21UA
40A
X2 33
542
RD/VT
X200 1
542
RD/VT
K8
Blower
Motor
Control
Module
3
M
B+
A90
Logic
1
4
B+
KR73
Ignition
Main
Relay
F24DA
5A
F13DA
10A
F9DA
10A
X51A
Fuse
Block -
Instrument
Panel
X2 37
25
X1 2
2840
RD/GY
X202 9
2840
RD/GY
J221
2840
RD/GY
539
VT/GY
3340
RD/VT
X203 47
48
539
VT/GY
3340
RD/VT
J253
539
VT/GY
3340
RD/VT
2050
BK
754
L-BU/GY
X2 15
9
1
IGN
B+
4
2
7531
GN/YE
5060
L-GN
K33
HVAC
Control
Module
X2 8
2050
BK
G300
2051
BK/WH
G305
X2 1
A26
HVAC
Controls
A/C
AUTO
SYNC
A90
Logic
B+
A/C
AUTO
SYNC
X2 9
3
10
LOC
DESC

Moisture, Sunload, and Temperature Sensors


Headlights/Daytime Running Lights (DRL) Schematics
278
WH/L-BU
5
6
B10B
Ambient
Light/Sunload
Sensor
A90
Logic
4
3
1783
YE/VT
734
L-BU/WH
1791
BK/YE
X1
14
4
X2
18
K33
HVAC
Control
Module
X1
18
X3
1
20
9
X1
7
5V
6
2
RH%
12
RH
5
518
BN
516
BN
6137
GY
407
BK/YE
X206
B
518
BN
A
B7B
Air
Temperature
Sensor -
Duct Lower
B
A
B7F
Air
Temperature
Sensor -
Duct Upper
B
A
B39
A/C
Evaporator
Temperature
Sensor
B
407
BK/YE
407
BK/YE
407
BK/YE
J252
7566
BK/L-BU
597
YE/RD
7565
GY/L-GN
7564
GY/L-BU
3197
YE/L-BU
X203
5
4
6
7
8
7566
BK/L-BU
597
YE/RD
7565
GY/L-GN
7564
GY/L-BU
3197
YE/L-BU
X300
7
6
8
14
15
7566
BK/L-BU
597
YE/RD
7565
GY/L-GN
7564
GY/L-BU
3197
YE/L-BU
X304
3
1
4
2
5
7566
BK
597
RD
7565
L-GN
7564
D-BU
3197
YE
1
4
2
5
B160
Windshield
Temperature
and Inside
Moisture
Sensor
A90
Logic
3

Mode and Temperature Control Actuators


K33
HVAC
Control
Module
B+
X3
15
3
5
2
4
11
12
13
14
16
17
18
19
J251
7572
OG
3166
WH/RD
3168
GN/WH
3165
YE
3167
GN/BN
7572
OG
3169
GN
3170
WH/PK
3171
GY/RD
3172
RD/BK
7572
OG
3173
GY
3174
BU/WH
3175
BN/GN
3176
RD/GN
2
3
6
1
4
M37
Mode Door
Actuator
M
A90
Logic
2
1
3
4
6
M6
Air
Temperature
Door
Actuator
M
A90
Logic
2
1
3
4
6
M4
Air Inlet
Door
Actuator
M
A90
Logic

A/C Compressor Controls


B+
X50A
Fuse Block - Underhood
KR75
Engine Controls Ignition Relay
F3UA
10A
86
30
KR29
A/C Compressor Clutch Relay
85
87
X3
34
50
459
WH/YE
59
BN/L-GN
K33
HVAC Control Module
B+
X2
11
10
7573
L-BU/BN
7574
L-BU/YE
X200
4
7
X101
10
19
P17
Info Display Module
2
B1
A/C Refrigerant Pressure Sensor
P
U
3
1
2700
BN/RD
380
L-GN
5514
BK/BN
J108 (LCV/LFX)
Engine Controls Schematics
5514
BK/BN (LWN)
6281
BK/L-GN (LCV/LFX)
G1
A/C Compressor
2
Q2
A/C Compressor Clutch
1
2
Q46
A/C Compressor Solenoid Valve
1
X1
37
57
(LCV)
X3
20 (LCV)
X1
46
47
48
(LWN)
X1
21
22
6
(LFX)
5V
K20
Engine Control Module
1450
BK
G114
X1 54 (LCV)
X1 32 (LFX)
X1 33 (LWN)

Auxiliary Heater (LWN)


B+
X50D
Fuse
Block -
Battery
F4UB
100A
X4
A
KR73
Ignition
Main
Relay
X51A
Fuse
Block -
Instrument
Panel
F24DA
5A
X2
37
K33
HVAC
Control
Module
X2
7
539
VT/GY
X203
47
4840
RD/GY
539
VT/GY
3195
VT
J253
539
VT/GY
X2
1
X1
2
1
E40
Electrical
Auxiliary
Heater
A90
Logic
B+
IGN
X2
2
1350
BK
G303

Description and Operation

Automatic HVAC Description and Operation

The air temperature and the air delivery description and operation are divided into eight areas:

- HVAC Control Components
- Air Speed
- Air Delivery
- Heating and A/C Operation
- Recirculation Operation
- Automatic Operation
- Auxiliary Electric Heater
- Engine Coolant and A/C System Refrigerant

HVAC Control Components

HVAC Control

The HVAC controls contains all buttons, switches, and dials which are required to control the functions of the HVAC system and serve as an interface between the operator and the HVAC control module. The selected values are passed to the HVAC control module via LIN-Bus.

HVAC Control Module

The HVAC control module is a GMLAN device that interfaces between the operator and the HVAC system to maintain and control desired air temperature and air distribution settings. The battery positive voltage circuit provides power that the HVAC control module uses for keep alive memory. If the battery positive voltage circuit loses power, all HVAC DTCs and settings will be erased from keep alive memory. The body control module (BCM), which is the vehicle mode master, provides a device ON-Signal. The HVAC control module provides blower, air delivery mode and air temperature settings.

The HVAC control module supports the following features:

Feature	Availability
Afterblow	Available if reprogrammed by the technician
Purge	Yes
Personalization	Yes
Actuator Calibration	Yes

Actuators

Doors in the HVAC case assembly are used to control air flow. The HVAC control module operates the doors through the use of actuators, with one actuator being used for each door. The system has the following air control doors and associated actuators: mode, temperature, and recirculation.

Each actuator used in the system is a 5-wire stepper motor. The HVAC control module supplies a 12 V reference voltage to the stepper motor and energizes the 4 stepper motor coils with a pulsed ground signal. The stepper motor moves the associated air control door into the calculated position in order to reach the selected position. The null point of the stepper motor will be calibrated, if the stepper motor is new. When the stepper motor is calibrated, the HVAC control module can drive the applicable coil to reach exactly the desired position of the door.

Blower Motor

The blower motor speed control signal from the HVAC Control Module, battery positive and ground circuits enable the blower motor to operate. The blower motor control circuitry is integrated within the blower motor assembly. The HVAC Control Module provides a pulse width modulation (PWM) signal to the blower motor to request a specific motor speed. The blower motor translates the PWM signal and drives the motor accordingly. As the requested blower speed increases, the HVAC control module increases the amount of time that the speed signal is modulated to ground. As the requested blower speed decreases, the HVAC control module decreases the amount of time that the signal is modulated to ground.

Evaporator Temperature Sensor

The evaporator temperature sensor is a 2-wire negative temperature coefficient thermistor. The sensor operates within a temperature range of −40 to +85°C (−40 to +185°F). The sensor is installed at the evaporator and measures its temperature. If the temperature drops under 3°C (38°F), the compressor will be switched off in order to prevent a frozen evaporator.

Duct Temperature Sensors

The air temperature sensors are 2-wire negative temperature coefficient thermistors. The sensors operate within a temperature range of −40 to +85°C (−40 to +185°F). The sensors are installed in the air distribution ducts and measurethe temperature of the air that streams from the ducts. The HVAC control module uses these values to calculate the desired Air temperature door position.

A/C Refrigerant Pressure Sensor

The A/C refrigerant pressure sensor is a 3-wire piezoelectric pressure transducer. The 5 V reference voltage, low reference, and signal circuits enable the sensor to operate. The A/C pressure signal can be between 0.2–4.8 V. When the A/C refrigerant pressure is low, the signal value is near 0 V. When the A/C refrigerant pressure is high, the signal value is near 5 V. The engine control module (ECM) converts the voltage signal to a pressure value. When pressure is too high or too low, the ECM will not allow the A/C compressor clutch to engage.

A/C Compressor

The A/C compressor uses a conventional belt driven magnetic clutch to engage and mechanically turn the compressor. When the A/C switch is pressed, the HVAC control module sends an A/C request message to the ECM via serial data. If specific criteria is met, the ECM then grounds the A/C compressor clutch relay control circuit, which will switch the A/C compressor clutch relay. With the relay contacts closed, battery voltage is supplied to the permanently grounded A/C compressor clutch. The A/C compressor clutch will then be activated.

This A/C system utilizes a variable displacement solenoid valve to alter the amount of displacement created by the turning of the compressor. The HVAC control module provides both battery voltage and a pulse width modulated ground to the variable displacement solenoid valve. When the A/C switch is pressed, the HVAC control module grounds the variable displacement solenoid using a (PWM) signal in order to determine the amount of compressor displacement. The performance of the A/C compressor is regulated based on the adjusted interior temperature.

Windshield Temperature and Inside Moisture Sensor

The windshield temperature and inside moisture sensor assembly provides information about:

- Relative humidity level at windshield (compartment side)
- Temperature of the windshield inside (compartment side)
- Temperature of the humidity sensor element

The relative humidity sensor measures the relative humidity of the compartment side of the windshield. It also detects the temperature of the windshield surface on the passenger compartment side. Both values are used as control inputs for the HVAC control module application to calculate the fog risk on windshield compartment side and ability to reduce fuel consumption by decreasing A/C compressor power to a minimum without causing any fog. The sensor will also enable partial recirculation mode in order to improve heat-up performance of the passenger compartment under cold ambient temperature conditions without the risk of mist build-up on the windshield. The humidity sensor element temperature sensor supplies the temperature of the humidity sensor element. It is only needed if the thermal contact between the humidity sensing element and the inside windshield surface is not sufficient.

Air Speed

The blower control switch is part of the HVAC controls. The selected value of the blower switch position is sent to the HVAC control module via LIN-Bus.

The HVAC control module provides a PWM signal to the blower motor in order to command the desired blower motor speed.

Afterblow

Afterblow is a feature that dries the evaporator core by operating the blower motor after the engine is turned OFF. This reduces the amount of microbial growth that can create undesirable odors. The vehicle does not come equipped with the afterblow feature turned ON. If the afterblow feature is required due to an odor concern, it must be enabled using the scan tool Afterblow configuration function.

After the HVAC control module has been programmed for afterblow, the following conditions must be met for afterblow to operate:

- The engine has been turned OFF for at least 30 minutes.
- The ambient air temperature is at least 21°C (70°F).
- The A/C compressor operated for more than 2 minutes before shut down.
- The system voltage is at least 12 volts.

Once the above conditions have been met, the blower motor will perform the following sequence up to 5 times. This could last up to an hour:

1. The blower motor will be OFF for 7–11 minutes.
2. The blower motor will RUN for 25–30 seconds.

Air Delivery

The desired air distribution mode can be selected with the air distribution switches at the HVAC controls. The HVAC controls delivers the values to the HVAC control module via LIN-Bus. The HVAC control module controls the air distribution actuator so that it drives the flap to the calculated position. Depending on the position of the flap, air is distributed through various ducts leading to the outlets in the dash. Turning the mode flap to the defrost position, the HVAC control module will move the recirculation actuator to outside air, reducing window fogging. When defrost is selected, the blower motor will be activated, regardless of the coolant temperature. The HVAC control module enables a high volume of air delivered to the front defrost vents. A/C is available in all modes.

The rear window defogger does not affect the HVAC system.

Heating and A/C Operation

The purpose of the heating and A/C system is to provide heated and cooled air to the interior of the vehicle. The A/C system will also remove humidity from the interior and reduce windshield fogging. Regardless of the temperature setting, the following can affect the rate that the HVAC system can achieve the desired temperature:

- Recirculation actuator setting
- Difference between inside and desired temperature
- Blower motor speed setting
- Mode setting

This vehicle may be equipped with a low voltage positive temperature coefficient cabin air heater. This is an electrical grid heater located in the HVAC case consisting of three 330 W stages used to heat the passenger compartment under cold conditions. When max temperature is selected and the engine coolant has not yet reached a sufficient temperature, the cabin air heater will be cycled on by the HVAC control module. The HVAC control module will monitor conditions in order to determine when to reduce or turn off the electrical cabin air heater.

When the A/C switch is pressed, the HVAC controls sends a signal to the HVAC control module via LIN-Bus. The HVAC control module evaluates this signal and sends an A/C request signal to the ECM via CAN-Bus. The ECM checks all preconditions before releasing and if all conditions are met sends a release signal back to the HVAC control module.

The following conditions must be met in order to activate the A/C compressor:

- Battery voltage is between 9–18 V
- Engine coolant temperature is less than 124°C (255°F)
- Engine speed is greater than 600 RPM

- Engine speed is less than 5 500 RPM
- A/C high side pressure is between 269–2 929 kPa (39–425 PSI)
- Throttle position is less than 100%
- Evaporator temperature is greater than 3°C (38°F)
- ECM does not detect excessive torque load
- ECM does not detect insufficient idle quality
- The ambient temperature is above 1°C (34°F)

The A/C high side pressure sensor information is used by the ECM to determine the following:

- The A/C high side pressure
- An A/C system load on the engine
- An immoderate A/C high side pressure
- The heat load at the A/C condenser

The air streams into the passenger compartment through the heater core and the evaporator core. The air temperature actuator drives the mixed air flap to determine the path of the incoming air. If the interior temperature should be increased, the mixed air flap is put into the position in which more air streams through the heater core. If the interior temperature should be decreased, the mixed air flap is put into the position in which more air streams through the evaporator core.

Recirculation Operation

The recirculation switch is integrated into the HVAC controls. The selected recirculation switch position is sent to the HVAC control module via LIN-Bus. The HVAC control module controls the air intake through the air inlet actuator and recirculation actuator. In the recirculation mode the air inlet flap closes and the recirculation flap opens in order to circulate the air within the vehicle. In fresh air mode the air inlet flap opens and the recirculation flap is closed again in order to route outside air into the vehicle. Recirculation is only available if the defrost mode is not active. When the defrost mode is active, the recirculation actuator opens the recirculation flap and the air inlet actuator opens the air inlet flap and outside air is circulated to the windshield to reduce fogging.

Automatic Operation

In automatic operation, the HVAC control module maintains the comfort level inside of the vehicle by controlling the A/C compressor clutch, the blower motor, the air temperature actuators, mode actuator and recirculation actuator.

To put the HVAC system in automatic mode, the following is required:

1. The auto switch must be activated.
2. The air temperature switch must be in any other position than full hot or full cold position.

Once the desired temperature is reached, the blower motor, mode, recirculation and temperature actuators automatically adjust to maintain the temperature selected. The HVAC control module performs the following functions to maintain the desired air temperature:

- Monitors the following sensors:
  - Ambient air temperature sensor
  - Lower left air temperature sensor
  - Upper left air temperature sensor
  - Windshield temperature and inside moisture sensor
  - Ambient light/sunload sensor
  - Air quality sensor
- Regulate blower motor speed
- Position the air temperature actuator
- Position the mode actuator
- Position the recirculation actuator
- Request A/C operation

When the warmest position is selected in automatic operation the blower speed will increase gradually until the vehicle reaches normal operating temperature. When normal operating temperature is reached the blower stays on high speed and the air temperature actuators stays in the full heat position.

When the coldest position is selected in automatic operation the blower stays on high and the air temperature actuators stay in full cold position. The mode actuator remains in the panel position and the recirculation actuator will remain in the recirculation position.

Under cold ambient temperatures, the automatic HVAC system provides heat in the most efficient manner. The operator can select an extreme temperature setting but the system will not warm the vehicle any faster. Under warm ambient temperatures, the automatic HVAC system also provides air conditioning in the most efficient manner. Selecting an extreme cool temperature will not cool the vehicle any faster.

In automatic mode the values of the windshield temperature and inside moisture sensor are used as control inputs for the HVAC control module application to calculate the fog risk on the passenger compartment side of the windshield and ability to reduce fuel consumption by decreasing A/C compressor power to a minimum without causing any fog. The A/C compressor and the defrost mode are activated to prevent or remove fog on the passenger compartment side of the windshield. The sensor will also enable partial recirculation mode in order to improve heat-up performance of the passenger compartment under cold ambient temperature conditions without the risk of mist build-up on the windshield.

Auxiliary Electric Heater (Diesel ONLY)

Models equipped with a diesel engine are also equipped with an auxiliary electric heater grid to provide faster cabin warm-ups in cold climates. The auxiliary heater grid is mounted in the low-center of the HVAC module, where heat is transferred from the grid to air which is directed to the floor outlet ducts.

The auxiliary heater is enabled only when the cabin temperature is set to MAX, the engine coolant temperature is less than 80°C (176°F), and the outside air temperature is below 12°C (54°F). When engine coolant temperature rises above 80°C (176°F), the temperature control is moved away from the MAX position, or the outside air temperature is above 12°C (54°F), the auxiliary electric heater is disabled, and cabin heat is managed only by the coolant-based heater core and temperature door position. If the auxiliary electric heater is activated and then turns off, it can actuate once again if the engine coolant temperature drops below 75°C (167°F), or the outside air temperature drops below 8°C (46°F).

The actual amount of heat output from the auxiliary electric heater can vary and is dependant upon internal overheating protection, battery state of charge, and other vehicle electrical load requirements.

Engine Coolant and A/C System Refrigerant

For information on engine coolant, coolant flow, A/C refrigerant, and the A/C refrigerant cycle, refer to CELL Link Error - Link target cell (cell ID 162334) is invalid for this publication..

HVAC

HVAC - Manual

Schematic and Routing Diagrams

HVAC Schematics

Power, Ground, Serial Data, HVAC and Blower Controls


B+
X50A
Fuse Block -
Underhood
F21UA
40A
X2
33
542
RD/VT
X200
1
542
RD/VT
K8
Blower
Motor
Control
Module
3
M
B+
A90
Logic
1
4
2050
BK
754
L-BU/GY
B+
KR73
Ignition
Main
Relay
F24DA
5A
F13DA
10A
F9DA
10A
X51A
Fuse
Block -
Instrument
Panel
X2
37
25
X1
2
2840
RD/GY
X202
9
2840
RD/GY
J221
2840
RD/GY
539
VT/GY
3340
RD/VT
X203
47
48
539
VT/GY
3340
RD/VT
J253
539
VT/GY
3340
RD/VT
X2
15
9
1
IGN
B+
4
2
K33
HVAC
Control
Module
X2
8
2050
BK
G300
7531
GN/YE
5060
L-GN
2051
BK/WH
G305
X2
1
A26
HVAC
Controls
A/C
A90
Logic
B+
A/C
X2
9
3
10
LOC
DESC

Temperature Sensors and Actuators


Headlights/Daytime Running Lights (DRL) Schematics
278 WH/L-BU
5
6
B10B Ambient Light/Sunload Sensor
A90 Logic
4
3
A
B39 A/C Evaporator Temperature Sensor
B
6137 GY
407 BK/YE
1783 YE/VT
734 L-BU/WH
1791 BK/YE
X3 20 9
X1 14 4
X2 18
K33 HVAC Control Module
B+
X3 15 3 5 2 4
11 12 13 14
16 17 18 19
J251
7572 OG
3166 WH/RD
3168 GN/WH
3165 YE
3167 GN/BN
7572 OG
3169 GN
3170 WH/PK
3171 GY/RD
3172 RD/BK
7572 OG
3173 GY
3174 BU/WH
3175 BN/GN
3176 RD/GN
2 3 6 1 4
M37 Mode Door Actuator
M
A90 Logic
2 1 3 4 6
M6 Air Temperature Door Actuator
M
A90 Logic
2 1 3 4 6
M4 Air Inlet Door Actuator
M
A90 Logic

A/C Compressor Controls

LOC
DESC


B+
X50A Fuse Block - Underhood
KR75 Engine Controls Ignition Relay
F3UA 10A
86
30
KR29 A/C Compressor Clutch Relay
85
87
X3
34
50
459 WH/YE
59 BN/L-GN
K33 HVAC Control Module
B+
X2
11
10
7573 L-BU/BN
7574 L-BU/YE
P17 Info Display Module
X200
4
7
7573 L-BU/BN
7574 L-BU/YE
X101
10
19
7573 L-BU/BN
7574 L-BU/YE
G1 A/C Compressor
2
Q2 A/C Compressor Clutch
2
Q46 A/C Compressor Solenoid Valve
1
1
1450 BK
G114
2
B1 A/C Refrigerant Pressure Sensor
P
U
3
1
2700 BN/RD
380 L-GN
5514 BK/BN
J108 (LCV/LFX)
Engine Controls Schematics
5514 BK/BN (LWN)
6281 BK/L-GN (LCV/LFX)
X1 37
57 (LCV)
X3 20 (LCV)
X1 46
47
48 (LWN)
X1 21
22
6 (LFX)
5V
K20 Engine Control Module
X1 54 (LCV)
X1 32 (LFX)
X1 33 (LWN)

Auxiliary Heater (LWN)


B+
X50D
Fuse
Block -
Battery
F4UB
100A
X4
A
KR73
Ignition
Main
Relay
F24DA
5A
X51A
Fuse
Block -
Instrument
Panel
X2
37
K33
HVAC
Control
Module
X2
7
539
VT/GY
X203
47
4840
RD/GY
539
VT/GY
3195
VT
J253
539
VT/GY
X2
1
X1
2
1
E40
Electrical
Auxiliary
Heater
A90
Logic
B+
IGN
X2
2
1350
BK
G303

LOC
DESC

Description and Operation

Manual HVAC Description and Operation

The air temperature and the air delivery description and operation are divided into seven areas:

- HVAC Control Components
- Air Speed
- Air Delivery
- Heating and A/C Operation
- Recirculation Operation
- Auxiliary Electric Heater
- Engine Coolant and A/C System Refrigerant

HVAC Control Components

HVAC Controls

The HVAC controls contains all switches, which are required to control the functions of HVAC and serve as interface between the operator and the HVAC control module. The selected values are passed to the HVAC control module via LIN-Bus.

HVAC Control Module

The HVAC control module is a GMLAN device that interfaces between the operator and the HVAC system to maintain and control desired air temperature and air distribution settings. The battery positive voltage circuit provides power that the HVAC control module uses for keep alive memory. If the battery positive voltage circuit loses power, all HVAC DTCs and settings will be erased from keep alive memory. The body control module (BCM), which is the vehicle mode master, provides a device ON-Signal. The HVAC control module provides blower, air delivery mode and air temperature settings.

The HVAC control module supports the following features:

Feature	Availability
Afterblow	Available if reprogrammed by the technician
Personalization	Yes
Actuator Calibration	Yes

Actuators

Doors in the HVAC case assembly are used to control air flow. The HVAC control module operates the doors through the use of actuators, with one actuator being used for each door. The system has the following air control doors and associated actuators: mode, temperature, and recirculation.

Each actuator used in the system is a 5-wire stepper motor. The HVAC control module supplies a 12 V reference voltage to the stepper motor and energizes the 4 stepper motor coils with a pulsed ground signal. The stepper motor moves the associated air control door into the calculated position in order to reach the selected position. The null point of the stepper motor will be calibrated, if the stepper motor is new. When the stepper motor is calibrated, the HVAC control module can drive the applicable coil to reach exactly the desired position of the door.

Blower Motor

The blower motor speed control signal from the HVAC Control Module, battery positive and ground circuits enable the blower motor to operate. The blower motor control circuitry is integrated within the blower motor assembly. The HVAC Control Module provides a pulse width modulation (PWM) signal to the blower motor to request a specific motor speed. The blower motor translates the PWM signal and drives the motor accordingly. As the requested blower speed increases, the HVAC control module increases the amount of time that the speed signal is modulated to ground. As the requested blower speed decreases, the HVAC control module decreases the amount of time that the signal is modulated to ground.

Evaporator Temperature Sensor

The evaporator temperature sensor is a 2-wire negative temperature co-efficient thermistor. The sensor operates within a temperature range of −40 to +85°C (−40 to +185°F). The sensor is installed at the evaporator and measures its temperature. If the temperature drops under 3°C (38°F), the compressor will be switched off in order to prevent a frozen evaporator.

A/C Refrigerant Pressure Sensor

The A/C refrigerant pressure sensor is a 3-wire piezoelectric pressure transducer. The 5 V reference voltage, low reference, and signal circuits enable the sensor to operate. The A/C pressure signal can be between 0.2–4.8 V. When the A/C refrigerant pressure is low, the signal value is near 0 V. When the A/C refrigerant pressure is high, the signal value is near 5 V. The engine control module (ECM) converts the voltage signal to a pressure value. When pressure is too high or too low, the ECM will not allow the A/C compressor clutch to engage.

A/C Compressor

The A/C compressor uses a conventional belt driven magnetic clutch to engage and mechanically turn the compressor. When the A/C switch is pressed, the HVAC control module sends an A/C request message to the ECM via serial data. If specific criteria is met, the ECM then grounds the A/C compressor clutch relay control circuit, which will switch the A/C compressor clutch relay. With the relay contacts closed, battery voltage is supplied to the permanently grounded A/C compressor clutch. The A/C compressor clutch will then be activated.

This A/C system utilizes a variable displacement solenoid valve to alter the amount of displacement created by the turning of the compressor. The HVAC control module provides both battery voltage and a pulse width modulated ground to the variable displacement solenoid valve. When the A/C switch is pressed, the HVAC control module grounds the variable displacement solenoid using a (PWM) signal in order to determine the amount of compressor displacement. The performance of the A/C compressor is regulated based on the adjusted interior temperature.

Air Speed

The blower control switch is part of the HVAC controls. The selected value of the blower switch position is sent to the HVAC control module via LIN-Bus.

The HVAC control module provides a PWM signal to the blower motor in order to command the desired blower motor speed.

Afterblow

Afterblow is a feature that dries the evaporator core by operating the blower motor after the engine is turned OFF. This reduces the amount of microbial growth that can create undesirable odors. The vehicle does not come equipped with the afterblow feature turned ON. If the afterblow feature is required due to an odor concern, it must be enabled using the scan tool Afterblow configuration function.

After the HVAC control module has been programmed for afterblow, the following conditions must be met for afterblow to operate:

- The engine has been turned OFF for at least 30 minutes.
- The ambient air temperature is at least 21°C (70°F).
- The A/C compressor operated for more than 2 minutes before shut down.
- The system voltage is at least 12 volts.

Once the above conditions have been met, the blower motor will perform the following sequence up to 5 times. This could last up to an hour:

1. The blower motor will be OFF for 7–11 minutes.
2. The blower motor will RUN for 25–30 seconds.

Air Delivery

The desired air distribution mode can be selected with the air distribution switches at the HVAC controls. The HVAC controls delivers the values to the HVAC control module via LIN-Bus. The HVAC control module controls the air distribution actuator so that it drives the flap to the calculated position. Depending on the position of the flap, air is distributed through various ducts leading to the outlets in the dash. Turning the mode flap to the defrost position, the HVAC control module will move the recirculation actuator to outside air, reducing window fogging. When defrost is selected, the blower motor will be activated, regardless of the coolant temperature. The HVAC control module enables a high volume of air delivered to the front defrost vents. A/C is available in all modes.

The rear window defogger does not affect the HVAC system.

Heating and A/C Operation

The purpose of the heating and A/C system is to provide heated and cooled air to the interior of the vehicle. The A/C system will also remove humidity from the interior and reduce windshield fogging. Regardless of the temperature setting, the following can affect the rate that the HVAC system can achieve the desired temperature:

- Recirculation actuator setting
- Difference between inside and desired temperature
- Blower motor speed setting
- Mode setting

This vehicle may be equipped with a low voltage positive temperature coefficient cabin air heater. This is an electrical grid heater located in the HVAC case consisting of three 330 W stages used to heat the passenger compartment under cold conditions. When max temperature is selected and the engine coolant has not yet reached a sufficient temperature, the cabin air heater will be cycled on by the HVAC control module. The HVAC control module will monitor conditions in order to determine when to reduce or turn off the electrical cabin air heater.

When the A/C switch is pressed, the HVAC controls sends a signal to the HVAC control module via LIN-Bus. The HVAC control module evaluates this signal and sends an A/C request signal to the ECM via CAN-Bus. The ECM checks all preconditions before releasing and if all conditions are met sends a release signal back to the HVAC control module.

The following conditions must be met in order to activate the A/C compressor:

- Battery voltage is between 9–18 V
- Engine coolant temperature is less than 124°C (255°F)
- Engine speed is greater than 600 RPM
- Engine speed is less than 5 500 RPM
- A/C high side pressure is between 269–2 929 kPa (39–425 PSI)
- Throttle position is less than 100%
- Evaporator temperature is greater than 3°C (38°F)
- ECM does not detect excessive torque load
- ECM does not detect insufficient idle quality
- The ambient temperature is above 1°C (34°F)

The A/C high side pressure sensor information is used by the ECM to determine the following:

- The A/C high side pressure
- An A/C system load on the engine
- An immoderate A/C high side pressure
- The heat load at the A/C condenser

The air streams into the passenger compartment through the heater core and the evaporator core. The air temperature actuator drives the mixed air flap to determine the path of the incoming air. If the interior temperature should be increased, the mixed air flap is put into the position in which more air streams through the heater core. If the interior temperature should be decreased, the mixed air flap is put into the position in which more air streams through the evaporator core.

Recirculation Operation

The recirculation switch is integrated into the HVAC controls. The selected recirculation switch position is sent to the HVAC control module via LIN-Bus. The HVAC control module controls the air intake through the air inlet actuator and recirculation actuator. In the recirculation mode the air inlet flap closes and the recirculation flap opens in order to circulate the air within the vehicle. In fresh air mode the air inlet flap opens and the recirculation flap is closed again in order to route outside air into the vehicle. Recirculation is only available if the defrost mode is not active. When the defrost mode is active, the recirculation actuator opens the recirculation flap and the air inlet actuator opens the air inlet flap and outside air is circulated to the windshield to reduce fogging.

Auxiliary Electric Heater (Diesel ONLY)

Models equipped with a diesel engine are also equipped with an auxiliary electric heater grid to provide faster cabin warm-ups in cold climates. The auxiliary heater grid is mounted in the low-center of the HVAC module, where heat is transferred from the grid to air which is directed to the floor outlet ducts.

The auxiliary heater is enabled only when the cabin temperature is set to MAX, the engine coolant temperature is less than 80°C (176°F), and the outside air temperature is below 12°C (54°F). When engine coolant temperature rises above 80°C (176°F), the temperature control is moved away from the MAX position, or the outside air temperature is above 12°C (54°F), the auxiliary electric heater is disabled, and cabin heat is managed only by the coolant-based heater core and temperature door position. If the auxiliary electric heater is activated and then turns off, it can actuate once again if the engine coolant temperature drops below 75°C (167°F), or the outside air temperature drops below 8°C (46°F).

The actual amount of heat output from the auxiliary electric heater can vary and is dependant upon internal overheating protection, battery state of charge, and other vehicle electrical load requirements.

Engine Coolant and A/C System Refrigerant

For information on engine coolant, coolant flow, A/C refrigerant, and the A/C refrigerant cycle, refer to CELL Link Error - Link target cell (cell ID 162334) is invalid for this publication..

Power and Signal Distribution

Data Communications

Schematic and Routing Diagrams

Data Communication Schematics

Serial Data Gateway Module and Data Link Connector Power and Ground


B+
X51A
Fuse
Block -
Instrument
Panel
F23DA
10A
X1
27
640
RD/WH
X203
48
640
RD/WH
16
4
X84
Data Link
Connector
5
2050
BK
2151
BJ/WH
G300
G307
B+
X51A
Fuse
Block -
Instrument
Panel
F16UA
10A
X1
8
6440
RD/WH
X203
25
6440
RD/WH
1
K56
Serial Data
Gateway
Module
6
1350
BK

High Speed GMLAN


K20 Engine Control Module
120 Ω
X1 9 10 (LCV)
X1 28 12 (LGZ)
X1 55 40 (LWN)
2500 L-BU
2501 WH
9
-MYB
MYB
MYB
-MYB
X1 37 38 (LGZ)
X1 10 11
K71 Transmission Control Module
X1 14 13
X1 53 54
X203 46 47
K9 Body Control Module
X1 25 24
X6 24 25
X2 24 23
X106 28 19
6 14
X84 Data Link Connector
K56 Serial Data Gateway Module
X1 1 2
X2 1 2
X203 40 41
-NQ6/NQ7
NQ6/NQ7
NQ6/NQ7
-NQ6/NQ7
K69 Transfer Case Control Module
X2 15 16
X2 7 8
X103 3 2
K43 Power Steering Control Module
X1 8 9
X1 10 11
X103 10 9
K17 Electronic Brake Control Module
11 10
12 9
R6A Terminating Resistor - High Speed Bus
120 Ω
A B
-JL1
JL1
JL1
-JL1
K38 Chassis Control Module
26 29
27 28

L O C
D E S C

Isolated High Speed GMLAN



L O C
D E S C
K56 Serial Data Gateway Module
120 Ω
X1 14 13
1305 WH/GN
1304 BU/GN
9
X1 12 11
X1 4 3
IOB
IO5/IO6
IO5/IO6
IOB
K74 Human Machine Interface Control Module
X1 14 13
X1 12 11
R6A Terminating Resistor - High Speed Bus
X2 11 12
1304 BU/GN
1305 WH/GN
X203 31 32
K73 Telematics Communication Interface Control Module
X1 10 12
X2 3 4
-UE1
UE1
UE1
-UE1
X203 42 43

Low Speed GMLAN


K9
Body
Control
Module
K56
Serial Data
Gateway
Module
A26
HVAC
Controls
X7 23
X2 22
X1 15
X2 3
5060
GN
K85
Passenger
Presence
Module
X1 3
A C D E F
JX200
G H J K L M
X1 A F
JX201
J
X301 17
X1 7
K109
Frontview
Camera
Module
X2 2
K33
HVAC
Control
Module
X1 1
X84
Data Link
Connector
X1 15
K36
Inflatable
Restraint
Sensing
and
Diagnostic
Module


K56
Serial Data
Gateway
Module
A11
Radio
P17
Info
Display
Module
P16
Instrument
Cluster
X2 10
X1 14
4 (IOB)
X1 3
X1 3
1102
GY/GN
A
B
C
D
E
F
JX202
G
H
J
K
L
M
X1 1
X3 1
K73
Telematics
Communication
Interface
Control Module
T3
Audio
Amplifier


K20
Engine
Control
Module
120 Ω
X1
8
7
9
7493
L-BU/BK
7494
WH
X101
36
37
9
7493
L-BU/BK
7494
WH
X106
35
36
9
7493
L-BU/BK
7494
WH
4
5
K111
Fuel Pump
Driver
Control
Module
12
13
7493
L-BU/BK
7494
WH
9
11
14
120 Ω

Powertrain NOX Bus (LWN)


K20
Engine
Control
Module
120 Ω
X1
54
39
4498
L-BU/BN
9
4499
WH
X107
28
29
4498
L-BU/BN
9
4499
WH
X1
3
2
K115
Reductant
Control
Module
X1
7
6
4498
L-BU/BN
9
4499
WH
2
5
B195A
Nitrogen
Oxides
Sensor 1
3
4
4498
L-BU/BN
9
4499
WH
B195B
Nitrogen
Oxides
Sensor 2
120 Ω
2
5
4498
L-BU/BN
9
4499
WH
5
2
B136
Exhaust
Particulate
Matter
Sensor
4
3


X84
Data Link
Connector
12
13
6105
L-BU/YE
9
6106
WH
J216
J215
6105
L-BU/YE
9
6106
WH
X1
18
20
120 Ω
K36
Inflatable
Restraint
Sensing
and
Diagnostic
Module
X200
4
5
X106
37
46
X103
12
11
X1
5
6
K43
Power Steering Control
Module
X1
3
4
X103
5
4
19
18
120 Ω
K17
Electronic Brake
Control Module


L O C
D E S C
A11
Radio
X2
1
2
3
4
3997
WH/L-GN
3998
GY/VT
9
18
17
P16
Instrument
Cluster
X299
2
1 (EARLY_PRODUCTION)
-UDD
UDD
UDD
-UDD
IO3
IO4/IO5/IO6
IO4/IO5/IO6
IO3
K74
Human
Machine
Interface
Control
Module
8
X4
5
6
T3
Audio
Amplifier
-UQA
UQA
UQA
-UQA

MOST Communication Enable


A11
Radio
X2
7
3999
WH/VT
J231
UDD
IO4/IO5/IO6
UQA
3999
WH/VT
3999
WH/VT
3999
WH/VT
5
P16
Instrument
Cluster
X2
1
K74
Human
Machine
Interface
Control
Module
X4
14
T3
Audio
Amplifier

Accessory Wakeup and Communications Enable


F1DA
IGN
X4
22
K9
Body
Control
Module
IGN
23
K73
Telematics
Communication
Interface
Control Module
IGN
X2
7
5985
VT/YE
5986
WH/L-BU
5986
WH/L-BU
J201
J205
NQ6/NQ7
5985
VT/YE
5985
VT/YE
5985
VT/YE
5986
WH/L-BU
5986
WH/L-BU
X106
33
26
X200
43
X101
42
5985
VT/YE
5985
VT/YE
5986
WH/L-BU
5986
WH/L-BU
J109 (MYB)
J104
J224
MYB
5985
VT/YE
5985
VT/YE
5986
WH/L-BU
5986
WH/L-BU
5986
WH/L-BU
5986
WH/L-BU
X103
8
5986
WH/L-BU
LFX/LWN
LCV
X1
9
T12
Automatic
Transmission
Assembly
X1 7 (LWN)
X1 70 (LFX)
X1 13 (LCV)
X1 14 (LWN)
X1 8 (LFX)
X1
7
6
X1
2
X1
17
X1
5
X2
6
IGN
K69
Transfer
Case
Control
Module
IGN
Q8
Control
Solenoid
Valve
Assembly
IGN
K20
Engine
Control
Module
IGN
K38
Chassis
Control
Module
IGN
K111
Fuel Pump
Driver
Control
Module
IGN
K17
Electronic
Brake
Control
Module
IGN
K43
Power
Steering
Control
Module
IGN
K36
Inflatable
Restraint
Sensing
and
Diagnostic
Module
IGN
K74
Human
Machine
Interface
Control
Module


K9 Body Control Module
X3 19
7527 L-GN/WH
KA1
2
7533 L-GN/WH
K89 Immobilizer Control Module
X6 9
6133 L-GN/L-BU
KA1/MYB
J208 (KA1+MYB)
KA1
MYB
X320 18
X202 42
X306 2
16
6132 L-GN/BN
X301 18
10
6134 L-GN/YE
J202
X500 33
X600 33
J504
X2 21
6135 L-GN/GY
X200 46
J212
X700 20
X800 20
J217
K33 HVAC Control Module
X2 4
7531 L-GN/YE
A11 Radio
X1 13
7532 L-GN/BU
K74 Human Machine Interface Control Module
X1 9
7527 L-GN/WH
X1 5
8
A22 Radio Controls
P17 Info Display Module
K38 Chassis Control Module
X1 30
JL1
4114 L-GN/VT
K20 Engine Control Module
X3 55
LCV
3890 GY
X101 45
X102 35
X105 3
P16 Instrument Cluster
20
W1Y
3894 L-GN/BK
X2 9
X85 Steering Wheel Air Bag Coil
X1 2
S32D Seat Heating Switch - Driver
S32P Seat Heating Switch - Passenger
K29 Seat Heating Control Module
X1 2
P2 Transmission Shift Lever Position Indicator
M74D Window Motor - Driver
S79D Window Switch - Driver
S79P Window Switch - Passenger
S79LR Window Switch - Left Rear
S79RR Window Switch - Right Rear
A26 HVAC Controls
K133 Trailer Brake Power Control Module
M96 Active Grille Air Shutter Actuator
S70R Steering Wheel Controls Switch - Right

Power, Ground, and Serial Data


B+
X50A Fuse Block - Underhood
F69UA 5A
F33UA 20A
X2 72 69
B+
X51A Fuse Block - Instrument Panel
F1DA 15A
F5DA 15A
F15DA 20A
F25DA 20A
F11DA 30A
F17DA 20A
X1 4 1 19 18 X2 7 18
440 RD/BN
2340 RD/YE
2140 RD/GY
2240 RD/BN
2640 RD/VT
2740 RD/WH
4040 RD/VT
2440 RD/L-GN
X202 25 4 7
X203 13 27
2340 RD/YE
2140 RD/GY
2240 RD/BN
4040 RD/VT
2440 RD/L-GN
Power Moding Schematics
755 GY/VT
5985 VT/YE
4 VT/YE
1020 WH/VT
1073 WH/BK
3 VT/BK
X4 20 X1 3 X2 1 X1 4 X5 4 3 X2 4 X1 2
X4 12 22 X3 5 15 22 6
B+ B+ B+ B+ B+ B+ B+ B+
IGN IGN 5V IGN
K9 Body Control Module
IGN ⏻ IGN ⏻
X7 23 X1 24 25 X3 2 19 X6 16 9 10 25 24 X2 21 22 23 24 X4 23 22 26 X6 3 X1 1 X2 2 X4 15
5060 L-GN
2501 WH
2500 L-BU
7533 L-GN/VT
7527 L-GN/WH
6132 L-GN/BN
6133 L-GN/L-BU
6134 L-GN/YE
2501 WH
2500 L-BU
6135 L-GN/GY
5060 L-GN
2501 WH
2500 L-BU
5986 WH/L-BU
5985 VT/YE
1650 BK
3150 BK
2150 BK
2150 BK
5199 L-GN/VT
Data Communication Schematics
Power Moding Schematics
G101 G301 G307

Subsystem References (1 of 3)



Shift Lock Control Schematics
Hood Latch Schematics
Starting and Charging Schematics
Transfer Case Control Schematics
Horn Schematics
Automatic Transmission Controls Schematics
Fog Lights Schematics
Theft Deterrent System Schematics
7553 VT/BK
109 BN/L-GN
5075 WH/YE
5076 L-BU/VT
5077 BK/VT
300 VT/BN
28 BN/WH
3287 L-GN/WH
5526 VT/YE
553 L-BU/GY
1317 BN/WH
192 L-BU/GY
728 GY
MYB
UTJ
NQ6/NQ7
MYB
MYB
T3U
T3U
X7 6
X4 24
18
21
X5 6
14
19
X3 18
X2 11
14
X5 13
X1 15
21
5V
+/-
K9 Body Control Module
X7 15
12
18
11
X6 27
1
4
2
X5 16
X2 18
6
27
12V
25
16
X1 26
X3 8
1134 L-BU/VT
3269 BN/WH
3268 GY/BK
748 GY
747 GY
5911 GY
294 BN/YE
3271 GY/L-GN
3267 VT/YE
3265 YE/BN
5697 GY
3274 YE/L-GN
3272 GY/WH
3273 GY
3275 L-BU/WH
6818 L-GN
Hydraulic Brake Schematics
Door Lock/ Indicator Schematics
Interior Lights Dimming Schematics
Remote Function Schematics
Steering Wheel Secondary/ Configurable Control Schematics

Subsystem References (2 of 3)


Headlights/Daytime Running Lights (DRL) Schematics
Exterior Lights Schematics
307 YE/BN
524 WH
306 L-GN/BN
103 WH/VT
278 WH/L-BU
1969 BN/VT
712 YE
312 YE
2509 BN/L-BU
7541 WH/YE
309 GY/BN
709 VT/GY
6846 L-GN/YE
7542 GY/YE
2609 BN/GY
24 L-GN/WH
1429 BN/WH
X3 17
11
X1 11
16
X2 10
X5 18
X4 2
1
7
4
5
6
13
X5 1
7
X7 3
X7 7
K9 Body Control Module
12V
5V
X3 16
9
4
12
24
X2 7
13
26
X5 2
X1 22
19
X7 8
14
X4 3
X2 20
X5 8
17
22
26
X7 16
5737 GY/L-GN
1884 BN/L-GN
1444 WH/RD
663 WH/L-GN
664 VT/L-BU
5361 L-BU/YE
5359 WH
111 L-GN/WH
1314 L-BU/WH
13 L-GN/GY
5360 BK/BN
5065 VT/WT
158 GY
1315 GN/VT
3691 WH/L-BU
5186 L-BU/WT
5187 YE/GY
45 L-BU
38 L-BU/BN
3691 WH/L-BU
Object Detection Schematics
Cruise Control Schematics
Exterior Lights Schematics
Trailer Connector/Provision Schematics

Subsystem References (3 of 3)


Interior Lights Dimming Schematics
Interior Lights Schematics
Antilock Brake System Schematics
Cruise Control Schematics
44 YE/GY
6817 YE
6816 WH
5005 BK/YE
1688 BU/RD
328 GY/GN
156 GY
6815 WH/BN
157 GY
1788 L-BU/VT
6844 L-BU/YE
6311 WH/L-BU
X2 9 8
X1 5 7 13 14
5v
X7 19 2
X2 5 14
X1 10
X5 12
K9 Body Control Module
X5 24
X3 10 13 20 25
X4 14 16 17 20
P
B+
X3 1 3
12v
X2 19 15
X7 21 24 13
860 WH/VT
6009 BK/GY
1714 YE/L-BU
1715 GY
94 WH/BK
2268 BN/GY
91 GY
196 BN/L-GN
440 RD/BN
3277 L-GN/GY
3276 GY/BK
780 BN/YE
781 BN/WH
244 YE/VT
245 BN/VT
5905 WH/VT
Wiper/Washer Schematics
Starting and Charging Schematics
Immobilizer Schematics
Door Lock/ Indicator Schematics
Ignition Lock Schematics

Description and Operation

Body Control System Description and Operation

The body control system consists of the body control module (BCM), communications, and various input and outputs. Some inputs, outputs and messages require other modules to interact with the BCM. The BCM also has discrete input and output terminals to control the vehicle's body functions. The BCM is wired to the high speed GMLAN serial data bus, low speed GMLAN serial data bus and Multiple LIN buses and acts as a gateway between them.

Power Mode Master

This vehicle body control module (BCM) functions as the power mode master (PMM). The ignition switch is a low current switch with multiple discrete ignition switch signals to the PMM for determining the power mode that will be sent over the serial data circuits to the other modules that need this information; the PMM will activate relays and other direct outputs of the PMM as needed. Refer to Power Mode Description and Operation for a complete description of power mode functions.

Gateway

The body control module (BCM) in this vehicle functions as a gateway or translator. The purpose of the gateway is to translate serial data messages between the GMLAN high speed bus and the GMLAN low speed bus for communication between the various modules. The gateway will interact with each network according to that network's transmission protocol.

All communication between the BCM and a scan tool is on the high speed GMLAN serial data circuits. A lost communication DTC typically is set in modules other than the module with a communication failure.

Body Control

The various body control module (BCM) input and output circuits are illustrated in the corresponding functional areas on the BCM electrical schematics. Refer to the Body Control System Schematics for more detailed information.

Data Link Communications Description and Operation

Note: This is an overview of different serial data buses used by GM devices to communicate with each others. Use Data Communication Schematics to find out which serial data buses are configured for a specific vehicle.

Circuit Description

There are many components in a vehicle that rely on information from other sources, transmit information to other sources, or both. Serial data communication networks provide a reliable, cost effective, way for various components of the vehicle to “talk” to one another and share information.

GM uses a number of different communication buses to insure the timely and efficient exchange of information between devices. When compared to each other, some of these buses are different in nature as far as speed, signal characteristics, and behavior. An example of this is the High Speed GMLAN and Low Speed GMLAN buses.

On the other hand, when other buses are compared to each other they have similar characteristics and simply operate in parallel. In this case they are used to group together components which have high interaction. Examples are the High Speed GMLAN, Powertrain Expansion, and Chassis Expansion buses. This allows them to communicate with each other on a bus with reduced message congestion insuring faster and the more timely exchange of information than if all vehicle devices were on a single bus.

The majority of information that exists within a given network generally stays local; however some information will have to be shared on other networks. Control modules designated as Gateway’s perform the function of transferring information between the various buses. A Gateway module is connected to at least 2 buses and will interact with each network according to its message strategy and transmission models.

GMLAN provides the capability for a receiving device to monitor message transmissions from other devices in order to determine if messages of interest are not being received. The primary purpose is to allow reasonable default values to be substituted for the information no longer being received. Additionally, a device may set a Diagnostic Trouble Code to indicate that the device it is expecting information from is no longer communicating.

High Speed GMLAN Circuit Description

A High Speed GMLAN Bus is used where data needs to be exchanged at a high enough rate to minimize the delay between the occurrence of a change in sensor value and the reception of this information by a control device using the information to adjust vehicle system performance.

The High Speed GMLAN serial data network consists of two twisted wires. One signal circuit is identified as GMLAN-High and the other signal circuit is identified as GMLAN-Low. At each end of the data bus there is a 120 Ω termination resistor between the GMLAN-High and GMLAN-Low circuits.

Data symbols (1’s and 0’s) are transmitted sequentially at a rate of 500 Kbit/s. The data to be transmitted over the bus is represented by the voltage difference between the GMLAN-High signal voltage and the GMLAN-Low signal voltage.

When the two wire bus is at rest the GMLAN-High and GMLAN-Low signal circuits are not being driven and this represents a logic “1”. In this state both signal circuits are at the same voltage of 2.5 V. The differential voltage is approximately 0 V.

When a logic “0” is to be transmitted, the GMLAN-High signal circuit is driven higher to about 3.5 V and the GMLAN-Low circuit is driven lower to about 1.5 V. The differential voltage becomes approximately 2.0 (+/- 0.5) V.

Chassis High Speed GMLAN Circuit Description

The GMLAN Chassis Expansion Bus is basically a copy of the High Speed GMLAN Bus except that its use is reserved for chassis components. This implementation splits message congestion between two parallel buses helping to insure timely message transmission and reception. Sometimes communication is required between the Chassis Expansion Bus and the primary High Speed GMLAN Bus. This is accomplished by using the K17 Electronic Brake Control Module (EBCM) as the Gateway module. Since the High Speed GMLAN Chassis Expansion Bus and primary High Speed GMLAN Bus operate in the same manner, the diagnostics for each are similar.

Powertrain High Speed GMLAN Circuit Description

The GMLAN Powertrain Expansion Bus is basically a copy of the High Speed GMLAN Bus except that its use is reserved for Powertrain components. The bus is optional based upon feature content. Sometimes communication is required between the Powertrain Expansion Bus and the primary High Speed GMLAN Bus. This is accomplished by using the K20 Engine Control Module (ECM) as the Gateway module. Since the High Speed GMLAN Powertrain Expansion Bus and the primary High Speed GMLAN Bus operate in the same manner, the diagnostics for each are similar.

Media Oriented Systems Transport (MOST) Circuit Description

The MOST Infotainment network is a dedicated high speed multimedia streaming data bus independent from GMLAN. The MOST bus will be configured in a physical hardwired loop with each device within the bus sends and receives data on an assigned MOST addresses in a set order. Each device on the MOST bus will be required to have twisted pair copper wires (2 transmit TX, 2 receive RX, and 1 electronic control line which is a 12 V wakeup signal line). The A11 Radio is the MOST Master and will monitor the bus for vehicle configuration, Infotainment data messages and errors on the bus. The MOST initialization consists of a short 100 ms low voltage pulse on the electronic control line (or MOST control line) connected to all devices contained on the MOST ring. This wakeup message once received by each device, will first respond with a generic device response. Once these initial responses on the MOST bus are reported successfully without error to the A11 Radio, the second data request will record the MOST device addresses, their functionality requirements and capabilities within. The A11 Radio will learn this information and also record the address node sequence on the MOST bus at this point. This node address list will now be stored within the A11 Radio as the MOST bus configuration (called “Last Working MOST ID of Node 1 – 9” on scan tool data display).

When MOST receive, transmit, or control line faults are detected, transmit/receive messages will not received as expected from the wakeup request. The A11 Radio and the K74 Human Machine Interface Control Module will then perform diagnostics to isolate these MOST faults. If the MOST control line is shorted low to 0 V for excess amount of time, the A11 Radio will set a U2098 DTC and K74 Human Machine Interface Control Module will set a U0029 02 DTC. At this point the MOST bus will be unable to communicate until the shorted MOST control line is repaired.

Once the shorted MOST control line diagnostics pass, the A11 Radio will attempt to resend the initial short pulse attempts up to 3 times on the MOST control line. If the expected responses are not received, the A11 Radio continues into a failure mode setting a U0028 DTC and will continue on to send one 300 ms long pulse, which will enable the furthest upstream transmitting device to become the surrogate MOST Master in this MOST fault/diagnostic mode. When the A11 Radio receives this new MOST Master identity, the surrogate MOST master device can be identified based on scan tool data parameter “Surrogate MOST Master Node Upstream Position”. The scan tool should be used to determine the MOST bus configuration and direction by utilizing the “Last Working MOST ID of Node 1 – 9” parameters from the A11 Radio data display. When a fault is present, it will indicate the newly enabled “Surrogate MOST Master Node Upstream Position” from the A11 Radio. This will assist in determining where the MOST bus/control is at fault. The MOST device upstream from the surrogate MOST master device, transmit, receive, or control lines will be the suspect areas for diagnostics at this point. These faults can be associated with any of the MOST transmit, receive, or control line twisted copper wires or possibly an internal device fault.

The K74 Human Machine Interface Control Module will set a U0029 00 DTC when it diagnoses a MOST bus not communicating properly after one attempt. When the DTC U0029 00 is set by the K74 Human Machine Interface Control Module without the corresponding DTC U0028 from the A11 Radio, it will be an indication of an intermittent wiring/device condition.

Low Speed GMLAN Circuit Description

Low Speed GMLAN Bus is used in applications where a high data rate is not required which allows for the use of less complex components. It is typically used for operator controlled functions where the response time requirements are slower than those required for dynamic vehicle control.

The Low Speed GMLAN Serial Data Network consists of a single wire, ground referenced bus with high side voltage drive. During on road vehicle operation data symbols (1’s and 0’s) are transmitted sequentially at the normal rate of 33.3 Kbit/s. For component programming only, a special high speed data mode of 83.3 Kbit/s may be used.

Unlike the high speed dual wire networks, the single wire low speed network does not use terminating resistors at either end of the network.

The data symbols to be transmitted over the bus are represented by different voltage signals on the bus. When the Low Speed GMLAN Bus is at rest and is not being driven, there is a low signal voltage of approximately 0.2 V. This represents a logic “1”. When a logic “0” is to be transmitted, the signal voltage is driven higher to around 4.0 V or higher.

Local Interconnect Network (LIN) Circuit Description

The Local Interconnect Network (LIN) Bus consists of a single wire with a transmission rate of 10.417 Kbit/s. This bus is used to exchange information between a master control module and other smart devices which provide supporting functionality. This type of configuration does not require the capacity or speed of either a High Speed GMLAN Bus or Low Speed GMLAN Bus and is thus relatively simpler.

The data symbols (1’s and 0’s) to be transmitted are represented by different voltage levels on the communication bus. When the LIN Bus is at rest and is not being driven, the signal is in a high voltage state of approximately Vbatt. This represents a logic “1”. When a logic “0” is to be transmitted, the signal voltage is driven low to about ground (0.0 V).

Communication Enable Circuit Description

Devices on High Speed GMLAN Bus enable or disable communication based on the voltage level of the communication enable circuit. When the circuit voltage is high (around 12 V), communications are enabled. When the circuit is low, communications are disabled.

Data Link Connector (DLC)

The X84 Data Link Connector (DLC) is a standardized 16-cavity connector. Connector design and location is dictated by an industry wide standard, and is required to provide the following:

- Terminal 1 Low speed GMLAN communications terminal
- Terminal 4 Scan tool power ground terminal
- Terminal 5 Common signal ground terminal
- Terminal 6 High speed GMLAN serial data bus (+) terminal
- Terminal 12 Chassis high speed GMLAN serial bus (+) terminal
- Terminal 13 Chassis high speed GMLAN serial bus (-) terminal
- Terminal 14 High speed GMLAN serial data bus (-) terminal
- Terminal 16 Scan tool power, battery positive voltage terminal

Serial Data Reference

The scan tool communicates over the various buses on the vehicle. When a scan tool is installed on a vehicle, the scan tool will try to communicate with every device that could be optioned into the vehicle. If an option is not installed on the vehicle, the scan tool will display No Comm (or Not Connected) for that optional device. In order to avert misdiagnoses of No Communication with a specific device, refer to CELL Link Error - Link target cell (cell ID 148085) is invalid for this publication. for a list of devices and the buses they communicate with. Use schematics and specific vehicle build RPO codes to determine optional devices.

Serial Data Gateway Module Description and Operation

The K56 Serial Data Gateway Module is used to handle communications between multiple GMLAN busses and functions as a gateway to isolate the secure networks from the unsecured networks. It was created to mitigate bus loading to support cyber security and new active/advanced safety features like Limited Ability Autonomous Driving and Enhanced Collision Avoidance (if equipped). The K56 Serial Data Gateway Module is used as a frame-to-frame gateway for all functional messages.

Depending on the vehicle contents, the K56 Serial Data Gateway Module is gating between primary High Speed GMLAN Bus, Gateway Expansion High Speed GMLAN Bus, Gateway Isolated High Speed GMLAN Bus, and Chassis High Speed GMLAN Bus. The K56 Serial Data Gateway Module is also gating between primary Low Speed GMLAN Bus and Gateway Isolated Low Speed GMLAN Bus.

Communication between the K56 Serial Data Gateway Module and a scan tool is done through the primary High Speed GMLAN Bus.

Power and Signal Distribution

Power Outlets

Schematic and Routing Diagrams

Cigar Lighter/Power Outlet Schematics

12-Volt DC Power Outlets


X51A
Fuse
Block -
Instrument
Panel
Power Distribution
Schematics
F41DA
15A
Power Distribution
Schematics
F39DA
15A
X2
20
10
1701
VT
2101
VT
X203
37
1701
VT
X305
1
14 (N8D)
1701
VT
2101
VT
SAO
-SAO
A
E32
Cigarette
Lighter
Receptacle
C
A
X80A
Accessory
Power
Receptacle -
Center
Console 1
C
A
X80B
Accessory
Power
Receptacle -
Center
Console 2
C
2050
BK
2050
BK
G300

Wireless Charging (K4C)

LOC
DESC


X51L
Fuse Block
- Instrument
Panel Left
KR76A
Retained Accessory
Power Relay 1
F35DA
10A
11
X202
5
4601
VT
X306
4
K9
Body
Control
Module
X1
5
J220
6816
WH
X306
5
X1
1
P46
Mobile Device
Wireless
Charger
Indicators
X1
2
X1
3
4512
GN
4511
BN
X1
1
X1
3
X1
4
IGN
T22
Mobile Device
Wireless
Charger
Module
X1
2
2050
BK
X306
3
G300

Description and Operation

Power Outlets Description and Operation

Power Outlet Receptacle Description and Operation

The vehicle is fitted with 12 V accessory power receptacles. The accessory power receptacles are controlled by an ignition operated relay. The accessory power receptacles are operational when the ignition is turned to either the On or the Accessories positions. The accessory power receptacles may be configured to be operational when the ignition is Off by changing the position of the 50A fuse from the F44DA position to the F40DA position in the instrument panel fuse block.

Power and Signal Distribution

Wiring Systems and Power Management

Schematic and Routing Diagrams

Harness Routing Views

Forward Lamp Harness Routing - Left Engine Compartment


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1
2
3
4
5
6
7

Items

1. J117
2. X102
3. X110
4. X104 (LCV)
5. J118
6. J119
7. X105

Forward Lamp Harness Routing - Left Engine Compartment (LWN)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1
2
3
4
5
6

Items

1. J117
2. J118
3. X102
4. X110
5. J119
6. X109 (LWN)

Forward Lamp Harness Routing - Right Engine Compartment


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1
2

Items

1. J120
2. X120

Body Harness Routing - Left Engine Compartment (LCV/LGZ)



1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
1
2
3
4
5
6
7
8

Items

1.	J103
2.	J102
3.	X106
4.	J123
5.	J101
6.	X101
7.	X102
8.	J100

Body Harness Routing - Left Engine Compartment (LWN)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
1
2
3
4
5
6
7
8

Items

1. J103
2. J102
3. X106
4. J123
5. X101
6. J101
7. X102
8. J100

Body Harness Routing - Center Engine Compartment


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1
2

Items

1. X100
2. X103

Engine Harness Routing - Left Front (LCV)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1
2
3
4
5
6
7

Items

1. J111
2. J109
3. J107
4. J110
5. J108 (LCV)
6. X101
7. J106

Engine Harness Routing - Right Front Top (LCV)



1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1
2
3
4

Items

1. X160
2. J112 (LCV)
3. J113
4. J114

Engine Harness Routing - Front (LGZ)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1
2
3
4
5
6
7
8
9
10

Items

1. J114
2. J110
3. J109
4. J111
5. J116 (LGZ)
6. J113
7. J107
8. J106
9. X101
10. J115 (LGZ)

Engine Harness Routing - Rear (LGZ)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
1
2
3
4

Items

1. X160
2. X161 (LGZ)
3. J128
4. J129

Engine Harness Routing - Top (LWN)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1
2

Items

1. X111 (LWN)
2. X112 (LWN)

Engine Harness Routing - Left Front (LWN)



1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1
2
3
4
5
6
7
8
9
10

Items

1. X109 (LWN)
2. J120
3. J127 (LWN)
4. J126 (LWN)
5. J125 (LWN)
6. J106
7. J110
8. X108 (LWN)
9. J133 (LWN)
10. J132 (LWN)

Engine Harness Routing - Right Rear (LCV)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1
2

Items

1. J128
2. J129

Engine Harness Routing - Right Rear (LWN)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1
2
3
4

Items

1. J111
2. X107 (LWN)
3. J131 (LWN)
4. J109

Instrument Panel Harness Routing - Rear


1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17
A B C D E F G H I J K L
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34

Items

1. J231
2. X207
3. J229 (UQ3)
4. J230 (UQ3)
5. J253 (LWN)
6. J237 (IO3/IO4+N8D)
7. X206 (C68)
8. J221
9. J219 (UQ3)
10. J218 (UQ3)
11. J220
12. JX200
13. J239
14. J217 (KA1)
15. X299 (EARLY_PRODUCTION)

16. J214
17. J215
18. J216
19. X200
20. X202
21. J203
22. X305
23. J223
24. J222 (IO5/IO6)
25. J238 (IO3/IO4+N8D)
26. J228
27. J225
28. J227
29. J226 (IO4/IO5/IO6)
30. J224
31. X203
32. X220 (IO6)
33. X219 (Except U2M)
34. X218 (U2M)

Center Console Harness Routing


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
1
2
3
4
5

Items

1. X302
2. X306 (MYB)
3. X305
4. J304 (IO3 with N8D)
5. J305

Body Harness Routing - Left Front of Passenger Compartment (Extended Cab)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16

Items

1. J302 (Extended Cab)
2. X500
3. J204
4. J202
5. J205
6. J201
7. JX200
8. J235
9. J200
10. J208
11. J207

12. J206

13. X202

14. X200

15. J209

16. X310

Body Harness Routing - Left Rear of Passenger Compartment (Extended Cab)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1
2
3

Items

1. X301

2. X303

3. X700

Body Harness Routing - Right Front of Passenger Compartment (Extended Cab)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
1
2
3
4
5
8
7
6

Items

1. X300
2. X218 (U2M)
3. X600
4. X203
5. X320
6. J301
7. X219 (Except U2M)
8. X220 (IO6)

Body Harness Routing - Right Rear of Passenger Compartment (Extended Cab)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1

Items

1. X800

Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

Items

1. X200
2. X500
3. J207
4. J204
5. J208
6. JX201
7. J202
8. J205
9. J201
10. J235
11. J200

11. J20

12. J206

13. X202

14. J212 (Crew Cab)

15. J211 (Crew Cab)

16. J210 (Crew Cab)

17. J209

18. X310

Body Harness Routing - Left Rear of Passenger Compartment (Crew Cab)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1
2
3

Items

1. X301

2. X303

3. X700

Body Harness Routing - Right Front of Passenger Compartment (Crew Cab)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
1
2
3
4
5
6
7
8
9
10
11

Items

1. X300
2. X218 (U2M)
3. X600
4. X203
5. X220 (IO6)
6. J213 (Crew Cab)
7. X800
8. X320
9. J301
10. J300 (Crew Cab)
11. X219 (Except U2M)

11. X21[illegible] (Except U2M)

Driver Seat Harness Routing


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
1
5
3
4
2

Items

1. J309 (AL9)
2. X311
3. X310
4. X311
5. J311 (AH6/AL9/KA1)

Passenger Seat Harness Routing


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
1
2
3
4
5

Items

1. X320
2. J310 (AT9)
3. J313
4. J312 (AAQ/AT9/KA1)
5. X321

Driver Door Harness Routing


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
1
2
3
4
5
6
7

Items

1. X510
2. X500
3. J504
4. J505
5. J503
6. J501
7. J502

Passenger Door Harness Routing


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
2
1
3

Items

1. X600
2. X610
3. J600

Left Rear Door Harness Routing (Crew Cab)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
1
2

Items

1. X700

2. J701

Right Rear Door Harness Routing (Crew Cab)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
1
2

Items

1. X800
2. J801

Left Rear Door Harness Routing (Exended Cab)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
1
3
2

Items

1. X700
2. J701
3. J700 (Extended Cab)

Right Rear Door Harness Routing (Extended Cab)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
1
2
3

Items

1. X800
2. J800 (Extended Cab)
3. J801

Headliner Harness Routing (Crew Cab)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1
2
3
4
5
6

Items

1. J307
2. J306
3. J308
4. X301
5. X304 (C68)
6. X300

Headliner Harness Routing (Extended Cab)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1
2
3
4
5
6

Items

1. J307
2. J306
3. J308
4. X301
5. X304 (C68)
6. X300

Chassis Harness Routing (Crew Cab)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
5
4
6
3
2
1
7
12
8
11
9
10

Items

1. J403 (LGZ)
2. J404
3. J405 (LCV/LGZ)
4. J105
5. X106
6. J104
7. X103
8. J401 (LCV/LGZ)
9. J400
10. J402
11. X420
12. X400
13. X410

Chassis Harness Routing (Extended Cab)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
4
5
6
3
1
2
7
8
9
10
11

Items

1. J403 (LGZ)
2. J404
3. J405 (LCV/LGZ)
4. J104
5. X106
6. J105
7. X103
8. J401 (LCV/LGZ)
9. J402
10. X420
11. J400
12. X410

Chassis Harness Routing (LWN)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25

Items

1. J418 (LWN)
2. J419 (LWN)
3. X420
4. J400
5. X400
6. J412
7. X401 (S0Y)
8. X410
9. J411
10. J415 (LWN)
11. J424 (LWN)
12. J404
13. J402
14. J105
15. X106

16. J104
17. X103
18. X107 (LWN)
19. J410 (LWN)
20. J423 (LWN)
21. J420 (LWN)
22. J421 (LWN)
23. J416 (LWN)
24. J422 (LWN)
25. J417 (LWN)

Chassis Harness Routing (S0Y)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1

Items

1. X401 (S0Y)

Rear License Plate Harness Routing


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
L
1
2
3
4
5

Items

1. J409
2. J408
3. J407
4. X400
5. J406

Vehicle Zoning Strategy

All grounds, in-line connectors, and splices have identifying numbers that correspond to where they are located in the vehicle. The following table explains the numbering system.



Vehicle Zoning Strategy

Callout Numbers	Zone Description
100-199	Engine compartment (all forward of the instrument panel)
200-299	Within the instrument panel area (between the bulkhead and the front plane of the instrument panel)
300-399	Passenger compartment (from the instrument panel to the rear of the cab)
400-499	Truck bed/chassis (from the rear of the cab to the rear of the vehicle)
500-599	Inline harness connectors to or within the driver door
600-699	Inline harness connectors to or within the front passenger door
700-799	Inline harness connectors to or within the left rear door
800-899	Inline harness connectors to or within the right rear door
900-999	Inline harness connectors to or within the endgate

B+ Bus X50D Fuse Block - Battery


L O C
1
RD
X7 1
+
C1
Battery
−
X50D
Fuse
Block -
Battery
F1UB
100A
F2UB
100A
F3UB
100A
F4UB
100A
F5UB
250A
F6UB
300A
X1 1
X2 1
X3 A
X4 A
X5 1
X6 1
842
RD/VT
42
RD/BU
842
RD/VT
4840
RD/GY
4042
RD/WH
2
RD/YE
X100 1
842
RD/VT
LFX
LWN
X1 2
X2 2
X1 23
21
X2 2
X4 A
X2 A
K43
Power
Steering
Control
Module
X51A
Fuse
Block -
Instrument
Panel
K22
Cooling
Fan
Control
Module
E40
Electrical
Auxiliary
Heater
X50A
Fuse Block -
Underhood
M64
Starter
Motor

B+ Bus X50A Fuse Block - Underhood (1 of 2)


LOC
X50A
Fuse Block -
Underhood
B+
F1UA 15A
F2UA 15A
F21UA 40A
F22UA 30A
F24UA 30A
F25UA 30A
F26UA 60A
F27UA 30A
F30UA 15A
F32UA 15A
F33UA 20A
F34UA 30A
LWN
F41UA 60A
F43UA 60A
F62UA 10A
F67UA 15A
F69UA 5A
F74UA 200A
30
KR73 Ignition Main Relay
87
LWN
F20UA 20A
87
KR23A Fuel Pump Relay
LCV/LFX
F5UA 10A
F13UA 15A
F17UA 10A
F19UA 10A
F12UA 30A
30
KR27 Starter Relay
F7UA 15A
30
KR112 Cargo Lamp Relay
F64UA 10A
KR61 Trailer Backup Lamps Relay
F36UA 10A
30
KR41 Center High Mounted Stop Lamp Relay
F3UA 10A
30
KR29 A/C Compressor Clutch Relay
LWN
F44UA 40A
30
KR22 Fuel Heater Relay
LWN
F45UA 30A
87
LWN
86
KR121A Reductant Control Module Relay 1
LWN
85
LWN
30
KR121B Reductant Control Module Relay 2
87
F4UA 15A
F40UA 5A

B+ Bus X50A Fuse Block - Underhood (2 of 2)


B+
X50A
Fuse Block -
Underhood
KR11
Windshield
Washer
Pump Relay
F56UA
15A
F6UA
30A
87
KR12B
Windshield
Wiper
Relay
85
KR12C
Windshield Wiper
Speed Control Relay
KR46
Front Fog
Lamp
Relay
F48UA
15A
KR48
Headlamp
High Beam
Relay
F37UA
10A
F38UA
10A
30
86
KR125
Trailer Park
Lamps
Relay
87A
87
F50UA
20A
30
KR5
Rear
Defogger
Relay
87
F28UA
40A
F60UA
7.5A
KR3
Horn
Relay
F51UA
15A
85
30
KR75
Engine Controls
Ignition Relay
87
KR63L
Trailer
Stop/Turn
Signal
Lamp
Relay -
Left
F66UA
10A
LFX
F45UA
30A
87
KR14
Brake
Booster
Pump
Motor
Relay
LWN
F46UA
10A
87
KR20F
Cooling Fan Relay
A90
Logic
B+
F8UA
15A
F9UA
15A (LCV/LFX)
7.5A (LWN)
F10UA
20A
F11UA
10A
F47UA
10A (LCV/LFX)
7.5A (LWN)
F65UA
10A
KR63R
Trailer
Stop/Turn
Signal
Lamp
Relay -
Right

F1UA, F2UA, F21UA, F22UA, F24UA, F25UA, F26UA, F27UA, F30UA, and F32UA Fuses


B+
X50A Fuse Block - Underhood
B+ Bus
F1UA 15A
F2UA 15A
F21UA 40A
F22UA 30A
F26UA 60A
F24UA 30A
F27UA 30A
F25UA 30A
F30UA 15A
F32UA 15A
X3 37
27
X2 33
34
41
36
42
40
56
68
MYB
NQ6/NQ7
NQ6
KA1
KA1
1840 RD/GN
140 RD/WH
542 RD/VT
442 RD/YE
1042 RD/GY
742 OG
242 RD/L-GN
1342 RD/GY
1342 RD/GY
5140 RD/L-GN
6140 RD/L-GN
Z82-JL1
JL1
X200 1
X106 2
1
38
X200 37
X106 29
X101 39
X320 3
9
742 OG
Z82
-Z82
542 RD/VT
442 RD/YE
1042 RD/GY
242 RD/L-GN
242 RD/L-GN
1342 RD/GY
5140 RD/L-GN
6140 RD/L-GN
X1 4
Q8 Control Solenoid Valve Assembly
X1 4 (LWN)
X1 15 (LCV)
X1 52 (LFX)
X1 3
25
1
E
1
X3 C
B
X2 3
2
T12 Automatic Transmission Assembly
K20 Engine Control Module
K8 Blower Motor Control Module
K17 Electronic Brake Control Module
X88 Trailer Connector
W8 Blunt Cut - Trailer Provision
W24 Blunt Cut - Trailer Brakes Provision
K133 Trailer Brake Power Control Module
K69 Transfer Case Control Module
A16 Transfer Case Motor
K29 Seat Heating Control Module

F3UA, F33UA, F34UA, F43UA, F62UA, F67UA, F69UA, and F74UA Fuses


B+
B+ Bus
X50A Fuse Block - Underhood
F34UA 30A
F43UA 60A
F3UA 10A
30
KR29 A/C Compressor Clutch Relay
87
F62UA 10A
F67UA 15A
F69UA 5A
F33UA 20A
F74UA 200A
X2 70
X1 35
X2 21
X2 10
(NOT USED)
X3 50
X2 73
74
72
69
X5 A
LCV
1940 RD/VT
4840 RD/GY
59 BN/L-GN
2440 RD/L-GN
5940 RD/BN
440 RD/BN
2340 RD/YE
2 RD/YE
X106 20
X106
24 (LWN)
33 (LCV/LFX)
21
X202 25
1940 RD/VT
2440 RD/L-GN
5940 RD/BN
X103 7
5940 RD/BN
2340 RD/YE
2
2
LFX/LWN
LCV
LWN
LCV/LFX
1
1
X1 1
2
X1 1
X4 20
X1 3
X2 A
K38 Chassis Control Module
K111 Fuel Pump Driver Control Module
K22 Cooling Fan Control Module
Q2 A/C Compressor Clutch
K115 Reductant Control Module
Q13 Evaporative Emission Vent Solenoid Valve
K43 Power Steering Control Module
K9 Body Control Module
G13 Generator

F4UA, F40UA, F41UA, and F45UA Fuses (LWN)


B+
X50A
Fuse Block -
Underhood
F45UA
30A
85
30
KR121B
Reductant
Control
Module
Relay 2
87
87
86
KR121A
Reductant
Control
Module
Relay 1
F41UA
60A
30
F40UA
5A
F4UA
15A
X1
38
50
X3
33
35
104
BN/L-BU
3921
L-BU
4320
VT/L-GN
3674
VT/L-BU
J130
3674
VT/L-BU
X109
1
2
J131
3921
L-BU
3674
VT/L-BU
3674
VT/L-BU
J132
J133
3674
VT/L-BU
3674
VT/L-BU
J424
X107
13
7
1
3674
VT/L-BU
3674
VT/L-BU
J423
J410
104
BN/L-BU
3921
L-BU
4320
VT/L-GN
3674
VT/L-BU
3674
VT/L-BU
J420
3674
VT/L-BU
3674
VT/L-BU
J419
J421
J422
3674
VT/L-BU
3674
VT/L-BU
3674
VT/L-BU
X1
5
X1
8
5
6
1
1
K20
Engine
Control
Module
K115
Reductant
Control
Module
B136
Exhaust
Particulate
Matter
Sensor
B195A
Nitrogen
Oxides
Sensor 1
B195B
Nitrogen
Oxides
Sensor 2

F5UA, F12UA, F13UA, F17UA, F19UA, and F20UA Fuses


B+
B+ Bus
30
KR73 Ignition Main Relay
87
X50A Fuse Block - Underhood
F20UA 20A
F12UA 30A
F5UA 10A
F13UA 15A
F17UA 10A
F19UA 10A
87
KR23A Fuel Pump Relay
30
30
KR27 Starter Relay
87
X3 20
4
X2 14
X1 69
X2 6
X3 5
MYB
NQ6/NQ7
LWN
139 VT/GY
2139 VT/BK
2139 VT/BK
4333 WH/VT
120 GY
6 YE
J110
139 VT/GY
139 VT/GY
X106 10
X105 2
X106 48
X101 3
139 VT/GY
2139 VT/BK
4333 WH/VT
X106 16
X103 1
139 VT/GY
2139 VT/BK
120 GY
LFX/LWN
LCV
X1 22 (LWN)
X1 51 (LCV/LFX)
25 (LWN)
21 (LFX)
21
X1 12
1
1
3
X1 1
Q8 Control Solenoid Valve Assembly
T12 Automatic Transmission Assembly
K20 Engine Control Module
K38 Chassis Control Module
K111 Fuel Pump Driver Control Module
M26 Front Axle Engagement Actuator
M96 Active Grille Air Shutter Actuator
A7 Fuel Pump and Level Sensor Assembly
M64 Starter Motor
L O C

F7UA, F28UA, F36UA, F45UA, and F60UA Fuses



B+
B+ Bus
X50A Fuse Block - Underhood
LOC
30
KR5 Rear Defogger Relay
87
F28UA 40A
F60UA 7.5A
F7UA 15A
30
KR112 Cargo Lamp Relay
87
F36UA 10A
30
KR41 Center High Mounted Stop Lamp Relay
87
LFX
F45UA 30A
87
KR14 Brake Booster Pump Motor Relay
30
X2 39
62
X1 9 (Not Used)
X1 37 (Not Used)
X1 80
75
50
X1 41 (Not Used)
X1 37 (Not Used)
LFX
293 BN/VT
2267 BN/YE
1430 WH/VT
1054 VT/GY
1470 BN/VT
X102 3
17
1
1430 WH/VT
J207
J123
2267 BN/YE
2267 BN/YE
1430 WH/VT
1430 WH/VT
1054 VT/GY
1470 BN/VT
X401 1
X303 1
2
X500 4
X600 4
X101 2
2267 BN/YE
2267 BN/YE
1430 WH/VT
-S0Y
S0Y
J413
1430 BN
1054 RD
1470 BN/VT
X510 4
X610 4
BK
BK
X1 A
X1 A
X1 A
E17D Outside Rearview Mirror Glass - Driver
E17P Outside Rearview Mirror Glass - Passenger
1430 WH/VT
1430 WH/VT
1430 WH/VT
A
E33L Cargo Lamp - Left
A
E33R Cargo Lamp - Right
A
1
E18 Rear Defogger Grid
A9A Outside Rearview Mirror - Driver
A9B Outside Rearview Mirror - Passenger
W26 Blunt Cut - Cargo Lamp Provision
E33L Cargo Lamp - Left
E33R Cargo Lamp - Right
E6 Center High Mounted Stop Lamp
M9 Brake Booster Pump Motor

F8UA, F9UA, F10UA, F11UA, and F47UA Fuses (LCV/LFX/Gasoline)


B+
B+ Bus
30
KR75 Engine Controls Ignition Relay
87
85
KR29 A/C Compressor Clutch Relay
X50A Fuse Block - Underhood
L O C
F11UA 10A
F10UA 20A
F47UA 10A
F8UA 15A
F9UA 15A
X3 7
X2 16 (Not Used)
X3 1
6
3
2
LCV
LFX
5292 VT/L-BU
J116
5294 VT/L-BU
5290 VT/L-BU
5290 VT/L-BU
5293 VT/L-BU
5292 VT/L-BU
5292 VT/L-BU
5292 VT/L-BU
5292 VT/L-BU
X1 73
16
D
D
D
X1 67
K20 Engine Control Module
T8B Ignition Coil 2
T8D Ignition Coil 4
T8F Ignition Coil 6
K20 Engine Control Module
5291 VT/L-BU
J111
J107
J113
LFX
LFX
LCV
LCV
LCV
LFX
LFX
LCV
LCV
LCV
LCV
LFX
5294 VT/L-BU
5294 VT/L-BU
5294 VT/L-BU
5294 VT/L-BU
5293 VT/L-BU
5293 VT/L-BU
5293 VT/L-BU
5293 VT/L-BU
5293 VT/L-BU
5293 VT/L-BU
5293 VT/L-BU
5291 VT/L-BU
5291 VT/L-BU
5291 VT/L-BU
5291 VT/L-BU
5291 VT/L-BU
5291 VT/L-BU
D
D
2
D
D
2
5
1
1
1
X3 16
4 (LCV) D (LFX)
4 (LCV) D (LFX)
4
4
D
X1 51 (LCV)
X1 62 (LFX)
B75C Multifunction Intake Air Sensor
B52D Heated Oxygen Sensor - Bank 1 Sensor 2
B52F Heated Oxygen Sensor - Bank 2 Sensor 2
B52B Heated Oxygen Sensor 2
E41 Engine Coolant Thermostat Heater
Q44 Engine Oil Pressure Control Solenoid Valve
Q12 Evaporative Emission Purge Solenoid Valve
B52E Heated Oxygen Sensor - Bank 2 Sensor 1
B52C Heated Oxygen Sensor - Bank 1 Sensor 1
K20 Engine Control Module
B52A Heated Oxygen Sensor 1
T8A Ignition Coil 1
T8C Ignition Coil 3
T8B Ignition Coil 2
T8D Ignition Coil 4
T8E Ignition Coil 5
K20 Engine Control Module

F8UA, F9UA, F10UA, F11UA, F46UA, and F47UA Fuses (LWN/Diesel)


B+
B+ Bus
30
KR75 Engine Controls Ignition Relay
87
85
KR29 A/C Compressor Clutch Relay
X50A Fuse Block - Underhood
F46UA 10A
87
KR20F Cooling Fan Relay
A90 Logic
B+
87A
F11UA 10A
F47UA 7.5A
F8UA 15A
F9UA 7.5A
F10UA 20A
X2 16 (Not Used)
X3
7
6
3
2
1
30
5294 VT/L-BU
5293 VT/L-BU
5292 VT/L-BU
5291 VT/L-BU
5290 VT/L-BU
2368 WH
J111
5294 VT/L-BU
B
5
2
X1
3
2
1
B75C Multifunction Intake Air Sensor
E45 Positive Crankcase Ventilation Heater
K20 Engine Control Module
K22 Cooling Fan Control Module

F37UA, F38UA, F48UA, F51UA, and F56UA Fuses



B+
B+ Bus
X50A Fuse Block - Underhood
KR11 Windshield Washer Pump Relay
KR46 Front Fog Lamp Relay
KR3 Horn Relay
KR48 Headlamp High Beam Relay
F56UA 15A
F48UA 15A
F51UA 15A
F38UA 10A
F37UA 10A
X1
30
31
11
14
13
T3U
228 GY/VT
2234 BN/VT
29 BN/GY
711 WH
311 WH
J118
2234 BN/VT
2234 BN/VT
1
1
1
2
X110
3
X120
3
BK A
BK A
G24 Windshield Washer Pump
E29LF Fog Lamp - Left Front
E29RF Fog Lamp - Right Front
P13 Horn Assembly
E4E Headlamp - Left High Beam
E4F Headlamp - Right High Beam
E13LA Headlamp Assembly - Left
E13RA Headlamp Assembly - Right

L O C

F50UA, F64UA, F65UA, and F66UA Fuses



B+
B+ Bus
X50A Fuse Block - Underhood
30
86
KR125 Trailer Park Lamps Relay
87A
87
F50UA 20A
KR63L Trailer Stop/Turn Signal Lamp Relay - Left
F65UA 10A
F66UA 10A
KR63R Trailer Stop/Turn Signal Lamp Relay - Right
F64UA 10A
KR61 Trailer Backup Lamps Relay
X1 70 (Not Used)
X1 8
X1 32 (Not Used)
X2 51
30
X1 10 (Not Used)
X2 52
X2 50 (Not Used)
2109 BN
1618 YE
1619 L-GN
1624 GY
X102 48
2109 BN
X106 39
5
4
3
2109 BN
1618 YE
1619 L-GN
1624 GY
J412 (8S3)
8S3
1624 GY
1624 GY
Audible Warnings Schematics
Z82
-Z82
-Z82
Z82
Z82
-Z82
-Z82
Z82
W8 Blunt Cut - Trailer Provision
W8 Blunt Cut - Trailer Provision
F
G
D
A
X88 Trailer Connector

X51A Fuse Block - Instrument Panel Bussing


B+
B+
X51A Fuse Block - Instrument Panel
F1DA 15
F4DA 5A
F5DA 15A
F8DA 5A
F9DA 10A
F11DA 30A
F14DA 20A
F15DA 20A
F17DA 20A
F20DA 10A
F25DA 20A
F13DA 10A
F18DA 10A
F23DA 10A
F32DA 2A
F42DA 30A
F43DA 30A
F45DA 30A
F46DA 30A
F40DA 50A
F44DA 50A
30
KR76 Retained Accessory Power Relay
87
F41DA 15A
F39DA 15A
F35DA 10A
30
KR73 Ignition Main Relay
87
F31DA 10A
F36DA 2A
F24DA 5A
F29DA 10A
F28DA 10A

F1DA, F5DA, F9DA, F11DA, F14DA, F15DA, F17DA, F20DA, F25DA, and F32DA Fuses


B+
B+ Bus
X51A Fuse Block - Instrument Panel
F1DA 15A
F5DA 15A
F11DA 30A
F17DA 20A
F15DA 20A
F25DA 20A
F20DA 30A
F14DA 20A
F9DA 10A
32DA 2A
X1 4
1
X2 7
18
X1 19
18
17
X2 35
X1 2
X2 3
4
UQA
6817 YE
6136 BN
Interior Lights Dimming Schematics
2140 RD/GY
2240 RD/BN
4040 RD/VT
2440 RD/L-GN
2640 RD/VT
2740 RD/WH
3740 RD/YE
340 RD/VT
2840 RD/GY
X202 4
7
X203 13
27
X203 1
35
X202 9
340 RD/VT
2840 RD/GY
2140 RD/GY
2240 RD/BN
4040 RD/VT
2440 RD/L-GN
3740 RD/YE
J223 (IO4/IO5/IO6)
IO4/IO5/IO6
340 RD/VT
340 RD/VT
J221
KA1
KA1
2840 RD/GY
2840 RD/GY
2840 RD/GY
2840 RD/GY
2840 RD/GY
X2 1
X1 4
X2 4
X1 2
X5 4
3
X1 4
X3 8
X1 7
7
X1 1
4
4
1
K9 Body Control Module
T3 Audio Amplifier
A11 Radio
K74 Human Machine Interface Control Module
P16 Instrument Cluster
P17 Info Display Module
S32D Seat Heating Switch - Driver
S32P Seat Heating Switch - Passenger
A26 HVAC Controls

F4DA, F8DA, F13DA, F16DA, F18DA, F23DA, and F32DA Fuses


B+
B+ Bus
X51A Fuse Block - Instrument Panel
F23DA 10A
F13DA 10A
F4DA 5A
F8DA 5A
F16DA 10A
F18DA 10A
X2 27
14
25
X1 14
3
16
8
5
X2 26 (Not Used)
UE1
W1Y+UDD
640 RD/WH
340 RD/VT
3340 RD/VT
3240 RD/L-BU
3040 RD/YE
1940 RD/VT
4440 RD/L-GN
X203 38
46
X202 6
X500 16
340 RD/VT
J222 (IO5/IO6)
IO5/IO6
340 RD/VT
340 RD/VT
3040 RD/YE
1940 RD/VT
6440 RD/WH
J301
4440 RD/L-GN
4440 RD/L-GN
IO3+N8D
IO3-N8D/ IO4/IO5/IO6
X2 10
X85 Steering Wheel Air Bag Coil
X1 1
X305 6
X305 6
3040 RD/YE
J232
J501
DL6/DL9
X200 10
X320 12
4440 RD/L-GN
4440 RD/L-GN
340 RD/VT
340 RD/VT
3340 RD/VT
3040 RD/YE
3040 RD/YE
1940 RD/VT
1940 RD/VT
16
X84 Data Link Connector
X1 6
X1 6
X2 1
X1 15
10
5
4
12
X1 1
1
X1 9
X83 Auxiliary Audio Input
X83R Auxiliary Audio Input - Rear
K33 HVAC Control Module
K73 Telematics Communication Interface Control Module
S70L Steering Wheel Controls Switch - Left
S70R Steering Wheel Controls Switch - Right
S79D Window Switch - Driver
S52 Outside Rearview Mirror Switch
K56 Serial Data Gateway Module
K85 Passenger Presence Module
K36 Inflatable Restraint Sensing and Diagnostic Module

L O C

F24DA, F28DA, F29DA, F42DA, F43DA, and F46DA Fuses


B+
B+ Bus
30
KR73 Ignition Main Relay
87
X51A Fuse Block - Instrument Panel
F24DA 5A
F29DA 10A
F28DA 10A
F43DA 30A
F46DA 30A
F42DA 30A
X2 37
38
X1 32
X3 13
14
X2 28
X1 27
36
25
539 VT/GY
1739 VT/L-GN
1739 VT/L-GN
1739 VT/L-GN
1139 VT/WH
1639 VT/BK
5040 RD/YE
1440 RD/BN
1240 RD/L-BU
X106 13
X203 47
X400 9
X301 10
19
X203 36
UEU
X310 1
X320 1
J213 (43)
J253 (LWN)
LWN
J309 (AL9)
J310 (AL9)
AL9
AL9
X500 1
X700 1
3
539 VT/GY
1739 VT/L-GN
1639 VT/BK
5040 RD/YE
1440 RD/BN
1240 RD/L-BU
X2 9
X1 2
X2 4
2
4
8
1
X1 D
X2 E
X1 D
X2 E
2
8
K33 HVAC Control Module
E40 Electrical Auxiliary Heater
B87 Rearview Camera
K69 Transfer Case Control Module
A10 Inside Rearview Mirror
P14 Passenger Air Bag Disabled Indicator
P16 Instrument Cluster
P43 Collision Alert Indicators
S64D Seat Adjuster Switch - Driver
S64P Seat Adjuster Switch - Passenger
M74D Window Motor - Driver
S79LR Window Switch - Left Rear

F31DA, F35DA, F36DA, F39DA, F40DA, F41DA, F44DA, and F45DA Fuses


B+
B+ Bus
X51A Fuse Block - Instrument Panel
F31DA 10A
F36DA 2A
F45DA 30A
F40DA 50A
F44DA 50A
30
KR76 Retained Accessory Power Relay
87
F41DA 15A
F39DA 15A
F35DA 10A
X3 12
X2 5
X1 35
X2 20
10
X1 44
X3 11 (Not Used)
UEU/UFL
1340 RD/WH
1701 VT
2101 VT
MYB
801 VT
3140 RD/L-GN
J300 (43)
X203 37
26
X202 8
540 RD/L-BU
1340 RD/WH
1340 RD/WH
1701 VT
2101 VT
801 VT
X305 1
14 (N8D)
X300 10
X203 11
X600 1
X800 1
X306 1
SAO
-SAO
3140 RD/L-GN
540 RD/L-BU
1340 RD/WH
1340 RD/WH
1701 VT
1701 VT
2101 VT
801 VT
3
2
4
8
A
A
A
1
K109 Frontview Camera Module
S39 Ignition Switch
S79P Window Switch - Passenger
S79RR Window Switch - Right Rear
E32 Cigarette Lighter Receptacle
X80A Accessory Power Receptacle - Center Console 1
X80B Accessory Power Receptacle - Center Console 2
P2 Transmission Shift Lever Position Indicator

Power Moding Schematics

Ignition Switch


B+
X51A
Fuse
Block -
Instrument
Panel
F36DA
2A
X2
5
540
RD/L-BU
X203
11
540
RD/L-BU
6
2
S39
Ignition
Switch
III
II
I
1.3K Ω
4
1073
WH/BK
1020
WH/VT
3
4
VT/YE
1
3
VT/BK
X3
22
15
5
6
5V
IGN
IGN
IGN
K9
Body
Control
Module
X4
22
15
5985
VT/YE
5199
L-GN/VT
J201
J204
NQ6/NQ7
5985
VT/YE
5985
VT/YE
5985
VT/YE
5199
L-GN/VT
5199
L-GN/VT
X106
9
X101
42
5985
VT/YE
5985
VT/YE
X1
42
86
X51A
Fuse
Block -
Instrument
Panel
KR73
Ignition
Main
Relay
LFX/LWN
LCV
J109
14 (LWN)
8 (LFX)
7
5985
VT/YE
5985
VT/YE
X2
6
IGN
IGN
IGN
MYB
X1
7 (LWN)
X1
70 (LFX)
X1
13 (LCV)
X2
17
X50A
Fuse Block -
Underhood
86
KR73
Ignition
Main
Relay
K69
Transfer Case Control
Module
K38
Chassis
Control
Module
K111
Fuel Pump
Driver
Control
Module
X1
9
IGN
Q8
Control
Solenoid
Valve
Assembly
T12
Automatic
Transmission
Assembly
IGN
K20
Engine
Control
Module

KR73 Ignition Main Relays and Accessory Power


K9 Body Control Module
F1DA
F15DA
X4 15
12
5199 L-GN/VT
755 GY/VT
J204
5199 L-GN/VT
5199 L-GN/VT
X2 17
B+
X50A Fuse Block - Underhood
86
30
KR73 Ignition Main Relay
85
87
LWN
F20UA 20A
87
KR23A Fuel Pump Relay
LCV/LFX
F5UA 10A
F13UA 15A
F17UA 10A
F19UA 10A
X1 71
B+
X1 42
43
B+
X51A Fuse Block - Instrument Panel
30
85
KR73 Ignition Main Relay
87
86
86
30
KR76 Retained Accessory Power Relay
85
87
F44DA 50A
F24DA 5A
F29DA 10A
F28DA 10A
F35DA 10A
F39DA 15A
F41DA 15A
X2 44
1150 BK
2050 BK
G103
G300
LOC
DESC

Key Capture, and Park Position Switch


F5DA
K9
Body
Control
Module
X3
7
X7
13
143
VT/YE
5905
WH/VT
X202
41
5905
WH/VT
X306
8
5905
WH/VT
6
S3
Transmission
Shift Lever
1
M93
Key Capture
Solenoid
Actuator
2
B81B
Park Position
Switch
2
2050
BK
2050
BK
G300

G100, G101, G102, and G105


K43 Power Steering Control Module
X2 1
K9 Body Control Module
X4 26
1650 BK
C1 Battery
+
−
E4K Park Lamp - Right Front
B
X88
E4AD Park/ Daytime Running Lamp - Right
Z88
E4AM Park/ Daytime Running Lamp - Right Lower
Z88
E4P Park/Turn Signal Lamp - Right
G
E4F Headlamp - Right High Beam
B
E4H Headlamp - Right Low Beam
2
E13RA Headlamp Assembly - Right
BK
BK
BK
BK
BK
J122
BK
X120 1
1050 BK
50 BK
250 BK
B55 Hood Ajar Switch
K22 Cooling Fan Control Module
E29RF Fog Lamp - Right Front
B
M96 Active Grille Air Shutter Actuator
X1 2 (LFX)
X1 4 (LCV)
1250 BK
X105 1
X100 2
C
1
1050 BK
1250 BK
1350 BK
1250 BK
1250 BK
1250 BK
UTJ
LCV/LFX
T3U
LCV/LFX
J120
1250 BK
150 BK
G100
G101
G102
G105


G24 Windshield Washer Pump
1
228 GY/VT
X1 30
X50A Fuse Block - Underhood
F56UA 15A
L O C
KR20F Cooling Fan Relay
KR61 Trailer Backup Lamps Relay
KR41 Center High Mounted Stop Lamp Relay
KR5 Rear Defogger Relay
KR73 Ignition Main Relay
KR113 Child Security Lock Disable Relay
KR11 Windshield Washer Pump Relay
KR12B Windshield Wiper Relay
86
LWN
86
85
85
85
85
X1 71
E13LA Headlamp Assembly - Left
E4J Park Lamp - Left Front
B
E4AC Park/ Daytime Running Lamp - Left
E4AL Park/ Daytime Running Lamp - Left Lower
E4N Park/Turn Signal Lamp - Left
G
E4E Headlamp - Left High Beam
B
E4G Headlamp - Left Low Beam
2
X88
Z88
Z88
BK
BK
BK
BK
BK
J121
BK
X110
1
E29LF Fog Lamp - Left Front
B
P13 Horn Assembly
G24 Windshield Washer Pump
1
1
1150 BK
1150 BK
1150 BK
1150 BK
1150 BK
T3U
J119
J117
1150 BK
1150 BK
G103

G107 (LCV/LFX) and G109 (LFX)


K20 Engine Control Module
Q8 Control Solenoid Valve Assembly
T12 Automatic Transmission Assembly
B75C Multifunction Intake Air Sensor
B35 Engine Oil Level Switch
B16 Backup Lamp Switch
T8B Ignition Coil 2
T8D Ignition Coil 4
T8F Ignition Coil 6
X2 73
X3 73
X1 5
7
1
B
A
A
A
1451 BK/WH
1451 BK/WH
1451 BK/WH
1451 BK/WH
1451 BK/WH
451 BK/WH
1550 BK
1550 BK
1550 BK
G108
Z
1450 BK
MYB
N8D
G107 (LCV/LFX)
G109 (LFX)

G107 (LWN)


M26 Front Axle Engagement Actuator
B75C Multifunction Intake Air Sensor
B35 Engine Oil Level Switch
K20 Engine Control Module
Q8 Control Solenoid Valve Assembly
T12 Automatic Transmission Assembly
G1 A/C Compressor
Q2 A/C Compressor Clutch
KR27 Starter Relay
KR23A Fuel Pump Relay
X50A Fuse Block - Underhood
Q85 Cooling Fan Clutch
4
1450 BK
X103 13
1450 BK
X106 11
1450 BK
X101 11
1450 BK
NQ6/NQ7
7
151 BK/WH
2
151 BK/WH
X1 6
451 BK/WH
X1 5
1451 BK/WH
1450 BK
1
1450 BK
86
85
X3 21
13
1450 BK
151 BK/WH
6
550 D-BU/BK
X108 6
550 BK
G107


LOC
M9
Brake
Booster
Pump
Motor
T8A
Ignition
Coil 1
T8B
Ignition
Coil 2
T8C
Ignition
Coil 3
T8D
Ignition
Coil 4
T8E
Ignition
Coil 5
G1
A/C
Compressor
Q2
A/C
Compressor
Clutch
M26
Front Axle
Engagement
Actuator
KR27
Starter
Relay
KR14
Brake
Booster
Pump
Motor
Relay
X50A
Fuse Block -
Underhood
86
85
X3
21
15
2
A (LFX)
1 (LCV)
1
A (LFX)
1 (LCV)
1
A
1450
BK
1
4
X103
13
X106
11
X101
11
NQ6/NQ7
LCV
LCV
LFX
J129
J128
G109
Z
LFX
LFX
G108


KR73 Ignition Main Relay
86
KR76 Retained Accessory Power Relay
85
X51A Fuse Block - Instrument Panel
X2 44
2050 BK
S70E Steering Wheel Controls Switch - Radio Presets
3
W1Y+UDD
S70F Steering Wheel Controls Switch - Radio Volume
3
W1Y+UDD
S70L Steering Wheel Controls Switch - Left
1
S70R Steering Wheel Controls Switch - Right
6
S33 Horn Switch
X2 1
2050 BK
J250
X84 Data Link Connector
4
P2 Transmission Shift Lever Position Indicator
3
S48A Multifunction Switch - Instrument Panel
14
S32D Seat Heating Switch - Driver
1
S32P Seat Heating Switch - Passenger
1
S77 Transfer Case Shift Control Switch
6
K33 HVAC Control Module
X2 8
E32 Cigarette Lighter Receptacle
C
SAO
X80A Accessory Power Receptacle - Center Console 1
C
-SAO
X80B Accessory Power Receptacle - Center Console 2
C
S3 Transmission Shift Lever
2
MYB
J305
M93 Key Capture Solenoid Actuator
2
W24 Blunt Cut - Trailer Brakes Provision
X1 9
X85 Steering Wheel Air Bag Coil
X2 2
K8 Blower Motor Control Module
1
X306 3
X305 1
8
MYB
KA1
KA1
NQ6/NQ7
MYB
Z82
J227
2050 BK
2250 BK
G300

G301



M75 Windshield Wiper Motor
3
3150 BK
2
95 YE/BN
X102 11
95 YE/BN
X1 73
X50A Fuse Block - Underhood
87A
KR12C Windshield Wiper Speed Control Relay
30
30
KR12B Windshield Wiper Relay
87A
KR112 Cargo Lamp Relay
85
X1 74
X2 43
X3 10 (Not Used)
3150 BK
X102 38
3150 BK
J103
3150 BK
3150 BK
A10 Inside Rearview Mirror
5
3150 BK
UE1/DD8
E37F Dome/Reading Lamps - Front
6
3150 BK
E37R Dome/Reading Lamps - Rear
6
3150 BK
P14 Passenger Air Bag Disabled Indicator
2
3150 BK
E31L Sunshade Mirror Lamp - Left
B
3150 BK
D6I
E31R Sunshade Mirror Lamp - Right
B
3150 BK
D6I
J308
2050 BK
X301 12
K9 Body Control Module
X6 3
K69 Transfer Case Control Module
X3 D
W7 Blunt Cut - Shield
1782 BK
J106
1782 BARE
X101 12
1782 BK
W7 Blunt Cut - Shield
1782 BARE
J101
NQ6/NQ7
NQ6/NQ7
E6 Center High Mounted Stop Lamp
E33L Cargo Lamp - Left
B
B
E33R Cargo Lamp - Right
B
3150 BK
X303 3
3150 BK
3150 BK
3150 BK
3250 BK
1782 BK
G301

G302 and G305



S64D Seat Adjuster Switch - Driver
K29 Seat Heating Control Module
S64P Seat Adjuster Switch - Passenger
A11 Radio
K74 Human Machine Interface Control Module
P17 Info Display Module
A26 HVAC Controls
X83 Auxiliary Audio Input
X83R Auxiliary Audio Input - Rear
F101 Passenger Instrument Panel Air Bag
T3 Audio Amplifier
L O C
X1 B
X2 H
X2 7
X1 B
X2 H
X3 16
X1 8
X3 16
10
X1 4
X1 4
X3 1
X1 8
3750 BK
3750 BK
3850 BK
3850 BK
3850 BK
2051 BK/WH
2051 BK/WH
2051 BK/WH
2051 BK/WH
2051 BK/WH
2051 BK/WH
2051 BK/WH
X305 2
2051 BK/WH
AL9
KA1
AAQ
AT9
IO4/IO5/IO6
IO5/IO6
J311
J312
J226
J228
-AL9
AL9
IO3
IO4/IO5/IO6
3750 BK
3850 BK
X310 16
X320 16
X207 5
3750 BK
3850 BK
2051 BK/WH
2051 BK/WH
2051 BK/WH
2251 BK/WH
UQA
G302
G305


E40 Electrical Auxiliary Heater
A9A Outside Rearview Mirror - Driver
E17D Outside Rearview Mirror Glass - Driver
A23D Door Latch Assembly - Driver
M74D Window Motor - Driver
S79D Window Switch - Driver
S52 Outside Rearview Mirror Switch
S13D Door Lock Switch - Driver
S79LR Window Switch - Left Rear
A23LR Door Latch Assembly - Left Rear
A23G Door Latch Assembly - Left Rear Lower
A23H Door Latch Assembly - Left Rear Upper
X2 1
X2 1
X510 5
3
2
1
11
5
3
5
3
1
1
3550 BK
1350 BK
3350 BK
J502
J505
J701
DL9
DL6/DL9 -ATG
ATG+ DL6/DL9
ATG- DL6/DL9
LWN
X700 11 (53) 2 (43)
X500 2
J302
G303
LOC

G304


K73
Telematics
Communication
Interface
Control Module
K109
Frontview
Camera
Module
A9B
Outside
Rearview
Mirror -
Passenger
E17P
Outside
Rearview
Mirror
Glass -
Passenger
A23P
Door Latch
Assembly -
Passenger
S13P
Door Lock
Switch -
Passenger
S79P
Window
Switch -
Passenger
S79RR
Window
Switch -
Right Rear
A23RR
Door Latch
Assembly -
Right Rear
A23J
Door Latch
Assembly -
Right Rear
Lower
A23K
Door Latch
Assembly -
Right Rear
Upper
X1 7
1
X2 1
X610 5
3
5
1
5
3
1
1
2051
BK/WH
3450
BK
3650
BK
3650
BK
3650
BK
3650
BK
3450
BK
3450
BK
3450
BK
3450
BK
UE1
UFL/UEU
DL9
J600
J801
3450
BK
3650
BK
3450
BK
X300 11
X600 2
X800
11 (53)
2 (43)
3450
BK
3650
BK
3450
BK
G304

G306 and G307


LOC
E18
Rear
Defogger
Grid
X2 A
3950
BK
C49
G306
K9
Body
Control
Module
X1 1 X2 2
2150
BK
2150
BK
J239
2150
BK
S30
Headlamp
Switch
8
P16
Instrument
Cluster
19
X84
Data Link
Connector
5
S78
Turn Signal/
Multifunction
Switch
3
P43
Collision Alert
Indicators
4
2151
BK/WH
J225
2151
BK/WH
K36
Inflatable
Restraint
Sensing
and
Diagnostic
Module
X1 19
2251
BK/WH
K85
Passenger
Presence
Module
4
B61P
Seat Belt
Tension
Sensor -
Passenger
2
2251
BK/WH
J313
X320 5
X200 42
AL0
G307

G400, G401, and G402


E42L
Tail Lamp
Assembly -
Left
E5AG
Tail/Stop
and Turn
Signal
Lamp - Left
Upper
E5A
Backup
Lamp -
Left
E5U
Tail/Stop
and Turn
Signal
Lamp - Left
Lower
G
B
G
BK
BK
BK
X410
4
E42R
Tail Lamp
Assembly -
Right
E5AH
Tail/Stop
and Turn
Signal Lamp
- Right
Upper
E5B
Backup
Lamp -
Right
E5V
Tail/Stop
and Turn
Signal Lamp
- Right
Lower
G
B
G
BK
BK
BK
X420
4
B87
Rearview
Camera
5
E7L
License
Plate
Lamp -
Left
E7R
License
Plate
Lamp -
Right
B
B
750
BK
750
BK
J407
751
BK/WH
750
BK
X400
8
2
J420
W26
Blunt Cut -
Cargo
Lamp
Provision
751
BK/WH
X401
2
751
BK/WH
750
BK
750
BK
750
BK
751
BK/WH
LWN
LWN
LCV/LFX
G401
K17
Electronic
Brake
Control
Module
13
B20
Brake
Fluid Level
Switch
1
X88
Trailer
Connector
B
W8
Blunt Cut -
Trailer
Provision
550
BK
551
BK/WH
22
WH
22
BK
Z82
-Z82
J404
550
BK
G400
K38
Chassis
Control
Module
25
K111
Fuel Pump
Driver
Control
Module
9 (LFX)
13 (LWN)
LCV
LFX/LWN
650
BK
850
BK
G402


A7 Fuel Pump and Level Sensor Assembly
B116 Water in Fuel Sensor
B136 Exhaust Particulate Matter Sensor
B195A Nitrogen Oxides Sensor 1
B195B Nitrogen Oxides Sensor 2
E11 Fuel Heater
K115 Reductant Control Module
4
2
1
6
6
3
4
1950 BK
650 BK
J418
J416
J417
J415
G404

Trailer Connector/Provision Schematics

Trailer Connector Pins: A,D,F, and G


B+
B+ Bus
X50A Fuse Block - Underhood
30
86
KR125 Trailer Park Lamps Relay
87A
87
85
F50UA 20A
KR63L Trailer Stop/Turn Signal Lamp Relay - Left
F65UA 10A
F66UA 10A
KR63R Trailer Stop/Turn Signal Lamp Relay - Right
TP24
F64UA 10A
KR61 Trailer Backup Lamps Relay
TP26
X1 70 (Not Used)
X1 8
X1 32 (Not Used)
X2 24
49
51
X2 59
30
X1 10 (Not Used)
X2 48
52
X1 71
X2 50 (Not Used)
2109 BN
45 L-BU
5186 L-BU/BN
1618 YE
1619 L-GN
1624 GY
X102 48
2109 BN
X106 39
5
4
3
2109 BN
1618 YE
1619 L-GN
1624 GY
J412
8S3
1624 GY
Audible Warnings Schematics
1624 GY
5187 YE/GY
38 L-BU/BN
X5 22
8
17
26
K9 Body Control Module
Z82
-Z82
-Z82
Z82
Z82
-Z82
-Z82
Z82
W8 Blunt Cut - Trailer Provision
W8 Blunt Cut - Trailer Provision
1150 BK
F
G
D
A
X88 Trailer Connector
G103
L O C
D E S C

Trailer Connector Pins: B,C, E, and Trailer Brakes Provisions


B+
B+ Bus
F24UA 30A
F27UA 30A
X50A Fuse Block - Underhood
X2 36
42
Trailer Brake Control Schematics
JL1
242 RD/L-GN
Z82-JL1
742 OG
47 L-BU
Audible Warnings Schematics
22 BK
J411 (8S3)
X106 38
48 (-JL1)
X202 14 (-JL1)
X200 37
K9 Body Control Module
12V
X7 16
X2 20
Z82-JL1
3691 WH/L-BU
X202 43
J203
742 OG
47 L-BU
22 BK
22 WH
Z82
-Z82
Z82-JL1
-Z82
Z82
-Z82
W8 Blunt Cut - Trailer Provision
W8 Blunt Cut - Trailer Provision
W8 Blunt Cut - Trailer Provision
Trailer Brake Control Schematics
47 L-BU
JL1
-JL1
47 L-BU
242 RD/L-GN
3691 WH/L-BU
2050 BK
W24 Blunt Cut - Trailer Brakes Provision
E
C
B
X88 Trailer Connector
22 BK (Z82)
22 WH (-Z82)
G400
G300

Master Electrical Component List

Code	Name	Option	Location	Locator View	Connector End View
A3L	Sunshade - Left	—	In the front of the passenger compartment, above the driver seat	—	—
A3R	Sunshade - Right	—	In the front of the passenger compartment, above the passenger seat	—	—
A7	Fuel Pump and Level Sensor Assembly	—	Under the vehicle, on top the fuel tank	Underbody Components (2 of 2)	• A7 Fuel Pump and Level Sensor Assembly (LCV/LGZ) • A7 Fuel Pump and Level Sensor Assembly (LWN)
A9A	Outside Rearview Mirror - Driver	—	Outside the vehicle, at the front of the driver door	• Front of Vehicle Components (Chevrolet/X88) • Front of Vehicle Components (GMC/Z88)	—
A9B	Outside Rearview Mirror - Passenger	—	Outside the vehicle, at the front of the passenger door	• Front of Vehicle Components (Chevrolet/X88) • Front of Vehicle Components (GMC/Z88)	—
A10	Inside Rearview Mirror	—	In the passenger compartment, at the top center of the windshield, behind mirror	• Headliner Components (Extended Cab) • Headliner Components (Crew Cab)	A10 Inside Rearview Mirror
A11	Radio	—	In the passenger compartment, center of the instrument panel, behind the info display module	Behind the Instrument Panel Components	• A11 Radio X1 (IO3) • A11 Radio X1 (IO5/IO6) • A11 Radio X2 (IO3) • A11 Radio X2 (IO3/IO5/IO6) • A11 Radio X3 (IOB) • A11 Radio X3 (UQ3-IOB) • A11 Radio X4 (IOB) • A11 Radio X4 (-IOB) • A11 Radio X6 • A11 Radio X7 (IO3) • A11 Radio X7 (IOB) • A11 Radio X8
A16	Transfer Case Motor	NQ6/NQ7	On the underbody, mounted to the bottom rear of the transfer case	Automatic Transmission Components (MYB with NQ6/NQ7)	• A16 Transfer Case Motor X1 (NQ6) • A16 Transfer Case Motor X1 (-NQ6) • A16 Transfer Case Motor X2
A22	Radio Controls	—	In the passenger compartment, at the center of the instrument panel, part of the info display module	Front of the Instrument Panel Components	—

A23D	Door Latch Assembly - Driver	—	In the passenger compartment, at the middle rear of the driver door	*Driver Door Components*	*A23D Door Latch Assembly - Driver*
A23G	Door Latch Assembly - Left Rear Lower	Extended Cab	In the passenger compartment, at the lower front of the left rear door	*Left Rear Door Components (Extended Cab)*	*A23G Door Latch Assembly - Left Rear Lower*
A23H	Door Latch Assembly - Left Rear Upper	Extended Cab	In the passenger compartment, at the upper front of the left rear door	*Left Rear Door Components (Extended Cab)*	*A23H Door Latch Assembly - Left Rear Upper*
A23J	Door Latch Assembly - Right Rear Lower	Extended Cab	In the passenger compartment, at the lower front of the right rear door	*Right Rear Door Components (Extended Cab)*	*A23J Door Latch Assembly - Right Rear Lower*
A23K	Door Latch Assembly - Right Rear Upper	Extended Cab	In the passenger compartment, at the upper front of the right rear door	*Right Rear Door Components (Extended Cab)*	*A23K Door Latch Assembly - Right Rear Upper*
A23LR	Door Latch Assembly - Left Rear	Crew Cab	In the passenger compartment, at the middle rear of the left rear door	*Left Rear Door Components (Crew Cab)*	—
A23P	Door Latch Assembly - Passenger	—	In the passenger compartment, at the middle rear of the passenger door	*Passenger Door Components*	*A23P Door Latch Assembly - Passenger*
A23RR	Door Latch Assembly - Right Rear	Crew Cab	In the passenger compartment, at the middle rear of the right rear door	*Right Rear Door Components (Crew Cab)*	—
A26	HVAC Controls	—	In the passenger compartment, at the middle center of the instrument panel, below the radio controls	*Front of the Instrument Panel Components*	*A26 HVAC Controls*
A38	Reductant Pump and Sensor Assembly	LWN	Outside the vehicle, above the spare tire, mounted on bottom of the reductant tank	*Underbody Components (LWN) (4 of 6)*	—
B1	A/C Refrigerant Pressure Sensor	LCV	In the front of the engine compartment, on the right side of the A/C compressor	*Left Front of the Engine Components (LCV)*	• *B1 A/C Refrigerant Pressure Sensor (LCV)* • *B1 A/C Refrigerant Pressure Sensor (-LCV)* • *B1 A/C Refrigerant Pressure Sensor (LGZ)* • *B1 A/C Refrigerant Pressure Sensor (LWN)*
B1	A/C Refrigerant Pressure Sensor	LGZ/LWN	In the front of the engine compartment, on the front left side of the engine, on the A/C compressor high pressure line above the compressor	• *Left Front of the Engine Components (LGZ)* • *Left Front of the Engine Components (LWN)*	• *B1 A/C Refrigerant Pressure Sensor (LCV)* • *B1 A/C Refrigerant Pressure Sensor (-LCV)* • *B1 A/C Refrigerant Pressure Sensor (LGZ)* • *B1 A/C Refrigerant Pressure Sensor (LWN)*
B5LF	Wheel Speed Sensor - Left Front	—	Outside the vehicle, in the left front hub assembly	*Wheel Well Components*	*B5LF Wheel Speed Sensor - Left Front*
B5LR	Wheel Speed Sensor - Left Rear	—	Outside the vehicle, in the left rear hub assembly	• *Underbody Components (2 of 2)* • *Wheel Well Components*	*B5LR Wheel Speed Sensor - Left Rear*
B5RF	Wheel Speed Sensor - Right Front	—	Outside the vehicle, in the right front hub assembly	*Wheel Well Components*	*B5RF Wheel Speed Sensor - Right Front*

B5RR	Wheel Speed Sensor - Right Rear	—	Outside the vehicle, in the right rear hub assembly	*Wheel Well Components*	*B5RR Wheel Speed Sensor - Right Rear*
B7B	Air Temperature Sensor - Duct Lower	C68	In the passenger compartment, in the floor vent of the front console	*HVAC Assembly Components*	*B7B Air Temperature Sensor - Duct Lower*
B7F	Air Temperature Sensor - Duct Upper	C68	In the passenger compartment, behind the instrument panel, on the upper left side of the HVAC module	*HVAC Assembly Components*	*B7F Air Temperature Sensor - Duct Upper*
B9	Ambient Air Temperature Sensor	—	Outside the vehicle, in the front, behind the bottom center of grille	• *Front of Vehicle Components (Chevrolet/X88)* • *Front of Vehicle Components (GMC/Z88)*	—
B10B	Ambient Light/Sunload Sensor	—	In the passenger compartment, at the top center of the instrument panel, in the defroster deflector	*Front of the Instrument Panel Components*	*B10B Ambient Light/Sunload Sensor*
B12A	Transmission Fluid Pressure Switch	MYB	Under the vehicle, inside the automatic transmission, part of the control solenoid valve assembly	—	—
B13	Transmission Fluid Temperature Sensor	MYB	Under the vehicle, inside the automatic transmission, part of the control solenoid valve assembly	—	—
B14A	Transmission Output Shaft Speed Sensor	MYB	Under the vehicle, internal to the transmission assembly	• *Automatic Transmission Components (MYB with NQ6/NQ7)* • *Manual Transmission Components (N8D)*	• *B14A Transmission Output Shaft Speed Sensor (N8D)* • *B14A Transmission Output Shaft Speed Sensor (NQ6/NQ7)*
B14A	Transmission Output Shaft Speed Sensor	NQ6/NQ7	Under the vehicle, on the transfer case assembly	• *Automatic Transmission Components (MYB with NQ6/NQ7)* • *Manual Transmission Components (N8D)*	• *B14A Transmission Output Shaft Speed Sensor (N8D)* • *B14A Transmission Output Shaft Speed Sensor (NQ6/NQ7)*
B14A	Transmission Output Shaft Speed Sensor	N8D	Under the vehicle, on the manual transmission assembly	• *Automatic Transmission Components (MYB with NQ6/NQ7)* • *Manual Transmission Components (N8D)*	• *B14A Transmission Output Shaft Speed Sensor (N8D)* • *B14A Transmission Output Shaft Speed Sensor (NQ6/NQ7)*
B14A	Transmission Output Shaft Speed Sensor	M5T	Under the vehicle, internal to the transmission assembly	—	—
B14C	Transmission Input Shaft Speed Sensor	MYB	Under the vehicle, internal to the transmission assembly	—	—
B14C	Transmission Input Shaft Speed Sensor	M5T	Under the vehicle, internal to the transmission assembly	—	—
B14D	Transmission Intermediate Shaft Speed Sensor	M5T	Under the vehicle, internal to the transmission assembly	—	—
B15	Transmission Internal Mode Switch	MYB	Under the vehicle, internal to the transmission assembly	—	—
B16	Backup Lamp Switch	N8D	In the engine compartment, on top of the transmission	*Manual Transmission Components (N8D)*	*B16 Backup Lamp Switch*
B18	Battery Current Sensor	—	In the engine compartment, on the negative battery cable	*Left Side of Engine Compartment Components*	*B18 Battery Current Sensor*

B19B	Brake Booster Vacuum Sensor	—	At the rear of the engine compartment, on the power brake booster vacuum check valve	*Left Side of Engine Compartment Components*	*B19B Brake Booster Vacuum Sensor*
B20	Brake Fluid Level Switch	—	At the rear of the engine compartment, on the brake fluid reservoir	*Left Side of Engine Compartment Components*	*B20 Brake Fluid Level Switch*
B22	Brake Pedal Position Sensor	—	In the passenger compartment, above the brake pedal assembly	• *Below Left Side of the Instrument Panel Components (MYB)* • *Below Left Side of the Instrument Panel Components (N8D)*	• *B22 Brake Pedal Position Sensor (MYB/M5T)* • *B22 Brake Pedal Position Sensor (N8D)*
B23A	Camshaft Position Sensor - Bank 1 Exhaust	LGZ	In the engine compartment, near front, right of center, above of the bank 1 exhaust camshaft position actuator solenoid valve	*Left Front of the Engine Components (LGZ)*	—
B23B	Camshaft Position Sensor - Bank 1 Intake	LGZ	In the engine compartment, near front, right of center, left of the bank 1 intake camshaft position actuator solenoid valve	*Left Front of the Engine Components (LGZ)*	—
B23C	Camshaft Position Sensor - Bank 2 Exhaust	LGZ	In the engine compartment, near front, left of center, above of the bank 2 exhaust camshaft position actuator solenoid valve	*Left Front of the Engine Components (LGZ)*	• *B23C Camshaft Position Sensor - Bank 2 Exhaust (LGZ)* • *B23C Camshaft Position Sensor - Bank 2 Exhaust (LGZ-ZR2)*
B23D	Camshaft Position Sensor - Bank 2 Intake	LGZ	In the engine compartment, near front, left of center, right of the bank 2 intake camshaft position actuator solenoid valve	*Left Front of the Engine Components (LGZ)*	• *B23D Camshaft Position Sensor - Bank 2 Intake (LGZ)* • *B23D Camshaft Position Sensor - Bank 2 Intake (LGZ-ZR2)*
B23E	Camshaft Position Sensor - Exhaust	LCV	In the engine compartment, rear left of center, mounted to cylinder head, on left side	*Left Front of the Engine Components (LCV)*	• *B23E Camshaft Position Sensor - Exhaust (LCV)* • *B23A Camshaft Position Sensor - Bank 1 Exhaust (LGZ)* • *B23E Camshaft Position Sensor - Exhaust (LGZ-ZR2)*
B23F	Camshaft Position Sensor - Intake	LCV	In the engine compartment, rear right of center, mounted to cylinder head, on right lower side	*Right Rear of Engine Components (LCV)*	• *B23F Camshaft Position Sensor - Intake (LCV)* • *B23B Camshaft Position Sensor - Bank 1 Intake (LGZ)* • *B23F Camshaft Position Sensor - Intake (LGZ-ZR2)*
B23	Camshaft Position Sensor	LWN	In the engine compartment, front of engine, right of center, near intake manifold	*Right Bottom of Engine Components (LWN)*	*B23 Camshaft Position Sensor (LWN)*
B24	Cellular Phone Microphone	UE1	In the passenger compartment, in the front left of the headliner, near the driver sunshade	• *Headliner Components (Extended Cab)* • *Headliner Components (Crew Cab)*	*B24 Cellular Phone Microphone*
B25B	Clutch Pedal Position Sensor	N8D	In the passenger compartment, under the driver side of the instrument panel, above the clutch pedal	*Below Left Side of the Instrument Panel Components (N8D)*	*B25B Clutch Pedal Position Sensor*

B26	Crankshaft Position Sensor	LCV	In the engine compartment, right of center, near rear, mounted to right side of engine block	*Right Bottom of Engine Components (LCV)*	- *B26 Crankshaft Position Sensor (LCV)* - *B26 Crankshaft Position Sensor (LGZ+ZR2)* - *B26 Crankshaft Position Sensor (LGZ-ZR2)* - *B26 Crankshaft Position Sensor (LWN)* - *B26 Crankshaft Position Sensor (LWN-LCV)*
B26	Crankshaft Position Sensor	LGZ	In the engine compartment, right of center, mounted to right rear side of engine block	*Right Bottom of Engine Components (LGZ)*	- *B26 Crankshaft Position Sensor (LCV)* - *B26 Crankshaft Position Sensor (LGZ+ZR2)* - *B26 Crankshaft Position Sensor (LGZ-ZR2)* - *B26 Crankshaft Position Sensor (LWN)* - *B26 Crankshaft Position Sensor (LWN-LCV)*
B26	Crankshaft Position Sensor	LWN	In the engine compartment, left of center, near rear, mounted to lower left side of engine block	*Left Front of the Engine Components (LWN)*	- *B26 Crankshaft Position Sensor (LCV)* - *B26 Crankshaft Position Sensor (LGZ+ZR2)* - *B26 Crankshaft Position Sensor (LGZ-ZR2)* - *B26 Crankshaft Position Sensor (LWN)* - *B26 Crankshaft Position Sensor (LWN-LCV)*
B34	Engine Coolant Temperature Sensor	LCV	In the engine compartment, rear center, mounted to coolant outlet at rear of cylinder head	*Right Rear of Engine Components (LCV)*	- *B34 Engine Coolant Temperature Sensor (LCV)* - *B34 Engine Coolant Temperature Sensor (LWN)*
B34	Engine Coolant Temperature Sensor	LGZ	In the engine compartment, left side, near rear, mounted to bank 2 cylinder head, near exhaust pipe	*Left Front of the Engine Components (LGZ)*	- *B34 Engine Coolant Temperature Sensor (LCV)* - *B34 Engine Coolant Temperature Sensor (LWN)*
B34	Engine Coolant Temperature Sensor	LWN	In the engine compartment, mounted to left side of engine block, above the starter	*Left Side of Engine Components (LWN)*	- *B34 Engine Coolant Temperature Sensor (LCV)* - *B34 Engine Coolant Temperature Sensor (LWN)*
B35	Engine Oil Level Switch	LCV	In the engine compartment, near middle, mounted to right side of oil pan	*Right Rear of Engine Components (LCV)*	- *B35 Engine Oil Level Switch (LCV)* - *B35 Engine Oil Level Switch (LGZ)* - *B35 Engine Oil Level Switch (LWN)*

B35	Engine Oil Level Switch	LGZ/LWN	In the engine compartment, mounted to right side of oil pan above the drain plug	• *Right Bottom of Engine Components (LGZ)* • *Right Bottom of Engine Components (LWN)*	• *B35 Engine Oil Level Switch (LCV)* • *B35 Engine Oil Level Switch (LGZ)* • *B35 Engine Oil Level Switch (LWN)*
B37B	Engine Oil Pressure Sensor	LCV	In the engine compartment, near middle, mounted to right side of engine block	*Right Bottom of Engine Components (LCV)*	• *B37B Engine Oil Pressure Sensor (LCV)* • *B37B Engine Oil Pressure Sensor (LGZ)* • *B37B Engine Oil Pressure Sensor (LWN)*
B37B	Engine Oil Pressure Sensor	LGZ	In the engine compartment, left of center, near front, mounted to oil filter adapter	• *Left Front of the Engine Components (LGZ)* • *Right Bottom of Engine Components (LWN)*	• *B37B Engine Oil Pressure Sensor (LCV)* • *B37B Engine Oil Pressure Sensor (LGZ)* • *B37B Engine Oil Pressure Sensor (LWN)*
B39	A/C Evaporator Temperature Sensor	—	In the passenger compartment, on HVAC module, behind the instrument panel	*HVAC Assembly Components*	*B39 A/C Evaporator Temperature Sensor*
B46	Fuel Level Sensor	—	Under the vehicle, inside the fuel tank, part of the fuel pump and level sensor assembly	—	—
B47B	Fuel Rail Pressure Sensor	LCV	In the engine compartment, middle, mounted to the fuel rail, below the intake manifold	*Right Top of Engine Components (LCV)*	*B47B Fuel Rail Pressure Sensor*
B47B	Fuel Rail Pressure Sensor	LGZ	In the engine compartment, rear of the engine, on fuel rail below the intake manifold	—	*B47B Fuel Rail Pressure Sensor*
B47B	Fuel Rail Pressure Sensor	LWN	In the engine compartment, left rear of engine, on fuel rail	*Right Rear of Engine Components (LWN)*	*B47B Fuel Rail Pressure Sensor*
B47	Fuel Pressure Sensor	LCV/LGZ	On the vehicle underbody, on the fuel line, next to the electronic brake control module	• *Chassis Underbody Components (Extended Cab)* • *Chassis Components (Crew Cab)* • *Chassis Components (Extended Cab)*	*B47 Fuel Pressure Sensor*
B52A	Heated Oxygen Sensor 1	LCV	In the engine compartment, left of center, in the exhaust manifold	*Left Front of the Engine Components (LCV)*	*B52A Heated Oxygen Sensor 1*
B52B	Heated Oxygen Sensor 2	LCV	In the engine compartment, rear, left of center, mounted to catalytic converter, near transmission	*Left Front of the Engine Components (LCV)*	*B52B Heated Oxygen Sensor 2*
B52C	Heated Oxygen Sensor - Bank 1 Sensor 1	LGZ	In the engine compartment, right of center, near rear, on exhaust pipe, before the catalytic converter	*Right Rear of Engine Components (LGZ)*	*B52C Heated Oxygen Sensor - Bank 1 Sensor 1*
B52D	Heated Oxygen Sensor - Bank 1 Sensor 2	LGZ	In the engine compartment, right of center, rear, on exhaust pipe, after the catalytic converter	*Right Rear of Engine Components (LGZ)*	*B52D Heated Oxygen Sensor - Bank 1 Sensor 2*
B52E	Heated Oxygen Sensor - Bank 2 Sensor 1	LGZ	In the engine compartment, left of center, near rear, on exhaust pipe, before the catalytic converter	*Left Front of the Engine Components (LGZ)*	*B52E Heated Oxygen Sensor - Bank 2 Sensor 1*
B52F	Heated Oxygen Sensor - Bank 2 Sensor 2	LGZ	In the engine compartment, left of center, rear, on exhaust pipe, after the catalytic converter	*Right Rear of Engine Components (LGZ)*	*B52F Heated Oxygen Sensor - Bank 2 Sensor 2*

B55	Hood Ajar Switch	UTJ	In the front of the engine compartment, part of the hood latch	*Left Front of Engine Compartment Components*	*B55 Hood Ajar Switch*
B59L	Front Impact Sensor - Left	—	In the engine compartment, lower left front of the radiator support	*Left Front of Engine Compartment Components*	*B59L Front Impact Sensor - Left*
B59R	Front Impact Sensor - Right	—	In the engine compartment, lower right front of the radiator support	*Right Front of Engine Compartment Components*	*B59R Front Impact Sensor - Right*
B60	Passenger Presence Sensor	—	In the passenger compartment, under the passenger seat cushion, part of the passenger presence module	—	—
B61P	Seat Belt Tension Sensor - Passenger	—	In the passenger compartment, part of the passenger seat belt buckle	—	—
B63LF	Side Impact Sensor - Left Front	—	In the driver door, behind the trim panel, toward the rear of the door	*Driver Door Components*	*B63LF Side Impact Sensor - Left Front*
B63LR	Side Impact Sensor - Left Rear	—	In the left rear door, behind the trim panel, toward the rear of the door	• *Left Passenger Components (Extended Cab)* • *Left Passenger Components (Crew Cab)*	*B63LR Side Impact Sensor - Left Rear*
B63RF	Side Impact Sensor - Right Front	—	In the passenger door, behind the trim panel, toward the rear of the door	*Passenger Door Components*	*B63RF Side Impact Sensor - Right Front*
B63RR	Side Impact Sensor - Right Rear	—	In the right rear door, behind the trim panel, toward the rear of the door	• *Right Passenger Components (Extended Cab)* • *Right Passenger Components (Crew Cab)*	*B63RR Side Impact Sensor - Right Rear*
B65	Intake Manifold Pressure and Air Temperature Sensor	LWN	In the engine compartment, left of center, mounted to top of intake manifold	*Top of Engine Components (LWN)*	*B65 Intake Manifold Pressure and Air Temperature Sensor*
B68A	Knock Sensor 1	LCV/LGZ	In the engine compartment, right of center, mounted to right side of engine block	• *Right Bottom of Engine Components (LGZ)* • *Right Bottom of Engine Components (LCV)*	*B68A Knock Sensor 1*
B68B	Knock Sensor 2	LCV	In the engine compartment, mounted to right side of engine block	*Right Bottom of Engine Components (LCV)*	*B68B Knock Sensor 2 (LCV)*
B68B	Knock Sensor 2	LGZ	In the engine compartment, middle, mounted to left side of engine block	*Left Front of the Engine Components (LGZ)*	*B68B Knock Sensor 2 (LFX)*
B74	Manifold Absolute Pressure Sensor	LCV	In the engine compartment, mounted to right side of intake manifold	*Right Bottom of Engine Components (LCV)*	• *B74 Manifold Absolute Pressure Sensor (LCV)* • *B74 Manifold Absolute Pressure Sensor (LGZ)*
B74	Manifold Absolute Pressure Sensor	LGZ	In the engine compartment, mounted to top of intake manifold	*Right Rear of Engine Components (LGZ)*	• *B74 Manifold Absolute Pressure Sensor (LCV)* • *B74 Manifold Absolute Pressure Sensor (LGZ)*

B75C	Multifunction Intake Air Sensor	LCV/LGZ/LWN	Right side of the engine compartment, in the air intake duct	• *Right Rear of Engine Components (LGZ)* • *Right Rear of Engine Components (LCV)* • *Right Rear of Engine Components (LWN)*	*B75C Multifunction Intake Air Sensor*
B80	Park Brake Switch	—	In the passenger compartment, at the left side of the Driver Footwell	• *Below Left Side of the Instrument Panel Components (N8D)* • *Below Left Side of the Instrument Panel Components (MYB)* • *Left Passenger Components (Crew Cab)*	*B80 Park Brake Switch*
B81B	Park Position Switch	MYB	In the passenger compartment, center near front, on shift lever within floor console	—	—
B87	Rearview Camera	UVC	In the lower center of the tailgate handle assembly	*Rear of Vehicle Components*	*B87 Rearview Camera*
B88D	Seat Belt Switch - Driver	—	In the passenger compartment, on the side of the driver seat cushion, part of the driver seat belt buckle	*Driver Seat Components*	—
B88P	Seat Belt Switch - Passenger	—	In the passenger compartment, on the side of the passenger seat cushion, part of the passenger front seat belt buckle	*Passenger Seat Components*	—
B107	Accelerator Pedal Position Sensor	—	In the passenger compartment, on the driver floor board above the accelerator pedal	• *Below Left Side of the Instrument Panel Components (MYB)* • *Below Left Side of the Instrument Panel Components (N8D)*	*B107 Accelerator Pedal Position Sensor*
B116	Water in Fuel Sensor	LWN	On the underbody, along the inboard side of the left frame rail, mounted to the fuel filter assembly	*Underbody Components (LWN) (3 of 6)*	*B116 Water in Fuel Sensor*
B130A	Exhaust Gas Recirculation Temperature Sensor 1	LWN	In the engine compartment, right front of engine, attached to the exhaust manifold at cylinder 1	*Right Rear of Engine Components (LWN)*	*B130A Exhaust Gas Recirculation Temperature Sensor 1*
B130B	Exhaust Gas Recirculation Temperature Sensor 2	LWN	In the engine compartment, left rear of engine, attached to the cylinder head at cylinder 4	*Right Rear of Engine Components (LWN)*	*B130B Exhaust Gas Recirculation Temperature Sensor 2*
B131A	Exhaust Temperature Sensor 1	LWN	In the engine compartment, right rear, mounted to the inlet side of the catalytic converter	*Right Rear of Engine Components (LWN)*	*B131A Exhaust Temperature Sensor 1*
B131B	Exhaust Temperature Sensor 2	LWN	In the engine compartment, right rear, mounted to the outlet side of the catalytic converter	*Right Rear of Engine Components (LWN)*	*B131B Exhaust Temperature Sensor 2*
B131C	Exhaust Temperature Sensor 3	LWN	On the underbody, right, mounted to the outlet side of the nitrogen oxides catalytic converter	*Underbody Components (LWN) (2 of 6)*	*B131C Exhaust Temperature Sensor 3*
B131D	Exhaust Temperature Sensor 4	LWN	On the underbody, inboard side of the right frame rail, mounted to the exhaust particulate filter	*Underbody Components (LWN) (2 of 6)*	*B131D Exhaust Temperature Sensor 4*
B131E	Exhaust Temperature Sensor 5	LWN	On the underbody, inboard side of the right frame rail, rear of the exhaust particulate filter, mounted to the exhaust pipe	*Underbody Components (LWN) (2 of 6)*	*B131E Exhaust Temperature Sensor 5*
B136	Exhaust Particulate Matter Sensor	LWN	On the underbody, mounted to the inboard side of the right frame rail, forward of the right rear shock	*Underbody Components (LWN) (4 of 6)*	*B136 Exhaust Particulate Matter Sensor*

B137	Power Steering Shaft Torque Sensor	—	In the engine compartment, lower left, part of power steering rack assembly	—	—
B150	Fuel Tank Pressure Sensor	LCV/LGZ	On the underbody, mounted to the fuel pump and level sensor assembly	• *Chassis Components (Crew Cab)* • *Chassis Components (Extended Cab)* • *Underbody Components (2 of 2)*	*B150 Fuel Tank Pressure Sensor*
B153D	Seat Belt Buckle - Driver	—	In the passenger compartment, at the inboard of the driver seat	—	—
B153P	Seat Belt Buckle - Passenger	—	In the passenger compartment, at the inboard of the passenger seat	—	—
B154	Diesel Particulate Filter Exhaust Differential Pressure Sensor	LWN	On the underbody, mounted to the underside side of the bed, above the right frame rail, forward of the right rear shock	*Underbody Components (LWN) (4 of 6)*	*B154 Diesel Particulate Filter Exhaust Differential Pressure Sensor*
B160	Windshield Temperature and Inside Moisture Sensor	C68	In the passenger compartment, behind the inside rearview mirror, near the windshield	• *Headliner Components (Extended Cab)* • *Headliner Components (Crew Cab)*	*B160 Windshield Temperature and Inside Moisture Sensor (C68)*
B193A	Charge Air Cooler Inlet Temperature Sensor	LWN	In the engine compartment, right front of engine, attached to the charge air cooler inlet duct	*Right Rear of Engine Components (LWN)*	*B193A Charge Air Cooler Inlet Temperature Sensor*
B193B	Charge Air Cooler Outlet Temperature Sensor	LWN	In the engine compartment, left front of engine, attached to the charge air cooler outlet duct	*Left Side of Engine Components (LWN)*	*B193B Charge Air Cooler Outlet Temperature Sensor*
B194	Reductant Pressure Sensor	LWN	Internal to the reductant fluid reservoir assembly	—	—
B195A	Nitrogen Oxides Sensor 1	LWN	In the engine compartment, right rear, mounted near the top of the catalytic converter	*Right Rear of Engine Components (LWN)*	*B195A Nitrogen Oxides Sensor 1*
B195B	Nitrogen Oxides Sensor 2	LWN	On the underbody, right, mounted to the outlet side of the nitrogen oxides catalytic converter	*Underbody Components (LWN) (2 of 6)*	*B195B Nitrogen Oxides Sensor 2*
B203	Engine Coolant Radiator Temperature Sensor	LCV	In the engine compartment, lower left corner of radiator	*Radiator Assembly Components*	*B203 Engine Coolant Radiator Temperature Sensor*
B213	Reductant Level Sensor	LWN	Internal to the reductant fluid reservoir assembly	*Underbody Components (LWN) (4 of 6)*	—
B214	Reductant Temperature Sensor	LWN	Internal to the reductant fluid reservoir assembly	—	—
B227	Gear Position Sensor	NQ6	Under the vehicle, on the top rear of the transfer case	*Automatic Transmission Components (MYB with NQ6/NQ7)*	*B227 Gear Position Sensor*
C1	Battery	—	In the engine compartment, on the left side, near the underhood fuse block on battery negative cable	*Left Side of Engine Compartment Components*	• *C1 Battery X1-A* • *C1 Battery X2*
E4AC	Park/Daytime Running Lamp - Left	Z88	Outside of the vehicle, at the left front of the vehicle, in the headlamp assembly	*Front of Vehicle Components (GMC/Z88)*	—
E4AD	Park/Daytime Running Lamp - Right	Z88	Outside of the vehicle, at the right front of the vehicle, in the headlamp assembly	*Front of Vehicle Components (GMC/Z88)*	—
E4AL	Park/Daytime Running Lamp - Left Lower	Z88	Outside of the vehicle, front left, in the headlamp assembly	*Front of Vehicle Components (GMC/Z88)*	—
E4AM	Park/Daytime Running Lamp - Right Lower	Z88	Outside of the vehicle, front right, in the headlamp assembly	*Front of Vehicle Components (GMC/Z88)*	—

E4E	Headlamp - Left High Beam	—	Outside of the vehicle, at the left front of the vehicle, in the headlamp assembly	• Front of Vehicle Components (GMC/Z88) • Front of Vehicle Components (Chevrolet/X88)	—
E4F	Headlamp - Right High Beam	—	Outside of the vehicle, at the right front of the vehicle, in the headlamp assembly	• Front of Vehicle Components (GMC/Z88) • Front of Vehicle Components (Chevrolet/X88)	—
E4G	Headlamp - Left Low Beam	—	Outside of the vehicle, at the left front of the vehicle, in the headlamp assembly	• Front of Vehicle Components (Chevrolet/X88) • Front of Vehicle Components (GMC/Z88)	—
E4H	Headlamp - Right Low Beam	—	Outside of the vehicle, at the right front of the vehicle, in the headlamp assembly	• Front of Vehicle Components (Chevrolet/X88) • Front of Vehicle Components (GMC/Z88)	—
E4J	Park Lamp - Left Front	X88	Outside of the vehicle, at the left front of the vehicle, in the headlamp assembly	Front of Vehicle Components (Chevrolet/X88)	—
E4K	Park Lamp - Right Front	X88	Outside of the vehicle, at the right front of the vehicle, in the headlamp assembly	Front of Vehicle Components (Chevrolet/X88)	—
E4N	Park/Turn Signal Lamp - Left	—	Outside of the vehicle, at the left front of the vehicle, in the headlamp assembly	• Front of Vehicle Components (GMC/Z88) • Front of Vehicle Components (Chevrolet/X88)	—
E4P	Park/Turn Signal Lamp - Right	—	Outside of the vehicle, at the right front of the vehicle, in the headlamp assembly	• Front of Vehicle Components (Chevrolet/X88) • Front of Vehicle Components (GMC/Z88)	—
E5A	Backup Lamp - Left	—	Outside of the vehicle, at the left rear corner of the vehicle, part of the left tail lamp assembly	Rear of Vehicle Components	—
E5AG	Tail/Stop and Turn Signal Lamp - Left Upper	—	Outside of the vehicle, at the left rear corner of the vehicle, part of the left tail lamp assembly	Rear of Vehicle Components	—
E5AH	Tail/Stop and Turn Signal Lamp - Right Upper	—	Outside of the vehicle, at the right rear corner of the vehicle, part of the right tail lamp assembly	Rear of Vehicle Components	—
E5B	Backup Lamp - Right	—	Outside of the vehicle, at the right rear corner of the vehicle, part of the right tail lamp assembly	Rear of Vehicle Components	—
E5U	Tail/Stop and Turn Signal Lamp - Left Lower	—	Outside of the vehicle, at the left rear corner of the vehicle, part of the left tail lamp assembly	Rear of Vehicle Components	—
E5V	Tail/Stop and Turn Signal Lamp - Right Lower	—	Outside of the vehicle, at the right rear corner of the vehicle, part of the right tail lamp assembly	Rear of Vehicle Components	—
E6	Center High Mounted Stop Lamp	—	Outside of the vehicle, at the rear center of the roof	Rear of Vehicle Components	—
E7L	License Plate Lamp - Left	—	Outside of the vehicle, at the rear center of the vehicle	Rear of Vehicle Components	E7L License Plate Lamp - Left

E7R	License Plate Lamp - Right	—	Outside of the vehicle, at the rear center of the vehicle	*Rear of Vehicle Components*	*E7R License Plate Lamp - Right*
E11	Fuel Heater	LWN	On the underbody, along the inboard side of the left frame rail, mounted to the fuel filter assembly	*Underbody Components (LWN) (3 of 6)*	—
E12A	Glow Plug 1	LWN	In the engine compartment, at the top left side of the engine at number 1 cylinder	*Top of Engine Components (LWN)*	—
E12B	Glow Plug 2	LWN	In the engine compartment, at the top left side of the engine at number 2 cylinder	*Top of Engine Components (LWN)*	—
E12C	Glow Plug 3	LWN	In the engine compartment, at the top left side of the engine at number 3 cylinder	*Top of Engine Components (LWN)*	—
E12D	Glow Plug 4	LWN	In the engine compartment, at the top left side of the engine at number 4 cylinder	*Top of Engine Components (LWN)*	—
E13LA	Headlamp Assembly - Left	—	Outside of the vehicle, at the front left of the vehicle	• *Front of Vehicle Components (Chevrolet/X88)* • *Front of Vehicle Components (GMC/Z88)*	—
E13RA	Headlamp Assembly - Right	—	Outside of the vehicle, at the front right of the vehicle	• *Front of Vehicle Components (Chevrolet/X88)* • *Front of Vehicle Components (GMC/Z88)*	—
E14A	Seat Heating Element - Driver Back	KA1	In the passenger compartment, in the driver seat back	*Driver Seat Components*	—
E14B	Seat Heating Element - Driver Cushion	KA1	In the passenger compartment, in the driver seat cushion	*Driver Seat Components*	—
E14C	Seat Heating Element - Passenger Back	KA1	In the passenger compartment, in the passenger seat back	*Passenger Seat Components*	—
E14D	Seat Heating Element - Passenger Cushion	KA1	In the passenger compartment, in the passenger seat cushion	• *Passenger Seat Components* • *Passenger Seat Components*	—
E17D	Outside Rearview Mirror Glass - Driver	DL9	Outside of the vehicle, on the driver door, part of outside rearview mirror	—	—
E17P	Outside Rearview Mirror Glass - Passenger	DL9	Outside of the vehicle, on the front passenger door, part of outside rearview mirror	—	—
E18	Rear Defogger Grid	C49	In the passenger compartment, on the inside of the rear window	*Rear of Vehicle Components*	• *E18 Rear Defogger Grid X1* • *E18 Rear Defogger Grid X2*
E29LF	Fog Lamp - Left Front	T3U	At the left front corner of the vehicle, below the left headlamp assembly	• *Front of Vehicle Components (Chevrolet/X88)* • *Front of Vehicle Components (GMC/Z88)*	*E29LF Fog Lamp - Left Front*
E29RF	Fog Lamp - Right Front	T3U	At the right front corner of the vehicle, below the right headlamp assembly	• *Front of Vehicle Components (Chevrolet/X88)* • *Front of Vehicle Components (GMC/Z88)*	*E29RF Fog Lamp - Right Front*

E31L	Sunshade Mirror Lamp - Left	D6I	In the passenger compartment, part of the left sunshade	- *Headliner Components (Extended Cab)* - *Headliner Components (Crew Cab)*	*E31L Sunshade Mirror Lamp - Left*
E31R	Sunshade Mirror Lamp - Right	D6I	In the passenger compartment, part of the right sunshade	- *Headliner Components (Extended Cab)* - *Headliner Components (Crew Cab)*	*E31R Sunshade Mirror Lamp - Right*
E32	Cigarette Lighter Receptacle	SAO	In the passenger compartment, at the forward right on the center console. Dealer installed accessory replaces the accessory power receptacle - center console 1	—	—
E33L	Cargo Lamp - Left	—	Outside of the vehicle, at the rear center of the roof, part of the center high mounted stop lamp	*Rear of Vehicle Components*	—
E33L	Cargo Lamp - Left	S0Y	Outside of the vehicle, on top of the left bed rail	*Rear of Vehicle Components*	—
E33R	Cargo Lamp - Right	—	Outside of the vehicle, at the rear center of the roof, part of the center high mounted stop lamp	*Rear of Vehicle Components*	—
E33R	Cargo Lamp - Right	S0Y	Outside of the vehicle, on top of the right bed rail	*Rear of Vehicle Components*	—
E36AH	Dome Lamp	—	In the passenger compartment, in the headliner, part of the headliner console	—	—
E37F	Dome/Reading Lamps - Front	C74	In the passenger compartment, in the headliner, part of the headliner console	- *Headliner Components (Extended Cab)* - *Headliner Components (Crew Cab)*	*E37F Dome/Reading Lamps - Front*
E37R	Dome/Reading Lamps - Rear	—	In the passenger compartment, on the roof, above the second row seating	- *Headliner Components (Extended Cab)* - *Headliner Components (Crew Cab)*	*E37R Dome/Reading Lamps - Rear*
E40	Electrical Auxiliary Heater	LWN	In the passenger compartment, center of instrument panel, attached to HVAC assembly	*HVAC Assembly Bottom Components (LWN)*	- *E40 Electrical Auxiliary Heater X1* - *E40 Electrical Auxiliary Heater X2*
E41	Engine Coolant Thermostat Heater	LCV	In the engine compartment, left front of the engine, on the thermostat housing	*Left Front of the Engine Components (LCV)*	*E41 Engine Coolant Thermostat Heater*
E42L	Tail Lamp Assembly - Left	—	Outside of the vehicle, at the left rear corner of the vehicle	*Rear of Vehicle Components*	—
E42R	Tail Lamp Assembly - Right	—	Outside of the vehicle, at the right rear corner of the vehicle	*Rear of Vehicle Components*	—
E45	Positive Crankcase Ventilation Heater	LWN	In the engine compartment, front right of the engine, forward of the turbocharger	*Right Bottom of Engine Components (LWN)*	*E45 Positive Crankcase Ventilation Heater*
E52	Reductant Line Heater	LWN	Outside the vehicle, above the spare tire, attached to the reductant fluid inlet line near the reductant pump and sensor assembly	*Underbody Components (LWN) (4 of 6)*	—
E53	Reductant Tank Heater	LWN	Internal to the reductant fluid reservoir assembly	*Underbody Components (LWN) (4 of 6)*	—
F101	Passenger Instrument Panel Air Bag	—	In the passenger compartment, at the top of the passenger side of the instrument panel	*Behind the Instrument Panel Components*	*F101 Passenger Instrument Panel Air Bag*

F105L	Roof Rail Air Bag - Left	—	In the passenger compartment, along the left roof rail, above headliner at door openings	• *Left Passenger Components (Extended Cab)* • *Left Passenger Components (Crew Cab)*	*F105L Roof Rail Air Bag - Left*
F105R	Roof Rail Air Bag - Right	—	In the passenger compartment, along the right roof rail, above headliner at door openings	• *Right Passenger Components (Extended Cab)* • *Right Passenger Components (Crew Cab)*	*F105R Roof Rail Air Bag - Right*
F106D	Seat Side Air Bag - Driver	—	In the passenger compartment, on the left side of the left front seat back	*Driver Seat Components*	—
F106P	Seat Side Air Bag - Passenger	—	In the passenger compartment, on the right side of the right front seat back	*Passenger Seat Components*	—
F107	Steering Wheel Air Bag	—	In the passenger compartment, in the center of the steering wheel	*Steering Column Components*	—
F112D	Seat Belt Retractor Pretensioner - Driver	Crew Cab	In the passenger compartment, at the base of the left B-pillar	*Left Passenger Components (Crew Cab)*	• *F112D Seat Belt Retractor Pretensioner - Driver (F43)* • *F112D Seat Belt Retractor Pretensioner - Driver (F53)*
F112D	Seat Belt Retractor Pretensioner - Driver	Extended Cab	In the passenger compartment, at the lower front of the left rear door	*Left Rear Door Components (Extended Cab)*	• *F112D Seat Belt Retractor Pretensioner - Driver (F43)* • *F112D Seat Belt Retractor Pretensioner - Driver (F53)*
F112P	Seat Belt Retractor Pretensioner - Passenger	Crew Cab	In the passenger compartment, at the base of the right B-pillar	*Right Passenger Components (Crew Cab)*	• *F112P Seat Belt Retractor Pretensioner - Passenger (F43)* • *F112P Seat Belt Retractor Pretensioner - Passenger (F53)*
F112P	Seat Belt Retractor Pretensioner - Passenger	Extended Cab	In the passenger compartment, at the lower front of the right rear door	*Right Rear Door Components (Extended Cab)*	• *F112P Seat Belt Retractor Pretensioner - Passenger (F43)* • *F112P Seat Belt Retractor Pretensioner - Passenger (F53)*
F113D	Seat Belt Anchor Pretensioner - Driver	Crew Cab	In the passenger compartment, between driver seat and center console, attached to driver seat	*M14E Door Lock Actuator - Left Sliding (BSK with UTK)*	*F113D Seat Belt Anchor Pretensioner - Driver*
F113D	Seat Belt Anchor Pretensioner - Driver	Extended Cab	In the passenger compartment, at the lower front of the left rear door	*M58 Transmission Gate Select Motor*	*F113D Seat Belt Anchor Pretensioner - Driver*
F113P	Seat Belt Anchor Pretensioner - Passenger	Crew Cab	In the passenger compartment, between passenger seat and center console, attached to passenger seat	*Passenger Seat Components*	*F113P Seat Belt Anchor Pretensioner - Passenger*
F113P	Seat Belt Anchor Pretensioner - Passenger	Extended Cab	In the passenger compartment, at the lower front of the right rear door	*Right Rear Door Components (Extended Cab)*	*F113P Seat Belt Anchor Pretensioner - Passenger*

G1	A/C Compressor	—	In the engine compartment, mounted on the lower left front of the engine	• *Left Front of the Engine Components (LWN)* • *Left Front of the Engine Components (LGZ)* • *Left Front of the Engine Components (LCV)*	—
G10	Cooling Fan Motor	—	At the front of the engine compartment, in the center of the fan assembly, part of fan control module	—	—
G12	Fuel Pump	—	Under the vehicle, in the fuel tank, part of the fuel pump and level sensor assembly	—	—
G13	Generator	LCV/LWN	In the engine compartment, at the top left front of the engine	• *Left Front of the Engine Components (LWN)* • *Right Rear of Engine Components (LCV)*	*G13 Generator X1*
G13	Generator	LGZ	In the engine compartment, bottom right side of the engine	*Right Rear of Engine Components (LGZ)*	*G13 Generator X1*
G18	High Pressure Fuel Pump	LCV	In the engine compartment, right of center, near rear, mounted to right side of cylinder head	*Right Rear of Engine Components (LCV)*	*G18 High Pressure Fuel Pump*
G18	High Pressure Fuel Pump	LGZ	In the engine compartment, left of center, rear, mounted to rear of bank 2 cylinder head	*Right Rear of Engine Components (LGZ)*	*G18 High Pressure Fuel Pump*
G24	Windshield Washer Pump	—	In the engine compartment, attached to the washer fluid reservoir	*Left Front of Engine Compartment Components*	*G24 Windshield Washer Pump*
G33	Reductant Pump	LWN	Internal to the reductant fluid reservoir assembly	—	—
K8	Blower Motor Control Module	—	In the passenger compartment, part of the blower motor	*HVAC Assembly Components*	*K8 Blower Motor Control Module*
K9	Body Control Module	—	In the passenger compartment, behind the left side of the instrument panel knee bolster	• *Left Passenger Components (Extended Cab)* • *Left Passenger Components (Crew Cab)* • *Behind the Instrument Panel Components*	• *K9 Body Control Module X1* • *K9 Body Control Module X2* • *K9 Body Control Module X3* • *K9 Body Control Module X4* • *K9 Body Control Module X5* • *K9 Body Control Module X6* • *K9 Body Control Module X7*
K17	Electronic Brake Control Module	—	On vehicle underbody, driver side, under driver seat area on the frame	• *Chassis Underbody Components (Extended Cab)* • *Chassis Components (Crew Cab)* • *Chassis Components (Extended Cab)*	*K17 Electronic Brake Control Module*

K20	Engine Control Module	—	In the engine compartment, to the right of the engine, under the coolant reservoir	*Right Rear of Engine Compartment Components*	• *K20 Engine Control Module X1 (LCV)* • *K20 Engine Control Module X1 (LGZ)* • *K20 Engine Control Module X1 (LGZ+ZR2)* • *K20 Engine Control Module X1 (LWN)* • *K20 Engine Control Module X2 (LCV)* • *K20 Engine Control Module X2 (LGZ)* • *K20 Engine Control Module X2 (LGZ+ZR2)* • *K20 Engine Control Module X2 (LWN)* • *K20 Engine Control Module X3 (LCV)* • *K20 Engine Control Module X3 (LGZ)* • *K20 Engine Control Module X3 (LGZ+ZR2)* • *K20 Engine Control Module X3 (LWN)*
K22	Cooling Fan Control Module	LCV/LGZ	In the engine compartment, forward of the engine, near radiator	*Radiator Assembly Components*	*K22 Cooling Fan Control Module*
K29	Seat Heating Control Module	KA1	In the passenger compartment, under the front of the passenger seat	*Passenger Seat Components*	—
K33	HVAC Control Module	—	In the passenger compartment, center of the instrument panel, behind the multifunction instrument panel switch	*Behind the Instrument Panel Components*	• *K33 HVAC Control Module X1* • *K33 HVAC Control Module X2* • *K33 HVAC Control Module X3*
K36	Inflatable Restraint Sensing and Diagnostic Module	—	In the passenger compartment, under the center console	• *Left Passenger Components (Extended Cab)* • *Left Passenger Components (Crew Cab)*	• *K36 Inflatable Restraint Sensing and Diagnostic Module X1* • *K36 Inflatable Restraint Sensing and Diagnostic Module X2*
K38	Chassis Control Module	LGZ	Under the vehicle, mounted to the bracket above the spare tire	• *Underbody Components (2 of 2)* • *Chassis Components (Crew Cab)* • *Chassis Components (Extended Cab)*	• *K38 Chassis Control Module (LCV)* • *K38 Chassis Control Module (-LCV)*
K38	Chassis Control Module	LWN	Under the vehicle, mounted to the bracket above the spare tire	*Right Rear Door Components (Crew Cab)*	• *K38 Chassis Control Module (LCV)* • *K38 Chassis Control Module (-LCV)*
K43	Power Steering Control Module	—	On the underbody, ower front of engine compartment, on the power steering rack assembly	*Underbody Components (1 of 2)*	• *K43 Power Steering Control Module X1* • *K43 Power Steering Control Module X2*

K69	Transfer Case Control Module	NQ6/NQ7	In the passenger compartment, under the instrument panel, behind glove box, right of the HVAC assembly	• *Right Passenger Components (Extended Cab)* • *Right Passenger Components (Crew Cab)*	• *K69 Transfer Case Control Module X1* • *K69 Transfer Case Control Module X2* • *K69 Transfer Case Control Module X3*
K71	Transmission Control Module	MYB	Underneath the vehicle, inside the automatic transmission assembly, part of the control solenoid valve	—	—
K73	Telematics Communication Interface Control Module	UE1	In the passenger compartment, above the right kick panel, behind the instrument panel I-beam	• *Right Passenger Components (Extended Cab)* • *Right Passenger Components (Crew Cab)*	• *K73 Telematics Communication Interface Control Module X1* • *K73 Telematics Communication Interface Control Module X2* • *K73 Telematics Communication Interface Control Module X5* • *K73 Telematics Communication Interface Control Module X7 (IO5+CV3)* • *K73 Telematics Communication Interface Control Module X7 (IO5-CV3)*
K74	Human Machine Interface Control Module	IO4/IO5/IO6	In the passenger compartment, center of the instrument panel, behind the HVAC controls	*Behind the Instrument Panel Components*	• *K74 Human Machine Interface Control Module X1* • *K74 Human Machine Interface Control Module X2* • *K74 Human Machine Interface Control Module X3* • *K74 Human Machine Interface Control Module X4* • *K74 Human Machine Interface Control Module X5* • *K74 Human Machine Interface Control Module X7*
K77	Remote Control Door Lock Receiver	—	In the passenger compartment, above the right rear of the headliner	• *Headliner Components (Extended Cab)* • *Headliner Components (Crew Cab)*	*K77 Remote Control Door Lock Receiver*
K85	Passenger Presence Module	—	In the passenger compartment, under the front of the front passenger seat cushion	*Passenger Seat Components*	—
K89	Immobilizer Control Module	—	In the passenger compartment, on the steering column, near the key cylinder	*Front of the Instrument Panel Components*	*K89 Immobilizer Control Module*
K109	Frontview Camera Module	UEU/UFL	In the passenger compartment, behind the inside rearview mirror on the windshield	• *Headliner Components (Extended Cab)* • *Headliner Components (Crew Cab)*	*K109 Frontview Camera Module*
K111	Fuel Pump Driver Control Module	LCV	Under the vehicle, mounted to the bracket above the spare tire	*Underbody Components (2 of 2)*	• *K111 Fuel Pump Driver Control Module (LCV)* • *K111 Fuel Pump Driver Control Module (LGZ)*

K115	Reductant Control Module	LWN	Under the vehicle, Above and behind the rear axle, mounted to the reductant fluid reservoir assembly	*Underbody Components (LWN) (4 of 6)*	*K115 Reductant Control Module*
K133	Trailer Brake Power Control Module	JL1	Under the vehicle, mounted to the bracket above the spare tire, near the chassis control module	*Underbody Components (LWN) (6 of 6)*	*K133 Trailer Brake Power Control Module*
M4	Air Inlet Door Actuator	—	In the passenger compartment, behind the instrument panel glove box	*HVAC Assembly Components*	*M4 Air Inlet Door Actuator*
M6	Air Temperature Door Actuator	—	In the passenger compartment, part of HVAC module, behind the instrument panel	*HVAC Assembly Components*	*M6 Air Temperature Door Actuator*
M7	Transmission Shift Lock Control Solenoid Actuator	MYB	In the passenger compartment, center near front, on the shift lever within floor console	—	—
M9	Brake Booster Pump Motor	LGZ	In the engine compartment, near front, right of center, mounted to the front of bank 1 cylinder head	*Right Bottom of Engine Components (LGZ)*	*M9 Brake Booster Pump Motor*
M26	Front Axle Engagement Actuator	NQ6/NQ7	Under the vehicle, on the rear of the transfer case	*Underbody Components (1 of 2)*	*M26 Front Axle Engagement Actuator*
M37	Mode Door Actuator	—	In the passenger compartment, behind the instrument panel, on the upper left side of the HVAC module	*HVAC Assembly Components*	*M37 Mode Door Actuator*
M38	Power Steering Motor	—	On the underbody, lower front of engine compartment, on the power steering rack assembly	*Underbody Components (1 of 2)*	—
M51D	Seat Horizontal Motor - Driver	—	In the passenger compartment, under the center of the driver seat, between the seat tracks	*Driver Seat Components*	—
M51P	Seat Horizontal Motor - Passenger	AAQ	In the passenger compartment, under the center of the passenger seat, between the seat tracks	*Passenger Seat Components*	—
M52D	Seat Lumbar Support Horizontal Motor - Driver	AL9	In the passenger compartment, part of the driver seat back	*Driver Seat Back Components*	—
M52P	Seat Lumbar Support Horizontal Motor - Passenger	AAQ	In the passenger compartment, part of the passenger seat back	*Passenger Seat Back Components*	—
M55D	Seat Rear Vertical Motor - Driver	—	In the passenger compartment, under the front of the driver seat, next to the left seat track	*Driver Seat Components*	—
M55P	Seat Rear Vertical Motor - Passenger	AAQ	In the passenger compartment, under the front of the passenger seat, next to the left seat track	*Passenger Seat Components*	—
M64	Starter Motor	LCV	In the engine compartment, lower right rear of the engine	*Right Rear of Engine Components (LCV)*	• *M64 Starter Motor (LCV)* • *M64 Starter Motor (LGZ)* • *M64 Starter Motor (LWN)*
M64	Starter Motor	LGZ	In the engine compartment, lower left rear of the engine	*Left Front of the Engine Components (LGZ)*	• *M64 Starter Motor (LCV)* • *M64 Starter Motor (LGZ)* • *M64 Starter Motor (LWN)*
M64	Starter Motor	LWN	In the engine compartment, lower left rear of the engine	*Left Front of the Engine Components (LWN)*	• *M64 Starter Motor (LCV)* • *M64 Starter Motor (LGZ)* • *M64 Starter Motor (LWN)*

M74D	Window Motor - Driver	—	In the passenger compartment, behind the driver door trim panel, at the center of the door	*Driver Door Components*	*M74D Window Motor - Driver*
M74LR	Window Motor - Left Rear	Crew Cab	In the passenger compartment, center of the left rear door, behind the door trim panel	*Left Rear Door Components (Crew Cab)*	—
M74P	Window Motor - Passenger	—	In the passenger compartment, behind the front passenger door trim panel, at the center of the door	*Passenger Door Components*	*M74P Window Motor - Passenger*
M74RR	Window Motor - Right Rear	Crew Cab	In the passenger compartment, center of the right rear door, behind the door trim panel	*Right Rear Door Components (Crew Cab)*	—
M75	Windshield Wiper Motor	—	At the left rear of the engine compartment, near the windshield	*Left Side of Engine Compartment Components*	*M75 Windshield Wiper Motor*
M77D	Outside Rearview Mirror Motor - Driver	DL6/DL9	Outside of the vehicle, on driver door, in the driver door mirror	—	—
M77P	Outside Rearview Mirror Motor - Passenger	DL6/DL9	Outside of the vehicle, on passenger door, in the passenger door mirror	—	—
M93	Key Capture Solenoid Actuator	MYB	In the passenger compartment, left front of instrument panel, attached to the right side of steering column	*Front of the Instrument Panel Components*	*M93 Key Capture Solenoid Actuator*
M96	Active Grille Air Shutter Actuator	LCV/LGZ	At front of the vehicle, center, behind upper grille	*Front of Engine Compartment Components*	—
M103	Turbocharger Vane Position Actuator	LWN	In the engine compartment, right side of engine, mounted to the exhaust manifold, forward of the catalytic converter	*Right Rear of Engine Components (LWN)*	*M103 Turbocharger Vane Position Actuator*
P2	Transmission Shift Lever Position Indicator	MYB	In the passenger compartment, center, near front, at top of floor console, near the shift lever	*Center Console Components (MYB)*	*P2 Transmission Shift Lever Position Indicator*
P3	Backup Alarm	8S3	On the vehicle exterior, at the right rear of the vehicle, near the right rear wheel speed sensor breakout	• *Underbody Components (LWN) (6 of 6)* • *Chassis Components (Crew Cab)* • *Chassis Components (Extended Cab)*	*P3 Backup Alarm (8S3)*
P7	Display	—	In the passenger compartment, front center, mounted to instrument panel, part of info display module	—	—
P9	Driver Information Center Display	—	In the passenger compartment, left center, mounted to instrument panel, part of instrument cluster	—	• *P9 Driver Information Center Display X1* • *P9 Driver Information Center Display X2*
P13	Horn Assembly	—	In the engine compartment, lower left corner of the radiator support	*Right Front of Engine Compartment Components*	*P13 Horn Assembly*
P14	Passenger Air Bag Disabled Indicator	—	In the passenger compartment, center of the overhead console	• *Headliner Components (Crew Cab)* • *Headliner Components (Extended Cab)*	*P14 Passenger Air Bag Disabled Indicator*
P16	Instrument Cluster	—	In the passenger compartment, at the top of the driver side of the instrument panel, above the steering column	*Front of the Instrument Panel Components*	• *P16 Instrument Cluster (UDC)* • *P16 Instrument Cluster (UDD)*

P17	Info Display Module	—	In the passenger compartment, at the top center of the instrument panel, above the radio controls	*Front of the Instrument Panel Components*	• *P17 Info Display Module X1* • *P17 Info Display Module X3*
P19AG	Speaker - Left Front Door	—	In the passenger compartment, at the front of the left front door, behind the door trim panel	*Driver Door Components*	*P19AG Speaker - Left Front Door*
P19AH	Speaker - Right Front Door	—	In the passenger compartment, at the front of the right front door, behind the door trim panel	*Passenger Door Components*	*P19AH Speaker - Right Front Door*
P19AL	Speaker - Left Rear Door	—	In the passenger compartment, in the lower left rear door, behind the door panel	• *Left Rear Door Components (Extended Cab)* • *Left Rear Door Components (Crew Cab)*	*P19AL Speaker - Left Rear Door*
P19AM	Speaker - Right Rear Door	—	In the passenger compartment, in the lower right rear door, behind the door panel	• *Right Rear Door Components (Extended Cab)* • *Right Rear Door Components (Crew Cab)*	*P19AM Speaker - Right Rear Door*
P19B	Speaker - Center Instrument Panel	UQA	In the passenger compartment, center of the instrument panel	*Front of the Instrument Panel Components*	*P19B Speaker - Center Instrument Panel*
P19H	Speaker - Left Front Tweeter	—	In the passenger compartment, in the upper left of the instrument panel	*Front of the Instrument Panel Components*	• *P19H Speaker - Left Front Tweeter X1 (-UQA)* • *P19H Speaker - Left Front Tweeter X2 (UQA)*
P19V	Speaker - Right Front Tweeter	—	In the passenger compartment, in the upper right of the instrument panel	*Front of the Instrument Panel Components*	• *P19V Speaker - Right Front Tweeter X1 (UQA)* • *P19V Speaker - Right Front Tweeter X2 (-UQA)*
P43	Collision Alert Indicators	UEU	In the passenger compartment, behind the upper left of the instrument panel, above the instrument cluster	*Behind the Instrument Panel Components*	*P43 Collision Alert Indicators*
Q2	A/C Compressor Clutch	—	In the engine compartment, on the lower left front of the engine	• *Left Front of the Engine Components (LWN)* • *Left Front of the Engine Components (LGZ)* • *Left Front of the Engine Components (LCV)*	*Q2 A/C Compressor Clutch*
Q5	Brake Pressure Modulator	—	In the engine compartment, right rear, behind strut tower, attached to the electronic brake control module	—	—
Q6A	Camshaft Position Actuator Solenoid Valve - Bank 1 Exhaust	LGZ	In the engine compartment, near front, right of center, below of the bank 1 exhaust camshaft position sensor	*Left Front of the Engine Components (LGZ)*	*Q6A Camshaft Position Actuator Solenoid Valve - Bank 1 Exhaust (LFX)*
Q6B	Camshaft Position Actuator Solenoid Valve - Bank 1 Intake	LGZ	In the engine compartment, near front, right of center, between the bank 1 camshaft position sensors	*Left Front of the Engine Components (LGZ)*	*Q6B Camshaft Position Actuator Solenoid Valve - Bank 1 Intake (LFX)*
Q6C	Camshaft Position Actuator Solenoid Valve - Bank 2 Exhaust	LGZ	In the engine compartment, near front, left of center, below of the bank 2 exhaust camshaft position sensor	*Left Front of the Engine Components (LGZ)*	*Q6C Camshaft Position Actuator Solenoid Valve - Bank 2 Exhaust*

Q6D	Camshaft Position Actuator Solenoid Valve - Bank 2 Intake	LGZ	In the engine compartment, near front, left of center, between the bank 2 camshaft position sensors	*Left Front of the Engine Components (LGZ)*	*Q6D Camshaft Position Actuator Solenoid Valve - Bank 2 Intake*
Q6E	Camshaft Position Actuator Solenoid Valve - Exhaust	LCV	In the engine compartment, front, left of center, mounted to camshaft cover on left side	*Left Front of the Engine Components (LCV)*	*Q6E Camshaft Position Actuator Solenoid Valve - Exhaust (LCV)*
Q6F	Camshaft Position Actuator Solenoid Valve - Intake	LCV	In the engine compartment, front, right of center, mounted to camshaft cover on right side	*Top of Engine Components (LCV)*	*Q6F Camshaft Position Actuator Solenoid Valve - Intake*
Q8	Control Solenoid Valve Assembly	MYB	Underneath the vehicle, inside the automatic transmission assembly	*Automatic Transmission Components (MYB with NQ6/NQ7)*	*Q8 Control Solenoid Valve Assembly*
Q12	Evaporative Emission Purge Solenoid Valve	LCV	In the engine compartment, right side, on the intake manifold cylinder 1	*Right Rear of Engine Components (LCV)*	*Q12 Evaporative Emission Purge Solenoid Valve*
Q12	Evaporative Emission Purge Solenoid Valve	LGZ	In the engine compartment, right side, top front of engine, near throttle body	*Right Rear of Engine Components (LGZ)*	*Q12 Evaporative Emission Purge Solenoid Valve*
Q13	Evaporative Emission Vent Solenoid Valve	—	On the underbody, at the top left side of the fuel tank on the evaporative emissions canister	● *Chassis Components (Crew Cab)* ● *Chassis Components (Extended Cab)*	*Q13 Evaporative Emission Vent Solenoid Valve*
Q14	Exhaust Gas Recirculation Valve	LWN	In the engine compartment, right rear of engine, near intake manifold	*Left Front of the Engine Components (LWN)*	*Q14 Exhaust Gas Recirculation Valve*
Q17A	Fuel Injector 1	LCV/LWN	In the engine compartment, right of center, near front, mounted to the cylinder head at cylinder 1	● *Right Top of Engine Components (LCV)* ● *Right Rear of Engine Components (LWN)*	*Q17A Fuel Injector 1*
Q17A	Fuel Injector 1	LGZ	In the engine compartment, near middle front, on the inboard side of bank 1 cylinder head, above cylinder 1	*Top of Engine Components (LGZ)*	*Q17A Fuel Injector 1*
Q17B	Fuel Injector 2	LCV/LWN	In the engine compartment, right of center, near middle, mounted to the cylinder head at cylinder 2	● *Right Top of Engine Components (LCV)* ● *Right Rear of Engine Components (LWN)*	*Q17B Fuel Injector 2*
Q17B	Fuel Injector 2	LGZ	In the engine compartment, near middle front, on the inboard side of bank 2 cylinder head, above cylinder 2	*Top of Engine Components (LGZ)*	*Q17B Fuel Injector 2*
Q17C	Fuel Injector 3	LCV/LWN	In the engine compartment, right of center, near middle, mounted to the cylinder head at cylinder 3	● *Right Top of Engine Components (LCV)* ● *Right Rear of Engine Components (LWN)*	*Q17C Fuel Injector 3*
Q17C	Fuel Injector 3	LGZ	In the engine compartment, near middle, on the inboard side of bank 1 cylinder head, above cylinder 3	*Top of Engine Components (LGZ)*	*Q17C Fuel Injector 3*
Q17D	Fuel Injector 4	LCV/LWM	In the engine compartment, right of center, near rear, mounted to the cylinder head at cylinder 4	● *Top of Engine Components (LGZ)* ● *Right Top of Engine Components (LCV)*	*Q17D Fuel Injector 4*
Q17D	Fuel Injector 4	LGZ	In the engine compartment, near middle, on the inboard side of bank 2 cylinder head, above cylinder 4	*Right Top of Engine Components (LCV)*	*Q17D Fuel Injector 4*

Q17E	Fuel Injector 5	LGZ	In the engine compartment, near middle rear, on the inboard side of bank 1 cylinder head, above cylinder 5	*Top of Engine Components (LGZ)*	—
Q17F	Fuel Injector 6	LGZ	In the engine compartment, near middle rear, on the inboard side of bank 2 cylinder head, above cylinder 6	*Top of Engine Components (LGZ)*	—
Q18A	Fuel Pressure Regulator 1	LWN	In the engine compartment, lower left of engine, attached to fuel injection pump	*Left Front of the Engine Components (LWN)*	*Q18A Fuel Pressure Regulator 1*
Q18B	Fuel Pressure Regulator 2	LWN	In the engine compartment, left of engine, between throttle body and cylinder head	*Left Front of the Engine Components (LWN)*	*Q18B Fuel Pressure Regulator 2*
Q27A	Pressure Control Solenoid Valve 1	MYB	Under the vehicle, inside the automatic transmission, part of the control solenoid valve assembly	—	—
Q27B	Pressure Control Solenoid Valve 2	MYB	Under the vehicle, inside the automatic transmission, part of the control solenoid valve assembly	—	—
Q27C	Pressure Control Solenoid Valve 3	MYB	Under the vehicle, inside the automatic transmission, part of the control solenoid valve assembly	—	—
Q27D	Pressure Control Solenoid Valve 4	MYB	Under the vehicle, inside the automatic transmission, part of the control solenoid valve assembly	—	—
Q27E	Pressure Control Solenoid Valve 5	MYB	Under the vehicle, inside the automatic transmission, part of the control solenoid valve assembly	—	—
Q32A	Shift Solenoid Valve 1	MYB	Under the vehicle, inside the automatic transmission, part of the control solenoid valve assembly	—	—
Q32B	Shift Solenoid Valve 2	MYB	Under the vehicle, inside the automatic transmission, part of the control solenoid valve assembly	—	—
Q38	Throttle Body	LCV	In the engine compartment, front, mounted to the right side of the intake manifold	*Top of Engine Components (LCV)*	• *Q38 Throttle Body (JL1-LCV)* • *Q38 Throttle Body (-LWN)*
Q38	Throttle Body	LGZ	In the engine compartment, center, mounted to the right side of the intake manifold	*Left Front of the Engine Components (LGZ)*	• *Q38 Throttle Body (JL1-LCV)* • *Q38 Throttle Body (-LWN)*
Q38	Throttle Body	LWN	In the engine compartment, top left of engine, mounted to the intake manifold	*Left Front of the Engine Components (LWN)*	• *Q38 Throttle Body (JL1-LCV)* • *Q38 Throttle Body (-LWN)*
Q39A	Torque Converter Clutch Pressure Control Solenoid Valve	MYB	Under the vehicle, inside the automatic transmission, part of the control solenoid valve assembly	—	—
Q44	Engine Oil Pressure Control Solenoid Valve	LCV	In the engine compartment, left rear, on side of the engine block	*Right Rear of Engine Components (LCV)*	• *Q44 Engine Oil Pressure Control Solenoid Valve (LCV)* • *Q44 Engine Oil Pressure Control Solenoid Valve (LGZ)*

Q46	A/C Compressor Solenoid Valve	—	In the engine compartment, front, bottom left of the engine, internal to the A/C compressor	• *Left Front of the Engine Components (LGZ)* • *Left Front of the Engine Components (LWN)* • *Left Front of the Engine Components (LCV)*	*Q46 A/C Compressor Solenoid Valve*
Q47	Exhaust Gas Recirculation Cooler Bypass Solenoid Valve	LWN	In the engine compartment, top of cylinder head, near front of the engine, right of the oil filler neck	*Right Bottom of Engine Components (LWN)*	*Q47 Exhaust Gas Recirculation Cooler Bypass Solenoid Valve*
Q61	Reductant Injector	LWN	On the underbody, right, mounted to the inlet side of the nitrogen oxides catalytic converter	*Underbody Components (LWN) (1 of 6)*	*Q61 Reductant Injector*
Q67	Exhaust Aftertreatment Fuel Injector	LWN	On the underbody, center of vehicle, mounted to the inboard side of the right frame rail	*Underbody Components (LWN) (2 of 6)*	*Q67 Exhaust Aftertreatment Fuel Injector*
Q85	Cooling Fan Clutch	LWN	At the front of the engine compartment, on center shaft of cooling fan assembly	*Left Side of Engine Components (LWN)*	—
R6A	Terminating Resistor - High Speed Bus	Crew Cab	Under the vehicle, rear right side, taped in the harness above the spare tire and across from the chassis control module	*Chassis Components (Crew Cab)*	*R6A Terminating Resistor - High Speed Bus*
R6A	Terminating Resistor - High Speed Bus	Extended Cab	Under the vehicle, left side, under second row seat, rear of vehicle, taped in the harness near the chassis control module	*Chassis Underbody Components (Extended Cab)*	*R6A Terminating Resistor - High Speed Bus*
R10	Cooling Fan Resistor	LWN	In the engine compartment, left, on battery tray in front of the battery	*Left Side of Engine Compartment Components*	*R10 Cooling Fan Resistor*
S2A	Transmission Manual Shift Switch - Up/Down	MYB	In the passenger compartment, part of the transmission shift lever	*Center Console Components (MYB)*	—
S3	Transmission Shift Lever	MYB	In the passenger compartment, center near front, within the floor console	*Center Console Components (MYB)*	*S3 Transmission Shift Lever*
S13D	Door Lock Switch - Driver	ATG	On driver door, upper, forward of the release handle on the door trim	*Driver Door Components*	*S13D Door Lock Switch - Driver*
S13P	Door Lock Switch - Passenger	ATG	On passenger door, upper, forward of the release handle on the door trim	*Passenger Door Components*	*S13P Door Lock Switch - Passenger*
S30	Headlamp Switch	—	In the passenger compartment, left of the steering column	*Front of the Instrument Panel Components*	*S30 Headlamp Switch*
S32D	Seat Heating Switch - Driver	KA1	In the passenger compartment, at the lower center of the instrument panel, below the HVAC controls	*Front of the Instrument Panel Components*	*S32D Seat Heating Switch - Driver*
S32P	Seat Heating Switch - Passenger	KA1	In the passenger compartment, at the lower center of the instrument panel, below the HVAC controls	*Front of the Instrument Panel Components*	*S32P Seat Heating Switch - Passenger*
S33	Horn Switch	—	In the passenger compartment, in the center of the steering wheel, behind the driver side air bag	—	—
S39	Ignition Switch	—	In the passenger compartment, behind the steering wheel, on the right side of the steering column	*Front of the Instrument Panel Components*	*S39 Ignition Switch*
S48A	Multifunction Switch - Instrument Panel	—	In the passenger compartment, in the center of the instrument panel, below the HVAC controls	*Front of the Instrument Panel Components*	*S48A Multifunction Switch - Instrument Panel*

S51	Telematics Button Assembly	UE1	In the passenger compartment, part of the inside rearview mirror	—	—
S52	Outside Rearview Mirror Switch	DL6/DL9	In the passenger compartment, on the driver door trim panel	*Driver Door Components*	*S52 Outside Rearview Mirror Switch*
S64D	Seat Adjuster Switch - Driver	—	In the passenger compartment, mounted to the outboard side of the driver seat cushion	*Driver Seat Components*	—
S64P	Seat Adjuster Switch - Passenger	AAQ	In the passenger compartment, mounted to the outboard side of the passenger seat cushion	*Passenger Seat Components*	—
S70E	Steering Wheel Controls Switch - Radio Presets	W1Y	In the passenger compartment, on the left rear side of the steering wheel	*Steering Column Components*	—
S70F	Steering Wheel Controls Switch - Radio Volume	W1Y	In the passenger compartment, on the right rear side of the steering wheel	*Steering Column Components*	—
S70L	Steering Wheel Controls Switch - Left	—	In the passenger compartment, on the left side of the steering wheel	*Steering Column Components*	—
S70R	Steering Wheel Controls Switch - Right	—	In the passenger compartment, on the right side of the steering wheel	*Steering Column Components*	—
S76	Trailer Brake Control Switch	JL1	In the passenger compartment, left of the steering column	*Front of the Instrument Panel Components*	*S76 Trailer Brake Control Switch*
S77	Transfer Case Shift Control Switch	NQ6/NQ7	In the passenger compartment, left of the steering column	*Front of the Instrument Panel Components*	*S77 Transfer Case Shift Control Switch*
S78	Turn Signal/Multifunction Switch	—	In the passenger compartment, on the left side of the steering column	• *Steering Column Components* • *Front of the Instrument Panel Components*	*S78 Turn Signal/Multifunction Switch*
S79D	Window Switch - Driver	—	In the passenger compartment, on the driver door trim panel, center of the door	*Driver Door Components*	*S79D Window Switch - Driver*
S79LR	Window Switch - Left Rear	Crew Cab	In the passenger compartment, at the center of the left rear door, on the door trim panel	*Left Rear Door Components (Crew Cab)*	—
S79P	Window Switch - Passenger	—	In the passenger compartment, on the passenger door trim panel, center of the door	*Passenger Door Components*	*S79P Window Switch - Passenger*
S79RR	Window Switch - Right Rear	Crew Cab	In the passenger compartment, at the center of the right rear door, on the door trim panel	*Right Rear Door Components (Crew Cab)*	—
S82	Windshield Wiper/Washer Switch	—	In the passenger compartment, on the right side of the steering column	• *Steering Column Components* • *Front of the Instrument Panel Components*	*S82 Windshield Wiper/Washer Switch*
T2	Antenna	—	In the passenger compartment, part of the remote control door lock receiver	—	—
T3	Audio Amplifier	UQA	In the rear passenger compartment, mounted behind the glove box	*Behind the Instrument Panel Components*	• *T3 Audio Amplifier X1* • *T3 Audio Amplifier X2* • *T3 Audio Amplifier X3* • *T3 Audio Amplifier X4*
T4G	Cellular Phone, Navigation, and Digital Radio Antenna	UE1	Outside the vehicle, at the rear of the roof	*Rear of Vehicle Components*	*T4G Cellular Phone, Navigation, and Digital Radio Antenna*

T4H	Digital Radio Antenna	U2M	Outside the vehicle, at the rear of the roof	—	*T4H Digital Radio Antenna*
T4M	Radio Antenna	—	Outside the vehicle, at the rear of the roof	—	—
T4S	Wireless Communication Antenna - Bluetooth	VV4	In the passenger compartment, right side of the instrument panel, behind the glove box, attached to the telematics communication interface control module	—	—
T8A	Ignition Coil 1	LCV	In the engine compartment, center near front, mounted to cylinder head, above cylinder 1	*Top of Engine Components (LCV)*	• *T8A Ignition Coil 1 (LCV)* • *T8A Ignition Coil 1 (LGZ)*
T8A	Ignition Coil 1	LGZ	In the engine compartment, right of center, near middle, above cylinder 1	*Top of Engine Components (LGZ)*	• *T8A Ignition Coil 1 (LCV)* • *T8A Ignition Coil 1 (LGZ)*
T8B	Ignition Coil 2	LCV	In the engine compartment, center near middle, mounted to cylinder head, above cylinder 2	*Top of Engine Components (LCV)*	• *T8B Ignition Coil 2 (LCV)* • *T8B Ignition Coil 2 (LGZ)*
T8B	Ignition Coil 2	LGZ	In the engine compartment, left of center, near middle, above cylinder 2	*Top of Engine Components (LGZ)*	• *T8B Ignition Coil 2 (LCV)* • *T8B Ignition Coil 2 (LGZ)*
T8C	Ignition Coil 3	LCV	In the engine compartment, center near middle, mounted to cylinder head, above cylinder 3	*Top of Engine Components (LCV)*	• *T8C Ignition Coil 3 (LCV)* • *T8C Ignition Coil 3 (LGZ)*
T8C	Ignition Coil 3	LGZ	In the engine compartment, right of center, near middle, above cylinder 3	*Top of Engine Components (LGZ)*	• *T8C Ignition Coil 3 (LCV)* • *T8C Ignition Coil 3 (LGZ)*
T8D	Ignition Coil 4	LCV	In the engine compartment, center near rear, mounted to cylinder head, above cylinder 4	*Top of Engine Components (LCV)*	• *T8D Ignition Coil 4 (LCV)* • *T8D Ignition Coil 4 (LGZ)*
T8D	Ignition Coil 4	LGZ	In the engine compartment, left of center, near middle, above cylinder 4	*Top of Engine Components (LGZ)*	• *T8D Ignition Coil 4 (LCV)* • *T8D Ignition Coil 4 (LGZ)*
T8E	Ignition Coil 5	LGZ	In the engine compartment, right of center, near rear, above cylinder 5	*Top of Engine Components (LGZ)*	*T8E Ignition Coil 5*
T8F	Ignition Coil 6	LGZ	In the engine compartment, left of center, near rear, above cylinder 6	*Top of Engine Components (LGZ)*	*T8F Ignition Coil 6*
T12	Automatic Transmission Assembly	MYB	In the engine compartment, underneath the first row seating, rear of the engine	—	*T12 Automatic Transmission Assembly X1*
T15	Navigation Antenna Signal Splitter	IO6	In the passenger compartment, above carpet in the right front footwell, near right front kick panel	• *Right Passenger Components (Extended Cab)* • *Right Passenger Components (Crew Cab)*	• *T15 Navigation Antenna Signal Splitter X1* • *T15 Navigation Antenna Signal Splitter X2* • *T15 Navigation Antenna Signal Splitter X3*
W8	Blunt Cut - Trailer Provision	—	Outside of the vehicle, at the rear, inboard of the left frame rail	—	—

W24	Blunt Cut - Trailer Brakes Provision	Z82	In the passenger compartment, behind the left front kick panel, taped to the harness next to X200 and X202	—	—
W26	Blunt Cut - Cargo Lamp Provision	S0Y	At rear of vehicle, in left tail lamp breakout	—	—
X50A	Fuse Block - Underhood	—	In the engine compartment, forward left of the engine, next to the battery	*Left Side of Engine Compartment Components*	Electrical Center Identification Views
X50D	Fuse Block - Battery	—	In the engine compartment, left front, on top of the battery (+) post	*Left Side of Engine Compartment Components*	Electrical Center Identification Views
X51A	Fuse Block - Instrument Panel	—	In the passenger compartment, below right side of the instrument panel, behind access cover on right front kick panel	• *Right Passenger Components (Extended Cab)* • *Right Passenger Components (Crew Cab)*	Electrical Center Identification Views
X80A	Accessory Power Receptacle - Center Console 1	—	In the passenger compartment, at the forward left of the center console	• *Front of the Instrument Panel Components* • *Center Console Components (N8D)*	*X80A Accessory Power Receptacle - Center Console 1*
X80B	Accessory Power Receptacle - Center Console 2	—	In the passenger compartment, at the rear of the center console	• *Center Console Components (MYB)* • *Center Console Components (N8D)*	*X80B Accessory Power Receptacle - Center Console 2*
X83R	Auxiliary Audio Input - Rear	IO5/IO6	In the passenger compartment, at the rear of the center console	*Center Console Components (MYB)*	• *X83R Auxiliary Audio Input - Rear X1 (IO5/IO6)* • *X83R Auxiliary Audio Input - Rear X2 (IO5/IO6)* • *X83R Auxiliary Audio Input - Rear X3 (IO5/IO6)*
X83	Auxiliary Audio Input	IO3/IO4 with N8D	In the passenger compartment, in the center console	*Center Console Components (N8D)*	• *X83 Auxiliary Audio Input X1 ((IO3)(MYB))* • *X83 Auxiliary Audio Input X1 ((IO4/IO5/IO6)(MYB))* • *X83 Auxiliary Audio Input X2 ((IO3)(MYB))* • *X83 Auxiliary Audio Input X2 ((IO4/IO5/IO6)(MYB))*
X83	Auxiliary Audio Input	IO3/IO4/IO5/IO6 with MYB	In the passenger compartment, in center of instrument panel, forward of the center floor console	*Front of the Instrument Panel Components*	• *X83 Auxiliary Audio Input X1 ((IO3)(MYB))* • *X83 Auxiliary Audio Input X1 ((IO4/IO5/IO6)(MYB))* • *X83 Auxiliary Audio Input X2 ((IO3)(MYB))* • *X83 Auxiliary Audio Input X2 ((IO4/IO5/IO6)(MYB))*
X84	Data Link Connector	—	In the passenger compartment, under the driver side of the instrument panel	—	*X84 Data Link Connector*

X85	Steering Wheel Air Bag Coil	—	In the passenger compartment, behind the steering wheel, in the upper steering column	*Steering Column Components*	• *X85 Steering Wheel Air Bag Coil X1* • *X85 Steering Wheel Air Bag Coil X2* • *X85 Steering Wheel Air Bag Coil X3*
X88	Trailer Connector	Z82	On the vehicle exterior, at the rear of the vehicle, left of the license plate	*Rear of Vehicle Components*	*X88 Trailer Connector*
X92	USB Receptacle	IO5/IO6	In the passenger compartment, right front of the center console storage bin	*Center Console Components (MYB)*	*X92 USB Receptacle (IO5/IO6)*
X100	Power Steering Harness to Battery Harness (4 cavities)	—	Outside of the vehicle, left front of the front frame crossmember, next to X103	*Body Harness Routing - Center Engine Compartment*	*X100 Battery Negative Harness to Power Steering Harness*
X101	Engine Harness to Body Harness (48 cavities)	—	In the engine compartment, left front of engine, near underhood fuse block next to X102	• *Body Harness Routing - Left Engine Compartment (LWN)* • *Engine Harness Routing - Left Front (LCV)* • *Body Harness Routing - Left Engine Compartment (LCV/LGZ)* • *Engine Harness Routing - Front (LGZ)*	*X101 Engine Harness to Body Harness (NQ6+LCV/LWN)*
X102	Forward Lamp Harness to Body Harness (48 cavities)	—	In the engine compartment, left front, at left headlamp assembly, in front of underhood fuse block next to X101	• *Forward Lamp Harness Routing - Left Engine Compartment* • *Forward Lamp Harness Routing - Left Engine Compartment (LWN)* • *Body Harness Routing - Left Engine Compartment (LWN)* • *Body Harness Routing - Left Engine Compartment (LCV/LGZ)*	*X102 Forward Lamp Harness to Body Harness*
X103	Chassis Harness to Power Steering Harness (16 cavities)	—	Outside of the vehicle, left front of the front frame crossmember, next to X100	• *Chassis Harness Routing (LWN)* • *Body Harness Routing - Center Engine Compartment* • *Chassis Harness Routing (Crew Cab)* • *Chassis Harness Routing (Extended Cab)*	*X103 Chassis Harness to Power Steering Harness*
X104	Forward Lamp Harness to Forward Lamp Extension Harness (2 cavities)	LCV	In the engine compartment, left front, near left radiator support	*Forward Lamp Harness Routing - Left Engine Compartment*	*X104 Forward Lamp Harness to Forward Lamp Extension Harness*
X105	Forward Lamp Harness to Ambient Temperature Sensor Extension Harness (6 cavities)	—	Outside of the vehicle, forward of left radiator support on front impact bar, below the left headlamp assembly	*Forward Lamp Harness Routing - Left Engine Compartment*	• *X105 Forward Lamp Harness to Ambient Temperature Sensor Extension Harness (LCV)* • *X105 Forward Lamp Harness to Ambient Temperature Sensor Extension Harness (LGZ)* • *X105 Forward Lamp Harness to Ambient Temperature Sensor Extension Harness (LWN)*

X106	Body Harness to Chassis Harness (48 cavities)	—	In the engine compartment, left of engine, near battery, rear of the underhood fuse block	• *Chassis Harness Routing (LWN)* • *Body Harness Routing - Left Engine Compartment (LWN)* • *Body Harness Routing - Left Engine Compartment (LCV/LGZ)* • *Chassis Harness Routing (Crew Cab)* • *Chassis Harness Routing (Extended Cab)*	• *X106 Body Harness to Chassis Harness (LWN)* • *X106 Body Harness to Chassis Harness (SWB)*
X107	Engine Harness to Chassis Harness (48 cavities)	LWN	In the engine compartment, right front, on frame at the right front shock	• *Chassis Harness Routing (LWN)* • *Engine Harness Routing - Right Rear (LWN)*	*X107 Engine Harness to Chassis Harness*
X108	Engine Harness to Cooling Fan Harness (6 cavities)	LWN	In the engine compartment, left front of engine, below the a/c compressor	*Engine Harness Routing - Left Front (LWN)*	*X108 Engine Harness to Cooling Fan Harness (LWN)*
X109	Engine Harness to Forward Lamp Harness (4 cavities)	LWN	In the engine compartment, left side of the cooling fan shroud	• *Engine Harness Routing - Left Front (LWN)* • *Forward Lamp Harness Routing - Left Engine Compartment (LWN)*	*X109 Engine Harness to Forward Lamp Harness*
X110	Forward Lamp Harness to Headlamp - Left Harness (6 cavities)	—	In the engine compartment, at the rear of the left headlamp assembly	• *Forward Lamp Harness Routing - Left Engine Compartment* • *Forward Lamp Harness Routing - Left Engine Compartment (LWN)*	*X110 Forward Lamp Harness to Left Front Lamp Harness*
X111	Engine Harness to Glow Plug Harness (4 cavities)	LWN	In the engine compartment, above engine, left front, near generator	*Engine Harness Routing - Top (LWN)*	*X111 Engine Harness to Glow Plug Harness (LWN)*
X112	Engine Harness to Intake Manifold Pressure Harness (4 cavities)	LWN	In the engine compartment, above engine, left front, near generator	*Engine Harness Routing - Top (LWN)*	—
X120	Forward Lamp Harness to Headlamp - Right Harness (6 cavities)	—	In the engine compartment, at the rear of the right headlamp assembly	*Forward Lamp Harness Routing - Right Engine Compartment*	*X120 Forward Lamp Harness to Right Front Lamp Harness*
X160	Engine Harness to Fuel Injector Harness (12 cavities)	LCV	In the engine compartment, right of center, forward of middle, mounted to intake manifold	*Engine Harness Routing - Right Front Top (LCV)*	• *X160 Engine Harness to Fuel Injector - Odd Harness (LGZ)* • *X160 Engine Harness to Fuel Injector Harness (LCV)*
X160	Engine Harness to Fuel Injector - Odd Harness (6 cavities)	LGZ	In the engine compartment, rear, right of center, behind right rear of cylinder head cover	*Engine Harness Routing - Rear (LGZ)*	• *X160 Engine Harness to Fuel Injector - Odd Harness (LGZ)* • *X160 Engine Harness to Fuel Injector Harness (LCV)*
X161	Engine Harness to Fuel Injector - Even Harness (12 cavities)	LGZ	In the engine compartment, rear, right of center, behind right rear of cylinder head cover	*Engine Harness Routing - Rear (LGZ)*	*X161 Engine Harness to Fuel Injector - Even Harness (LGZ)*
X175	Engine Harness to Transmission Harness	M5T	Under the vehicle, internal to the transmission assembly	—	*Left Front Tire and Wheel Replacement*
X176	Transmission Harness to Transmission Jumper	M5T	Under the vehicle, internal to the transmission assembly	—	—

X177	Transmission Harness to Transmission Jumper	M5T	Under the vehicle, internal to the transmission assembly	—	—
X200	Body Harness to Instrument Panel Harness (48 cavities)	—	In the passenger compartment, left side of the instrument panel, behind the left front kick panel, next to X202	• *Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)* • *Body Harness Routing - Left Front of Passenger Compartment (Extended Cab)* • *Instrument Panel Harness Routing - Rear*	*X200 Body Harness to Instrument Panel Harness*
X202	Body Harness to Instrument Panel Harness (44 cavities)	—	In the passenger compartment, left side of the instrument panel, behind the left front kick panel, next to X200	• *Body Harness Routing - Left Front of Passenger Compartment (Extended Cab)* • *Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)* • *Instrument Panel Harness Routing - Rear*	*X202 Body Harness to Instrument Panel Harness*
X203	Body Harness to Instrument Panel Harness (48 cavities)	—	In the passenger compartment, right side of the instrument panel, below instrument panel fuse block, behind right front kick panel	• *Instrument Panel Harness Routing - Rear* • *Body Harness Routing - Right Front of Passenger Compartment (Extended Cab)* • *Body Harness Routing - Right Front of Passenger Compartment (Crew Cab)*	*X203 Body Harness to Instrument Panel Harness*
X206	Instrument Panel Harness to HVAC Harness (2 cavities)	C68	In the passenger compartment, left of center, near left side of HVAC Assembly	*Instrument Panel Harness Routing - Rear*	*X206 Instrument Panel Harness to HVAC Harness*
X207	Instrument Panel Harness to Passenger Air Bag Extension Harness (6 cavities)	—	In the passenger compartment, at the top of the passenger side of the instrument panel, near passenger instrument panel air bag	*Instrument Panel Harness Routing - Rear*	—
X218	Instrument Panel COAX Harness to Body COAX Harness	U2M	In the passenger compartment, right side of the instrument panel, below instrument panel fuse block, behind right front kick panel	• *Body Harness Routing - Right Front of Passenger Compartment (Extended Cab)* • *Body Harness Routing - Right Front of Passenger Compartment (Crew Cab)* • *Instrument Panel Harness Routing - Rear*	*X218 Instrument Panel Harness to Body Harness (UK2)*
X219	Instrument Panel COAX Harness to Body COAX Harness	Except U2M	In the passenger compartment, right side of the instrument panel, below instrument panel fuse block, behind right front kick panel	• *Body Harness Routing - Right Front of Passenger Compartment (Crew Cab)* • *Instrument Panel Harness Routing - Rear* • *Body Harness Routing - Right Front of Passenger Compartment (Extended Cab)*	*X219 Instrument Panel Harness to Body Harness*

X220	Instrument Panel COAX Harness to Body COAX Harness	IO6	In the passenger compartment, right side of the instrument panel, below instrument panel fuse block, behind right front kick panel	• *Instrument Panel Harness Routing - Rear* • *Body Harness Routing - Right Front of Passenger Compartment (Crew Cab)* • *Body Harness Routing - Right Front of Passenger Compartment (Extended Cab)*	*X220 Instrument Panel Harness to Body Harness (IO6)*
X299	Instrument Panel Harness to Instrument Panel Harness (2 cavities)	EARLY_PRODUCTION	In the passenger compartment, below the lower left side of the instrument panel, taped to harness above the data link connector	*Instrument Panel Harness Routing - Rear*	*X299 Instrument Panel Harness to Instrument Panel Harness*
X300	Headliner Harness to Body Harness (16 cavities)	—	In the passenger compartment , top right instrument panel, at the A-pillar	• *Body Harness Routing - Right Front of Passenger Compartment (Extended Cab)* • *Body Harness Routing - Right Front of Passenger Compartment (Crew Cab)* • *Headliner Harness Routing (Crew Cab)* • *Headliner Harness Routing (Extended Cab)*	*X300 Headliner Harness to Body Harness*
X301	Headliner Harness to Body Harness (22 cavities)	—	In the passenger compartment , rear of cab roof, at center high mounted stop lamp	• *Body Harness Routing - Left Rear of Passenger Compartment (Extended Cab)* • *Body Harness Routing - Left Rear of Passenger Compartment (Crew Cab)* • *Headliner Harness Routing (Crew Cab)* • *Headliner Harness Routing (Extended Cab)*	*X301 Headliner Harness to Body Harness*
X302	Floor Console USB Harness to Instrument Panel USB Harness	—	In the passenger compartment, right of center, under front of the center console	*Center Console Harness Routing*	*X302 Floor Console Harness to Instrument Panel Harness*
X302	Floor Console USB Harness to Instrument Panel USB Harness	—	In the passenger compartment, right of center, under front of the center console	*Center Console Harness Routing*	*X302 Floor Console Harness to Instrument Panel Harness*
X303	Body Harness to CHMSL Harness (3 cavities)	—	In the passenger compartment , rear of cab roof, at center high mounted stop lamp	• *Body Harness Routing - Left Rear of Passenger Compartment (Extended Cab)* • *Body Harness Routing - Left Rear of Passenger Compartment (Crew Cab)*	*X303 Body Harness to CHMSL Harness*
X304	Windshield Sensor Harness to Headliner Harness (6 cavities)	C68	In the passenger compartment, behind the inside rearview mirror, near the windshield	• *Headliner Harness Routing (Crew Cab)* • *Headliner Harness Routing (Extended Cab)*	—
X305	Instrument Panel Harness to Floor Console Harness (14 cavities)	—	In the passenger compartment, left of center, beneath the instrument panel, under front of the center console	• *Instrument Panel Harness Routing - Rear* • *Center Console Harness Routing*	*X305 Instrument Panel Harness to Floor Console Harness*
X306	Instrument Panel Harness to Floor Console Harness (8 cavities)	MYB	In the passenger compartment, right of center, under front of the center console	*Center Console Harness Routing*	*X306 Instrument Panel Harness to Floor Console Harness*

X310	Driver Seat Cushion Harness to Body Harness (23 cavities)	—	In the passenger compartment, under the driver seat	• *Body Harness Routing - Left Front of Passenger Compartment (Extended Cab)* • *Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)* • *Driver Seat Harness Routing*	*X310 Driver Seat Cushion Harness to Body Harness*
X320	Passenger Seat Cushion Harness to Body Harness (23 cavities)	—	In the passenger compartment, under the passenger seat	• *Passenger Seat Harness Routing* • *Body Harness Routing - Right Front of Passenger Compartment (Extended Cab)* • *Body Harness Routing - Right Front of Passenger Compartment (Crew Cab)*	*X320 Passenger Seat Cushion Harness to Body Harness*
X400	Chassis Harness to License Lamp Harness (10 cavities)	—	Outside of vehicle, under left rear, inboard of the left frame rail, rearward of the left rear leaf spring mount	• *Chassis Harness Routing (Crew Cab)* • *Rear License Plate Harness Routing* • *Chassis Harness Routing (LWN)*	*X400 Chassis Harness to License Lamp Harness (X88/Z88)*
X401	Chassis Harness to Cargo Lamp Harness (2 cavities)	S0Y	At left rear of vehicle, under the bed next to X410	• *Chassis Harness Routing (S0Y)* • *Chassis Harness Routing (LWN)*	*X401 Cargo Lamp Harness to Chassis Harness*
X410	Tail Lamp - Left Harness to Chassis Harness (6 cavities)	—	At left rear of vehicle, under bed, at the left rear bed rail	• *Chassis Harness Routing (Extended Cab)* • *Chassis Harness Routing (Crew Cab)* • *Chassis Harness Routing (LWN)*	*X410 Tail Lamp - Left Harness to Chassis Harness*
X420	Tail Lamp - Right Harness to Chassis Harness (6 cavities)	—	At right rear of vehicle, under bed, at the right rear bed rail	• *Chassis Harness Routing (Extended Cab)* • *Chassis Harness Routing (Crew Cab)* • *Chassis Harness Routing (LWN)*	*X420 Tail Lamp - Right Harness to Chassis Harness*
X500	Body Harness to Driver Door Harness (34 cavities)	—	In the passenger compartment, left front, in the left front door opening, between hinges on door side	• *Driver Door Harness Routing* • *Body Harness Routing - Left Front of Passenger Compartment (Extended Cab)* • *Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)*	*X500 Body Harness to Driver Door Harness*
X510	Driver Outside Rearview Mirror Harness to Driver Door Harness (10 cavities)	—	At side of vehicle, front of the driver door, behind the door trim on the door	*Driver Door Harness Routing*	*X510 OSRVM Harness to Driver Door Harness*
X600	Body Harness to Passenger Door Harness (34 cavities)	—	In the passenger compartment, right front, in the right front door opening, between hinges on door side	• *Passenger Door Harness Routing* • *Body Harness Routing - Right Front of Passenger Compartment (Extended Cab)* • *Body Harness Routing - Right Front of Passenger Compartment (Crew Cab)*	*X600 Body Harness to Passenger Door Harness*
X610	Passenger Outside Rearview Mirror Harness to Passenger Door Harness (10 cavities)	—	At side of vehicle, front of the passenger door, behind the door trim on the door	*Passenger Door Harness Routing*	*X610 OSRVM Harness to Passenger Door Harness*

X700	Left Rear Door Harness to Body Harness (12 cavities)	Crew Cab	In the passenger compartment, behind the left B-pillar, near the middle	• Left Rear Door Harness Routing (Crew Cab) • Body Harness Routing - Left Rear of Passenger Compartment (Crew Cab)	• X700 Left Rear Door Harness to Body Harness (AXG) • X700 Left Rear Door Harness to Body Harness (UQA)
X700	Left Rear Door Harness to Body Harness (20 cavities)	Extended Cab	In the passenger compartment, behind the left side rear trim panel	• Left Rear Door Harness Routing (Exended Cab) • Body Harness Routing - Left Rear of Passenger Compartment (Extended Cab)	• X700 Left Rear Door Harness to Body Harness (AXG) • X700 Left Rear Door Harness to Body Harness (UQA)
X800	4507318	Crew Cab	In the passenger compartment, behind the right B-pillar, near the middle	• Right Rear Door Harness Routing (Crew Cab) • Body Harness Routing - Right Front of Passenger Compartment (Crew Cab)	• X800 Right Rear Door Harness to Body Harness (AXG) • X800 Right Rear Door Harness to Body Harness (UQA)
X800	Right Rear Door Harness to Body Harness (20 cavities)	Extended Cab	In the passenger compartment, behind the right side rear trim panel	• Body Harness Routing - Right Rear of Passenger Compartment (Extended Cab) • Right Rear Door Harness Routing (Extended Cab)	• X800 Right Rear Door Harness to Body Harness (AXG) • X800 Right Rear Door Harness to Body Harness (UQA)
G100	Battery Negative Harness	—	In the engine compartment, left front, below front of underhood fuse block	G100 and G101	—
G101	Battery Negative Harness	—	In the engine compartment, left side, on frame at left front frame cross rail	G100 and G101	—
G102	Battery Negative Harness	LCV	In the engine compartment, on the left side of engine block, near the oil filter	G102 (LCV)	—
G102	Battery Negative Harness	LGZ	In the engine compartment, on the left side of engine block, near the starter	G102 (LGZ)	—
G102	Engine Harness	LWN	In the engine compartment, on the left rear of the cylinder head	—	—
G103	Forward Lamp Harness	LCV/LGZ	In the engine compartment, beneath the left headlamp assembly, mounted to the radiator support	G103 (LCV/LGZ), G105 (LWN)	—
G103	Forward Lamp Harness	LWN	In the engine compartment, beneath the right headlamp assembly, mounted to the radiator support	G103 (LWN), G105 (LCV/LGZ)	—
G105	Forward Lamp Harness	LCV/LGZ	In the engine compartment, beneath the right headlamp assembly, mounted to the radiator support	G103 (LCV/LGZ), G105 (LWN)	—
G105	Forward Lamp Harness	LWN	In the engine compartment, beneath the left headlamp assembly, mounted to the radiator support	G103 (LWN), G105 (LCV/LGZ)	—
G107	Engine Harness	LCV	In the engine compartment, on the right side of the engine block, rear of generator	G107 (LCV)	—
G107	Engine Harness	LGZ	In the engine compartment, on the right of the engine block, above the generator	G107 and G108 (LGZ)	—
G107	Engine Harness	LWN	In the engine compartment, on the right rear of the cylinder head	G107 (LWN)	—

G108	Engine Harness	LCV	In the engine compartment, on the rear of the engine block	*G108 (LCV)*	—
G108	Engine Harness	LGZ	In the engine compartment, on the right side of the engine block, rear of the generator	*G107 and G108 (LGZ)*	—
G109	Engine Harness	LGZ	In the engine compartment, on the left front of the engine block, beneath cylinder one	*G109 (LGZ)*	—
G300	Instrument Panel Harness	—	In the passenger compartment, center, beneath the floor console, rear of floor shifter	*G300, G305, and G307*	—
G301	Body harness	—	In the passenger compartment, under the driver seat on the floor pan	• *G301 and G303 (LWN)* • *G301 and G303*	—
G302	Body Harness	—	In the passenger compartment, under the passenger seat on the floor pan	*G302 and G304 (Crew Cab)*	—
G303	Body Harness	—	In the passenger compartment, under the driver seat on the floor pan	*G301 and G303*	—
G303	Body Harness	LWN	In the passenger compartment, under the driver seat on the floor pan	*G301 and G303 (LWN)*	—
G304	Body Harness	—	In the passenger compartment, under the passenger seat on the floor pan	*G302 and G304 (Crew Cab)*	—
G305	Instrument Panel Harness	—	In the passenger compartment, center, beneath the floor console, rear of floor shifter	*G300, G305, and G307*	—
G306	Body Harness	C49	In the passenger compartment, left rear, on upper pillar	*G306 (C49)*	—
G307	Instrument Panel Harness	—	In the passenger compartment, center, beneath the floor console, rear of floor shifter	*G300, G305, and G307*	—
G400	Chassis Harness	—	Under vehicle, outboard of left frame rail, rearward of the fuel filler neck	• *G400 (Crew Cab)* • *G400 (Extended Cab)*	—
G401	Chassis Harness	LCV/LGZ	Under vehicle, outboard of left frame rail, forward of the left leaf spring mount	• *G401 (Crew Cab)* • *G401 (Extended Cab)*	—
G401	Chassis Harness	LWN	Under vehicle, outboard of left frame rail, forward of the left leaf spring mount	*G401 and G404 (LWN)*	—
G402	Chassis Harness	—	Under vehicle, outboard of right frame rail, forward of the right leaf spring mount	• *G402 (Crew Cab)* • *G402 (Extended Cab)*	—
G404	Chassis Harness	LWN	Under vehicle, outboard of left frame rail, forward of the left leaf spring mount	*G401 and G404 (LWN)*	—
J100	Body Harness	NQ6	In engine compartment, approximately 10.7 cm (4.21 in) from battery current sensor breakout towards rear of vehicle	*Body Harness Routing - Left Engine Compartment (LCV/LGZ)*	—
J100	Body Harness	NQ6 with LWN	In engine compartment, approximately 10.5 cm (4.13 in) from underhood fuse block X2 breakout towards X101/X102 breakouts	*Body Harness Routing - Left Engine Compartment (LWN)*	—

J101	Body Harness	NQ6/NQ7	In engine compartment, approximately 15.7 cm (6.18 in) from battery current sensor breakout towards rear of vehicle	*Body Harness Routing - Left Engine Compartment (LCV/LGZ)*	—
J101	Body Harness	NQ6/NQ7 with LWN	In engine compartment, approximately 5.0 cm (1.97 in) into X101 breakout	*Body Harness Routing - Left Engine Compartment (LWN)*	—
J102	Body Harness	—	In engine compartment, approximately 4.0 cm (1.57 in) into X106 breakout	*Body Harness Routing - Left Engine Compartment (LCV/LGZ)*	—
J102	Body Harness	LWN	In engine compartment, approximately 3.6 cm (1.42 in) into X106 breakout	*Body Harness Routing - Left Engine Compartment (LWN)*	—
J103	Body Harness	—	In engine compartment, approximately 12.5 cm (4.92 in) from battery ground breakout towards body grommet	*Body Harness Routing - Left Engine Compartment (LCV/LGZ)*	—
J103	Body Harness	LWN	In engine compartment, approximately 5.9 cm (2.32 in) from windshield wiper motor breakout towards body grommet	*Body Harness Routing - Left Engine Compartment (LWN)*	—
J104	Chassis Harness	—	In engine compartment, approximately 30.7 cm (12.1 in) from X106 breakout towards front of vehicle	• *Chassis Harness Routing (LWN)* • *Chassis Harness Routing (Extended Cab)* • *Chassis Harness Routing (Crew Cab)*	—
J105	Chassis Harness	—	In engine compartment, approximately 5.4 cm (2.13 in) into X106 breakout	• *Chassis Harness Routing (LWN)* • *Chassis Harness Routing (Crew Cab)* • *Chassis Harness Routing (Extended Cab)*	—
J106	Engine Harness	LCV with NQ6/NQ7	In engine compartment, left front of engine, approximately 3 cm (1.81 in) from X101 breakout towards engine	*Engine Harness Routing - Left Front (LCV)*	—
J106	Engine Harness	LGZ with NQ6/NQ7	In engine compartment, left front of engine, approximately 6.6 cm (2.60 in) into X101 breakout	*Engine Harness Routing - Front (LGZ)*	—
J106	Engine Harness	LWN with NQ6/NQ7	In engine compartment, left of engine, approximately 17.7 cm (6.97 in) from underhood fuse block X3 breakout towards front of vehicle	*Engine Harness Routing - Left Front (LWN)*	—
J107	Engine Harness	LCV	In engine compartment, front of engine, approximately 5 cm (1.97 in) from camshaft position actuator solenoid valve exhaust breakout towards manifold absolute pressure sensor breakout	*Engine Harness Routing - Left Front (LCV)*	—
J107	Engine Harness	LGZ	In engine compartment, left front of engine, approximately 12.9 cm (5.08 in) into fuse block underhood X3 breakout	*Engine Harness Routing - Front (LGZ)*	—
J108	Engine Harness	LCV	In engine compartment, left front of engine, approximately 11.1 cm (4.37 in) from camshaft position actuator solenoid valve - exhaust breakout towards X101 breakout	*Engine Harness Routing - Left Front (LCV)*	—

J109	Engine Harness	LCV with MYB	In engine compartment, front of engine, approximately 10.9 cm (4.29 in) from camshaft position actuator solenoid valve - exhaust breakout towards manifold absolute pressure sensor breakout	*Engine Harness Routing - Left Front (LCV)*	—
J109	Engine Harness	LGZ with MYB	In engine compartment, left front of engine, approximately 6.1 cm (2.40 in) from ignition coil 2 breakout towards rear of engine	*Engine Harness Routing - Front (LGZ)*	—
J109	Engine Harness	LWN	Underneath vehicle, right front of transmission, approximately 16.6 cm (6.53 in) from reductant injector breakout towards front of vehicle	*Engine Harness Routing - Right Rear (LWN)*	—
J110	Engine Harness	LCV	In engine compartment, front of engine, approximately 2.5 cm (0.98 in) from camshaft position actuator solenoid valve - exhaust breakout towards manifold absolute pressure sensor breakout	*Engine Harness Routing - Left Front (LCV)*	—
J110	Engine Harness	LGZ	In engine compartment, right front of engine, approximately 14 cm (5.51 in) from evaporative emission purge solenoid valve breakout towards throttle body	*Engine Harness Routing - Front (LGZ)*	—
J110	Engine Harness	LWN	In engine compartment, left of engine, approximately 20.2 cm (7.95 in) from underhood fuse block X3 breakout towards front of vehicle	*Engine Harness Routing - Left Front (LWN)*	—
J111	Engine Harness	LCV	In engine compartment, front of engine, approximately 13.4 cm (5.28 in) from camshaft position actuator solenoid valve - exhaust breakout towards manifold absolute pressure sensor breakout	*Engine Harness Routing - Left Front (LCV)*	—
J111	Engine Harness	LGZ	In engine compartment, left front of engine, approximately 2 cm (6.10 in) from ignition coil 2 breakout towards ignition coil 4 breakout	*Engine Harness Routing - Front (LGZ)*	—
J112	Engine Harness	LCV	In engine compartment, right front of engine, approximately 5 cm (1.97 in) from ignition coil 1 breakout towards ignition coil 2 breakout	*Engine Harness Routing - Right Front Top (LCV)*	—
J113	Engine Harness	LCV	In engine compartment, right front of engine, approximately 2.5 cm (0.98 in) from ignition coil 1 breakout towards ignition coil 2 breakout	*Engine Harness Routing - Right Front Top (LCV)*	—
J113	Engine Harness	LGZ	In engine compartment, left front of engine, approximately 15.5 cm (6.10 in) into fuse block underhood X3 breakout	*Engine Harness Routing - Front (LGZ)*	—
J114	Engine Harness	LCV	In engine compartment, right front of engine, approximately 2.5 cm (0.98 in) from ignition coil 1 breakout towards camshaft position actuator solenoid valve - intake breakout	*Engine Harness Routing - Right Front Top (LCV)*	—
J114	Engine Harness	LGZ	In engine compartment, right front of engine, approximately 6.1 cm (2.40 in) from evaporative emission purge solenoid valve breakout towards throttle body	*Engine Harness Routing - Front (LGZ)*	—
J115	Engine Harness	LGZ	In engine compartment, left front of engine, approximately 15.5 cm (6.10 in) from X101 breakout towards right side of engine, near oil fill cap	*Engine Harness Routing - Front (LGZ)*	—

J116	Engine Harness	LGZ	In engine compartment, left front of engine, approximately 2 cm (0.79 in) from ignition coil 2 breakout towards rear of engine	*Engine Harness Routing - Front (LGZ)*	—
J117	Forward Lamp Harness	LCV/LGZ	In engine compartment, approximately 7.8 cm (3.07 in) into underhood fuse block X1 breakout	*Forward Lamp Harness Routing - Left Engine Compartment*	—
J117	Forward Lamp Harness	LWN	In engine compartment, approximately 9.5 cm (3.74 in) into underhood fuse block X1 breakout	*Forward Lamp Harness Routing - Left Engine Compartment (LWN)*	—
J118	Forward Lamp Harness	T3U with LCV/LGZ	In engine compartment, approximately 29.6 cm (11.7 in) into underhood fuse block X1 breakout	*Forward Lamp Harness Routing - Left Engine Compartment*	—
J118	Forward Lamp Harness	T3U with LWN	In engine compartment, approximately 29.2 cm (11.5 in) into underhood fuse block X1 breakout	*Forward Lamp Harness Routing - Left Engine Compartment (LWN)*	—
J119		T3U with LCV/LGZ	In engine compartment, approximately 15.6 cm (6.14 in) into underhood fuse block X1 breakout	*Forward Lamp Harness Routing - Left Engine Compartment*	—
J119	Forward Lamp Harness	T3U with LWN	In engine compartment, approximately 10.9 cm (4.29 in) into underhood fuse block X1 breakout	*Forward Lamp Harness Routing - Left Engine Compartment (LWN)*	—
J120	Forward Lamp Harness	—	In engine compartment, approximately 28.2 cm (11.7 in) from right fog lamp breakout towards cooling fan control module breakout	• *Forward Lamp Harness Routing - Right Engine Compartment* • *Engine Harness Routing - Left Front (LWN)*	—
J121	Left Headlamp Harness	—	Outside of the vehicle, internal to the left headlamp assembly	—	—
J122	Right Headlamp Harness	—	Outside of the vehicle, internal to the right headlamp assembly	—	—
J123	Body Harness	LCV/LGZ	In engine compartment, approximately 29.7 cm (11.7 in) from battery current sensor towards rear of vehicle	*Body Harness Routing - Left Engine Compartment (LCV/LGZ)*	—
J123	Body Harness	LWN	In engine compartment, approximately 9.6 cm (3.78 in) from battery current sensor towards rear of vehicle	*Body Harness Routing - Left Engine Compartment (LWN)*	—
J125	Engine Harness	LWN	In engine compartment, left of engine, approximately 14.8 cm (5.83 in) from underhood fuse block X3 breakout towards front of vehicle	*Engine Harness Routing - Left Front (LWN)*	—
J126	Engine Harness	LWN	In engine compartment, left of engine, approximately 12.4 cm (4.88 in) from underhood fuse block X3 breakout towards front of vehicle	*Engine Harness Routing - Left Front (LWN)*	—
J127	Engine Harness	LWN	In engine compartment, left of engine, approximately 6 cm (2.36 in) from underhood fuse block X3 breakout towards front of vehicle	*Engine Harness Routing - Left Front (LWN)*	—
J128	Engine Harness	LCV	In engine compartment, left rear of engine, approximately 12 cm (4.72 in) from G108	*Engine Harness Routing - Right Rear (LCV)*	—
J128	Engine Harness	LGZ	In engine compartment, right front of engine, approximately 3 cm (1.81 in) from evaporative emission purge solenoid valve breakout towards left side of engine	*Engine Harness Routing - Rear (LGZ)*	—
J129	Engine Harness	LCV	In engine compartment, right front of engine, approximately 4.1 cm (1.61 in) from the engine oil level switch breakout towards the rear of vehicle	*Engine Harness Routing - Right Rear (LCV)*	—

J129	Engine Harness	LGZ	In engine compartment, right front of engine, approximately 3 cm (1.81 in) into G108 breakout	*Engine Harness Routing - Rear (LGZ)*	—
J130	Engine Harness	LWN	In engine compartment, left of engine, approximately 5 cm (1.97 in) from underhood fuse block X3 breakout towards X109 breakout	—	—
J131	Engine Harness	LWN	In engine compartment, left of engine, approximately 20.7 cm (8.15 in) from crankshaft position sensor breakout towards harness main bundle	*Engine Harness Routing - Right Rear (LWN)*	—
J132	Engine Harness	LWN	In engine compartment, right of engine, approximately 5.7 cm (2.24 in) from engine oil pressure sensor breakout towards exhaust gas recirculation temperature sensor 2 breakout	*Engine Harness Routing - Left Front (LWN)*	—
J133	Engine Harness	LWN	In engine compartment, right of engine, approximately 6.0 cm (2.36 in) from engine oil pressure sensor breakout towards X107 breakout	*Engine Harness Routing - Left Front (LWN)*	—
J177	Transmission Harness (Circuit 4170)	M5T	Under the vehicle, internal to the transmission assembly	—	—
J200	Body Harness	—	In passenger compartment, approximately 12.5 cm (4.92 in) from accelerator pedal position sensor breakout towards brake pedal position sensor breakout	• *Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)* • *Body Harness Routing - Left Front of Passenger Compartment (Extended Cab)*	—
J201	Body Harness	—	In passenger compartment, approximately 15.6 cm (6.14 in) from park brake switch breakout towards main harness	• *Body Harness Routing - Left Front of Passenger Compartment (Extended Cab)* • *Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)*	—
J202	Body Harness	—	In passenger compartment, approximately 8.2 cm (3.23 in) from park brake switch breakout towards main harness	• *Body Harness Routing - Left Front of Passenger Compartment (Extended Cab)* • *Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)*	—
J203	Body Harness	—	In passenger compartment, approximately 4.1 cm (1.61 in) from park brake switch breakout towards body control module breakouts	*Instrument Panel Harness Routing - Rear*	—
J204	Body Harness	—	In passenger compartment, approximately 8.1 cm (3.19 in) from park brake switch breakout towards body control module breakouts	• *Body Harness Routing - Left Front of Passenger Compartment (Extended Cab)* • *Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)*	—
J205	Body Harness	—	In passenger compartment, approximately 11.9 cm (4.69 in) from park brake switch breakout towards main harness	• *Body Harness Routing - Left Front of Passenger Compartment (Extended Cab)* • *Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)*	—

J206	Body Harness	—	In passenger compartment, approximately 4.1 cm (1.61 in) from X500 breakout towards G301 breakout	● *Body Harness Routing - Left Front of Passenger Compartment (Extended Cab)* ● *Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)*	—
J207	Body Harness	—	In passenger compartment, approximately 4.6 cm (1.81 in) from X500 breakout towards JX201 breakout	● *Body Harness Routing - Left Front of Passenger Compartment (Extended Cab)* ● *Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)*	—
J208	Body Harness	—	In passenger compartment, approximately 9.6 cm (3.78 in) from X500 breakout towards JX201 breakout	● *Body Harness Routing - Left Front of Passenger Compartment (Extended Cab)* ● *Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)*	—
J209	Body Harness	Crew Cab	In passenger compartment, approximately 5.0 cm (1.97 in) from G301 breakout towards front of vehicle	*Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)*	—
J209	Body Harness	Extended Cab	In passenger compartment, approximately 12.3 cm (4.84 in) from G301 breakout towards front of vehicle	*Body Harness Routing - Left Front of Passenger Compartment (Extended Cab)*	—
J210	Body Harness	Crew Cab	In passenger compartment, approximately 1.23 cm (4.84 in) from G301 breakout towards front of vehicle	*Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)*	—
J211	Body Harness	Crew Cab	In passenger compartment, approximately 22 cm (8.66 in) from G301 breakout towards front of vehicle	*Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)*	—
J212	Body Harness	Crew Cab	In passenger compartment, approximately 30.2 cm (11.9 in) from G301 breakout towards front of vehicle	*Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)*	—
J213	Body Harness	Crew Cab	In passenger compartment, under passenger door trim plate, approximately 12 cm (4.72 in) from antenna coaxial cable inline connector breakout towards rear of vehicle	*Body Harness Routing - Right Front of Passenger Compartment (Crew Cab)*	—
J214	Instrument Panel Harness	—	In passenger compartment, behind left side of instrument panel, approximately 8.8 cm (3.46 in) from data link connector breakout towards steering column	*Instrument Panel Harness Routing - Rear*	—
J215	Instrument Panel Harness	—	In passenger compartment, behind left side of instrument panel, approximately 2.5 cm (1.0 in) from data link connector breakout towards floor	*Instrument Panel Harness Routing - Rear*	—
J216	Instrument Panel Harness	—	In passenger compartment, behind left side of instrument panel, approximately 7.6 cm (2.99 in) from data link connector breakout towards floor	*Instrument Panel Harness Routing - Rear*	—
J217	Instrument Panel Harness	KA1	In passenger compartment, behind left side of instrument panel, near body control module, approximately 5.3 cm (2.09 in) into main harness bundle leading toward body control module X1 breakout	*Instrument Panel Harness Routing - Rear*	—

J218	Instrument Panel Harness	UQ3	In passenger compartment, behind left side of instrument panel, approximately 6.6 cm (2.60 in) from left front speaker breakout towards steering column	*Instrument Panel Harness Routing - Rear*	—
J219	Instrument Panel Harness	UQ3	In passenger compartment, behind left side of instrument panel, approximately 10 cm (3.94 in) from left front speaker breakout towards steering column	*Instrument Panel Harness Routing - Rear*	—
J220	Instrument Panel Harness	—	In passenger compartment, behind left side of instrument panel, approximately 3.2 cm (1.26 in) from left front speaker breakout towards steering column	*Instrument Panel Harness Routing - Rear*	—
J221	Instrument Panel Harness	—	In passenger compartment, behind left side of instrument panel, approximately 15.9 cm (6.26 in) into secondary bundle leading toward steering wheel air bag coil breakout	*Instrument Panel Harness Routing - Rear*	—
J222	Instrument Panel Harness	IO5/IO6	In passenger compartment, behind center of instrument panel, approximately 13 cm (5.12 in) from X305 breakout towards center console accessory power receptacle breakout	*Instrument Panel Harness Routing - Rear*	—
J223	Instrument Panel Harness	—	In passenger compartment, behind center of instrument panel, approximately 3.3 cm (1.30 in) from center console accessory power receptacle breakout towards X305 breakout	*Instrument Panel Harness Routing - Rear*	—
J224	Instrument Panel Harness	—	In passenger compartment, behind center of instrument panel, approximately 5.2 cm (2.05 in) from center console accessory power receptacle breakout towards G305 breakout under center floor console	*Instrument Panel Harness Routing - Rear*	—
J225	Instrument Panel Harness	—	In passenger compartment, behind center of instrument panel, approximately 29.6 cm (11.7 in) from center console accessory power receptacle breakout towards G305 breakout under center floor console	*Instrument Panel Harness Routing - Rear*	—
J226	Instrument Panel Harness	IO4/IO5/IO6	In passenger compartment, behind center of instrument panel, approximately 14.7 cm (5.79 in) from center console accessory power receptacle breakout towards G305 breakout under center floor console	*Instrument Panel Harness Routing - Rear*	—
J227	Instrument Panel Harness	—	In passenger compartment, behind center of instrument panel, approximately 24.4 cm (9.61 in) from center console accessory power receptacle breakout towards G305 breakout under center floor console	*Instrument Panel Harness Routing - Rear*	—
J228	Instrument Panel Harness	—	In passenger compartment, behind center of instrument panel, approximately 35.3 cm (13.9 in) from center console accessory power receptacle breakout towards G305 breakout under center floor console	*Instrument Panel Harness Routing - Rear*	—
J229	Instrument Panel Harness	UQ3	In passenger compartment, behind right side of instrument panel, approximately 4.5 cm (1.77 in) from passenger instrument panel air bag breakout towards radio X4 breakout	*Instrument Panel Harness Routing - Rear*	—

J230	Instrument Panel Harness	UQ3	In passenger compartment, behind right side of instrument panel, approximately 9 cm (3.54 in) from passenger instrument panel air bag breakout towards radio X4 breakout	*Instrument Panel Harness Routing - Rear*	—
J231	Instrument Panel Harness	—	In passenger compartment, behind right side of instrument panel, approximately 18 cm (3.54 in) from right front speaker breakout towards passenger instrument panel air bag breakout	*Instrument Panel Harness Routing - Rear*	—
J232	Steering Wheel Harness	—	In passenger compartment, in the steering wheel harness	—	—
J233	Steering Wheel Harness	—	In passenger compartment, in the steering wheel harness	—	—
J234	Steering Wheel Harness	—	In passenger compartment, in the steering wheel harness	—	—
J235	Body Harness	—	In passenger compartment, approximately 5 cm (1.97 in) from brake pedal position sensor breakout towards accelerator pedal position sensor breakout	• *Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)* • *Body Harness Routing - Left Front of Passenger Compartment (Extended Cab)*	—
J236	Instrument Panel Harness	IO3/IO4+MYB	In passenger compartment, behind center of instrument panel, approximately 11.1 cm (4.37 in) into auxiliary audio input X1 breakout	—	—
J237	Instrument Panel Harness	IO3/IO4+N8D	In passenger compartment, behind center of instrument panel, approximately 4 cm (3.54 in) from radio X1 breakout towards left side of vehicle	*Instrument Panel Harness Routing - Rear*	—
J238	Instrument Panel Harness	IO3/IO4+N8D	In passenger compartment, behind center of instrument panel, approximately 16 cm (6.30 in) from X302 breakout	*Instrument Panel Harness Routing - Rear*	—
J239	Instrument Panel Harness	—	In passenger compartment, behind left side of instrument panel, approximately 5 cm (1.97 in) from splice pack JX200 breakout towards floor	*Instrument Panel Harness Routing - Rear*	—
J250	Steering Wheel Harness	—	In passenger compartment, in the steering wheel harness	—	—
J251	HVAC Harness	—	In passenger compartment, HVAC assembly harness	—	—
J252	HVAC Harness	—	In passenger compartment, HVAC assembly harness	—	—
J253	Instrument Panel Harness	LWN	In passenger compartment, behind center of instrument panel, approximately 35.3 cm (13.9 in) from	*Instrument Panel Harness Routing - Rear*	—
J300	Body Harness	Crew Cab	In passenger compartment, under passenger door trim plate, approximately 22 cm (8.66 in) from G304 breakout towards front of vehicle	*Body Harness Routing - Right Front of Passenger Compartment (Crew Cab)*	—

J301	Body Harness	—	In passenger compartment, under passenger seat, approximately 4.0 cm (1.57 in) from X320 breakout towards floor console	• *Body Harness Routing - Right Front of Passenger Compartment (Extended Cab)* • *Body Harness Routing - Right Front of Passenger Compartment (Crew Cab)*	—
J302	Body Harness	Extended Cab	In passenger compartment, under driver door trim plate, approximately 5 cm (1.97 in) from G303 breakout towards rear of vehicle	*Body Harness Routing - Left Front of Passenger Compartment (Extended Cab)*	—
J304	Floor Console Harness	IO3 with N8D	In passenger compartment, under center floor console, approximately 12.3 cm (4.84 in) from X302 USB inline connector breakout towards rear of vehicle	*Center Console Harness Routing*	—
J305	Floor Console Harness	—	In passenger compartment, under center floor console, approximately 11.7 cm (4.61 in) from USB receptacle breakout towards rear of vehicle	*Center Console Harness Routing*	—
J306	Headliner Harness	—	In passenger compartment, above the headliner, approximately 20.3 cm (4.72 in) from the left sunshade mirror lamp breakout towards rear of vehicle	• *Headliner Harness Routing (Crew Cab)* • *Headliner Harness Routing (Extended Cab)*	—
J307	Headliner Harness	—	In passenger compartment, above the headliner, approximately 11.7 cm (4.61 in) from the left sunshade mirror lamp breakout towards rear of vehicle	• *Headliner Harness Routing (Crew Cab)* • *Headliner Harness Routing (Extended Cab)*	—
J308	Headliner Harness	Crew Cab	In passenger compartment, above the headliner, approximately 35.3 cm (13.9 in) from the left sunshade mirror lamp breakout towards rear of vehicle	*Headliner Harness Routing (Crew Cab)*	—
J308	Headliner Harness	Extended Cab	In passenger compartment, above the headliner, approximately 13.8 cm (4.61 in) from the rear dome lamp breakout towards rear of vehicle	*Headliner Harness Routing (Extended Cab)*	—
J309	Driver Seat Cushion Harness	AL9	In passenger compartment, under driver seat, approximately 11 cm (4.3 in) from X310 towards the seat adjuster switch	*Driver Seat Harness Routing*	—
J310	Passenger Seat Cushion Harness	AT9	In passenger compartment, under passenger seat, approximately 11 cm (4.3 in) from X320 towards the seat adjuster switch	*Passenger Seat Harness Routing*	—
J311	Driver Seat Cushion Harness	AH6/AL9/KA1	In passenger compartment, under driver seat, approximately 21.5 cm (8.5 in) from X310	*Driver Seat Harness Routing*	—
J312	Passenger Seat Cushion Harness	AAQ/AT9/KA1	In passenger compartment, under passenger seat, approximately 17.5 cm (6.9 in) from X320	*Passenger Seat Harness Routing*	—
J313	Passenger Seat Cushion Harness	—	In passenger compartment, under passenger seat, approximately 23.5 cm (9.3 in) from X320	*Passenger Seat Harness Routing*	—
J314	Driver Seat Cushion Harness	—	In passenger compartment, under driver seat	—	—
J315	Driver Seat Cushion Harness	—	In passenger compartment, under driver seat	—	—
J316	Passenger Seat Cushion Harness	AAQ/AT9/KA1	In passenger compartment, under passenger seat	—	—

J400	Chassis Harness	—	Underneath the rear of vehicle, approximately 5.3 cm (2.09 in) from G401 breakout towards rear of vehicle	• *Chassis Harness Routing (Extended Cab)* • *Chassis Harness Routing (LWN)* • *Chassis Harness Routing (Crew Cab)*	—
J401	Chassis Harness	LCV/LGZ	Underneath the rear of vehicle, approximately 13.5 cm (5.31 in) from chassis control module (LFX) or fuel pump driver control module (LCV) breakout towards front of vehicle	• *Chassis Harness Routing (Crew Cab)* • *Chassis Harness Routing (Extended Cab)*	—
J402	Chassis Harness	LCV/LGZ	Underneath the rear of vehicle, approximately 6.1 cm (2.40 in) from chassis control module (LFX) or fuel pump driver control module (LCV) breakout towards left frame rail	• *MOST 50 Bus (IO5 or IO6 without TG5, KOT and UQA)* • *P9 Driver Information Center Display (UGI without UV9)*	—
J402	Chassis Harness	LWN	Underneath the rear of vehicle, approximately 14.1 cm (5.50 in) from trailer brake power control module breakout towards left frame rail	*Chassis Harness Routing (LWN)*	—
J404	Chassis Harness	—	Underneath the rear of vehicle, approximately 6.2 cm (2.44 in) into G400 breakout	• *Chassis Harness Routing (LWN)* • *Chassis Harness Routing (Crew Cab)* • *Chassis Harness Routing (Extended Cab)*	—
J405	Chassis Harness	LCV/LGZ	Underneath the rear of vehicle, approximately 20.1 cm (7.91 in) from G400 breakout towards front of vehicle	• *Chassis Harness Routing (Crew Cab)* • *Chassis Harness Routing (Extended Cab)*	—
J406	License Harness	—	At rear of vehicle, approximately 10 cm (3.94 in) from inline connector X400	*Rear License Plate Harness Routing*	—
J407	License Harness	—	At rear of vehicle, approximately 12.5 cm (4.92 in) from inline connector X400	*Rear License Plate Harness Routing*	—
J408	License Harness	—	At rear of vehicle, approximately 14.9 cm (5.87 in) from left license lamp breakout towards rear camera breakout	*Rear License Plate Harness Routing*	—
J409	License Harness	—	At rear of vehicle, approximately 4.8 cm (1.89 in) into rear camera breakout	*Rear License Plate Harness Routing*	—
J410	Chassis Harness	LWN	Underneath the rear of vehicle, approximately 41.2 cm (16.22 in) from the exhaust temperature sensor 2 breakout towards front of vehicle	*Chassis Harness Routing (LWN)*	—
J411	Chassis Harness	8S3 With Z82	Underneath the rear of vehicle, approximately 65.2 cm (25.7 in) from the exhaust temperature sensor 2 breakout towards front of vehicle	*Chassis Harness Routing (LWN)*	—
J411	Chassis Harness	8S3 Without Z82 With LCV/LGZ	Underneath the rear of vehicle, approximately 4.8 cm (1.89 in) into the blunt cut trailer provision	*Chassis Harness Routing (LWN)*	—
J412	Chassis Harness	8S3 With Z82	Underneath the rear of vehicle, approximately 55.2 cm (21.7 in) from the trailer connector	*Chassis Harness Routing (LWN)*	—
J412	Chassis Harness	8S3 Without Z82 With LCV/LGZ	Underneath the rear of vehicle, approximately 10 cm (3.94 in) into the blunt cut trailer provision	*Chassis Harness Routing (LWN)*	—
J413	Chassis Harness	S0Y	At rear of vehicle, in left tail lamp breakout, present with accessory bed lighting kit installed	—	—

J414	Chassis Harness	S0Y	At rear of vehicle, in left tail lamp breakout, present with accessory bed lighting kit installed	—	—
J415	Chassis Harness	LWN	At rear of vehicle, approximately 10 cm (3.82 in) from the G401/G404 breakout towards trailer brake power control module	*Chassis Harness Routing (LWN)*	—
J416	Chassis Harness	LWN	At front of vehicle, approximately 3.3 cm (1.30 in) from the right front wheel speed sensor breakout towards nitrogen oxide sensor 1 breakout	*Chassis Harness Routing (LWN)*	—
J417	Chassis Harness	LWN	At middle of vehicle, approximately 26.9 cm (10.59 in) into the nitrogen oxide sensor 2 breakout	*Chassis Harness Routing (LWN)*	—
J418	Chassis Harness	LWN	At middle of vehicle, approximately 14 cm (5.51 in) from exhaust particulate matter sensor breakout towards exhaust temperature sensor 5 breakout	*Chassis Harness Routing (LWN)*	—
J419	Chassis Harness	LWN	At middle of vehicle, approximately 9.1 cm (3.58 in) from exhaust particulate matter sensor breakout towards exhaust temperature sensor 5 breakout	*Chassis Harness Routing (LWN)*	—
J420	Chassis Harness	LWN	Underneath the rear of vehicle, approximately 25.7 cm (10.12 in) from the exhaust temperature sensor 2 breakout towards front of vehicle	*Chassis Harness Routing (LWN)*	—
J421	Chassis Harness	LWN	Underneath the rear of vehicle, approximately 5 cm (1.97 in) from the exhaust temperature sensor 2 breakout towards front of vehicle	*Chassis Harness Routing (LWN)*	—
J422	Chassis Harness	LWN	At middle of vehicle, approximately 31.9 cm (12.56 in) into the nitrogen oxide sensor 2 breakout	*Chassis Harness Routing (LWN)*	—
J423	Chassis Harness	LWN	Underneath the rear of vehicle, approximately 36.2 cm (14.25 in) from the exhaust temperature sensor 2 breakout towards front of vehicle	*Chassis Harness Routing (LWN)*	—
J424	Chassis Harness	LWN	Underneath the rear of vehicle, approximately 16 cm (16.22 in) from the reductant control module connector X1	*Chassis Harness Routing (LWN)*	—
J501	Driver Door Harness	—	In the driver door, approximately 7.9 cm (3.11 in) from window motor breakout towards front of vehicle	*Driver Door Harness Routing*	—
J502	Driver Door Harness	—	In the driver door, approximately 3.2 cm (1.26 in) from window motor breakout towards impact sensor breakout	*Driver Door Harness Routing*	—
J503	Driver Door Harness	—	In the driver door, approximately 21.3 cm (8.39 in) from window motor breakout towards front	*Driver Door Harness Routing*	—
J504	Driver Door Harness	—	In the driver door, approximately 15.4 cm (6.06 in) from speaker breakout towards rear of vehicle	*Driver Door Harness Routing*	—
J505	Driver Door Harness	—	In the driver door, approximately 31.5 cm (12.4 in) from speaker breakout towards rear of vehicle	*Driver Door Harness Routing*	—
J600	Passenger Door Harness	—	In the passenger door, approximately 18.2 cm (7.17 in) from window motor breakout towards front of vehicle	*Passenger Door Harness Routing*	—

J700	Left Rear Door Harness	Extended Cab	In the left rear door, near rear, approximately 15.9 cm (6.29 in) from speaker breakout towards rear of vehicle	*Left Rear Door Harness Routing (Exended Cab)*	—
J701	Left Rear Door Harness	Crew Cab	In the left rear door, near front, approximately 6.0 cm (2.36 in) from window switch — left rear breakout towards window motor	*Left Rear Door Harness Routing (Crew Cab)*	—
J701	Left Rear Door Harness	Extended Cab	In the left rear door, near rear, approximately 22 cm (8.66 in) from speaker breakout towards rear of vehicle	*Left Rear Door Harness Routing (Exended Cab)*	—
J800	Right Rear Door Harness	Extended Cab	In the right rear door, near rear, approximately 16.2 cm (6.38 in) from speaker breakout towards rear of vehicle	*Right Rear Door Harness Routing (Extended Cab)*	—
J801	Right Rear Door Harness	Crew Cab	In the right rear door, near front, approximately 6.0 cm (2.36 in) from window switch — right rear breakout towards window motor	*Right Rear Door Harness Routing (Crew Cab)*	—
J801	Right Rear Door Harness	Extended Cab	In the right rear door, near rear, approximately 23.3 cm (9.17 in) from speaker breakout towards rear of vehicle	*Right Rear Door Harness Routing (Extended Cab)*	—
JX200	Splice Pack - Instrument Panel	—	In the passenger compartment, under the instrument panel, left of the steering column and the body control module	• *Instrument Panel Harness Routing - Rear* • *Body Harness Routing - Left Front of Passenger Compartment (Extended Cab)*	*JX200 Splice Pack*
JX201	Splice Pack - Body	—	In the passenger compartment, under the instrument panel, behind the emergency brake assembly at carpet	*Body Harness Routing - Left Front of Passenger Compartment (Crew Cab)*	*JX201 Splice Pack*
JX202	Splice Pack - Body	—	—	—	*JX202 Splice Pack*

Front of Vehicle Components (Chevrolet/X88)



Items

1. A9B Outside Rearview Mirror - Passenger
2. E13RA Headlamp Assembly - Right
3. E13LA Headlamp Assembly - Left
4. A9A Outside Rearview Mirror - Driver
5. E4J Park Lamp - Left Front (X88)
6. E4G Headlamp - Left Low Beam
7. E4E Headlamp - Left High Beam
8. E4N Park/Turn Signal Lamp - Left
9. E29LF Fog Lamp - Left Front (T3U)
10. B9 Ambient Air Temperature Sensor
11. E29RF Fog Lamp - Right Front (T3U)

11. E29RF Fog Lamp - Right Front (T3U)
12. E4P Park/Turn Signal Lamp - Right
13. E4F Headlamp - Right High Beam
14. E4H Headlamp - Right Low Beam
15. E4K Park Lamp - Right Front (X88)

Front of Vehicle Components (GMC/Z88)



Items

1. A9B Outside Rearview Mirror - Passenger
2. E13RA Headlamp Assembly - Right
3. E13LA Headlamp Assembly - Left
4. A9A Outside Rearview Mirror - Driver
5. E4AC Park/Daytime Running Lamp - Left (Z88)
6. E4N Park/Turn Signal Lamp - Left
7. E4AL Park/Daytime Running Lamp - Left Lower (Z88)
8. E4G Headlamp - Left Low Beam
9. E29LF Fog Lamp - Left Front (T3U)
10. E4E Headlamp - Left High Beam
11. B9 Ambient Air Temperature Sensor

11. B9 Ambient Air Temperature Sensor
12. E4F Headlamp - Right High Beam
13. E29RF Fog Lamp - Right Front (T3U)
14. E4H Headlamp - Right Low Beam
15. E4AM Park/Daytime Running Lamp - Right Lower (Z88)
16. E4P Park/Turn Signal Lamp - Right
17. E4AD Park/Daytime Running Lamp - Right (Z88)

Left Side of Engine Compartment Components



Items

1. M75 Windshield Wiper Motor
2. B19B Brake Booster Vacuum Sensor
3. B20 Brake Fluid Level Switch
4. C1 Battery
5. X50D Fuse Block - Battery
6. R10 Cooling Fan Resistor (LWN)
7. X50A Fuse Block - Underhood
8. B18 Battery Current Sensor

Left Front of Engine Compartment Components



Items

1. G24 Windshield Washer Pump
2. B55 Hood Ajar Switch (UTJ)
3. B59L Front Impact Sensor - Left

Front of Engine Compartment Components



Items

1. M96 Active Grille Air Shutter Actuator (LCV/LGZ)

Radiator Assembly Components



Items

1. K22 Cooling Fan Control Module (LCV/LGZ)
2. B203 Engine Coolant Radiator Temperature Sensor (LCV)

Right Front of Engine Compartment Components



Items

1. B59R Front Impact Sensor - Right
2. P13 Horn Assembly

Right Rear of Engine Compartment Components



Items

1. K20 Engine Control Module

Top of Engine Components (LCV)



Items

1.	T8D Ignition Coil 4
2.	T8C Ignition Coil 3
3.	T8B Ignition Coil 2
4.	T8A Ignition Coil 1
5.	Q6F Camshaft Position Actuator Solenoid Valve - Intake (LCV)
6.	Q38 Throttle Body

Top of Engine Components (LGZ)



Items

1. Q17F Fuel Injector 6 (LGZ)
2. Q17D Fuel Injector 4
3. T8F Ignition Coil 6 (LGZ)
4. T8D Ignition Coil 4
5. T8B Ignition Coil 2
6. Q17B Fuel Injector 2
7. Q17A Fuel Injector 1
8. Q17C Fuel Injector 3
9. T8A Ignition Coil 1
10. T8C Ignition Coil 3
11. T8E Ignition Coil 5 (LGZ)

11. T8E Ignition Coil 5 (LGZ)

12. Q17E Fuel Injector 5 (LGZ)

Top of Engine Components (LWN)



Items

1. E12A Glow Plug 1 (LWN)

2. E12B Glow Plug 2 (LWN)

3. E12C Glow Plug 3 (LWN)

4. E12D Glow Plug 4 (LWN)

5. B65 Intake Manifold Pressure and Air Temperature Sensor (LWN)

Left Side of Engine Components (LWN)



Items

1. B193B Charge Air Cooler Outlet Temperature Sensor (LWN)
2. B34 Engine Coolant Temperature Sensor
3. Q85 Cooling Fan Clutch (LWN)

Left Front of the Engine Components (LCV)



Items

1. Q6E Camshaft Position Actuator Solenoid Valve - Exhaust (LCV)
2. B23E Camshaft Position Sensor - Exhaust (LCV)
3. B52A Heated Oxygen Sensor 1 (LCV)
4. B52B Heated Oxygen Sensor 2 (LCV)
5. B1 A/C Refrigerant Pressure Sensor
6. E41 Engine Coolant Thermostat Heater (LCV)
7. Q46 A/C Compressor Solenoid Valve
8. G1 A/C Compressor
9. Q2 A/C Compressor Clutch

Left Front of the Engine Components (LGZ)



Items

1. Q6A Camshaft Position Actuator Solenoid Valve - Bank 1 Exhaust (LGZ)
2. B23A Camshaft Position Sensor - Bank 1 Exhaust (LGZ)
3. Q6B Camshaft Position Actuator Solenoid Valve - Bank 1 Intake (LGZ)
4. B23B Camshaft Position Sensor - Bank 1 Intake (LGZ)
5. Q38 Throttle Body
6. B23C Camshaft Position Sensor - Bank 2 Exhaust (LGZ)
7. Q6D Camshaft Position Actuator Solenoid Valve - Bank 2 Intake (LGZ)
8. Q6C Camshaft Position Actuator Solenoid Valve - Bank 2 Exhaust (LGZ)
9. B23D Camshaft Position Sensor - Bank 2 Intake (LGZ)
10. B52E Heated Oxygen Sensor - Bank 2 Sensor 1 (LGZ)
11. B34 Engine Coolant Temperature Sensor

11. B34 Engine Coolant Temperature Sensor
12. B37B Engine Oil Pressure Sensor
13. M64 Starter Motor
14. B68B Knock Sensor 2
15. Q46 A/C Compressor Solenoid Valve
16. G1 A/C Compressor
17. Q2 A/C Compressor Clutch
18. B1 A/C Refrigerant Pressure Sensor

Left Front of the Engine Components (LWN)



Items

1. G13 Generator
2. Q18B Fuel Pressure Regulator 2 (LWN)
3. Q38 Throttle Body
4. Q14 Exhaust Gas Recirculation Valve (LWN)
5. M64 Starter Motor
6. Q46 A/C Compressor Solenoid Valve
7. B26 Crankshaft Position Sensor
8. Q18A Fuel Pressure Regulator 1 (LWN)
9. B1 A/C Refrigerant Pressure Sensor
10. Q2 A/C Compressor Clutch
11. G1 A/C Compressor

11. G1 A/C Compressor

Right Rear of Engine Components (LCV)



Items

1. Q44 Engine Oil Pressure Control Solenoid Valve (LCV)
2. B34 Engine Coolant Temperature Sensor
3. B23F Camshaft Position Sensor - Intake (LCV)
4. G18 High Pressure Fuel Pump
5. Q12 Evaporative Emission Purge Solenoid Valve
6. B75C Multifunction Intake Air Sensor (LCV/LGZ/LWN)
7. G13 Generator
8. M64 Starter Motor
9. B35 Engine Oil Level Switch

Right Rear of Engine Components (LGZ)



Items

1. G18 High Pressure Fuel Pump
2. B74 Manifold Absolute Pressure Sensor
3. Q12 Evaporative Emission Purge Solenoid Valve
4. B75C Multifunction Intake Air Sensor (LCV/LGZ/LWN)
5. G13 Generator
6. B52C Heated Oxygen Sensor - Bank 1 Sensor 1 (LGZ)
7. B52D Heated Oxygen Sensor - Bank 1 Sensor 2 (LGZ)
8. B52F Heated Oxygen Sensor - Bank 2 Sensor 2 (LGZ)

Right Rear of Engine Components (LWN)



Items

1. B130B Exhaust Gas Recirculation Temperature Sensor 2 (LWN)
2. B47B Fuel Rail Pressure Sensor
3. Q17D Fuel Injector 4
4. Q17C Fuel Injector 3
5. Q17B Fuel Injector 2
6. Q17A Fuel Injector 1
7. B130A Exhaust Gas Recirculation Temperature Sensor 1 (LWN)
8. B75C Multifunction Intake Air Sensor (LCV/LGZ/LWN)
9. B193A Charge Air Cooler Inlet Temperature Sensor (LWN)
10. M103 Turbocharger Vane Position Actuator (LWN)
11. B131A Exhaust Temperature Sensor 1 (LWN)

11. B131A Exhaust Temperature Sensor 1 (LWN)

12. B131B Exhaust Temperature Sensor 2 (LWN)

13. B195A Nitrogen Oxides Sensor 1 (LWN)

Right Top of Engine Components (LCV)



Items

1. B47B Fuel Rail Pressure Sensor

2. Q17A Fuel Injector 1

3. Q17B Fuel Injector 2

4. Q17C Fuel Injector 3

5. Q17D Fuel Injector 4

Right Bottom of Engine Components (LCV)



Items

1. B74 Manifold Absolute Pressure Sensor
2. B68A Knock Sensor 1 (LCV/LGZ)
3. B37B Engine Oil Pressure Sensor
4. B26 Crankshaft Position Sensor
5. B68B Knock Sensor 2

Right Bottom of Engine Components (LGZ)



Items

1. B68A Knock Sensor 1 (LCV/LGZ)
2. M9 Brake Booster Pump Motor (LGZ)
3. B35 Engine Oil Level Switch
4. B26 Crankshaft Position Sensor

Right Bottom of Engine Components (LWN)



Items

1. Q47 Exhaust Gas Recirculation Cooler Bypass Solenoid Valve (LWN)
2. B23 Camshaft Position Sensor (LWN)
3. B37B Engine Oil Pressure Sensor
4. B35 Engine Oil Level Switch
5. E45 Positive Crankcase Ventilation Heater (LWN)

Automatic Transmission Components (MYB with NQ6/NQ7)



Items

1. Q8 Control Solenoid Valve Assembly (MYB)
2. B14A Transmission Output Shaft Speed Sensor
3. A16 Transfer Case Motor (NQ6/NQ7)
4. B227 Gear Position Sensor (NQ6)

Manual Transmission Components (N8D)



Items

1. B16 Backup Lamp Switch (N8D)

2. B14A Transmission Output Shaft Speed Sensor

Instrument Panel/Center Console Component Views

Behind the Instrument Panel Components



Items

1. F101 Passenger Instrument Panel Air Bag
2. A11 Radio
3. K74 Human Machine Interface Control Module (IO4/IO5/IO6)
4. P43 Collision Alert Indicators (UEU)
5. K9 Body Control Module
6. K33 HVAC Control Module
7. T3 Audio Amplifier (UQA)

Front of the Instrument Panel Components



Items

1. S78 Turn Signal/Multifunction Switch
2. P19H Speaker - Left Front Tweeter
3. P16 Instrument Cluster
4. S82 Windshield Wiper/Washer Switch
5. P19B Speaker - Center Instrument Panel (UQA)
6. B10B Ambient Light/Sunload Sensor
7. P17 Info Display Module
8. A22 Radio Controls
9. P19V Speaker - Right Front Tweeter
10. A26 HVAC Controls
11. S32P Seat Heating Switch - Passenger (KA1)
12. X80A Accessory Power Receptacle - Center Console 1
13. S48A Multifunction Switch - Instrument Panel
14. X83 Auxiliary Audio Input
15. S32D Seat Heating Switch - Driver (KA1)

15. S52D Seat Heating Switch - Driver (KA1)
16. S39 Ignition Switch
17. M93 Key Capture Solenoid Actuator (MYB)
18. K89 Immobilizer Control Module
19. S77 Transfer Case Shift Control Switch (NQ6/NQ7)
20. S30 Headlamp Switch
21. S76 Trailer Brake Control Switch (JL1)

Below Left Side of the Instrument Panel Components (N8D)



Items

1. B80 Park Brake Switch
2. B25B Clutch Pedal Position Sensor (N8D)
3. B22 Brake Pedal Position Sensor
4. B107 Accelerator Pedal Position Sensor

Below Left Side of the Instrument Panel Components (MYB)



Items

1. B80 Park Brake Switch
2. B22 Brake Pedal Position Sensor
3. B107 Accelerator Pedal Position Sensor

Steering Column Components



Items

1. S78 Turn Signal/Multifunction Switch
2. X85 Steering Wheel Air Bag Coil
3. S82 Windshield Wiper/Washer Switch
4. S70F Steering Wheel Controls Switch - Radio Volume (W1Y)
5. S70E Steering Wheel Controls Switch - Radio Presets (W1Y)
6. S70R Steering Wheel Controls Switch - Right
7. F107 Steering Wheel Air Bag
8. S70L Steering Wheel Controls Switch - Left

HVAC Assembly Components



Items

1. B7F Air Temperature Sensor - Duct Upper (C68)
2. B7B Air Temperature Sensor - Duct Lower (C68)
3. M37 Mode Door Actuator
4. K8 Blower Motor Control Module
5. M4 Air Inlet Door Actuator
6. B39 A/C Evaporator Temperature Sensor
7. M6 Air Temperature Door Actuator

HVAC Assembly Bottom Components (LWN)



Items

1. E40 Electrical Auxiliary Heater (LWN)

Center Console Components (MYB)



Items

1. S3 Transmission Shift Lever (MYB)
2. X80B Accessory Power Receptacle - Center Console 2
3. X83R Auxiliary Audio Input - Rear (IO5/IO6)
4. X92 USB Receptacle (IO5/IO6)
5. P2 Transmission Shift Lever Position Indicator (MYB)
6. S2A Transmission Manual Shift Switch - Up/Down (MYB)

Center Console Components (N8D)



Items

1. X83 Auxiliary Audio Input
2. X80B Accessory Power Receptacle - Center Console 2
3. X80A Accessory Power Receptacle - Center Console 1

Driver Seat Back Components



Items

1. M52D Seat Lumbar Support Horizontal Motor - Driver (AL9)

Driver Seat Components



Items

1. M51D Seat Horizontal Motor - Driver
2. M55D Seat Rear Vertical Motor - Driver
3. E14A Seat Heating Element - Driver Back (KA1)
4. F106D Seat Side Air Bag - Driver
5. F113D Seat Belt Anchor Pretensioner - Driver
6. S64D Seat Adjuster Switch - Driver
7. E14B Seat Heating Element - Driver Cushion (KA1)
8. B88D Seat Belt Switch - Driver

Passenger Seat Back Components



Items

1. M52P Seat Lumbar Support Horizontal Motor - Passenger (AAQ)

Passenger Seat Components



Items

1. M55P Seat Rear Vertical Motor - Passenger (AAQ)
2. K85 Passenger Presence Module
3. M51P Seat Horizontal Motor - Passenger (AAQ)
4. K29 Seat Heating Control Module (KA1)
5. E14C Seat Heating Element - Passenger Back (KA1)
6. B88P Seat Belt Switch - Passenger
7. E14D Seat Heating Element - Passenger Cushion (KA1)
8. S64P Seat Adjuster Switch - Passenger (AAQ)
9. F113P Seat Belt Anchor Pretensioner - Passenger
10. F106P Seat Side Air Bag - Passenger
11. E14D Seat Heating Element - Passenger Cushion (KA1)

11. E14D Seat Heating Element - Passenger Cushion (KA1)

Left Passenger Components (Crew Cab)



Items

1. B63LR Side Impact Sensor - Left Rear
2. F105L Roof Rail Air Bag - Left
3. B80 Park Brake Switch
4. K9 Body Control Module
5. K36 Inflatable Restraint Sensing and Diagnostic Module
6. F112D Seat Belt Retractor Pretensioner - Driver

Left Passenger Components (Extended Cab)



Items

1. B63LR Side Impact Sensor - Left Rear
2. F105L Roof Rail Air Bag - Left
3. K9 Body Control Module
4. K36 Inflatable Restraint Sensing and Diagnostic Module

Right Passenger Components (Crew Cab)



Items

1. K73 Telematics Communication Interface Control Module (UE1)
2. F105R Roof Rail Air Bag - Right
3. B63RR Side Impact Sensor - Right Rear
4. F112P Seat Belt Retractor Pretensioner - Passenger
5. X51A Fuse Block - Instrument Panel
6. K69 Transfer Case Control Module (NQ6/NQ7)
7. T15 Navigation Antenna Signal Splitter (IO6)

Right Passenger Components (Extended Cab)



Items

1. K73 Telematics Communication Interface Control Module (UE1)
2. F105R Roof Rail Air Bag - Right
3. B63RR Side Impact Sensor - Right Rear
4. X51A Fuse Block - Instrument Panel
5. K69 Transfer Case Control Module (NQ6/NQ7)
6. T15 Navigation Antenna Signal Splitter (IO6)

Headliner Components (Crew Cab)



Items

1. K109 Frontview Camera Module (UEU/UFL)
2. B160 Windshield Temperature and Inside Moisture Sensor (C68)
3. K77 Remote Control Door Lock Receiver
4. E37R Dome/Reading Lamps - Rear
5. E37F Dome/Reading Lamps - Front (C74)
6. P14 Passenger Air Bag Disabled Indicator
7. E31R Sunshade Mirror Lamp - Right (D6I)
8. A10 Inside Rearview Mirror
9. E31L Sunshade Mirror Lamp - Left (D6I)
10. B24 Cellular Phone Microphone (UE1)

Headliner Components (Extended Cab)



Items

1. K109 Frontview Camera Module (UEU/UFL)
2. B160 Windshield Temperature and Inside Moisture Sensor (C68)
3. K77 Remote Control Door Lock Receiver
4. E37R Dome/Reading Lamps - Rear
5. E37F Dome/Reading Lamps - Front (C74)
6. E31R Sunshade Mirror Lamp - Right (D6I)
7. P14 Passenger Air Bag Disabled Indicator
8. A10 Inside Rearview Mirror
9. E31L Sunshade Mirror Lamp - Left (D6I)
10. B24 Cellular Phone Microphone (UE1)

16. B24 Cellular Phone Microphone (UE1)

Door Component Views

Driver Door Components



Items

1. A23D Door Latch Assembly - Driver
2. M74D Window Motor - Driver
3. P19AG Speaker - Left Front Door
4. S13D Door Lock Switch - Driver (ATG)
5. S52 Outside Rearview Mirror Switch (DL6/DL9)
6. S79D Window Switch - Driver
7. B63LF Side Impact Sensor - Left Front

Passenger Door Components



Items

1. M74P Window Motor - Passenger
2. A23P Door Latch Assembly - Passenger
3. B63RF Side Impact Sensor - Right Front
4. P19AH Speaker - Right Front Door
5. S79P Window Switch - Passenger
6. S13P Door Lock Switch - Passenger (ATG)

Left Rear Door Components (Crew Cab)



Items

1. A23LR Door Latch Assembly - Left Rear (Crew Cab)
2. M74LR Window Motor - Left Rear (Crew Cab)
3. P19AL Speaker - Left Rear Door
4. S79LR Window Switch - Left Rear (Crew Cab)

Left Rear Door Components (Extended Cab)



Items

1. A23H Door Latch Assembly - Left Rear Upper (Extended Cab)
2. P19AL Speaker - Left Rear Door
3. F112D Seat Belt Retractor Pretensioner - Driver
4. F113D Seat Belt Anchor Pretensioner - Driver
5. A23G Door Latch Assembly - Left Rear Lower (Extended Cab)

Right Rear Door Components (Crew Cab)





Items

1. M74RR Window Motor - Right Rear (Crew Cab)
2. A23RR Door Latch Assembly - Right Rear (Crew Cab)
3. S79RR Window Switch - Right Rear (Crew Cab)
4. P19AM Speaker - Right Rear Door

Right Rear Door Components (Extended Cab)



Items

1. A23K Door Latch Assembly - Right Rear Upper (Extended Cab)
2. P19AM Speaker - Right Rear Door
3. A23J Door Latch Assembly - Right Rear Lower (Extended Cab)
4. F112P Seat Belt Retractor Pretensioner - Passenger
5. F113P Seat Belt Anchor Pretensioner - Passenger

Rear of Vehicle Components



Items

1. E42L Tail Lamp Assembly - Left
2. E5A Backup Lamp - Left
3. E5AG Tail/Stop and Turn Signal Lamp - Left Upper
4. E18 Rear Defogger Grid (C49)
5. E33L Cargo Lamp - Left
6. T4G Cellular Phone, Navigation, and Digital Radio Antenna (UE1)
7. E6 Center High Mounted Stop Lamp
8. E33R Cargo Lamp - Right
9. B87 Rearview Camera (UVC)
10. E5AH Tail/Stop and Turn Signal Lamp - Right Upper
11. E5B Backup Lamp - Right

11. E5B Backup Lamp - Right
12. E42R Tail Lamp Assembly - Right
13. E5V Tail/Stop and Turn Signal Lamp - Right Lower
14. E7R License Plate Lamp - Right
15. X88 Trailer Connector (Z82)
16. E7L License Plate Lamp - Left
17. E5U Tail/Stop and Turn Signal Lamp - Left Lower

Underbody Components (1 of 2)



Items

1. K43 Power Steering Control Module
2. M26 Front Axle Engagement Actuator (NQ6/NQ7)
3. M38 Power Steering Motor



Items

1. K38 Chassis Control Module
2. K111 Fuel Pump Driver Control Module (LCV)
3. B5LR Wheel Speed Sensor - Left Rear
4. B150 Fuel Tank Pressure Sensor (LCV/LGZ)
5. A7 Fuel Pump and Level Sensor Assembly

Underbody Components (LWN) (1 of 6)



Items

1. Q61 Reductant Injector (LWN)

Underbody Components (LWN) (2 of 6)



Items

1. B131D Exhaust Temperature Sensor 4 (LWN)
2. B131E Exhaust Temperature Sensor 5 (LWN)
3. B131C Exhaust Temperature Sensor 3 (LWN)
4. Q67 Exhaust Aftertreatment Fuel Injector (LWN)
5. B195B Nitrogen Oxides Sensor 2 (LWN)

Underbody Components (LWN) (3 of 6)


VIN MARKING AREA
1
2

Items

1. B116 Water in Fuel Sensor (LWN)
2. E11 Fuel Heater (LWN)



Items

1. B136 Exhaust Particulate Matter Sensor (LWN)
2. B154 Diesel Particulate Filter Exhaust Differential Pressure Sensor (LWN)

Underbody Components (LWN) (4 of 6)



Items

1. E52 Reductant Line Heater (LWN)
2. K115 Reductant Control Module (LWN)
3. A38 Reductant Pump and Sensor Assembly (LWN)
4. B213 Reductant Level Sensor (LWN)
5. E53 Reductant Tank Heater (LWN)

Underbody Components (LWN) (6 of 6)



Items

1. K133 Trailer Brake Power Control Module (JL1)
2. K38 Chassis Control Module
3. P3 Backup Alarm (8S3)

Wheel Well Components



Items

1. B5RF Wheel Speed Sensor - Right Front
2. B5RR Wheel Speed Sensor - Right Rear
3. B5LR Wheel Speed Sensor - Left Rear
4. B5LF Wheel Speed Sensor - Left Front

Chassis Components (Crew Cab)



Items

1. K38 Chassis Control Module
2. B150 Fuel Tank Pressure Sensor (LCV/LGZ)
3. Q13 Evaporative Emission Vent Solenoid Valve
4. K17 Electronic Brake Control Module
5. B47 Fuel Pressure Sensor (LCV/LGZ)
6. P3 Backup Alarm (8S3)
7. R6A Terminating Resistor - High Speed Bus

Chassis Components (Extended Cab)



Items

1. K38 Chassis Control Module
2. B150 Fuel Tank Pressure Sensor (LCV/LGZ)
3. Q13 Evaporative Emission Vent Solenoid Valve
4. K17 Electronic Brake Control Module
5. B47 Fuel Pressure Sensor (LCV/LGZ)
6. P3 Backup Alarm (8S3)
7. R6A Terminating Resistor - High Speed Bus

Chassis Underbody Components (Extended Cab)



Items

1. K17 Electronic Brake Control Module
2. B47 Fuel Pressure Sensor (LCV/LGZ)
3. R6A Terminating Resistor - High Speed Bus

G100 and G101



Items

1. G100
2. G101

G102 (LCV)



Items

1. G102

G102 (LGZ)



Items

1. G102



Items

1. G102
2. G107

G103 (LCV/LGZ), G105 (LWN)



Items

1. G103
2. G105

G103 (LWN), G105 (LCV/LGZ)



Items

1. G105
2. G103

G107 and G108 (LGZ)



Items

1. G108

2. G107

G107 (LCV)



Items

1. G107

G107 (LWN)



Items

1. G107

G108 (LCV)



Items

1. G108

G109 (LGZ)



Items

1. G109 (LGZ)

G300, G305, and G307



Items

1. G300
2. G305
3. G307

G301 and G303



Items

1. G303
2. G301

G301 and G303 (LWN)



Items

1. G301
2. G303

G302 and G304 (Crew Cab)



Items

1. G302
2. G304

G306 (C49)



Items

1. G306 (C49)

G400 (Crew Cab)



Items

1. G400

G400 (Extended Cab)



Items

1. G400

G401 (Crew Cab)



Items

1. G401

G401 (Extended Cab)



Items

1. G401

G401 and G404 (LWN)



Items

1. G404 (LWN)
2. G401

G402 (Crew Cab)



Items

1. G402

G402 (Extended Cab)



Items

1. G402

Electrical Center Identification Views

X50A Fuse Block - Underhood Label (LCV/LGZ/Gasoline)


F66
F65
F71
F70
F69
F64
F63
F68
F62
F67
F61
F60
F74
F75
F72
F73
K17
K28
K27
K16
F59
F56
F55
F54
F58
F53
F57
F52
K15
F23
K8
F20
F19
K26
K22
F18
F17
F16
F15
F14
K25
K24
K21
F35
F34
F33
F32
F31
F30
F29
F51
F50
F49
F48
F47
F46
K14
K13
K7
F11
F10
F9
F8
F13
F12
K2
F45
F44
F43
F42
K12
K11
K6
K5
F7
F5
F3
F2
F40
F39
F38
F37
F41
F36
K10
K9
K4
F6
K3
F4
F1
K1

∗IF EQUIPPED

RELAYS

K1	A/C CLTCH	K7	PWR TRN	K13	VAC PUMP
K2	STRTR	K8	EMPTY	K14	PRK LAMPS
K3	EMPTY	K9	EMPTY	K15	RUN/CRNK
K4	WPR SPD	K10	EMPTY	K16	EMPTY
K5	WPR CNTRL	K11	CHMSL	K17	REAR WNDW DEFOG
K6	CARGO LAMP	K12	EMPTY		

FUSES

F1	TCC BATT (15A)	F41	EMPTY
F2	ECM BATT (15A)	F42	EMPTY
F3	A/C CLTCH (10A)	F43	COOL FAN (60A)
F4	EMPTY	F44	EMPTY
F5	FUEL MDL RUN/CRNK (10A)	F45	VAC PUMP (30A)
F6	WPR (30A)	F46	EMPTY
F7	CARGO LAMP (15A)	F47	MISC 2 (10A)
F8	INJ EVEN (15A)	F48	FOG LAMP (15A) ∗
F9	INJ ODD (15A)	F49	EMPTY
F10	ECM (20A)	F50	TRLR PRK LAMP (20A)
F11	MISC 1 (10A)	F51	HORN (15A)
F12	STRTR (30A)	F52	EMPTY
F13	TCM (15A)	F53	EMPTY
F14	EMPTY	F54	EMPTY
F15	EMPTY	F55	EMPTY
F16	EMPTY	F56	WASH PUMP (15A)
F17	FRT AXLE ACT (10A)	F57	EMPTY
F18	EMPTY	F58	EMPTY
F19	AERO SHTR (10A)	F59	EMPTY
F20	EMPTY	F60	MIR DEFOG (7.5A)
F21	FRT BLWR (40A)	F61	EMPTY
F22	ABS VLV (30A)	F62	CNSTR VENT SOL (10A)
F23	EMPTY	F63	EMPTY
F24	TRLR (30A)	F64	TRLR REV LAMP (10A)
F25	TREC (30A)	F65	TRLR STOP/TRN LAMP LT (10A)
F26	ABS PUMP (60A)	F66	TRLR STOP/TRN LAMP RT (10A)
F27	TRLR BRK CNTRL MDL (30A)	F67	EPS (15A)
F28	REAR WNDW DEFOG (40A)	F68	EMPTY
F29	EMPTY	F69	RVC (5A)
F30	HTD SEAT BATT1 (15A)	F70	EMPTY
F31	EMPTY	F71	EMPTY
F32	HTD SEAT BATT2 (15A)	F72	EMPTY
F33	BCM 3 (20A)	F73	EMPTY
F34	FSCM (30A)	F74	GEN (200A)
F35	EMPTY	F75	EMPTY
F36	CHMSL (10A)		
F37	HI BEAM RT (10A)		
F38	HI BEAM LT (10A)		
F39	EMPTY		
F40	EMPTY		

X50A Fuse Block - Underhood Label (LWN/Diesel)


F66
F65
F71
F70
F69
F64
F63
F68
F62
F67
F61
F60
F74
F75
F72
F73
K17
K28
K27
K16
F59
F56
F55
F54
F58
F53
F57
F52
K15
F23
K8
F20
F19
K26
K22
F18
F17
F16
F15
F14
K25
K24
K21
F35
F34
F33
F32
F31
F30
F29
F51
F50
F49
F48
F47
F46
K14
K13
K7
F11
F10
F9
F8
F13
F12
K2
F45
F44
F43
F42
K12
K11
K6
K5
F7
F5
F3
F2
F40
F39
F38
F37
F41
F36
K10
K9
K4
F6
K3
F4
F1
K1

∗IF EQUIPPED

RELAYS

K1	A/C CLTCH	K7	PWR TRN	K13	DIESEL EXH FLUID CNTRL
K2	STRTR	K8	FUEL PUMP	K14	TRLR PRK LAMPS
K3	NOx SNSR-SCRPM	K9	EMPTY	K15	RUN/CRNK
K4	WPR SPD	K10	EMPTY	K16	COOL FAN CLTCH
K5	WPR CNTRL	K11	CHMSL	K17	REAR WNDW DEFOG
K6	CARGO LAMP	K12	FUEL HTR		

FUSES

F1	TCC BATT (15A)	F41	GLOW PLUG MODULE (60A)
F2	ECM BATT (15A)	F42	EMPTY
F3	A/C CLTCH (10A)	F43	COOL FAN (60A)
F4	NOx SNSR (15A)	F44	FUEL HTR (40A)
F5	ICCM (10A)	F45	DIESEL EXH FLUID CNTRL (30A)
F6	WPR (30A)	F46	COOL FAN CLTCH (10A)
F7	CARGO LAMP (15A)	F47	HTR CRANKCASE VENTILATION (7.5A)
F8	INJ EVEN (15A)	F48	FOG LAMPS (15A) ∗
F9	INJ ODD (7.5A)	F49	EMPTY
F10	ECM (20A)	F50	TRLR PRK LAMPS (20A)
F11	WATER IN FUEL (10A)	F51	HORN (15A)
F12	STRTR (30A)	F52	EMPTY
F13	TCM RUN/CRNK (15A)	F53	EMPTY
F14	EMPTY	F54	EMPTY
F15	EMPTY	F55	EMPTY
F16	EMPTY	F56	WASH PUMP (15A)
F17	FRT AXLE ACT (10A)	F57	EMPTY
F18	EMPTY	F58	EMPTY
F19	EMPTY	F59	EMPTY
F20	FUEL PUMP (20A)	F60	MIR DEFOG (7.5A)
F21	FRT BLWR (40A)	F61	EMPTY
F22	ABS VLV (30A)	F62	CNSTR VENT SOL (10A)
F23	EMPTY	F63	EMPTY
F24	TRLR (30A)	F64	TRLR REV LAMP (10A)
F25	TREC (30A)	F65	TRLR STOP/TRN LAMP LT (10A)
F26	ABS PUMP (60A)	F66	TRLR STOP/TRN LAMP RT (10A)
F27	ITBC (30A)	F67	EPS (15A)
F28	REAR WNDW DEFOG (40A)	F68	EMPTY
F29	EMPTY	F69	RVC (5A)
F30	HTD SEAT BATT1 (15A)	F70	EMPTY
F31	EMPTY	F71	EMPTY
F32	HTD SEAT BATT2 (15A)	F72	EMPTY
F33	BCM3 (20A)	F73	EMPTY
F34	ICCM (30A)	F74	GEN (200A)
F35	EMPTY	F75	EMPTY
F36	CHMSL (10A)		
F37	HI BEAM RT (10A)		
F38	HI BEAM LT (10A)		
F39	EMPTY		
F40	SCRPM (5A)		

X50A Fuse Block - Underhood Top View (LCV/LGZ/Gasoline)



Usage Table

No.	Device Label Name	Device Assigned Name	Rating	Description
Fuses				
F1	TCM BATT	F1UA	15A	• •
F2	ECM BATT	F2UA	15A	•
F3	A/C CLTCH	F3UA	10A	• •
F4	EMPTY	F4UA	—	•
F5	FUEL MDL RUN/CRNK	F5UA	10A	• • •
F6	WPR	F6UA	30A	•

F6	WPR	F6UA	30A	• •
F7	CARGO LAMP	F7UA	15A	•
F8	INJ EVEN	F8UA	15A	• • • •
F9	INJ ODD	F9UA	15A	• • • • • • • •
F10	ECM	F10UA	20A	•
F11	MISC 1	F11UA	10A	• • • •
F12	STRTR	F12UA	30A	•
F13	TCM	F13UA	15A	• •
F14	EMPTY	F14UA	—	•
F15	EMPTY	F15UA	—	•
F16	EMPTY	F16UA	—	•
F17	FRT AXLE ACT	F17UA	10A	•
F18	EMPTY	F18UA	—	•
F19	AERO SHTR	F19UA	10A	•
F20	EMPTY	F20UA	—	•
F21	FRT BLWR	F21UA	40A	•
F22	ABS VLV	F22UA	30A	•

F23	EMPTY	F23UA	—	•
F24	TRLR	F24UA	30A	• •
F25	TREC	F25UA	30A	• •
F26	ABS PUMP	F26UA	60A	•
F27	TRLR BRK CNTRL MDL	F27UA	30A	•
F28	REAR WNDW DEFOG	F28UA	40A	• •
F29	EMPTY	F29UA	—	•
F30	HTD SEAT BATT1	F30UA	15A	•
F31	EMPTY	F31UA	—	•
F32	HTD SEAT BATT2	F32UA	15A	•
F33	BCM 3	F33UA	20A	•
F34	FSCM	F34UA	30A	• •
F35	FSCM	F35UA	30A	•
F36	CHMSL	F36UA	10A	•
F37	HI BEAM RT	F37UA	10A	•
F38	HI BEAM LT	F38UA	10A	•
F39	EMPTY	F39UA	—	•
F40	EMPTY	F40UA	—	•
F41	EMPTY	F41UA	—	•
F42	EMPTY	F42UA	—	•
F43	COOL FAN	F43UA	60A	•
F44	EMPTY	F44UA	—	•
F45	VAC PUMP	F45UA	30A	•
F46	EMPTY	F46UA	—	•

F47	MISC 2	F47UA	10A	• • • • • • •
F48	FOG LAMP	F48UA	15A	• •
F49	EMPTY	F49UA	—	•
F50	TRLR PRK LAMP	F50UA	20A	• •
F51	HORN	F51UA	15A	•
F52	EMPTY	F52UA	—	•
F53	EMPTY	F53UA	—	•
F54	EMPTY	F54UA	—	•
F55	EMPTY	F55UA	—	•
F56	WASH PUMP	F56UA	15A	•
F57	EMPTY	F57UA	—	•
F58	EMPTY	F58UA	—	•
F59	EMPTY	F59UA	—	•
F60	MIR DEFOG	F60UA	7.5A	• •
F61	EMPTY	F61UA	—	•
F62	CNSTR VENT SOL	F62UA	10A	•
F63	EMPTY	F63UA	—	•
F64	TRLR REV LAMP	F64UA	10A	•
F65	TRLR STOP/TRN LAMP LT	F65UA	10A	• •
F66	TRLR STOP/TRN LAMP RT	F66UA	10A	•

F67	EPS	F67UA	15A	•
F68	EMPTY	F68UA	—	•
F69	RVC	F69UA	5A	•
F70	EMPTY	F70UA	—	•
F71	EMPTY	F71UA	—	•
F72	EMPTY	F72UB	—	•
F73	EMPTY	F73UB	—	•
F74	GEN	F74UB	200A	•
F75	EMPTY	F75UB	—	•
K1	A/C CLTCH	KR29 A/C Compressor Clutch Relay	—	•
K2	STRTR	KR27 Starter Relay	—	•
K3	EMPTY	—	—	• Not Used
K4	WPR SPD	KR12C Windshield Wiper Speed Control Relay	—	•
K5	WPR CNTRL	KR12B Windshield Wiper Relay	—	•
K6	CARGO LAMP	KR112 Cargo Lamp Relay	—	•
K7	PWR TRN	KR75 Engine Controls Ignition Relay	—	• • • • • •
K8	EMPTY	—	—	• Not Used
K9	EMPTY	—	—	• Not Used
K10	EMPTY	—	—	• Not Used
K11	CHMSL	KR41 Center High Mounted Stop Lamp Relay	—	•
K12	EMPTY	—	—	• Not Used
K13	VAC PUMP	KR14 Brake Booster Pump Motor	—	•

		Relay		•
K14	PRK LAMPS	KR125 Trailer Park Lamps Relay	—	•
K15	RUN/CRNK	KR73 Ignition Main Relay	—	• • • • • • • • • •
K16	EMPTY	—	—	• Not Used
K17	REAR WNDW DEFOG	KR5 Rear Defogger Relay	—	• • • • • •
—	—	KR3 Horn Relay	—	•
—	—	KR11 Windshield Washer Pump Relay	—	•
—	—	KR46 Front Fog Lamp Relay	—	•
—	—	KR48 Headlamp High Beam Relay	—	• •
—	—	KR61 Trailer Backup Lamps Relay	—	• • •
—	—	KR63L Trailer Stop/Turn Signal Lamp Relay - Left	—	• • •
—	—	KR63R Trailer Stop/Turn Signal Lamp Relay - Right	—	• •
—	—	KR113 Child Security Lock Disable Relay	—	• •

				• •
TP19	—	TP19	—	•
TP18	CKT 3271	TP18	—	•
TP24	CKT 1619	TP24	—	•
TP26	CKT 1624	TP26	—	•

X50A Fuse Block - Underhood Top View (LWN/Diesel)


X5
74
71
70
69
68
67
66
65
TP26
64
63
62
61
60
28
59
58
57
56
55
54
53
52
51
50
49
48
47
46
TP24
45
44
43
42
41
40
39
38
37
36
85
30
87
86
87A
TP18
TP19
31
30
29
24
21
22
23
20
19
18
17
16
15
14
13
12
11
10
09
08
07
06
05
04
03
02
01
27
25
26
32
33
34
35

Usage Table

No.	Device Label Name	Device Assigned Name	Rating	Description
Fuses				
F1	TCM BATT	F1UA	15A	•
F2	ECM BATT	F2UA	15A	•
F3	A/C CLTCH	F3UA	10A	• •
F4	NOx SNSR	F4UA	15A	• • •
F5	ICCM	F5UA	10A	• • •

				•
F6	WPR	F6UA	30A	• •
F7	CARGO LAMP	F7UA	15A	•
F8	INJ EVEN	F8UA	15A	•
F9	INJ ODD	F9UA	7.5A	•
F10	ECM	F10UA	20A	•
F11	WATER IN FUEL	F11UA	10A	•
F12	STRTR	F12UA	30A	•
F13	TCM RUN/CRNK	F13UA	15A	• •
F14	EMPTY	F14UA	—	•
F15	EMPTY	F15UA	—	•
F16	EMPTY	F16UA	—	•
F17	FRT AXLE ACT	F17UA	10A	•
F18	EMPTY	F18UA	—	•
F19	EMPTY	F19UA	—	•
F20	FUEL PUMP	F20UA	20A	•
F21	FRT BLWR	F21UA	40A	•
F22	ABS VLV	F22UA	30A	•
F23	EMPTY	F23UA	—	•
F24	TRLR	F24UA	30A	•
F25	TREC	F25UA	30A	• •
F26	ABS PUMP	F26UA	60A	•
F27	ITBC	F27UA	30A	•
F28	REAR WNDW DEFOG	F28UA	40A	• •

F29	EMPTY	F29UA	—	•
F30	HTD SEAT BATT1	F30UA	15A	•
F31	EMPTY	F31UA	—	•
F32	HTD SEAT BATT2	F32UA	15A	•
F33	BCM 3	F33UA	20A	•
F34	ICCM	F34UA	30A	•
F35	EMPTY	F35UA	—	•
F36	CHMSL	F36UA	10A	•
F37	HI BEAM RT	F37UA	10A	•
F38	HI BEAM LT	F38UA	10A	•
F39	EMPTY	F39UA	—	•
F40	SCRPN	F40UA	5A	•
F41	GLOW PLUG MODULE	F41UA	60A	•
F42	EMPTY	F42UA	—	•
F43	COOL FAN	F43UA	60A	•
F44	FUEL HTR	F44UA	40A	•
F45	DIESEL EXH FLUID CNTRL	F45UA	30A	•
F46	COOL FAN CLTCH	F46UA	10A	•
F47	HTR CRANKCASE VENTILATION	F47UA	7.5A	•
F48	FOG LAMPS	F48UA	15A	• •
F49	EMPTY	F49UA	—	•
F50	TRLR PRK LAMPS	F50UA	20A	•
F51	HORN	F51UA	15A	•
F52	EMPTY	F52UA	—	•
F53	EMPTY	F53UA	—	•

F54	EMPTY	F54UA	—	•
F55	EMPTY	F55UA	—	•
F56	WASH PUMP	F56UA	15A	•
F57	EMPTY	F57UA	—	•
F58	EMPTY	F58UA	—	•
F59	EMPTY	F59UA	—	•
F60	MIR DEFOG	F60UA	7.5A	• •
F61	EMPTY	F61UA	—	•
F62	CNSTR VENT SOL	F62UA	10A	•
F63	EMPTY	F63UA	—	•
F64	TRLR REV LAMP	F64UA	10A	•
F65	TRLR STOP/TRN LAMP LT	F65UA	10A	•
F66	TRLR STOP/TRN LAMP RT	F66UA	10A	•
F67	EPS	F67UA	15A	•
F68	EMPTY	F68UA	—	•
F69	RVC	F69UA	5A	•
F70	EMPTY	F70UA	—	•
F71	EMPTY	F71UA	—	•
F72	EMPTY	F72UB	—	•
F73	EMPTY	F73UB	—	•
F74	GEN	F74UB	200A	•
F75	EMPTY	F75UB	—	•
K1	A/C CLTCH	KR29 A/C Compressor Clutch Relay	—	•
K2	STRTR	KR27 Starter Relay	—	•
K3	NOx SNSR-SCRPM	KR121B Reductant Control Module Relay 2	—	•

		Module Relay 2		• • • • •
K4	WPR SPD	KR12C Windshield Wiper Speed Control Relay	—	•
K5	WPR CNTRL	KR12B Windshield Wiper Relay	—	•
K6	CARGO LAMP	KR112 Cargo Lamp Relay	—	•
K7	PWR TRN	KR75 Engine Controls Ignition Relay	—	• • • • • •
K8	FUEL PUMP	KR23A Fuel Pump Relay	—	•
K9	EMPTY	—	—	• Not Used
K10	EMPTY	—	—	• Not Used
K11	CHMSL	KR41 Center High Mounted Stop Lamp Relay	—	•
K12	FUEL HTR	KR22 Fuel Heater Relay	—	•
K13	DIESEL EXH FLUID CNTRL	KR121A Reductant Control Module Relay 1	—	•
K14	PRK LAMPS	KR125 Trailer Park Lamps Relay	—	•
K15	RUN/CRNK	KR73 Ignition Main Relay	—	• • • • • • • • • •
K16	COOL FAN CLTCH	KR20F Cooling Fan Relay	—	•
K17	REAR WNDW DEFOG	KR5 Rear Defogger Relay	—	•

[illegible]	REAR WNDW DEFOG	KR5 Rear Defogger Relay		• • • • • •
—	—	KR3 Horn Relay	—	•
—	—	KR11 Windshield Washer Pump Relay	—	•
—	—	KR46 Front Fog Lamp Relay	—	•
—	—	KR48 Headlamp High Beam Relay	—	• •
—	—	KR61 Trailer Backup Lamps Relay	—	• •
—	—	KR63L Trailer Stop/Turn Signal Lamp Relay - Left	—	• •
—	—	KR63R Trailer Stop/Turn Signal Lamp Relay - Right	—	•
—	—	KR113 Child Security Lock Disable Relay	—	• • •
TP19	—	TP19	—	•
TP18	CKT 3271	TP18	—	•
TP24	CKT 1619	TP24	—	•
TP26	CKT 1624	TP26	—	•

X50A Fuse Block - Underhood Bottom View



X50A Fuse Block - Underhood X1



Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 13262028

Service Connector: 13576528

Description: 82-Way F 1.5, 2.8 DSQ, 800 Metri-Pack Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13327116	J-35616-35 (VT)	J-38125-36	Not Available	Not Available	Not Available	Not Available
II	13575355	J-35616-44 (YE)	J-38125-558	12110127	Delphi 19	F	G
III	13575491	J-35616-35 (VT)	J-38125-36	Not Available	Not Available	Not Available	Not Available
IV	13575718	J-35616-44 (YE)	J-38125-558	12092445	Delphi 18	G	G
V	13575718	J-35616-44 (YE)	J-38125-558	Not Available	Not Available	Not Available	Not Available
VI	13575774	J-35616-14 (GN)	J-38125-560	Not Available	Not Available	Not Available	Not Available
VII	13575780	J-35616-35 (VT)	J-38125-36	Not Available	Not Available	Not Available	Not Available
VIII	13578869	J-35616-14 (GN)	J-38125-560	Not Available	Not Available	Not Available	Not Available
IX	13579922	J-35616-44 (YE)	J-38125-558	12065915	Delphi 5	A	D

X50A Fuse Block - Underhood X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 7	—	—	—	Not Occupied	—	—
8	1.5	BN	2109	Trailer Park Lamp Control	I	—
9 - 10	—	—	—	Not Occupied	—	—
11	0.75	BN/GY	29	Horn Control	VII	—
12	—	—	—	Not Occupied	—	—

13	0.75	WH	311	Right Headlamp High Beam Control	VI	—
14	0.5	WH	711	Left Headlamp High Beam Control	VI	—
15 - 29	—	—	—	Not Occupied	—	—
30	0.75	GY/VT	228	Windshield Washer Pump Control	VI	—
31	0.75	BN/VT	2234	Front Fog Lamp Control	VI	—
32 - 34	—	—	—	Not Occupied	—	—
35	6	RD/GY	4840	Battery Positive Voltage	V	—
36 - 37	—	—	—	Not Occupied	—	—
38	4	BN/BU	104	Glow Plug Control	IV	—
39 - 40	—	—	—	Not Occupied	—	—
41	1.5	GN/BU	3889	DEF Power Module Relay Control	IX	—
42 - 48	—	—	—	Not Occupied	—	—
49	2.5	BU/GN	7071	Heater Fuel Control	II	—
50	2.5	BN/VT	1470	Brake Booster Pump Motor Control	II	LFX
	4	BU	3921	DEF Heater Supply 1	IV	NQ6
51 - 67	—	—	—	Not Occupied	—	—
68	0.5	BN	6305	Brake Vacuum Switch Signal	VI	LFX
	1.5	GN/BU	3889	DEF Power Module Relay Control	VIII	NQ6
69	0.5	WH/VT	4333	Aero Shutter Actuator Control	VI	—
70	—	—	—	Not Occupied	—	—

71	0.75	BK	1150	Ground	VII	—
72	1.5	WH	92	Windshield Wiper Motor High Speed Control	I	—
73	1.5	YE/BN	95	Windshield Wiper Motor Low Speed Control	I	—
74	1.5	BK	3150	Ground	I	—
75	0.35	VT/GY	1054	Stop Lamp Control	III	—
76 - 79	—	—	—	Not Occupied	—	—
80	0.75	WH/VT	1430	Exterior Courtesy Lamp Control	VII	—
81 - 82	—	—	—	Not Occupied	—	—

X50A Fuse Block - Underhood X2



Connector Part Information

Harness Type: Body

OEM Connector: 13732284

Service Connector: 13576544

Description: 74-Way F 1.5, 2.8 DSQ, 800 Metri-Pack Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13327116	J-35616-35 (VT)	J-38125-36	Not Available	Not Available	Not Available	Not Available
II	13575355	J-35616-44 (YE)	J-38125-558	12110127	Delphi 19	F	G
III	13575718	J-35616-44 (YE)	J-38125-558	12092445	Delphi 18	G	G
IV	13575718	J-35616-44 (YE)	J-38125-558	Not Available	Not Available	Not Available	Not Available
V	13575773	J-35616-14 (GN)	J-38125-560	Not Available	Not Available	Not Available	Not Available
VI	13575774	J-35616-14 (GN)	J-38125-560	Not Available	Not Available	Not Available	Not Available
VII	13575781	J-35616-35 (VT)	J-38125-36	Not Available	Not Available	Not Available	Not Available
VIII	13578869	J-35616-14 (GN)	J-38125-560	Not Available	Not Available	Not Available	Not Available
IX	19299860	J-35616-35 (VT)	J-38125-36	Not Available	Not Available	Not Available	Not Available

X50A Fuse Block - Underhood X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 3	—	—	—	Not Occupied	—	—
4	0.75	GY	295	Door Lock Actuator Lock Control	IX	CREW CAB
	1.5	GY	295	Door Lock Actuator Lock Control	VII	EXTENDED CAB
5	1.5	WH/BU	3266	Child Security Lock Motor Lock Control	VII	—
6	2.5	GY	120	Fuel Pump Control	I	—

6	2.5	GY	120	Fuel Pump Control	I	—
7 - 11	—	—	—	Not Occupied	—	—
12	1.5	GY/GN	3271	Door Lock Control 2	VIII	—
13	0.5	VT/YE	3267	Child Security Lock Relay Control	V	—
14	0.75	VT/BK	2139	Run/Crank Ignition 1 Voltage	VI	—
15 - 16	—	—	—	Not Occupied	—	—
17	0.5	GN/VT	5199	Run/Crank Relay Coil Control	V	—
18	—	—	—	Not Occupied	—	—
19	0.5	BN/WH	1317	Fog Lamp Relay Control	V	—
20 - 21	—	—	—	Not Occupied	—	—
22	0.5	GY	91	Windshield Wiper Motor Relay Coil Control	V	—
23	—	—	—	Not Occupied	—	—
24	0.5	BU	45	Park Lamp Relay Control	V	—
25	0.5	BN/WH	28	Horn Relay Control	V	—
26 - 29	—	—	—	Not Occupied	—	—
30	0.75	GN	1619	Right Rear Trailer Stop/Turn Lamp Control	VI	—
31 - 32	—	—	—	Not Occupied	—	—
33	2.5	RD/VT	542	Battery Positive Voltage	II	—
34	2.5	RD/YE	442	Battery Positive Voltage	II	—
35	—	—	—	Not Occupied	—	—

36	4	OG	742	Battery Positive Voltage	III	—
37 - 38	—	—	—	Not Occupied	—	—
39	2.5	BN/VT	293	Rear Defog Element Control	II	—
40	2.5	RD/GY	1342	Battery Positive Voltage	II	EXTENDED CAB
	2.5	RD/GY	1342	Battery Positive Voltage	II	NQ6
	2.5	RD/GY	1342	Battery Positive Voltage	IV	T3U
	2.5	RD/GY	1342	Battery Positive Voltage	IV	TU3
41	4	RD/GY	1042	Battery Positive Voltage	III	—
42	2.5	RD/GN	242	Battery Positive Voltage	II	—
43	0.5	BK	3150	Ground	V	—
44	—	—	—	Not Occupied	—	—
45	0.5	WH/VT	860	Front Windshield Wiper Switch High Signal	V	—
46	0.5	VT/WH	5065	Stop Lamp Relay Coil Control	V	—
47	0.5	BN/WH	1429	Standing Lamp Relay Control	V	—
48	0.5	BU/BN	38	Backup Lamp Relay Control	V	—
49	0.5	BU/WH	5186	Left Trailer Turn Signal Lamp Control	V	—
50	—	—	—	Not Occupied	—	—
51	0.75	YE	1618	Left Rear Trailer Stop/Turn Lamp Control	VI	—
52	0.75	GY	1624	Trailer Backup Lamp Control	VI	—

52	0.75	GY	1624	Trailer Backup Lamp Control	VI	—
53 - 55	—	—	—	Not Occupied	—	—
56	0.75	RD/GN	5140	Battery Positive Voltage	VI	—
57	—	—	—	Not Occupied	—	—
58	0.5	BN/VT	1969	Headlamp High Beam Relay Control	V	—
59	0.5	YE/GY	5187	Right Trailer Turn Signal Lamp Control	V	—
60	0.5	BN/GY	2268	Windshield Washer Relay Control	V	—
61	0.5	BN/VT	193	Rear Defog Relay Control	V	—
62	0.5	BN/YE	2267	Mirror Heating Element Control	V	—
63 - 67	—	—	—	Not Occupied	—	—
68	0.75	RD/GN	6140	Battery Positive Voltage	IX	—
69	2.5	RD/YE	2340	Battery Positive Voltage	I	—
70	2.5	RD/VT	1940	Battery Positive Voltage	I	—
71	—	—	—	Not Occupied	—	—
72	0.5	RD/BN	440	Battery Positive Voltage	IX	—
73	0.5	RD/GN	2440	Battery Positive Voltage	IX	—
74	0.5	RD/BN	5940	Battery Positive Voltage	IX	—

X50A Fuse Block - Underhood X3



Connector Part Information

Harness Type: Engine

OEM Connector: 13732282

Service Connector: 13505902

Description: 50-Way F 1.5, 2.8 DSQ, 800 Metri-Pack Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13327116	J-35616-35 (VT)	J-38125-36	Not Available	Not Available	Not Available	Not Available
II	13575773	J-35616-14 (GN)	J-38125-560	Not Available	Not Available	Not Available	Not Available
III	13575774	J-35616-14 (GN)	J-38125-560	Not Available	Not Available	Not Available	Not Available
IV	13575781	J-35616-35 (VT)	J-38125-36	Not Available	Not Available	Not Available	Not Available
V	13578869	J-35616-14 (GN)	J-38125-560	Not Available	Not Available	Not Available	Not Available
VI	19299860	J-35616-35 (VT)	J-38125-36	Not Available	Not Available	Not Available	Not Available

X50A Fuse Block - Underhood X3

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	VT/BU	5290	Powertrain Main Relay Fused Supply 1	VI	LCV
	0.75	VT/BU	5290	Powertrain Main Relay Fused Supply 1	I	LFX
	2.5	VT/BU	5290	Powertrain Main Relay Fused Supply 1	IV	LWN
2	0.75	VT/BU	5291	Powertrain Main Relay Fused Supply 2	VI	—
3	1.5	VT/BU	5292	Powertrain Main Relay Fused Supply 3	IV	LCV
	0.75	VT/BU	5292	Powertrain Main Relay Fused Supply 3	VI	LFX

4	0.5	VT/BK	2139	Run/Crank Ignition 1 Voltage	VI	—
5	2.5	YE	6	Starter Solenoid Crank Ignition Voltage	IV	LCV
	2	YE	6	Starter Solenoid Crank Ignition Voltage	IV	LFX
6	0.5	VT/BU	5293	Powertrain Main Relay Fused Supply 4	II	—
7	0.5	VT/BU	5294	Powertrain Main Relay Fused Supply 5	III	LCV
	0.75	VT/BU	5294	Powertrain Main Relay Fused Supply 5	III	LFX
8	—	—	—	Not Occupied	—	—
9	0.5	GN/GY	465	Fuel Pump Primary Relay Control	II	—
10	—	—	—	Not Occupied	—	—
11	0.5	VT/GY	6386	Starter Enable Relay (PPEI 3) Control	II	—
12	0.5	WH/BK	2366	Cooling Fan Control Relay Speed Signal	II	—
13	0.75	BK/WH	151	Signal Ground	III	—
14	—	—	—	Not Occupied	—	—
15	2.5	BK	1450	Ground	II	LFX
	0.5	GN/BU	3889	DEF Power Module Relay Control	II	LWN
16	—	—	—	Not Occupied	—	—
17	0.5	YE	5991	Powertrain Relay Coil Control	II	—
18 - 19	—	—	—	Not Occupied	—	—
20	0.75	VT/GY	139	Run/Crank Ignition 1 Voltage	III	—

21	0.5	BK	1450	Ground	II	—
22 - 26	—	—	—	Not Occupied	—	—
27	0.5	RD/WH	140	Battery Positive Voltage	VI	—
28 - 29	—	—	—	Not Occupied	—	—
30	0.5	WH	2368	Cooling Fan Control Signal	II	—
31 - 32	—	—	—	Not Occupied	—	—
33	0.5	VT/GN	4320	Selective Catalytic Reduction Power Module Wake-Up Signal	II	—
34	0.5	WH/GY	459	A/C Compressor Clutch Relay Control	II	—
35	1.5	VT/BU	3674	NOx Sensor 1 Control	V	—
36	—	—	—	Not Occupied	—	—
37	0.75	RD/GN	1840	Battery Positive Voltage	III	—
38 - 39	—	—	—	Not Occupied	—	—
40	0.5	BU	3017	Fuel Heater Relay Control 1	II	—
41 - 48	—	—	—	Not Occupied	—	—
49	0.5	GN/BU	3889	DEF Power Module Relay Control	VI	—
50	0.75	BN/GN	59	A/C Compressor Clutch Control	VI	—

X50A Fuse Block - Underhood X4





Connector Part Information

Harness Type: Fuse Block - Underhood

OEM Connector: 15327720

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way Ring Terminal (NA)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray	Core Crimp	Insulation Crimp
I	Not Available	No Tool Required	Not Available	Not Available	Not Available	Not Available	Not Available

X50A Fuse Block - Underhood X4

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	35	RD/WH	4042	Battery Positive Voltage	I	—

X50A Fuse Block - Underhood X5





Connector Part Information

Harness Type: Generator Cable

OEM Connector: 15327720

Service Connector: Service by Cable Assembly - See Part Catalog

Description: 1-Way Ring Terminal

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

X50A Fuse Block - Underhood X5

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	35	RD	1	Unfused Battery Positive Voltage	I	—
	35	RD	2	Battery Positive Voltage	I	—

X50D Fuse Block - Battery Top View



Usage Table

No.	Device Label Name	Device Assigned Name	Rating	Description
Fuses				
1	—	F1UB	100A	•
2	—	F2UB	100A	•
3	—	F3UB	100A	•
4	—	F4UB	100A	•
5	—	F5UB	250A	•
6	—	F6UB	300A	•

X50D Fuse Block - Battery X1



Connector Part Information

Harness Type: Fuse Block - Battery

OEM Connector: 13371977

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way Ring Terminal (NA)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray	Core Crimp	Insulation Crimp
I	Not Available	No Tool Required	Not Available	Not Available	Not Available	Not Available	Not Available

X50D Fuse Block - Battery X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	10	RD/VT	842	Battery Positive Voltage	I	—

X50D Fuse Block - Battery X2



Connector Part Information

Harness Type: Body

OEM Connector: 13869260

Service Connector: Service by Cable Assembly - See Part Catalog

Description: 1-Way Ring Terminal

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

X50D Fuse Block - Battery X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	10	RD/VT	842	Battery Positive Voltage	I	—

X50D Fuse Block - Battery X3



Connector Part Information

Harness Type: Body

OEM Connector: 13869260

Service Connector: Service by Cable Assembly - See Part Catalog

Description: 1-Way Ring Terminal

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

X50D Fuse Block - Battery X3

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	10	RD/VT	842	Battery Positive Voltage	I	—

X50D Fuse Block - Battery X4 (LFX)





Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 13869288

Service Connector: Service by Cable Assembly - See Part Catalog

Description: 1-Way Ring Terminal

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

X50D Fuse Block - Battery X4 (LFX)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	10	RD/GY	4840	Battery Positive Voltage	I	—

X50D Fuse Block - Battery X4 (LWN)





Connector Part Information

Harness Type: Body

OEM Connector: 13869288

Service Connector: Service by Cable Assembly - See Part Catalog

Description: 1-Way Ring Terminal

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

X50D Fuse Block - Battery X4 (LWN)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	10	RD/GY	4840	Battery Positive Voltage	I	—

X50D Fuse Block - Battery X5



Connector Part Information

Harness Type: Fuse Block - Battery

OEM Connector: 13293547

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way Ring Terminal (NA)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray	Core Crimp	Insulation Crimp
I	Not Available	No Tool Required	Not Available	Not Available	Not Available	Not Available	Not Available

X50D Fuse Block - Battery X5

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	35	RD/WH	4042	Battery Positive Voltage	I	—

X50D Fuse Block - Battery X6



Connector Part Information

Harness Type: Generator Cable

OEM Connector: 13644223

Service Connector: Service by Cable Assembly - See Part Catalog

Description: 1-Way Ring Terminal

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

X50D Fuse Block - Battery X6

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	35	RD	1	Unfused Battery Positive Voltage	I	—
	35	RD	2	Battery Positive Voltage	I	—

X50D Fuse Block - Battery X7





Connector Part Information

Harness Type: Fuse Block - Battery

OEM Connector: 13303048

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way Ring Terminal (NA)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray	Core Crimp	Insulation Crimp
I	Not Available	No Tool Required	Not Available	Not Available	Not Available	Not Available	Not Available

X50D Fuse Block - Battery X7

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	35	RD	1	Battery Positive Voltage	I	—

X51A Fuse Block - Instrument Panel Label


F1
F2
F3
F4
F5
F6
F7
F8
F9
F10
F11
F12
F13
F14
F15
F16
F17
F18
F19
F20
F21
F22
F23
F24
F25
F26
F27
F28
F29
F30
F31
F32
F33
F34
F35
F36
F37
F38
F39
F40
BOTTOM SIDE
F41
K1
K2
K3
F42
F43
F44
F45
F46

1 BCM 1 (15A)
2 EMPTY
3 EMPTY
4 STR/WHL/CNTRL (5A)
5 BCM 2 (15A)
6 EMPTY
7 EMPTY
8 MIR WNDW MDL (5A)
9 I/P CLSTR (10A)
10 EMPTY
11 BCM 8 (30A)
12 EMPTY
13 ONSTAR/HVAC (10/10A)
14 RDO/INFOTMNT (20A)
15 BCM 6 (20A)
16 EMPTY
17 BCM 4 (20A)
18 AIRBAG (10A)
19 EMPTY
20 AMP (30A)
21 EMPTY
22 EMPTY
23 DLC/USB (10/10A)
24 HVAC RUN/CRNK (5A)
25 BCM 7 (20A)
26 EMPTY
27 EMPTY
28 I/P IGN/SDM IGN (10/10A)
29 MISC RUN/CRNK (10A)
30 EMPTY
31 FRT CAMERA (10A)
32 SWC BKLT (2A)
33 EMPTY
34 EMPTY
35 PRNDL (10A)
36 DLIS (2A)
37 EMPTY
38 EMPTY
39 APO 2 (15A)
40 EMPTY
41 APO 1/LTR (15A)
42 LT PWR WNDW (30A)
43 DRVR PWR SEAT (30A)
44 APO (50A)
45 RT PWR WNDW (30A)
46 PASS PWR SEAT (30A)

BOTTOM SIDE RELAYS
K1 RAP/ACCY
K2 RUN/CRANK
K3 EMPTY

X51A Fuse Block - Instrument Panel Top View Fuses


X3
X1
10
20
1
11
F1
F4
F5
F8
F9
F11
F13
F14
F15
F16
F17
F18
F19
F20
F23
F24
F25
F28
F29
F31
F32
F34
F35
F36
F39
F40
F41
F42
F43
F44
F45
F46
1
6
7
10
11
16
17
20
21
22
23
24
25
28
29
34
35
38
39
44

Usage Table

No.	Device Label Name	Device Assigned Name	Rating	Description
Fuses				
F1	BCM 1	F1DA	15A	•
F2	EMPTY	F2DA	—	•
F3	EMPTY	F3DA	—	•
F4	STR/WHL/CNTRL	F4DA	5A	• •
F5	BCM 2	F5DA	15A	•
F6	EMPTY	F6DA	—	•
F7	EMPTY	F7DA	—	•
F8	MIR WNDW MDL	F8DA	5A	• •
F9	I/P CLSTR	F9DA	10A	• • • •

				• •
F10	EMPTY	F10DA	—	•
F11	BCM 8	F11DA	30A	•
F12	EMPTY	F12DA	—	•
F13	ONSTAR/HVAC	F13DA	10A	• •
F14	RDO/INFOTMNT	F14DA	20A	• •
F15	BCM 6	F15DA	20A	•
F16	EMPTY	F16DA	—	•
F17	BCM 4	F17DA	20A	•
F18	AIRBAG	F18DA	10A	• •
F19	EMPTY	F19DA	—	•
F20	AMP	F20DA	30A	•
F21	EMPTY	F21DA	—	•
F22	EMPTY	F22DA	—	•
F23	DLC/USB	F23DA	10A	• • •
F24	HVAC RUN/CRNK	F24DA	5A	• •
F25	BCM 7	F25DA	20A	•
F26	EMPTY	F26DA	—	•
F27	EMPTY	F27DA	—	•
F28	I/P IGN/SDM IGN	F28DA	10A	• • •
F29	MISC RUN/CRNK	F29DA	10A	• •

				• •
F30	EMPTY	F30DA	—	•
F31	FRT CAMERA	F31DA	10A	•
F32	SWC BKLT	F32DA	2A	• • • •
F33	EMPTY	F33DA	—	•
F34	EMPTY	F34DA	—	•
F35	PRNDL	F35DA	10A	•
F36	DLIS	F36DA	2A	•
F37	EMPTY	F37DA	—	•
F38	EMPTY	F38DA	—	•
F39	APO 2	F39DA	15A	•
F40	EMPTY	F40DA	50A	• • • • •
F41	APO 1/LTR	F41DA	15A	• •
F42	LT PWR WNDW	F42DA	30A	• •
F43	DRVR PWR SEAT	F43DA	30A	•
F44	APO	F44DA	50A	• • • • •
F45	RT PWR WNDW	F45DA	30A	• •
F46	PASS PWR SEAT	F46DA	30A	•

F46	PASS PWR SEAT	F46DA	30A	•

X51A Fuse Block - Instrument Panel Bottom View Relays


X2
39
35
29
25
23
21
17
11
7
1
44
38
34
28
24
22
20
16
10
6
K3
87
86
87A
K2
85
30
30
85
K1
86
87

Usage Table

No.	Device Label Name	Device Assigned Name	Rating	Description
Relays				
K1	K1	KR76 Retained Accessory Power Relay	—	• •
K2	K2	KR73 Ignition Main Relay	—	• • •
K3	K3	—	—	• Not Used

X51A Fuse Block - Instrument Panel X1



Connector Part Information

Harness Type: Body

OEM Connector: 13967687

Service Connector: 19329455

Description: 44-Way F 1.5, 2.8, 800 Metri-Pack Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	19301761	J-35616-35 (VT)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
II	19301767	J-35616-2A (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available
III	Not Required	J-35616-44 (YE)	No Tool Required	Not Available	Not Available	Not Available	Not Available

X51A Fuse Block - Instrument Panel X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	RD/BN	2240	Battery Positive Voltage	II	—
2	0.5	RD/GY	2840	Battery Positive Voltage	II	—
3	0.35	RD/YE	3040	Battery Positive Voltage	II	—
4	0.5	RD/GY	2140	Battery Positive Voltage	II	—
5	0.5	RD/GN	4440	Battery Positive Voltage	II	—
6 - 13	—	—	—	Not Occupied	—	—
14	0.35	RD/BU	3240	Battery Positive Voltage	II	—
15	—	—	—	Not Occupied	—	—

15	—	—	—	Not Occupied	—	—
16	0.35	RD/VT	1940	Battery Positive Voltage	II	—
17	2.5	RD/YE	3740	Battery Positive Voltage	I	—
18	1.5	RD/WH	2740	Battery Positive Voltage	I	—
19	1.5	RD/VT	2640	Battery Positive Voltage	I	—
20	—	—	—	Not Occupied	—	—
21	10	RD/VT	842	Battery Positive Voltage	III	—
22	—	—	—	Not Occupied	—	—
23	10	RD/BU	42	Battery Positive Voltage	III	—
24	—	—	—	Not Occupied	—	—
25	2.5	RD/BU	1240	Battery Positive Voltage	I	—
26	—	—	—	Not Occupied	—	—
27	2.5	RD/YE	5040	Battery Positive Voltage	I	—
28 - 31	—	—	—	Not Occupied	—	—
32	0.35	VT/GN	1739	Run/Crank Ignition 1 Voltage	II	—
33 - 34	—	—	—	Not Occupied	—	—
35	2.5	RD/WH	1340	Battery Positive Voltage	I	—
36	2.5	RD/BN	1440	Battery Positive Voltage	I	—
37 - 41	—	—	—	Not Occupied	—	—
42	0.35	GN/VT	5199	Run/Crank Relay Coil Control	II	—

43	0.35	GY/VT	755	RAP Relay Coil Control	II	—
44	0.35	VT	801	Retained Accessory Power Fuse Control	II	—

X51A Fuse Block - Instrument Panel X2



Connector Part Information

Harness Type: Body

OEM Connector: 13967688

Service Connector: 19329456

Description: 44-Way F 1.5, 2.8, 800 Metri-Pack Series (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	19300649	J-35616-35 (VT)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
II	19301761	J-35616-35 (VT)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
III	19301767	J-35616-2A (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available

X51A Fuse Block - Instrument Panel X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 2	—	—	—	Not Occupied	—	—
3	0.35	YE	6817	LED Backlight Dimming Control	III	—
4	0.35	BN	6136	Control	III	—
5	0.5	RD/BU	540	Battery Positive Voltage	III	—
6	—	—	—	Not Occupied	—	—
7	2.5	RD/VT	4040	Battery Positive Voltage	II	—
8 - 9	—	—	—	Not Occupied	—	—
10	1.5	VT	2101	Retained Accessory Power Fuse Ignition	II	—
11 - 13	—	—	—	Not Occupied	—	—

11 - 13	—	—	—	Not Occupied	—	—
14	0.5	RD/VT	340	Battery Positive Voltage	III	—
15 - 17	—	—	—	Not Occupied	—	—
18	2.5	RD/GN	2440	Battery Positive Voltage	II	—
19	—	—	—	Not Occupied	—	—
20	1.5	VT	1701	Retained Accessory Power Ignition	II	—
21 - 24	—	—	—	Not Occupied	—	—
25	0.5	RD/VT	3340	Battery Positive Voltage	I	—
26	—	—	—	Not Occupied	—	—
27	0.5	RD/WH	640	Battery Positive Voltage	I	—
28	0.5	VT/BK	1639	Run/Crank Ignition 1 Voltage	I	—
29 - 34	—	—	—	Not Occupied	—	—
35	1	RD/VT	340	Battery Positive Voltage	II	—
36	—	—	—	Not Occupied	—	—
37	0.35	VT/GY	539	Run/Crank Ignition 1 Voltage	I	—
38	0.5	VT/GN	1739	Run/Crank Ignition 1 Voltage	I	—
39 - 43	—	—	—	Not Occupied	—	—
44	0.75	BK	2050	Ground	III	—

X51A Fuse Block - Instrument Panel X3 (LCV/LFX+N8D)



Connector Part Information

Harness Type: Body

OEM Connector: 15522322

Service Connector: 13597270

Description: 20-Way F 1.5, 2.8 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	19300649	J-35616-35 (VT)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
II	19301767	J-35616-2A (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available

X51A Fuse Block - Instrument Panel X3 (LCV/LFX+N8D)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 11	—	—	—	Not Occupied	—	—
12	0.35	RD/L-GN	3140	Battery Positive Voltage	II	—
13	0.5	VT/L-GN	1739	Run/Crank Ignition 1 Voltage	II	—
14	0.35	VT/WH	1139	Run/Crank Ignition 1 Voltage	I	—
15 - 20	—	—	—	Not Occupied	—	—

X51A Fuse Block - Instrument Panel X3 (LCV/LFX-N8D)



Connector Part Information

Harness Type: Body

OEM Connector: 15547106

Service Connector: 13597270

Description: 20-Way F 1.5, 2.8 OCS Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	19300649	J-35616-35 (VT)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
II	19301767	J-35616-2A (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available

X51A Fuse Block - Instrument Panel X3 (LCV/LFX-N8D)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 11	—	—	—	Not Occupied	—	—
12	0.35	RD/GN	3140	Battery Positive Voltage	II	—
13	0.5	VT/GN	1739	Run/Crank Ignition 1 Voltage	II	—
14	0.35	VT/WH	1139	Run/Crank Ignition 1 Voltage	I	—
15 - 20	—	—	—	Not Occupied	—	—

X51A Fuse Block - Instrument Panel X3 (LWN)



Connector Part Information

Harness Type: Body

OEM Connector: 15522322

Service Connector: 13597270

Description: 20-Way F 1.5, 2.8 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	19300649	J-35616-35 (VT)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
II	19301767	J-35616-2A (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available

X51A Fuse Block - Instrument Panel X3 (LWN)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 11	—	—	—	Not Occupied	—	—
12	0.35	RD/L-GN	3140	Battery Positive Voltage	II	—
13	0.5	VT/L-GN	1739	Run/Crank Ignition 1 Voltage	II	—
14	0.35	VT/WH	1139	Run/Crank Ignition 1 Voltage	I	—
15 - 20	—	—	—	Not Occupied	—	—

A7 Fuel Pump and Level Sensor Assembly (LCV/LGZ)



Connector Part Information

Harness Type: Chassis

OEM Connector: 13527865

Service Connector: 13587174

Description: 4-Way F 280 GT Series, Sealed (NA)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-4A (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

A7 Fuel Pump and Level Sensor Assembly (LCV/LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	2.5	GY	120	Fuel Pump Control	I	—
2	2.5	BK/GN	1580	Fuel Pump Low Reference	I	—
3	0.5	BK/GN	6281	Fuel Level Sensor Low Reference	I	—
4	0.5	L-BU/VT	1589	Primary Fuel Level Sensor Signal	I	—

A7 Fuel Pump and Level Sensor Assembly (LWN)



Connector Part Information

Harness Type: Chassis

OEM Connector: 2109441-2

Service Connector: 19330153

Description: 8-Way F 2.8 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

A7 Fuel Pump and Level Sensor Assembly (LWN)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 2	—	—	—	Not Occupied	—	—
3	2.5	GY	120	Fuel Pump Control	I	—
4	2.5	BK	1950	Ground	I	—
5	0.5	L-BU/VT	1589	Primary Fuel Level Sensor Signal	I	—
6	0.5	BK/GN	6281	Fuel Level Sensor Low Reference	I	—
7 - 8	—	—	—	Not Occupied	—	—

A10 Inside Rearview Mirror



Connector Part Information

Harness Type: Headliner

OEM Connector: 13577390

Service Connector: 13577390

Description: 10-Way F 0.64 Kaizen Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575867	J-35616-64B (LT BU)	J-38125-215A	SAIT-A03T-M064	Yazaki 14	P	P

A10 Inside Rearview Mirror

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GN/WH	24	Backup Lamp Control	I	—
2	0.5	VT/GN	1739	Run/Crank Ignition 1 Voltage	I	—
3	0.35	GN/WH	2514	Keypad Signal	I	—
4	0.35	GN/BK	2515	Keypad Control	I	—
5	0.5	BK	3150	Ground	I	—
6	0.35	YE/VT	2516	Keypad Green LED Control	I	—
7	0.35	BN/WH	2517	Keypad Red LED Control	I	—
8 - 10	—	—	—	Not Occupied	—	—

A11 Radio X1 (IO3)



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 31410-0201

Service Connector: 13593932

Description: 20-Way F USCAR 64 Series (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575845	J-35616-64B (LT BU)	J-38125-215A	SAIT-A03T-M064	Yazaki 14	P	P
II	19300631	J-35616-64B (LT BU)	J-38125-215A	Not Available	Not Available	Not Available	Not Available

A11 Radio X1 (IO3)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	BK/WH	1551	Signal Ground	I	—
2	0.35	BK/GN	2804	Radio Display Backlight Low Reference	II	—
3	0.35	GY/BN	3761	Infotainment Regulated Control	II	—
4	0.35	GY/GN	1102	Low Speed GMLAN Serial Data #2	II	—
5	—	—	—	Not Occupied	—	—
6	0.35	BK/GY	5152	Voice Recognition Audio Low Reference	II	—
7	0.35	GY/YE	5149	Voice Recognition Audio Signal	II	—
8	0.35	BN/GN	3983	Display Radio Bank Switch Signal 2	II	—

9	0.35	BK/YE	659	Cellular Telephone Voice Low Reference	II	—
10	0.35	YE	658	Cellular Telephone Voice Signal	II	—
11	0.75	RD/VT	340	Battery Positive Voltage	I	—
12 - 13	—	—	—	Not Occupied	—	—
14	0.35	WH/L-BU	6973	Camera Signal 2	II	—
15	0.35	GY/YE	6972	Camera Signal 2 +	II	—
16	0.5	BK	5842	Auxiliary Audio Screen 2	I	—
17	0.35	L-BU	2060	Auxiliary Detection Signal	II	—
18	0.35	VT	5843	Auxiliary Audio Common Signal	II	—
19	0.35	GY	5839	Left Auxiliary Audio Signal 2	II	—
20	0.35	GN	5841	Right Auxiliary Audio Signal 2	II	—

A11 Radio X1 (IO5/IO6)



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 31410-1201

Service Connector: 15126710

Description: 20-Way F 64 Series, Sealed (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575845	J-35616-64B (LT BU)	J-38125-215A	SAIT-A03T-M064	Yazaki 14	P	P

A11 Radio X1 (IO5/IO6)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 3	—	—	—	Not Occupied	—	—
4	0.35	WH/L-BU	6973	Camera Signal 2	I	—
5	0.35	GY/YE	6972	Camera Signal 2 +	I	—
6	0.5	BK	5842	Auxiliary Audio Screen 2	I	IO3+N8D
	0.5	BARE	5842	Auxiliary Audio Screen 2	I	IO5/IO6
7	0.35	L-BU	2060	Auxiliary Detection Signal	I	—
8	0.35	VT	5843	Auxiliary Audio Common Signal	I	—
9	0.35	GY	5839	Left Auxiliary Audio Signal 2	I	—
10	0.35	GN	5841	Right Auxiliary Audio Signal 2	I	—

10	0.35	GN	5841	Right Auxiliary Audio Signal 2	I	—
11 - 12	—	—	—	Not Occupied	—	—
13	0.5	GN/L-BU	7532	Local Interconnect Network Serial Data Bus 10	I	—
14	0.5	GY/GN	1102	Low Speed GMLAN Serial Data #2	I	—
15 - 18	—	—	—	Not Occupied	—	—
19	0.35	BK/YE	659	Cellular Telephone Voice Low Reference	I	—
20	0.35	YE	658	Cellular Telephone Voice Signal	I	—

A11 Radio X2 (IO3)



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 31410-0202

Service Connector: 13593933

Description: 20-Way F USCAR 64 Series (BN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575845	J-35616-64B (LT BU)	J-38125-215A	SAIT-A03T-M064	Yazaki 14	P	P
II	13575846	J-35616-64B (LT BU)	J-38125-215A	Not Available	Not Available	Not Available	Not Available

A11 Radio X2 (IO3)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 2	—	—	—	Not Occupied	—	—
3	0.35	GY	314	Radio On Signal	I	—
4	0.35	VT/GY	1381	LCD Dimming Signal	I	—
5	0.35	GY/L-BU	3989	Display Radio Bank Switch Dim Signal	I	—
6	0.35	BN/GN	4502	Video Display Request Signal	I	—
7	0.35	BN/GN	3364	Navigation Display Reset Signal	I	—
8	0.35	L-BU	4315	Radio Volume Up Signal	I	—
9	0.35	GY/BN	4314	Radio Volume Down Signal	I	—

10	0.75	BK/WH	1551	Signal Ground	II	—
11	0.75	WH	46	Right Rear Speaker Control (+)	I	—
12	0.75	L-BU/BK	115	Right Rear Speaker Signal (-)	I	—
13	0.75	GN	199	Left Rear Speaker Control (+)	I	—
14	0.75	GN/BK	116	Left Rear Speaker Signal (-)	I	—
15	0.75	YE/BK	117	Right Front Speaker Signal (-) 1	I	—
16	0.75	YE	200	Right Front Speaker Control (+) 1	I	—
17	0.75	BN/L-BU	118	Left Front Speaker Signal (-) 1	I	—
18	0.75	L-BU	201	Left Front Speaker Control (+) 1	I	—
19	—	—	—	Not Occupied	—	—
20	0.75	RD/VT	340	Battery Positive Voltage	II	—

A11 Radio X2 (IO3/IO5/IO6)



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 7283-9029-40

Service Connector: 19115653

Description: 8-Way F YESC Kaizen Series (L-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

A11 Radio X2 (IO3/IO5/IO6)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	WH/GN	3997	MOST Serial Data (-)	I	—
2	0.5	GY/VT	3998	MOST Serial Data (+)	I	—
3	0.5	WH/GN	3997	MOST Serial Data (-)	I	—
4	0.5	GY/VT	3998	MOST Serial Data (+)	I	—
5 - 6	—	—	—	Not Occupied	—	—
7	0.35	WH/VT	3999	MOST Control	I	—
8	—	—	—	Not Occupied	—	—

A11 Radio X3 (IOB)





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13580207

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 5-Way M 2.0 Mini-B USB Type (BU)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

A11 Radio X3 (IOB)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	USB	—	USB Serial Data	I	—

A11 Radio X3 (UQ3-IOB)



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 7283-6453-60

Service Connector: 89047090

Description: 16-Way F 1.5 Kaizen Series (GN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575829	J-35616-2A (GY)	J-38125-11A	Not Available	Not Available	Not Available	Not Available

A11 Radio X3 (UQ3-IOB)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	L-BU	201	Left Front Speaker Control (+) 1	I	—
2	0.75	YE	200	Right Front Speaker Control (+) 1	I	—
3	0.75	GN	199	Left Rear Speaker Control (+)	I	—
4	0.75	WH	46	Right Rear Speaker Control (+)	I	—
5 - 7	—	—	—	Not Occupied	—	—
8	1	RD/VT	340	Battery Positive Voltage	I	—
9	0.75	BN/L-BU	118	Left Front Speaker Signal (-) 1	I	—
10	0.75	YE/BK	117	Right Front Speaker Signal (-) 1	I	—

11	0.75	GN/BK	116	Left Rear Speaker Signal (-)	I	—
12	0.75	L-BU/BK	115	Right Rear Speaker Signal (-)	I	—
13 - 15	—	—	—	Not Occupied	—	—
16	1	BK/WH	2051	Signal Ground	I	—

A11 Radio X4 (IOB)



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13581686

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way F Coax Type (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

A11 Radio X4 (IOB)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	Coax	—	(AM/FM) Antenna RF Signal	I	—

A11 Radio X4 (-IOB)





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13581701

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way F Coax Type (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

A11 Radio X4 (-IOB)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	Coax	—	(AM/FM) Antenna RF Signal	I	—

A11 Radio X6



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13581707

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way F Coax Type (CU)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

A11 Radio X6

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	Coax	—	(XM +/-HD) Coaxial Antenna XM Signal	I	—

A11 Radio X7 (IO3)



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13581318

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 5-Way M 2.0 Mini-B USB Type (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

A11 Radio X7 (IO3)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	USB	—	USB Serial Data	I	—

A11 Radio X7 (IOB)





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13580212

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 5-Way M 2.0 Mini-B USB Type (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

A11 Radio X7 (IOB)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	USB	—	USB Serial Data	I	—

A11 Radio X8



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13581314

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 5-Way M 2.0 Mini-B USB Type (BN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

A11 Radio X8

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	USB	—	USB Serial Data	I	—

A16 Transfer Case Motor X1 (NQ6)



Connector Part Information

Harness Type: Engine

OEM Connector: 13538370

Service Connector: 19352361

Description: 8-Way F 280 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-4A (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

A16 Transfer Case Motor X1 (NQ6)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	2.5	YE/GY	1552	Transfer Case Motor Clockwise Control	I	—
B	2.5	RD/GY	1342	Battery Positive Voltage	I	—
C	2.5	YE/BN	1569	Transfer Case Lock Solenoid Control	I	—
D	2.5	YE/VT	1553	Transfer Case Motor Counter Clockwise Control	I	—
E	0.5	L-BU/GY	7473	Incremental Encoder Impulse Signal	I	—
F	0.5	YE	7474	Incremental Encoder Direction Signal	I	—
G	0.5	WH/GN	7475	Incremental Encoder Sensor 8V Reference	I	—
H	0.5	VT	7476	Incremental Encoder Sensor Low Reference	I	—

A16 Transfer Case Motor X1 (-NQ6)



Connector Part Information

Harness Type: Engine

OEM Connector: 13538370

Service Connector: 19352361

Description: 8-Way F 280 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-4A (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

A16 Transfer Case Motor X1 (-NQ6)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	2.5	YE/GY	1552	Transfer Case Motor Clockwise Control	I	—
B - C	—	—	—	Not Occupied	—	—
D	2.5	YE/VT	1553	Transfer Case Motor Counter Clockwise Control	I	—
E	0.5	L-BU/GY	7473	Incremental Encoder Impulse Signal	I	—
F	0.5	YE	7474	Incremental Encoder Direction Signal	I	—
G	0.5	WH/GN	7475	Incremental Encoder Sensor 8V Reference	I	—
H	0.5	VT	7476	Incremental Encoder Sensor Low Reference	I	—

A16 Transfer Case Motor X2



Connector Part Information

Harness Type: Engine

OEM Connector: 13538370

Service Connector: 19352361

Description: 8-Way F 280 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-4A (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

A16 Transfer Case Motor X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	2.5	YE/GY	1552	Transfer Case Motor Clockwise Control	I	—
B	2.5	RD/GY	1342	Battery Positive Voltage	I	—
C	2.5	YE/BN	1569	Transfer Case Lock Solenoid Control	I	—
D	2.5	YE/VT	1553	Transfer Case Motor Counter Clockwise Control	I	—
E	0.5	L-BU/GY	7473	Incremental Encoder Impulse Signal	I	—
F	0.5	YE	7474	Incremental Encoder Direction Signal	I	—
G	0.5	WH/GN	7475	Incremental Encoder Sensor 8V Reference	I	—
H	0.5	VT	7476	Incremental Encoder Sensor Low Reference	I	—

A23D Door Latch Assembly - Driver



Connector Part Information

Harness Type: Driver Door

OEM Connector: 7283-9043-60

Service Connector: Service by Harness - See Part Catalog

Description: 10-Way F 0.64 YESC Kaizen Series (GN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

A23D Door Latch Assembly - Driver

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	GY	745	Left Front Door Ajar Switch Signal	I	—
2	—	—	—	Not Occupied	—	—
3	0.35	BK	3550	Ground	I	—
4	0.35	WH/VT	3270	Driver Door Lock Motor Status Signal	I	—
5	0.35	L-BU/VT	1124	Door Lock Key Switch Unlock Signal	I	—
6	—	—	—	Not Occupied	—	—
7	0.75	GY	5911	Door Lock Actuator Lock Control 2	I	—
8	0.75	BN/YE	294	Door Lock Actuator Unlock Control	I	—
9 - 10	—	—	—	Not Occupied	—	—

A23G Door Latch Assembly - Left Rear Lower



Connector Part Information

Harness Type: Left Rear Door

OEM Connector: 7282-6160

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way M 090 Series (NA)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-19 (BK)	No Tool Required	Not Required	Not Required	Not Required	Not Required

A23G Door Latch Assembly - Left Rear Lower

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	BK	3350	Ground	I	—
2	0.35	GY	747	Left Rear Door Ajar Switch Signal	I	—

A23H Door Latch Assembly - Left Rear Upper





Connector Part Information

Harness Type: Left Rear Door

OEM Connector: 7282-6160

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way M 090 Series (NA)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-19 (BK)	No Tool Required	Not Required	Not Required	Not Required	Not Required

A23H Door Latch Assembly - Left Rear Upper

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	BK	3350	Ground	I	—
2	0.35	GY	747	Left Rear Door Ajar Switch Signal	I	—

A23J Door Latch Assembly - Right Rear Lower



Connector Part Information

Harness Type: Right Rear Door

OEM Connector: 7282-6160

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way M 090 Series (NA)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-19 (BK)	No Tool Required	Not Required	Not Required	Not Required	Not Required

A23J Door Latch Assembly - Right Rear Lower

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	BK	3450	Ground	I	—
2	0.35	GY	748	Right Rear Door Ajar Switch Signal	I	—

A23K Door Latch Assembly - Right Rear Upper





Connector Part Information

Harness Type: Right Rear Door

OEM Connector: 7282-6160

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way M 090 Series (NA)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-19 (BK)	No Tool Required	Not Required	Not Required	Not Required	Not Required

A23K Door Latch Assembly - Right Rear Upper

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	BK	3450	Ground	I	—
2	0.35	GY	748	Right Rear Door Ajar Switch Signal	I	—

A23P Door Latch Assembly - Passenger



Connector Part Information

Harness Type: Passenger Door

OEM Connector: 7283-9043-60

Service Connector: Service by Harness - See Part Catalog

Description: 10-Way F 0.64 YESC Kaizen Series (GN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

A23P Door Latch Assembly - Passenger

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 2	—	—	—	Not Occupied	—	—
3	0.35	BK	3650	Ground	I	—
4	—	—	—	Not Occupied	—	—
5	0.35	GY	746	Right Front Door Ajar Switch Signal	I	—
6 - 7	—	—	—	Not Occupied	—	—
8	0.75	BN/YE	294	Door Lock Actuator Unlock Control	I	—
9	0.75	GY	295	Door Lock Actuator Lock Control	I	—
10	—	—	—	Not Occupied	—	—

A26 HVAC Controls



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: AIT2PB-10P-2BH

Service Connector: 13581139

Description: 10-Way F 0.64 Kaizen Series (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575867	J-35616-64B (LT BU)	J-38125-215A	SAIT-A03T-M064	Yazaki 14	P	P

A26 HVAC Controls

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	RD/GY	2840	Battery Positive Voltage	I	—
2	—	—	—	Not Occupied	—	—
3	0.35	GN	5060	Low Speed GMLAN Serial Data	I	—
4 - 8	—	—	—	Not Occupied	—	—
9	0.35	GN/YE	7531	Local Interconnect Network Serial Data Bus 9	I	—
10	0.35	BK/WH	2051	Signal Ground	I	—

B1 A/C Refrigerant Pressure Sensor (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 13532244

Service Connector: 88988301

Description: 3-Way F 150 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B1 A/C Refrigerant Pressure Sensor (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BK/BN	5514	A/C Refrigerant Pressure Sensor Low Reference	I	—
2	0.5	BN/RD	2700	A/C Pressure Sensor 5V Reference	I	—
3	0.5	GN	380	A/C Refrigerant Pressure Sensor Signal	I	—

B1 A/C Refrigerant Pressure Sensor (-LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 13532244

Service Connector: 88988301

Description: 3-Way F 150 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B1 A/C Refrigerant Pressure Sensor (-LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BK/BN	5514	A/C Refrigerant Pressure Sensor Low Reference	I	—
2	0.5	BN/RD	2700	A/C Pressure Sensor 5V Reference	I	—
3	0.5	GN	380	A/C Refrigerant Pressure Sensor Signal	I	—

B1 A/C Refrigerant Pressure Sensor (LGZ)



Connector Part Information

Harness Type: Engine

OEM Connector: 13602480

Service Connector: 88988301

Description: 3-Way F 150 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B1 A/C Refrigerant Pressure Sensor (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BK/BN	5514	A/C Refrigerant Pressure Sensor Low Reference	I	—
2	0.5	BN/RD	2700	A/C Pressure Sensor 5V Reference	I	—
3	0.5	GN	380	A/C Refrigerant Pressure Sensor Signal	I	—

B1 A/C Refrigerant Pressure Sensor (LWN)



Connector Part Information

Harness Type: Engine

OEM Connector: 13532244

Service Connector: 88988301

Description: 3-Way F 150 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B1 A/C Refrigerant Pressure Sensor (LWN)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BK/BN	5514	A/C Refrigerant Pressure Sensor Low Reference	I	—
2	0.5	BN/RD	2700	A/C Pressure Sensor 5V Reference	I	—
3	0.5	GN	380	A/C Refrigerant Pressure Sensor Signal	I	—

B5LF Wheel Speed Sensor - Left Front





Connector Part Information

Harness Type: Chassis

OEM Connector: 7287-0973-30

Service Connector: 13586115

Description: 2-Way F 1.5 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B5LF Wheel Speed Sensor - Left Front

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/WH	7064	Wheel Speed Sensor Control Left Front	I	—
2	0.5	GY	830	Wheel Speed Sensor Signal Left Front	I	—

B5LR Wheel Speed Sensor - Left Rear





Connector Part Information

Harness Type: Chassis

OEM Connector: 7287-0973-30

Service Connector: 13586115

Description: 2-Way F 1.5 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B5LR Wheel Speed Sensor - Left Rear

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/BK	7127	Wheel Speed Sensor Control Left Rear	I	—
2	0.5	L-BU	884	Wheel Speed Sensor Signal Left Rear	I	—





Connector Part Information

Harness Type: Chassis

OEM Connector: 7287-0973-30

Service Connector: 13586115

Description: 2-Way F 1.5 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B5RF Wheel Speed Sensor - Right Front

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/BN	7065	Wheel Speed Sensor Control Right Front	I	—
2	0.5	YE	872	Wheel Speed Sensor Signal Right Front	I	—

B5RR Wheel Speed Sensor - Right Rear





Connector Part Information

Harness Type: Chassis

OEM Connector: 7287-0973-30

Service Connector: 13586115

Description: 2-Way F 1.5 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B5RR Wheel Speed Sensor - Right Rear

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/YE	7128	Wheel Speed Sensor Control Right Rear	I	—
2	0.5	VT	882	Wheel Speed Sensor Signal Right Rear	I	—

B7B Air Temperature Sensor - Duct Lower



Connector Part Information

Harness Type: HVAC

OEM Connector: 12047662

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F 150 Metri-Pack Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B7B Air Temperature Sensor - Duct Lower

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	20	BN	518	Lower Left Air Temperature Sensor Signal	I	—
B	22	BK/YE	407	Sensor Low Reference	I	—

B7F Air Temperature Sensor - Duct Upper



Connector Part Information

Harness Type: HVAC

OEM Connector: 12047662

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F 150 Metri-Pack Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B7F Air Temperature Sensor - Duct Upper

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	22	BN	516	Upper Left Air Temperature Sensor Signal	I	—
B	22	BK/YE	407	Sensor Low Reference	I	—

B10B Ambient Light/Sunload Sensor



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 24419225

Service Connector: 13576539

Description: 6-Way F 0.64 Micro-Quadlock Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B10B Ambient Light/Sunload Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	GY	728	Security Indicator Control	I	—
2	—	—	—	Not Occupied	—	—
3	0.35	L-BU/WH	734	Inside Air Temperature Sensor Signal	I	—
4	0.35	YE/VT	1783	Twilight Sentinel Delay Signal	I	—
5	0.35	WH/L-BU	278	Ambient Light Sensor Signal	I	—
6	0.35	BK/YE	1791	Air Temperature Door Control Low Reference	I	—

B14A Transmission Output Shaft Speed Sensor (N8D)



Connector Part Information

Harness Type: Engine

OEM Connector: 90508602

Service Connector: 19330658

Description: 3-Way F 2.8 Junior Power Timer Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B14A Transmission Output Shaft Speed Sensor (N8D)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BK/GN	822	Vehicle Speed Sensor Low Reference	I	—
2	0.5	VT/WH	821	Vehicle Speed Sensor Signal	I	—
3	0.5	L-BU/RD	1688	5V Reference	I	—

B14A Transmission Output Shaft Speed Sensor (NQ6/NQ7)



Connector Part Information

Harness Type: Engine

OEM Connector: 13511996

Service Connector: 13580873

Description: 3-Way F 150 GT Series, Sealed (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B14A Transmission Output Shaft Speed Sensor (NQ6/NQ7)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	L-BU/RD	1688	5V Reference	I	—
2	0.5	VT/WH	821	Vehicle Speed Sensor Signal	I	—
3	0.5	BK/GN	822	Vehicle Speed Sensor Low Reference	I	—

B16 Backup Lamp Switch



Connector Part Information

Harness Type: Engine

OEM Connector: 90346580

Service Connector: 13580106

Description: 2-Way F 150 Metri-Pack Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B16 Backup Lamp Switch

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	GN/WH	5007	Reverse Switch Signal	I	—
B	0.5	BK/WH	451	Signal Ground	I	—

B18 Battery Current Sensor



Connector Part Information

Harness Type: Body

OEM Connector: 13519047

Service Connector: 13580871

Description: 3-Way F 150 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B18 Battery Current Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	L-BU/VT	5076	Current Sensor Control	I	—
B	0.5	BK/VT	5077	Current Sensor Low Reference	I	—
C	0.5	WH/YE	5075	Current Sensor Signal	I	—

B19B Brake Booster Vacuum Sensor



Connector Part Information

Harness Type: Chassis

OEM Connector: 13503570

Service Connector: 19299690

Description: 3-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B19B Brake Booster Vacuum Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	YE/VT	6030	Brake Vacuum Sensor Signal	I	—
2	0.5	BK/YE	6032	Brake Vacuum Sensor Low Reference	I	—
3	0.5	YE/RD	6031	Brake Vacuum Sensor 5V Reference	I	—

B20 Brake Fluid Level Switch



Connector Part Information

Harness Type: Chassis

OEM Connector: 15449028

Service Connector: 88987993

Description: 2-Way F 150 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B20 Brake Fluid Level Switch

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	BK/WH	551	Signal Ground	I	—
B	0.5	GN/GY	333	Brake Fluid Level Sensor Signal	I	—

B22 Brake Pedal Position Sensor (MYB/M5T)



Connector Part Information

Harness Type: Body

OEM Connector: 31404-6810

Service Connector: 19304011

Description: 6-Way F 64 Series, Sealed (NA)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B22 Brake Pedal Position Sensor (MYB/M5T)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BK/BN	5360	Brake Apply Sensor Low Reference	I	—
2	0.5	WH	5359	Brake Apply Sensor Control	I	—
3	0.5	L-BU/YE	5361	Brake Apply Sensor Signal	I	—
4	0.5	WH/GN	5380	Brake Position Sensor Signal	I	—
5	0.5	BK/YE	5382	Brake Position Sensor Low Reference	I	—
6	0.5	WH/RD	5381	Brake Position Sensor 5V Reference	I	—

B22 Brake Pedal Position Sensor (N8D)



Connector Part Information

Harness Type: Body

OEM Connector: 15332132

Service Connector: 88953364

Description: 3-Way F 150 GT Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B22 Brake Pedal Position Sensor (N8D)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	WH	5359	Brake Apply Sensor Control	I	—
B	0.5	L-BU/YE	5361	Brake Apply Sensor Signal	I	—
C	0.5	BK/BN	5360	Brake Apply Sensor Low Reference	I	—

B23 Camshaft Position Sensor (LWN)



Connector Part Information

Harness Type: Engine

OEM Connector: 13503570

Service Connector: 19299690

Description: 3-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B23 Camshaft Position Sensor (LWN)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/L-BU	5300	Camshaft Position Intake Sensor Control 1	I	—
2	0.5	BK/GN	5301	Camshaft Position Intake Sensor Low Reference 1	I	—
3	0.5	YE/VT	5275	Camshaft Position Intake Sensor 1	I	—

B23A Camshaft Position Sensor - Bank 1 Exhaust (LGZ)



Connector Part Information

Harness Type: Engine

OEM Connector: 2098541-5

Service Connector: 19329387

Description: 3-Way F 1.2 MCP Series, Sealed (BN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B23A Camshaft Position Sensor - Bank 1 Exhaust (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/YE	5297	Camshaft Position Exhaust Sensor Control 1	I	—
2	0.5	BK/GY	5296	Camshaft Position Exhaust Sensor Low Reference 1	I	—
3	0.5	VT/BK	5273	Camshaft Position Exhaust Sensor 1	I	—

B23B Camshaft Position Sensor - Bank 1 Intake (LGZ)





Connector Part Information

Harness Type: Engine

OEM Connector: 2098541-5

Service Connector: 19329387

Description: 3-Way F 1.2 MCP Series, Sealed (BN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B23B Camshaft Position Sensor - Bank 1 Intake (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/L-BU	5300	Camshaft Position Intake Sensor Control 1	I	—
2	0.5	BK/GN	5301	Camshaft Position Intake Sensor Low Reference 1	I	—
3	0.5	YE/VT	5275	Camshaft Position Intake Sensor 1	I	—

B23C Camshaft Position Sensor - Bank 2 Exhaust (LGZ)



Connector Part Information

Harness Type: Engine

OEM Connector: 2098541-5

Service Connector: 19329387

Description: 3-Way F 1.2 MCP Series, Sealed (BN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B23C Camshaft Position Sensor - Bank 2 Exhaust (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GN/BN	5298	Camshaft Position Exhaust Sensor Control 2	I	—
2	0.5	BK/BN	5299	Camshaft Position Exhaust Sensor Low Reference 2	I	—
3	0.5	VT/L-BU	5274	Camshaft Position Exhaust Sensor 2	I	—

B23D Camshaft Position Sensor - Bank 2 Intake (LGZ)



Connector Part Information

Harness Type: Engine

OEM Connector: 2098541-5

Service Connector: 19329387

Description: 3-Way F 1.2 MCP Series, Sealed (BN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B23D Camshaft Position Sensor - Bank 2 Intake (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	WH/L-BU	5302	Camshaft Position Intake Sensor Control 2	I	—
2	0.5	BK/VT	5303	Camshaft Position Intake Sensor Low Reference 2	I	—
3	0.5	YE	5276	Camshaft Position Intake Sensor 2	I	—

B23E Camshaft Position Sensor - Exhaust (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 13503570

Service Connector: 19299690

Description: 3-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B23E Camshaft Position Sensor - Exhaust (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/YE	5297	Camshaft Position Exhaust Sensor Control 1	I	—
2	0.5	BK/GY	5296	Camshaft Position Exhaust Sensor Low Reference 1	I	—
3	0.5	VT/BK	5273	Camshaft Position Exhaust Sensor 1	I	—

B23F Camshaft Position Sensor - Intake (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 13503570

Service Connector: 19299690

Description: 3-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B23F Camshaft Position Sensor - Intake (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/L-BU	5300	Camshaft Position Intake Sensor Control 1	I	—
2	0.5	BK/GN	5301	Camshaft Position Intake Sensor Low Reference 1	I	—
3	0.5	YE/VT	5275	Camshaft Position Intake Sensor 1	I	—

B24 Cellular Phone Microphone



Connector Part Information

Harness Type: Headliner

OEM Connector: 12047663

Service Connector: 13584278

Description: 2-Way M 150 Metri-Pack Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-3 (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B24 Cellular Phone Microphone

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.35	BK/BN	654	Cellular Telephone Microphone Low Reference	I	—
B	0.35	L-BU	655	Cellular Telephone Microphone Signal	I	—

B25B Clutch Pedal Position Sensor



Connector Part Information

Harness Type: Body

OEM Connector: 15332132

Service Connector: 88953364

Description: 3-Way F 150 GT Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B25B Clutch Pedal Position Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	GY/RD	6109	Clutch Apply Sensor 5V Reference	I	—
B	0.5	YE	6111	Clutch Apply Sensor Signal	I	—
C	0.5	BK/GY	6110	Clutch Apply Sensor Low Reference	I	—

B26 Crankshaft Position Sensor (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 13503570

Service Connector: 19299690

Description: 3-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B26 Crankshaft Position Sensor (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/L-BU	6270	Crankshaft 60X Sensor 5V Reference	I	—
2	0.5	BK/VT	6272	Crankshaft 60X Sensor Low Reference	I	—
3	0.5	GN	6271	Crankshaft 60X Sensor Signal	I	—

B26 Crankshaft Position Sensor (LGZ+ZR2)



Connector Part Information

Harness Type: Engine

OEM Connector: 2098541-5

Service Connector: 19329387

Description: 3-Way F 1.2 MCP Series, Sealed (BN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B26 Crankshaft Position Sensor (LGZ+ZR2)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/L-BU	6270	Crankshaft 60X Sensor 5V Reference	I	—
2	0.5	BK/VT	6272	Crankshaft 60X Sensor Low Reference	I	—
3	0.5	GN	6271	Crankshaft 60X Sensor Signal	I	—

B26 Crankshaft Position Sensor (LGZ-ZR2)





Connector Part Information

Harness Type: Engine

OEM Connector: 4-2272004-1

Service Connector: 19352065

Description: 3-Way F 1.2 MCP Series, Sealed (BN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B26 Crankshaft Position Sensor (LGZ-ZR2)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/L-BU	6270	Crankshaft 60X Sensor 5V Reference	I	—
2	0.5	BK/VT	6272	Crankshaft 60X Sensor Low Reference	I	—
3	0.5	GN	6271	Crankshaft 60X Sensor Signal	I	—

B26 Crankshaft Position Sensor (LWN)



Connector Part Information

Harness Type: Engine

OEM Connector: 13503570

Service Connector: 19299690

Description: 3-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B26 Crankshaft Position Sensor (LWN)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/L-BU	6270	Crankshaft 60X Sensor 5V Reference	I	—
2	0.5	BK/VT	6272	Crankshaft 60X Sensor Low Reference	I	—
3	0.5	GN	6271	Crankshaft 60X Sensor Signal	I	—

B26 Crankshaft Position Sensor (LWN-LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 13503570

Service Connector: 19299690

Description: 3-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B26 Crankshaft Position Sensor (LWN-LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/L-BU	6270	Crankshaft 60X Sensor 5V Reference	I	—
2	0.5	BK/VT	6272	Crankshaft 60X Sensor Low Reference	I	—
3	0.5	GN	6271	Crankshaft 60X Sensor Signal	I	—

B34 Engine Coolant Temperature Sensor (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 1-967644-1

Service Connector: 13576533

Description: 2-Way F 0.64 Micro-Quadlock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B34 Engine Coolant Temperature Sensor (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	L-BU	410	Engine Coolant Temperature Sensor Signal	I	—
2	0.5	BK/BN	2761	Coolant Temperature Sensor Low Reference	I	—

B34 Engine Coolant Temperature Sensor (LWN)



Connector Part Information

Harness Type: Engine

OEM Connector: 13115612

Service Connector: 88953309

Description: 2-Way F 2.8 Junior Power Timer Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B34 Engine Coolant Temperature Sensor (LWN)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	L-BU	410	Engine Coolant Temperature Sensor Signal	I	—
2	0.5	BK/BN	2761	Coolant Temperature Sensor Low Reference	I	—

B35 Engine Oil Level Switch (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 1928403874

Service Connector: 88988963

Description: 2-Way F 2.8 Kompakt Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B35 Engine Oil Level Switch (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BK/WH	1451	Signal Ground	I	—
2	0.5	BN/GN	1174	Oil Level Switch Signal	I	—

B35 Engine Oil Level Switch (LGZ)



Connector Part Information

Harness Type: Engine

OEM Connector: 10010337

Service Connector: 13587326

Description: 2-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B35 Engine Oil Level Switch (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BK	650	Ground	I	—
2	0.5	BN/GN	1174	Oil Level Switch Signal	I	—

B35 Engine Oil Level Switch (LWN)



Connector Part Information

Harness Type: Engine

OEM Connector: 10010337

Service Connector: 13587326

Description: 2-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B35 Engine Oil Level Switch (LWN)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BN/GN	1174	Oil Level Switch Signal	I	—
2	0.75	BK/WH	151	Signal Ground	I	—

B37B Engine Oil Pressure Sensor (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 13503570

Service Connector: 19299690

Description: 3-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B37B Engine Oil Pressure Sensor (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	YE/BN	331	Oil Pressure Sensor Signal	I	—
2	0.5	BK/VT	2755	Oil Pressure Sensor Low Reference	I	—
3	0.5	WH/RD	2705	Oil Pressure Sensor 5V Reference	I	—

B37B Engine Oil Pressure Sensor (LGZ)



Connector Part Information

Harness Type: Engine

OEM Connector: 10010344

Service Connector: 19301717

Description: 3-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B37B Engine Oil Pressure Sensor (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	YE/BN	331	Oil Pressure Sensor Signal	I	—
2	0.5	BK/VT	2755	Oil Pressure Sensor Low Reference	I	—
3	0.5	WH/RD	2705	Oil Pressure Sensor 5V Reference	I	—

B37B Engine Oil Pressure Sensor (LWN)



Connector Part Information

Harness Type: Engine

OEM Connector: 10010344

Service Connector: 19301717

Description: 3-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B37B Engine Oil Pressure Sensor (LWN)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	YE/BN	331	Oil Pressure Sensor Signal	I	—
2	0.5	BK/VT	2755	Oil Pressure Sensor Low Reference	I	—
3	0.5	WH/RD	2705	Oil Pressure Sensor 5V Reference	I	—

B39 A/C Evaporator Temperature Sensor



Connector Part Information

Harness Type: HVAC

OEM Connector: 12047662

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F 150 Metri-Pack Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B39 A/C Evaporator Temperature Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	22	GY	6137	EVAP Core Temperature Sensor Signal	I	—
B	22	BK/YE	407	Sensor Low Reference	I	—

B47 Fuel Pressure Sensor



Connector Part Information

Harness Type: Chassis

OEM Connector: 13511131

Service Connector: 19168035

Description: 3-Way F 150 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B47 Fuel Pressure Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	L-BU/WH	7446	Fuel Line Pressure Sensor Signal	I	—
2	0.5	BK/YE	7447	Fuel Line Pressure Sensor Low Reference	I	—
3	0.5	BN/RD	7445	Fuel Line Pressure Sensor 5V Reference	I	—

B47B Fuel Rail Pressure Sensor



Connector Part Information

Harness Type: Engine

OEM Connector: 10010346

Service Connector: 13587299

Description: 4-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B47B Fuel Rail Pressure Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BN/RD	2917	Fuel Rail Pressure Sensor 5V Reference	I	—
2	0.5	BN/YE	2161	Fuel Rail Pressure Sensor 2 Signal	I	—
3	0.5	BK/GN	2919	Fuel Rail Pressure Sensor Low Reference	I	—
4	0.5	L-BU/WH	2918	Fuel Rail Pressure Sensor Signal	I	—

B52A Heated Oxygen Sensor 1



Connector Part Information

Harness Type: Engine

OEM Connector: 10010346

Service Connector: 13587299

Description: 4-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B52A Heated Oxygen Sensor 1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/WH	3113	Heated Oxygen Sensor Heater Low Control Bank 1 Sensor 1	I	—
2	0.5	VT/L-BU	5293	Powertrain Main Relay Fused Supply 4	I	—
3	0.5	WH/BK	3111	Heated Oxygen Sensor Low Signal Bank 1 Sensor 1	I	—
4	0.5	VT/GY	3110	Heated Oxygen Sensor High Signal Bank 1 Sensor 1	I	—

B52B Heated Oxygen Sensor 2



Connector Part Information

Harness Type: Engine

OEM Connector: 10010347

Service Connector: 13587298

Description: 4-Way F 1.2 Multilock Series, Sealed (L-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B52B Heated Oxygen Sensor 2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/WH	3122	Heated Oxygen Sensor Heater Low Control Bank 1 Sensor 2	I	—
2	0.5	VT/L-BU	5294	Powertrain Main Relay Fused Supply 5	I	—
3	0.5	WH/YE	3121	Heated Oxygen Sensor Low Signal Bank 1 Sensor 2	I	—
4	0.5	VT/L-BU	3120	Heated Oxygen Sensor High Signal Bank 1 Sensor 2	I	—

B52C Heated Oxygen Sensor - Bank 1 Sensor 1



Connector Part Information

Harness Type: Engine

OEM Connector: 10021266

Service Connector: 19330920

Description: 4-Way M 1.2 Multilock Series, Sealed (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B52C Heated Oxygen Sensor - Bank 1 Sensor 1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/WH	3113	Heated Oxygen Sensor Heater Low Control Bank 1 Sensor 1	I	—
2	0.5	VT/L-BU	5293	Powertrain Main Relay Fused Supply 4	I	—
3	0.5	WH/BK	3111	Heated Oxygen Sensor Low Signal Bank 1 Sensor 1	I	—
4	0.5	VT/GY	3110	Heated Oxygen Sensor High Signal Bank 1 Sensor 1	I	—

B52D Heated Oxygen Sensor - Bank 1 Sensor 2



Connector Part Information

Harness Type: Engine

OEM Connector: 10021266

Service Connector: 19330920

Description: 4-Way M 1.2 Multilock Series, Sealed (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B52D Heated Oxygen Sensor - Bank 1 Sensor 2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/WH	3122	Heated Oxygen Sensor Heater Low Control Bank 1 Sensor 2	I	—
2	0.5	VT/L-BU	5294	Powertrain Main Relay Fused Supply 5	I	—
3	0.5	WH/YE	3121	Heated Oxygen Sensor Low Signal Bank 1 Sensor 2	I	—
4	0.5	VT/L-BU	3120	Heated Oxygen Sensor High Signal Bank 1 Sensor 2	I	—

B52E Heated Oxygen Sensor - Bank 2 Sensor 1



Connector Part Information

Harness Type: Engine

OEM Connector: 10021266

Service Connector: 19330920

Description: 4-Way M 1.2 Multilock Series, Sealed (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B52E Heated Oxygen Sensor - Bank 2 Sensor 1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GN/YE	3212	Heated Oxygen Sensor Heater Low Control Bank 2 Sensor 1	I	—
2	0.5	VT/L-BU	5293	Powertrain Main Relay Fused Supply 4	I	—
3	0.5	YE/WH	3211	Heated Oxygen Sensor Low Signal Bank 2 Sensor 1	I	—
4	0.5	VT/WH	3210	Heated Oxygen Sensor High Signal Bank 2 Sensor 1	I	—

B52F Heated Oxygen Sensor - Bank 2 Sensor 2



Connector Part Information

Harness Type: Engine

OEM Connector: 10021266

Service Connector: 19330920

Description: 4-Way M 1.2 Multilock Series, Sealed (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B52F Heated Oxygen Sensor - Bank 2 Sensor 2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	WH/BN	3223	Heated Oxygen Sensor Heater Low Control Bank 2 Sensor 2	I	—
2	0.5	VT/L-BU	5294	Powertrain Main Relay Fused Supply 5	I	—
3	0.5	YE/L-BU	3221	Heated Oxygen Sensor Low Signal Bank 2 Sensor 2	I	—
4	0.5	VT/GN	3220	Heated Oxygen Sensor High Signal Bank 2 Sensor 2	I	—

B55 Hood Ajar Switch



Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 13519047

Service Connector: 13580871

Description: 3-Way F 150 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B55 Hood Ajar Switch

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	—	—	—	Not Occupied	—	—
B	0.5	BN/GN	109	Hood Ajar Switch Signal	I	—
C	0.75	BK	1250	Ground	I	BTV/UTJ-LWN
	0.75	BK/WH	1251	Signal Ground	I	LWN

B59L Front Impact Sensor - Left





Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 54390241

Service Connector: 19329742

Description: 2-Way F 0.64 Series, Sealed

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B59L Front Impact Sensor - Left

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	OG/YE	354	Left Front Discriminating Sensor Signal	I	—
2	0.5	BK/OG	5045	Left Front Discriminating Sensor Low Reference	I	—

B59R Front Impact Sensor - Right



Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 54390241

Service Connector: 19329742

Description: 2-Way F 0.64 Series, Sealed

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B59R Front Impact Sensor - Right

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	OG/GN	1409	Right Front Discriminating Sensor Signal	I	—
2	0.5	BK/OG	5600	Right Front Discriminating Sensor Low Reference	I	—

B63LF Side Impact Sensor - Left Front



Connector Part Information

Harness Type: Driver Door

OEM Connector: 54390240

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F 0.64 Series, Sealed (L-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B63LF Side Impact Sensor - Left Front

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	OG/GN	2132	Left Front Side Impact Sensing Module Signal	I	—
2	0.35	BK/OG	6628	Left Front Side Impact Sensing Module Low Reference	I	—

B63LR Side Impact Sensor - Left Rear



Connector Part Information

Harness Type: Body

OEM Connector: 54390242

Service Connector: 13585852

Description: 2-Way F 0.64 Series, Sealed (D-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B63LR Side Impact Sensor - Left Rear

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	OG/L-BU	6620	Left Middle Side Impact Sensing Module Signal	I	—
2	0.35	BK/OG	6621	Left Middle Side Impact Sensing Module Low Reference	I	—

B63RF Side Impact Sensor - Right Front



Connector Part Information

Harness Type: Passenger Door

OEM Connector: 54390240

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F 0.64 Series, Sealed (L-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B63RF Side Impact Sensor - Right Front

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	BN/OG	2134	Right Front Side Impact Sensing Module Signal	I	—
2	0.35	BK/OG	6629	Right Front Side Impact Sensing Module Low Reference	I	—

B63RR Side Impact Sensor - Right Rear



Connector Part Information

Harness Type: Body

OEM Connector: 54390242

Service Connector: 13585852

Description: 2-Way F 0.64 Series, Sealed (D-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B63RR Side Impact Sensor - Right Rear

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	OG/VT	6624	Right Middle Side Impact Sensing Module Signal	I	—
2	0.35	BK/OG	6625	Right Middle Side Impact Sensing Module Low Reference	I	—

B65 Intake Manifold Pressure and Air Temperature Sensor



Connector Part Information

Harness Type: Engine

OEM Connector: 1928405525

Service Connector: 13584423

Description: 4-Way F 2.8 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B65 Intake Manifold Pressure and Air Temperature Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BK/GN	469	Manifold Absolute Pressure Sensor Low Reference	I	—
2	0.5	BN	7348	Induction Air Temperature Sensor 2 Signal	I	—
3	0.5	GY/RD	2704	Manifold Absolute Pressure Sensor 5V Reference	I	—
4	0.5	GN/WH	432	Manifold Absolute Pressure Sensor Signal	I	—

B68A Knock Sensor 1



Connector Part Information

Harness Type: Engine

OEM Connector: 34752-0204

Service Connector: 19301207

Description: 2-Way F 150 MX Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B68A Knock Sensor 1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/GY	496	Knock Sensor Signal 1	I	—
2	0.5	BK/YE	1716	Knock Sensor Low Reference 1	I	—



Connector Part Information

Harness Type: Engine

OEM Connector: 34752-0204

Service Connector: 19301207

Description: 2-Way F 150 MX Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B68B Knock Sensor 2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	WH/GY	1876	Knock Sensor Signal 2	I	—
2	0.5	BK/GY	2303	Knock Sensor Low Reference 2	I	—

B74 Manifold Absolute Pressure Sensor (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 13145408

Service Connector: 13585850

Description: 3-Way F 2.8 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B74 Manifold Absolute Pressure Sensor (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/RD	2704	Manifold Absolute Pressure Sensor 5V Reference	I	—
2	0.5	BK/GN	469	Manifold Absolute Pressure Sensor Low Reference	I	—
3	0.5	GN/WH	432	Manifold Absolute Pressure Sensor Signal	I	—

B74 Manifold Absolute Pressure Sensor (LGZ)



Connector Part Information

Harness Type: Engine

OEM Connector: 13503570

Service Connector: 19299690

Description: 3-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B74 Manifold Absolute Pressure Sensor (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/RD	2704	Manifold Absolute Pressure Sensor 5V Reference	I	—
2	0.5	BK/GN	469	Manifold Absolute Pressure Sensor Low Reference	I	—
3	0.5	GN/WH	432	Manifold Absolute Pressure Sensor Signal	I	—

B75C Multifunction Intake Air Sensor



Connector Part Information

Harness Type: Engine

OEM Connector: ATSSPB-C08C-1AK

Service Connector: 13583440

Description: 8-Way F 0.64 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B75C Multifunction Intake Air Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	WH/L-BU	6289	Induction Air Temperature Sensor Signal	I	—
2	0.5	WH/RD	3201	Throttle Inlet Absolute Pressure Sensor 5V Reference	I	—
3	0.5	BK/BN	2761	Coolant Temperature Sensor Low Reference	I	LCV
	0.5	BK/VT	2760	Intake Air Temperature Sensor Low Reference	I	LWN
4	0.5	YE/WH	3200	Throttle Inlet Absolute Pressure Sensor Signal	I	—
5	0.5	VT/L-BU	5294	Powertrain Main Relay Fused Supply 5	I	—
6	0.5	GN/WH	492	Mass Air Flow Sensor Signal	I	—
7	0.5	BK/WH	1451	Signal Ground	I	LCV

	0.75	BK/WH	151	Signal Ground	I	LWN
8	0.5	BN/GY	4008	Humidity Sensor Signal	I	—

B80 Park Brake Switch



Connector Part Information

Harness Type: Body

OEM Connector: 13705266

Service Connector: 19301743

Description: 1-Way F 630 Metri-Pack Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-42 (RD)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B80 Park Brake Switch

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	L-BU/VT	1134	Park Brake Switch Signal	I	—

B87 Rearview Camera



Connector Part Information

Harness Type: License Lamp

OEM Connector: 33482-0601

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way M 150 MX Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-3 (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B87 Rearview Camera

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GN/WH	24	Backup Lamp Control	I	—
2	0.5	GY/YE	6972	Camera Signal 2 +	I	—
3	0.5	VT/GN	1739	Run/Crank Ignition 1 Voltage	I	—
4	0.5	GN	6974	Camera Low Reference	I	—
5	0.5	BK/WH	751	Signal Ground	I	—
6	0.5	WH/L-BU	6973	Camera Signal 2	I	—

B107 Accelerator Pedal Position Sensor



Connector Part Information

Harness Type: Body

OEM Connector: 9115133

Service Connector: 13580116

Description: 6-Way F 1.2 Micro-Timer II Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B107 Accelerator Pedal Position Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BN/RD	1274	Accelerator Pedal Position 5V Reference 2	I	—
2	0.5	WH/RD	1164	Accelerator Pedal Position 5V Reference 1	I	—
3	0.5	YE/WH	1161	Accelerator Pedal Position Signal 1	I	—
4	0.5	BK/L-BU	1271	Accelerator Pedal Position Low Reference 1	I	—
5	0.5	BK/VT	1272	Accelerator Pedal Position Low Reference 2	I	—
6	0.5	GN/WH	1162	Accelerator Pedal Position Signal 2	I	—

B116 Water in Fuel Sensor



Connector Part Information

Harness Type: Chassis

OEM Connector: 15397338

Service Connector: 13585845

Description: 3-Way F 2.8 Junior Power Timer Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B116 Water in Fuel Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	VT/GY	139	Run/Crank Ignition 1 Voltage	I	—
2	0.75	BK	1950	Ground	I	—
3	0.5	L-BU/YE	6861	Water In Fuel Sensor Signal	I	—

B130A Exhaust Gas Recirculation Temperature Sensor 1





Connector Part Information

Harness Type: Engine

OEM Connector: 10094237

Service Connector: 19332628

Description: 2-Way F 1.2 Multilock Series, Sealed (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B130A Exhaust Gas Recirculation Temperature Sensor 1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BK/YE	6275	Exhaust Gas Recirculation Temperature Sensor 2 Low Reference	I	—
2	0.5	YE/GN	3236	Exhaust Gas Recirculation Temperature Sensor 2 Signal	I	—

B130B Exhaust Gas Recirculation Temperature Sensor 2





Connector Part Information

Harness Type: Engine

OEM Connector: 10094234

Service Connector: 19332719

Description: 2-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B130B Exhaust Gas Recirculation Temperature Sensor 2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BK/L-BU	6274	Exhaust Gas Recirculation Temperature Sensor Low Reference	I	—
2	0.5	WH/BN	3237	Exhaust Gas Recirculation Temperature Sensor Signal	I	—

B131A Exhaust Temperature Sensor 1





Connector Part Information

Harness Type: Engine

OEM Connector: 10094234

Service Connector: 19332719

Description: 2-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B131A Exhaust Temperature Sensor 1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BK/BN	6782	Exhaust Gas Temperature Sensor 1 Low Reference	I	—
2	0.5	L-BU/WH	5277	Exhaust Gas Temperature Sensor 1	I	—

B131B Exhaust Temperature Sensor 2



Connector Part Information

Harness Type: Chassis

OEM Connector: 10094236

Service Connector: 19332627

Description: 2-Way F 1.2 Multilock Series, Sealed (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B131B Exhaust Temperature Sensor 2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BK/L-BU	6783	Exhaust Gas Temperature Sensor 2 Low Reference	I	—
2	0.5	L-BU/GN	5377	Exhaust Gas Temperature Sensor 2	I	—

B131C Exhaust Temperature Sensor 3





Connector Part Information

Harness Type: Chassis

OEM Connector: 10094237

Service Connector: 19332628

Description: 2-Way F 1.2 Multilock Series, Sealed (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B131C Exhaust Temperature Sensor 3

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BK/GN	3657	Exhaust Gas Temperature Sensor 3 Low Reference	I	—
2	0.5	GY/GN	5378	Exhaust Gas Temperature Sensor 3	I	—

B131D Exhaust Temperature Sensor 4





Connector Part Information

Harness Type: Chassis

OEM Connector: 10094234

Service Connector: 19332719

Description: 2-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B131D Exhaust Temperature Sensor 4

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BK/GY	3659	Exhaust Gas Temperature Sensor 4 Low Reference	I	—
2	0.5	VT/BN	3658	Exhaust Gas Temperature Sensor 4 Signal	I	—

B131E Exhaust Temperature Sensor 5





Connector Part Information

Harness Type: Chassis

OEM Connector: 10094236

Service Connector: 19332627

Description: 2-Way F 1.2 Multilock Series, Sealed (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B131E Exhaust Temperature Sensor 5

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BK/VT	3661	Exhaust Gas Temperature Sensor 5 Low Reference	I	—
2	0.5	L-BU/GY	3660	Exhaust Gas Temperature Sensor 5 Signal	I	—

B136 Exhaust Particulate Matter Sensor



Connector Part Information

Harness Type: Chassis

OEM Connector: 34900-6121

Service Connector: 19354530

Description: 6-Way F 1.2 MCON-LL Series, Sealed (BN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B136 Exhaust Particulate Matter Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	BK	1950	Ground	I	—
2	0.5	WH	4499	High Speed GMLAN Serial Data (-) 7	I	—
3	0.5	WH	4499	High Speed GMLAN Serial Data (-) 7	I	—
4	0.5	L-BU/BN	4498	High Speed GMLAN Serial Data (+) 7	I	—
5	0.5	L-BU/BN	4498	High Speed GMLAN Serial Data (+) 7	I	—
6	1	VT/L-BU	3674	NOx Sensor 1 Control	I	—

B150 Fuel Tank Pressure Sensor



Connector Part Information

Harness Type: Chassis

OEM Connector: 13511996

Service Connector: 13580873

Description: 3-Way F 150 GT Series, Sealed (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B150 Fuel Tank Pressure Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	L-BU/WH	890	Fuel Tank Pressure Sensor Signal	I	—
2	0.5	BK/GN	6281	Fuel Level Sensor Low Reference	I	—
3	0.5	YE/RD	2709	Fuel Tank Pressure Sensor 5V Reference	I	—

B154 Diesel Particulate Filter Exhaust Differential Pressure Sensor



Connector Part Information

Harness Type: Chassis

OEM Connector: 1928405523

Service Connector: 13384360

Description: 3-Way F 2.8 Series, Sealed (BK with BU Lock)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B154 Diesel Particulate Filter Exhaust Differential Pressure Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	WH/RD	6054	Exhaust Pressure Sensor 5V Reference 1	I	—
2	0.5	BK/YE	6055	Exhaust Pressure Sensor Low Reference 1	I	—
3	0.5	L-BU	6053	Exhaust Pressure Sensor Signal 1	I	—

B160 Windshield Temperature and Inside Moisture Sensor (C68)



Connector Part Information

Harness Type: Headliner

OEM Connector: AIT2WSB-06-1AK

Service Connector: 19299681

Description: 6-Way M 0.64 Kaizen Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-65B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B160 Windshield Temperature and Inside Moisture Sensor (C68)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	YE/RD	597	5V Reference	I	—
2	0.35	GY/L-BU	7564	Humidity Sensor Signal	I	—
3	0.35	BK/L-BU	7566	Humidity/Windscreen Temp Sensor Low Reference	I	—
4	0.35	GY/GN	7565	Windscreen Temp Sensor Signal	I	—
5	0.35	YE/L-BU	3197	Humidity Temperature Sensor Signal	I	—
6	—	—	—	Not Occupied	—	—

B193A Charge Air Cooler Inlet Temperature Sensor



Connector Part Information

Harness Type: Engine

OEM Connector: 7283-7020-10

Service Connector: 13576415

Description: 2-Way F 090 Series, Sealed (D-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-18 (BK)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B193A Charge Air Cooler Inlet Temperature Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GN	3683	Charge Air Cooler Inlet Temperature Sensor Signal	I	—
2	0.5	YE/BK	3682	Charge Air Cooler Inlet Temperature Sensor Low Reference	I	—

B193B Charge Air Cooler Outlet Temperature Sensor



Connector Part Information

Harness Type: Engine

OEM Connector: 7283-7020-10

Service Connector: 13576415

Description: 2-Way F 090 Series, Sealed (D-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-18 (BK)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B193B Charge Air Cooler Outlet Temperature Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BN	3681	Charge Air Cooler Outlet Temperature Sensor Signal	I	—
2	0.5	YE/L-BU	3680	Charge Air Cooler Outlet Temperature Sensor Low Reference	I	—

B195A Nitrogen Oxides Sensor 1



Connector Part Information

Harness Type: Chassis

OEM Connector: 34900-6119

Service Connector: 19353874

Description: 6-Way F 1.2 MCON-LL Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B195A Nitrogen Oxides Sensor 1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	VT/L-BU	3674	NOx Sensor 1 Control	I	—
2	0.5	L-BU/BN	4498	High Speed GMLAN Serial Data (+) 7	I	—
3	0.5	L-BU/BN	4498	High Speed GMLAN Serial Data (+) 7	I	—
4	0.5	WH	4499	High Speed GMLAN Serial Data (-) 7	I	—
5	0.5	WH	4499	High Speed GMLAN Serial Data (-) 7	I	—
6	1	BK	1950	Ground	I	—

B195B Nitrogen Oxides Sensor 2



Connector Part Information

Harness Type: Chassis

OEM Connector: 34900-6128

Service Connector: 19353875

Description: 6-Way F 1.2 MCON-LL Series, Sealed (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B195B Nitrogen Oxides Sensor 2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	VT/L-BU	3674	NOx Sensor 1 Control	I	—
2	0.5	L-BU/BN	4498	High Speed GMLAN Serial Data (+) 7	I	—
3 - 4	—	—	—	Not Occupied	—	—
5	0.5	WH	4499	High Speed GMLAN Serial Data (-) 7	I	—
6	1	BK	1950	Ground	I	—

B203 Engine Coolant Radiator Temperature Sensor



Connector Part Information

Harness Type: Forward Lamp Extension

OEM Connector: 10010337

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B203 Engine Coolant Radiator Temperature Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	YE/BK	3000	Coolant Temperature Sensor 2 Signal	I	—
2	0.5	BK/L-BU	6813	Coolant Temperature Sensor 2 Low Reference	I	—

B227 Gear Position Sensor



Connector Part Information

Harness Type: Engine

OEM Connector: 15326808

Service Connector: 13580871

Description: 3-Way F 150 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

B227 Gear Position Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	YE/BK	7478	Rotary Position Sensor Low Reference	I	—
B	0.5	WH/RD	7477	Rotary Position Sensor 5V Reference	I	—
C	0.5	WH/GN	7479	Rotary Position Sensor Signal	I	—

C1 Battery X1-A





Connector Part Information

Harness Type: Generator Cable

OEM Connector: 15327720

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way Ring Terminal

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

C1 Battery X1-A

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	35	RD	1	Unfused Battery Positive Voltage	I	—

C1 Battery X2





Connector Part Information

Harness Type: Body

OEM Connector: 13268280

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way Ring Terminal

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

C1 Battery X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	BK	1650	Ground	I	—

C3 Telematics Communication Interface Control Module Battery



Connector Part Information

Harness Type: Body

OEM Connector: 12047662

Service Connector: 12085535

Description: 2-Way F 150 Metri-Pack Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

C3 Telematics Communication Interface Control Module Battery

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	YE/VT	5235	Battery Backup Control	I	—
B	0.5	BK/VT	5167	Battery Backup Low Reference	I	—

E7L License Plate Lamp - Left



Connector Part Information

Harness Type: License Lamp

OEM Connector: 15324946

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F Lamp Socket Wedge Base, Type W-2 (D-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

E7L License Plate Lamp - Left

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	GN/YE	6846	Rear License Lamp Control	I	—
B	0.5	BK	750	Ground	I	—

E7R License Plate Lamp - Right



Connector Part Information

Harness Type: License Lamp

OEM Connector: 15324946

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F Lamp Socket Wedge Base, Type W-2 (D-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

E7R License Plate Lamp - Right

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	GN/YE	6846	Rear License Lamp Control	I	—
B	0.5	BK	750	Ground	I	—

E11B Fuel Heater/Temperature Sensor



Connector Part Information

Harness Type: Chassis

OEM Connector: 15397339

Service Connector: 13384331

Description: 4-Way F 2.8 Junior Power Timer Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

E11B Fuel Heater/Temperature Sensor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BN/GY	7072	Sensor Fuel Temperature 1 Signal	I	—
2	0.5	BN/WH	7073	Sensor Fuel Temperature 1 Low Reference	I	—
3	2.5	BK	1950	Ground	I	—
4	2.5	L-BU/GN	7071	Heater Fuel Control	I	—

E18 Rear Defogger Grid X1





Connector Part Information

Harness Type: Body

OEM Connector: 7123-5014-30

Service Connector: 88988465

Description: 1-Way F 250 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-42 (RD)	No Tool Required	Not Required	Not Required	Not Required	Not Required

E18 Rear Defogger Grid X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	2.5	BN/VT	293	Rear Defog Element Control	I	C49

E18 Rear Defogger Grid X2





Connector Part Information

Harness Type: Body

OEM Connector: 7123-5014-30

Service Connector: 88988465

Description: 1-Way F 250 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-18 (BK)	No Tool Required	Not Required	Not Required	Not Required	Not Required

E18 Rear Defogger Grid X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	4	BK	3950	Ground	I	—

E29LF Fog Lamp - Left Front



Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 13513272

Service Connector: 19153187

Description: 2-Way F 150 GT Series, Sealed (NA)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

E29LF Fog Lamp - Left Front

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.75	BN/VT	2234	Front Fog Lamp Control	I	—
B	0.75	BK	1150	Ground	I	—

E29RF Fog Lamp - Right Front



Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 13513272

Service Connector: 19153187

Description: 2-Way F 150 GT Series, Sealed (NA)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

E29RF Fog Lamp - Right Front

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.75	BN/VT	2234	Front Fog Lamp Control	I	—
B	0.75	BK	1250	Ground	I	—

E31L Sunshade Mirror Lamp - Left



Connector Part Information

Harness Type: Headliner

OEM Connector: 12047663

Service Connector: 13584278

Description: 2-Way M 150 Metri-Pack Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-3 (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

E31L Sunshade Mirror Lamp - Left

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	WH/BN	6815	Inadvertent Power Control	I	—
B	0.5	BK	3150	Ground	I	—

E31R Sunshade Mirror Lamp - Right



Connector Part Information

Harness Type: Headliner

OEM Connector: 12047663

Service Connector: 13584278

Description: 2-Way M 150 Metri-Pack Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-3 (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

E31R Sunshade Mirror Lamp - Right

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	WH/BN	6815	Inadvertent Power Control	I	—
B	0.5	BK	3150	Ground	I	—

E37F Dome/Reading Lamps - Front



Connector Part Information

Harness Type: Headliner

OEM Connector: 6098-5985

Service Connector: 13576538

Description: 6-Way F 1.5 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

E37F Dome/Reading Lamps - Front

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	WH/BN	6815	Inadvertent Power Control	I	—
2	0.5	GY	157	Interior Lamp Control	I	—
3	0.5	YE	6817	LED Backlight Dimming Control	I	—
4	0.35	GY/GN	328	Interior Lamp Defeat Switch Signal	I	—
5	0.35	GY	156	Courtesy Lamp Switch Signal	I	—
6	0.5	BK	3150	Ground	I	—

E37R Dome/Reading Lamps - Rear



Connector Part Information

Harness Type: Headliner

OEM Connector: 6098-5985

Service Connector: 13576538

Description: 6-Way F 1.5 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

E37R Dome/Reading Lamps - Rear

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	WH/BN	6815	Inadvertent Power Control	I	—
2	0.5	GY	157	Interior Lamp Control	I	—
3 - 5	—	—	—	Not Occupied	—	—
6	0.5	BK	3150	Ground	I	—

E40 Electrical Auxiliary Heater X1



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 1379029-1

Service Connector: 13584096

Description: 4-Way F 0.64 Micro-Quadlock Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

E40 Electrical Auxiliary Heater X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT	3195	Auxiliary Heater Control	I	—
2	0.35	VT/GY	539	Run/Crank Ignition 1 Voltage	I	—
3 - 4	—	—	—	Not Occupied	—	—

E40 Electrical Auxiliary Heater X2



Connector Part Information

Harness Type: Body

OEM Connector: 7287-1405-80

Service Connector: Service by Harness - See Part Catalog

Description: 4-Way F 1.5, 9.5 Series, Sealed (BN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-42 (RD)	No Tool Required	Not Required	Not Required	Not Required	Not Required

E40 Electrical Auxiliary Heater X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	10	BK	1350	Ground	I	—
2	10	RD/GY	4840	Battery Positive Voltage	I	—
3 - 4	—	—	—	Not Occupied	—	—

E41 Engine Coolant Thermostat Heater



Connector Part Information

Harness Type: Engine

OEM Connector: 33471-0206

Service Connector: 13577534

Description: 2-Way F 1.5 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

E41 Engine Coolant Thermostat Heater

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/L-BU	5293	Powertrain Main Relay Fused Supply 4	I	—
2	0.5	L-BU	6814	Thermostat Engine Cool Control	I	—

E45 Positive Crankcase Ventilation Heater



Connector Part Information

Harness Type: Engine

OEM Connector: 13595623

Service Connector: 13355762

Description: 2-Way F 2.8 ATS Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-4A (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

E45 Positive Crankcase Ventilation Heater

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	YE/L-BU	1497	Crankcase Ventilation (Blowby) Heater Control Signal	I	—
2	0.5	VT/L-BU	5293	Powertrain Main Relay Fused Supply 4	I	—

F101 Passenger Instrument Panel Air Bag



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 1-2141530-5

Service Connector: 19300377

Description: 6-Way F 1.2 MCP Series, Sealed (YE)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

F101 Passenger Instrument Panel Air Bag

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	YE/OG	3025	Passenger IP Module Stage 1 High Control	I	—
2	0.35	OG/WH	3024	Passenger IP Module Stage 1 Low Control	I	—
3	0.35	GY/OG	3027	Passenger IP Module Stage 2 High Control	I	—
4	0.35	OG/VT	3026	Passenger IP Module Stage 2 Low Control	I	—
5	0.5	BK/WH	2051	Signal Ground	I	—
6	—	—	—	Not Occupied	—	—

F105L Roof Rail Air Bag - Left



Connector Part Information

Harness Type: Body

OEM Connector: 19178108

Service Connector: 19300405

Description: 2-Way F FPB 180-1 Series (BK with YE Cover)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

F105L Roof Rail Air Bag - Left

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	OG/GN	5019	Left Front Head Curtain Module High Control	I	—
2	0.5	VT/OG	5020	Left Front Head Curtain Module Low Control	I	—

F105R Roof Rail Air Bag - Right



Connector Part Information

Harness Type: Body

OEM Connector: 19178108

Service Connector: 19300405

Description: 2-Way F FPB 180-1 Series (BK with YE Cover)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

F105R Roof Rail Air Bag - Right

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	OG/GY	5021	Right Front Head Curtain Module High Control	I	—
2	0.5	WH/OG	5022	Right Front Head Curtain Module Low Control	I	—

F112D Seat Belt Retractor Pretensioner - Driver (F43)



Connector Part Information

Harness Type: Body

OEM Connector: 13596551

Service Connector: 19354083

Description: 2-Way F 1.0 MAC Series (PU with YE Cover)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

F112D Seat Belt Retractor Pretensioner - Driver (F43)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	OG/WH	3477	Driver Seat Belt Retractor Pretensioner High Control	I	—
2	0.5	GY/OG	3478	Driver Seat Belt Retractor Pretensioner Low Control	I	—

F112D Seat Belt Retractor Pretensioner - Driver (F53)



Connector Part Information

Harness Type: Left Rear Door

OEM Connector: 13596551

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F 1.0 MAC Series (PU with YE Cover)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

F112D Seat Belt Retractor Pretensioner - Driver (F53)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	OG/WH	3477	Driver Seat Belt Retractor Pretensioner High Control	I	—
2	0.5	GY/OG	3478	Driver Seat Belt Retractor Pretensioner Low Control	I	—

F112P Seat Belt Retractor Pretensioner - Passenger (F43)



Connector Part Information

Harness Type: Body

OEM Connector: 13596551

Service Connector: 19354083

Description: 2-Way F 1.0 MAC Series (PU with YE Cover)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

F112P Seat Belt Retractor Pretensioner - Passenger (F43)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	OG/GN	3475	Passenger Seat Belt Retractor Pretensioner High Control	I	—
2	0.5	WH/OG	3476	Passenger Seat Belt Retractor Pretensioner Low Control	I	—

F112P Seat Belt Retractor Pretensioner - Passenger (F53)



Connector Part Information

Harness Type: Right Rear Door

OEM Connector: 13596551

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F 1.0 MAC Series (PU with YE Cover)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

F112P Seat Belt Retractor Pretensioner - Passenger (F53)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	OG/GN	3475	Passenger Seat Belt Retractor Pretensioner High Control	I	—
2	0.5	WH/OG	3476	Passenger Seat Belt Retractor Pretensioner Low Control	I	—

F113D Seat Belt Anchor Pretensioner - Driver





Connector Part Information

Harness Type: Left Rear Door

OEM Connector: 13596550

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F 1.0 MAC Series (PK with YE Cover)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

F113D Seat Belt Anchor Pretensioner - Driver

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	OG/YE	3481	Driver Seat Belt Anchor Pretensioner High Control	I	—
2	0.5	YE/OG	3482	Driver Seat Belt Anchor Pretensioner Low Control	I	—

F113P Seat Belt Anchor Pretensioner - Passenger



Connector Part Information

Harness Type: Right Rear Door

OEM Connector: 13596550

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F 1.0 MAC Series (PK with YE Cover)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

F113P Seat Belt Anchor Pretensioner - Passenger

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	OG/BN	3479	Passenger Seat Belt Anchor Pretensioner High Control	I	—
2	0.5	GY/OG	3480	Passenger Seat Belt Anchor Pretensioner Low Control	I	—

G13 Generator X1



Connector Part Information

Harness Type: Engine

OEM Connector: 12186308

Service Connector: 13585849

Description: 2-Way F Junior Power Timer Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

G13 Generator X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	L-BU/WH	225	Generator Turn On Signal	I	LGZ
	0.5	BN	25	Charge Indicator Control	I	LWN
2	0.5	GY	23	Generator Field Duty Cycle Signal	I	—

G18 High Pressure Fuel Pump



Connector Part Information

Harness Type: Engine

OEM Connector: 33471-0206

Service Connector: 13577534

Description: 2-Way F 1.5 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

G18 High Pressure Fuel Pump

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	YE	7301	High Pressure Fuel Pump Actuator High - Control	I	LCV
	0.5	VT/BK	7300	High Pressure Fuel Pump Actuator Low - Control	I	LGZ
2	0.5	VT/BK	7300	High Pressure Fuel Pump Actuator Low - Control	I	LCV
	0.5	YE	7301	High Pressure Fuel Pump Actuator High - Control	I	LGZ

G24 Windshield Washer Pump



Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 1-1355200-1

Service Connector: 13576532

Description: 2-Way F 2.8 MDK5 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

G24 Windshield Washer Pump

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	GY/VT	228	Windshield Washer Pump Control	I	—
2	0.75	BK	1150	Ground	I	—

K8 Blower Motor Control Module



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 1-1418507-2

Service Connector: 19352990

Description: 4-Way F 2.8, 6.3 MCON Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-40 (BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required
III	Not Required	J-35616-42 (RD)	No Tool Required	Not Required	Not Required	Not Required	Not Required

K8 Blower Motor Control Module

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	5	BK	2250	Ground	III	—
2	—	—	—	Not Occupied	—	—
3	2.5	RD/VT	542	Battery Positive Voltage	II	—
4	0.35	L-BU/GY	754	Blower Motor Speed Control	I	—

K9 Body Control Module X1





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: HIT2PB-26-B-S

Service Connector: 19151262

Description: 26-Way F 0.64, 2.8 Series (WH)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575560	J-35616-35 (VT)	J-38125-12A	SNAC-A081T-M2.8	Delphi 20	A	D
II	13575870	J-35616-64B (LT BU)	J-38125-12A	SNAC3-A021T-M0.64	Delphi 20	J	J
III	13575871	J-35616-35 (VT)	J-38125-12A	SNAC-A061T-M2.8	Delphi 20	E	A

K9 Body Control Module X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	BK	2150	Ground	III	—
2	2.5	RD/GN	2440	Battery Positive Voltage	I	—
3	2.5	RD/YE	2340	Battery Positive Voltage	I	—
4	0.75	RD/BN	2240	Battery Positive Voltage	III	—
5	0.35	WH	6816	Indicator Dimming Control	II	—
6	—	—	—	Not Occupied	—	—
7	0.35	BK/YE	5005	Instrument Panel Lamp Dimmer Switch Low Reference	II	—
8 - 9	—	—	—	Not Occupied	—	—

8 - 9	—	—	—	Not Occupied	—	—
10	0.35	L-BU/YE	6844	ABS/TCS Hill Descent Control Switch Signal	II	—
11	0.35	GN/BN	306	Headlamp Switch Headlamps Off Signal Control	II	—
12	—	—	—	Not Occupied	—	—
13	0.35	L-BU/RD	1688	5V Reference	II	—
14	0.35	GY/GN	328	Interior Lamp Defeat Switch Signal	II	—
15	0.35	L-BU/GY	192	Front Fog Lamp Switch Signal	II	—
16	0.35	WH/VT	103	Headlamp Switch On Signal	II	—
17 - 18	—	—	—	Not Occupied	—	—
19	0.35	BK/BN	5360	Brake Apply Sensor Low Reference	II	—
20	—	—	—	Not Occupied	—	—
21	0.35	GY	728	Security Indicator Control	II	—
22	0.35	GN/GY	13	Headlamp Switch Park Lamp Signal	II	—
23	—	—	—	Not Occupied	—	—
24	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	II	—
25	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	II	—
26	0.35	L-BU/WH	3275	Remote Function Actuator Receive Signal	II	—

K9 Body Control Module X2





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: HIT2PB-27-C-LE

Service Connector: 19151266

Description: 27-Way F 0.64, 2.8 Series (L-BU)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575560	J-35616-35 (VT)	J-38125-12A	SNAC-A081T-M2.8	Delphi 20	A	D
II	13575870	J-35616-64B (LT BU)	J-38125-12A	SNAC3-A021T-M0.64	Delphi 20	J	J
III	13575871	J-35616-35 (VT)	J-38125-12A	SNAC-A061T-M2.8	Delphi 20	E	A

K9 Body Control Module X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	RD/GY	2140	Battery Positive Voltage	III	—
2	0.75	BK	2150	Ground	III	—
3	—	—	—	Not Occupied	—	—
4	2.5	RD/VT	4040	Battery Positive Voltage	I	—
5	0.5	GY	157	Interior Lamp Control	II	—
6	0.35	GY	5697	Child Lockout Indicator Control	II	—
7	0.35	L-BU/YE	5361	Brake Apply Sensor Signal	II	—

8	0.5	YE	6817	LED Backlight Dimming Control	II	—
9	0.35	YE/GY	44	Instrument Panel Lamp Dimmer Switch Signal	II	—
10	0.35	WH/L-BU	278	Ambient Light Sensor Signal	II	—
11	0.35	VT/YE	5526	Tap Up/Tap Down Switch Signal	II	—
12	—	—	—	Not Occupied	—	—
13	0.35	WH	5359	Brake Apply Sensor Control	II	—
14	0.35	L-BU/VT	1788	Traction Control Switch Signal 1	II	—
15	0.35	BN/WH	781	Driver Door Lock Switch Unlock Signal	II	—
16	0.35	GY	3273	Remote Function Actuator Low Reference	II	—
17	—	—	—	Not Occupied	—	—
18	0.35	YE/BN	3265	Child Security Lock Switch Signal	II	—
19	0.35	BN/YE	780	Driver Door Lock Switch Lock Signal	II	—
20	0.5	WH/L-BU	3691	Trailer Brake Apply Signal	II	—
21	0.5	GN/GY	6135	Local Interconnect Network Serial Data Bus 4	II	—
22	0.5	GN	5060	Low Speed GMLAN Serial Data	II	—
23	0.35	WH	2501	High Speed GMLAN Serial Data (-) 1	II	—
24	0.35	L-BU	2500	High Speed GMLAN Serial Data (+) 1	II	—

25	0.35	GY/WH	3272	Remote Function Actuator Control	II	—
26	0.35	GN/WH	111	Hazard Switch Signal	II	—
27	0.35	YE/GN	3274	Remote Function Actuator Transmit Signal	II	—

K9 Body Control Module X3





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: HIT2PB-25-A-LM

Service Connector: 19151261

Description: 25-Way F 0.64 Series (L-GN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575870	J-35616-64B (LT BU)	J-38125-12A	SNAC3-A021T-M0.64	Delphi 20	J	J

K9 Body Control Module X3

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	GN/GY	3277	Vehicle Anti-Theft System Immobilizer Low Reference	I	—
2	0.35	GN/VT	7533	Local Interconnect Network Serial Data Bus 11	I	—
3	0.35	GY/BK	3276	Vehicle Anti-Theft System Immobilizer Control	I	—
4	0.35	WH/RD	1444	12V Reference	I	—
5	0.5	VT/YE	4	Accessory Ignition Voltage	I	—
6	0.5	VT/BK	3	Run/Crank Ignition 1 Voltage	I	—
7	0.35	VT/YE	143	Accessory Ignition Voltage	I	—
8	0.35	GN	6818	Steering Wheel Resistor Ladder Signal 1	I	—

9	0.35	BN/GN	1884	Cruise Control Set/Coast/Resume/Accelerate Switch Signal	I	—
10	0.35	BK/GY	6009	Windshield Wiper Switch Low Reference	I	—
11	0.35	WH	524	Headlamp Dimmer Switch High Beam Signal	I	—
12	0.35	WH/GN	663	Hazard Switch Left Turn Signal	I	—
13	0.35	YE/L-BU	1714	Windshield Wiper Switch Low Signal	I	—
14	0.35	L-BU/GY	553	Shift Select Switch Performance Signal	I	—
15	0.5	WH/VT	1020	Off/Run/Crank Ignition Voltage	I	—
16	0.35	GY/GN	5737	Adaptive Cruise Control Gap Up/Down Switch Signal	I	—
17	0.35	YE/BN	307	Headlamp Switch Flash To Pass Signal	I	—
18	0.35	GN/WH	3287	Horn Switch Signal	I	—
19	0.5	GN/WH	7527	Local Interconnect Network Serial Data Bus 5	I	—
20	0.35	GY	1715	Windshield Wiper Switch High Signal	I	—
21	—	—	—	Not Occupied	—	—
22	0.5	WH/BK	1073	Ignition Key Resistor Signal	I	—
23	0.35	GY	5054	Sport Mode Switch Signal	I	—
24	0.35	VT/L-BU	664	Hazard Switch Right Turn Signal	I	—

25	0.35	WH/BK	94	Windshield Washer Switch Signal	I	—

K9 Body Control Module X4





Connector Part Information

Harness Type: Body

OEM Connector: HIT2PB-26-D-K

Service Connector: 19151263

Description: 26-Way F 0.64, 2.8 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575870	J-35616-64B (LT BU)	J-38125-12A	SNAC3-A021T-M0.64	Delphi 20	J	J
II	13575871	J-35616-35 (VT)	J-38125-12A	SNAC-A061T-M2.8	Delphi 20	C	A
III	13575871	J-35616-35 (VT)	J-38125-12A	SNAC-A061T-M2.8	Delphi 20	E	A

K9 Body Control Module X4

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1.5	YE	312	Right Headlamp Low Beam Control	II	—
2	1.5	YE	712	Left Headlamp Low Beam Control	II	—
3	0.75	GN/VT	1315	Right Front Turn Signal Lamp Control	III	—
4	1.5	WH/YE	7541	Right Rear Stop Lamp Control	II	—
5	0.5	GY/BN	309	Right Park Lamp Control	I	—
6	0.5	VT/GY	709	Left Park Lamp Control	I	—
7	0.5	BN/L-BU	2509	Left Rear Park Lamp Control	I	—

8 - 11	—	—	—	Not Occupied	—	—
12	0.35	GY/VT	755	RAP Relay Coil Control	I	—
13	0.5	GN/YE	6846	Rear License Lamp Control	I	—
14	0.5	BN/GY	2268	Windshield Washer Relay Control	I	—
15	0.35	GN/VT	5199	Run/Crank Relay Coil Control	I	—
16	0.5	GY	91	Windshield Wiper Motor Relay Coil Control	I	—
17	0.5	BN/GN	196	Windshield Wiper Motor Park Switch Signal	I	—
18	0.5	WH/YE	5075	Current Sensor Signal	I	—
19	—	—	—	Not Occupied	—	—
20	0.75	RD/BN	440	Battery Positive Voltage	III	—
21	0.5	L-BU/VT	5076	Current Sensor Control	I	—
22	0.35	VT/YE	5985	Accessory Wakeup Serial Data	I	—
23	0.5	WH/L-BU	5986	Serial Data Communication Enable	I	—
24	0.5	BN/GN	109	Hood Ajar Switch Signal	I	—
25	—	—	—	Not Occupied	—	—
26	0.5	BK	1650	Ground	I	—

K9 Body Control Module X5





Connector Part Information

Harness Type: Body

OEM Connector: HIT2PB-26-E-N

Service Connector: 19151264

Description: 26-Way F 0.64, 2.8 Series (BN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575870	J-35616-64B (LT BU)	J-38125-12A	SNAC3-A021T-M0.64	Delphi 20	J	J
II	13575871	J-35616-35 (VT)	J-38125-12A	SNAC-A061T-M2.8	Delphi 20	C	A
III	13575871	J-35616-35 (VT)	J-38125-12A	SNAC-A061T-M2.8	Delphi 20	E	A

K9 Body Control Module X5

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1.5	GY/YE	7542	Left Rear Stop Lamp Control	II	—
2	0.75	L-BU/WH	1314	Left Front Turn Signal Lamp Control	III	—
3	1.5	RD/WH	2740	Battery Positive Voltage	II	—
4	1.5	RD/VT	2640	Battery Positive Voltage	II	—
5	—	—	—	Not Occupied	—	—
6	0.5	BK/VT	5077	Current Sensor Low Reference	I	—
7	0.5	BN/GY	2609	Right Rear Park Lamp Control	I	—

8	0.5	L-BU/WH	5186	Left Trailer Turn Signal Lamp Control	I	—
9 - 11	—	—	—	Not Occupied	—	—
12	0.5	WH/L-BU	6311	Cruise/ETC/TCC Brake Signal	I	—
13	0.5	BN/WH	1317	Fog Lamp Relay Control	I	—
14	0.5	VT/BN	300	Run Ignition 3 Voltage	I	—
15	—	—	—	Not Occupied	—	—
16	0.5	VT/YE	3267	Child Security Lock Relay Control	I	—
17	0.5	YE/GY	5187	Right Trailer Turn Signal Lamp Control	I	—
18	0.5	BN/VT	1969	Headlamp High Beam Relay Control	I	—
19	0.5	BN/WH	28	Horn Relay Control	I	—
20 - 21	—	—	—	Not Occupied	—	—
22	0.5	L-BU	45	Park Lamp Relay Control	I	—
23	—	—	—	Not Occupied	—	—
24	0.5	WH/VT	860	Front Windshield Wiper Switch High Signal	I	—
25	—	—	—	Not Occupied	—	—
26	0.5	L-BU/BN	38	Backup Lamp Relay Control	I	—

K9 Body Control Module X6





Connector Part Information

Harness Type: Body

OEM Connector: HIT2PB-27-F-PK

Service Connector: 19151267

Description: 27-Way F 0.64, 2.8 Series (PK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575870	J-35616-64B (LT BU)	J-38125-12A	SNAC3-A021T-M0.64	Delphi 20	J	J
II	13575871	J-35616-35 (VT)	J-38125-12A	SNAC-A061T-M2.8	Delphi 20	C	A
III	13575871	J-35616-35 (VT)	J-38125-12A	SNAC-A061T-M2.8	Delphi 20	E	A

K9 Body Control Module X6

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	GY	5911	Door Lock Actuator Lock Control 2	III	—
2	1.5	GY/GN	3271	Door Lock Control 2	II	—
3	1.5	BK	3150	Ground	II	—
4	1.5	BN/YE	294	Door Lock Actuator Unlock Control	II	CREW CAB
	0.75	BN/YE	294	Door Lock Actuator Unlock Control	III	EXTENDED CAB
5 - 8	—	—	—	Not Occupied	—	—
9	0.5	GN/L-BU	6133	Local Interconnect Network Serial Data Bus 2	I	—
10	0.5	GN/YE	6134	Local Interconnect Network Serial Data Bus 3	I	CREW CAB

10	0.5	GN/YE	6134	Local Interconnect Network Serial Data Bus 3	I	CREW CAB
	0.35	GN/YE	6134	Local Interconnect Network Serial Data Bus 3	I	EXTENDED CAB
11 - 15	—	—	—	Not Occupied	—	—
16	0.5	GN/BN	6132	Local Interconnect Network Serial Data Bus 1	I	—
17 - 23	—	—	—	Not Occupied	—	—
24	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	I	—
25	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	I	—
26	—	—	—	Not Occupied	—	—
27	0.35	GY	747	Left Rear Door Ajar Switch Signal	I	—

K9 Body Control Module X7





Connector Part Information

Harness Type: Body

OEM Connector: HIT2PB-26-G-H

Service Connector: 19151265

Description: 26-Way F 0.64, 2.8 Series (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575870	J-35616-64B (LT BU)	J-38125-12A	SNAC3-A021T-M0.64	Delphi 20	J	J
II	13575871	J-35616-35 (VT)	J-38125-12A	SNAC-A061T-M2.8	Delphi 20	E	A

K9 Body Control Module X7

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	—	—	—	Not Occupied	—	—
2	0.75	WH/BN	6815	Inadvertent Power Control	II	—
3	0.75	GN/WH	24	Backup Lamp Control	II	—
4 - 5	—	—	—	Not Occupied	—	—
6	0.5	VT/BK	7553	Park Lock Solenoid Control	I	—
7	0.5	BN/WH	1429	Standing Lamp Relay Control	I	—
8	0.5	VT/WH	5065	Stop Lamp Relay Coil Control	I	—
9 - 10	—	—	—	Not Occupied	—	—
11	0.35	GY	748	Right Rear Door Ajar Switch Signal	I	—

12	0.35	BN/WH	3269	Child Security Lock Motor Status Signal Left Rear	I	—
13	0.5	WH/VT	5905	Key Capture/Column Lock Shift Position Signal	I	—
14	0.5	GY	158	Cargo Lamp Switch Signal	I	—
15	0.5	L-BU/VT	1134	Park Brake Switch Signal	I	—
16	0.5	WH/L-BU	3691	Trailer Brake Apply Signal	I	—
17	—	—	—	Not Occupied	—	—
18	0.35	GY/BK	3268	Child Security Lock Motor Status Signal Right Rear	I	—
19	0.35	GY	156	Courtesy Lamp Switch Signal	I	—
20	—	—	—	Not Occupied	—	—
21	0.35	YE/VT	244	Passenger Door Lock Switch Lock Control	I	—
22	—	—	—	Not Occupied	—	—
23	0.5	GN	5060	Low Speed GMLAN Serial Data	I	—
24	0.35	BN/VT	245	Passenger Door Lock Switch Unlock Control	I	—
25 - 26	—	—	—	Not Occupied	—	—

K17 Electronic Brake Control Module



Connector Part Information

Harness Type: Chassis

OEM Connector: 13359630

Service Connector: 19299780

Description: 38-Way F 1.5, 2.8, 4.8 Series, Sealed

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13578852	J-35616-40 (BU)	J-38125-561	Not Available	Not Available	Not Available	Not Available
II	13578853	J-35616-35 (VT)	J-38125-561	Not Available	Not Available	Not Available	Not Available
III	13584537	J-35616-14 (GN)	J-38125-560	Not Available	Not Available	Not Available	Not Available
IV	19119381	J-35616-14 (GN)	J-38125-215A	Not Available	Not Available	Not Available	Not Available

K17 Electronic Brake Control Module

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	4	RD/GY	1042	Battery Positive Voltage	I	—
2 - 3	—	—	—	Not Occupied	—	—
4	0.5	YE/VT	6030	Brake Vacuum Sensor Signal	III	—
5	—	—	—	Not Occupied	—	—
6	0.5	WH/L-BU	5986	Serial Data Communication Enable	III	—
7 - 8	—	—	—	Not Occupied	—	—
9	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	III	—
10	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	III	—

11	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	III	—
12	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	III	—
13	4	BK	550	Ground	I	—
14 - 15	—	—	—	Not Occupied	—	—
16	0.5	YE/RD	6031	Brake Vacuum Sensor 5V Reference	III	—
17	—	—	—	Not Occupied	—	—
18	0.5	WH	6106	High Speed GMLAN Serial Data (-) 2	III	—
19	0.5	L-BU/YE	6105	High Speed GMLAN Serial Data (+) 2	III	—
20	—	—	—	Not Occupied	—	—
21	0.5	GN/GY	333	Brake Fluid Level Sensor Signal	IV	—
22	0.5	BK/YE	6032	Brake Vacuum Sensor Low Reference	III	—
23 - 24	—	—	—	Not Occupied	—	—
25	2.5	RD/YE	442	Battery Positive Voltage	II	—
26	0.5	YE	872	Wheel Speed Sensor Signal Right Front	III	—
27	0.5	GY/BN	7065	Wheel Speed Sensor Control Right Front	III	—
28	0.5	BN	6305	Brake Vacuum Switch Signal	III	—
29	0.5	GY/BK	7127	Wheel Speed Sensor Control Left Rear	III	—
30	0.5	L-BU	884	Wheel Speed Sensor Signal Left Rear	III	—

31 - 32	—	—	—	Not Occupied	—	—
33	0.5	VT	882	Wheel Speed Sensor Signal Right Rear	III	—
34	0.5	GY/YE	7128	Wheel Speed Sensor Control Right Rear	III	—
35	—	—	—	Not Occupied	—	—
36	0.5	GY/WH	7064	Wheel Speed Sensor Control Left Front	III	—
37	0.5	GY	830	Wheel Speed Sensor Signal Left Front	III	—
38	—	—	—	Not Occupied	—	—

K20 Engine Control Module X1 (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 34566-0303

Service Connector: 13574782

Description: 73-Way F 0.64, 2.8 Series, Sealed (BK with BU Terminal Position Assurance)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575812	J-35616-64B (LT BU)	J-38125-213	Not Available	Not Available	Not Available	Not Available
II	13579769	J-35616-4A (PU)	J-38125-11A	7116-4151-02	Yazaki 9	C	1

K20 Engine Control Module X1 (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 6	—	—	—	Not Occupied	—	—
7	0.5	WH	7494	High Speed GMLAN Serial Data (-)3	I	—
8	0.5	L-BU/YE	7493	High Speed GMLAN Serial Data (+)3	I	—
9	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	I	—
10	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	I	—
11	0.5	BN/RD	1274	Accelerator Pedal Position 5V Reference 2	I	—
12	0.5	WH/RD	1164	Accelerator Pedal Position 5V Reference 1	I	—
13	0.5	VT/YE	5985	Accessory Wakeup Serial Data	I	—

14	0.5	VT/GY	139	Run/Crank Ignition 1 Voltage	I	—
15	0.5	RD/WH	140	Battery Positive Voltage	I	—
16	0.75	VT/L-BU	5290	Powertrain Main Relay Fused Supply 1	I	—
17 - 24	—	—	—	Not Occupied	—	—
25	0.5	BK/YE	5382	Brake Position Sensor Low Reference	I	—
26	0.5	BK/GY	6110	Clutch Apply Sensor Low Reference	I	—
27	0.5	BK/VT	1272	Accelerator Pedal Position Low Reference 2	I	—
28	0.5	BK/L-BU	1271	Accelerator Pedal Position Low Reference 1	I	—
29 - 32	—	—	—	Not Occupied	—	—
33	0.5	GN/WH	1162	Accelerator Pedal Position Signal 2	I	—
34	0.5	GN/WH	492	Mass Air Flow Sensor Signal	I	—
35 - 36	—	—	—	Not Occupied	—	—
37	0.5	BN/RD	2700	A/C Pressure Sensor 5V Reference	I	—
38 - 40	—	—	—	Not Occupied	—	—
41	0.5	WH/RD	5381	Brake Position Sensor 5V Reference	I	—
42	0.5	GY/RD	6109	Clutch Apply Sensor 5V Reference	I	—
43	—	—	—	Not Occupied	—	—
44	0.5	VT/GY	6386	Starter Enable Relay (PPEI 3) Control	I	—

45	0.5	YE/WH	1161	Accelerator Pedal Position Signal 1	I	—
46	0.5	YE/BK	3000	Coolant Temperature Sensor 2 Signal	I	—
47	0.5	L-BU/GY	636	Outside Ambient Air Temperature Sensor Signal	I	—
48	0.5	WH/L-BU	6289	Induction Air Temperature Sensor Signal	I	—
49	0.5	WH/GY	1786	Transmission Park/Neutral Signal 1	I	—
50	0.5	WH/L-BU	6311	Cruise/ETC/TCC Brake Signal	I	—
51	0.75	VT/L-BU	5291	Powertrain Main Relay Fused Supply 2	I	—
52	0.5	WH/BK	2366	Cooling Fan Control Relay Speed Signal	I	—
53	—	—	—	Not Occupied	—	—
54	0.5	WH/GY	459	A/C Compressor Clutch Relay Control	I	—
55 - 56	—	—	—	Not Occupied	—	—
57	0.5	GN	380	A/C Refrigerant Pressure Sensor Signal	I	—
58 - 59	—	—	—	Not Occupied	—	—
60	0.5	BN/GY	4008	Humidity Sensor Signal	I	—
61	0.5	WH/GN	5380	Brake Position Sensor Signal	I	—
62	0.5	YE	6111	Clutch Apply Sensor Signal	I	—
63	—	—	—	Not Occupied	—	—
64	0.5	GN/GY	465	Fuel Pump Primary Relay Control	I	—

65	0.5	WH	1310	EVAP Canister Vent Solenoid Control	I	—
66	—	—	—	Not Occupied	—	—
67	0.5	YE	5991	Powertrain Relay Coil Control	I	—
68	—	—	—	Not Occupied	—	—
69	0.5	L-BU	6814	Thermostat Engine Cool Control	I	—
70	—	—	—	Not Occupied	—	—
71	0.5	BN/WH	419	Check Engine Indicator Control	I	—
72	—	—	—	Not Occupied	—	—
73	1	VT/L-BU	5290	Powertrain Main Relay Fused Supply 1	II	—

K20 Engine Control Module X1 (LGZ)



Connector Part Information

Harness Type: Engine

OEM Connector: 34566-0303

Service Connector: 13574782

Description: 73-Way F 0.64, 2.8 Series, Sealed (BK with BU Terminal Position Assurance)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575812	J-35616-64B (LT BU)	J-38125-213	Not Available	Not Available	Not Available	Not Available
II	13576392	J-35616-4A (PU)	J-38125-11A	7116-4152-02	Yazaki 9	2	5

K20 Engine Control Module X1 (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 4	—	—	—	Not Occupied	—	—
5	0.5	BK/VT	1272	Accelerator Pedal Position Low Reference 2	I	—
6	0.5	YE/WH	1161	Accelerator Pedal Position Signal 1	I	—
7	0.5	BK/L-BU	1271	Accelerator Pedal Position Low Reference 1	I	—
8	0.5	WH	7494	High Speed GMLAN Serial Data (-)3	I	—
9	0.5	BK/YE	5382	Brake Position Sensor Low Reference	I	—
10 - 11	—	—	—	Not Occupied	—	—
12	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	I	—

13	0.5	WH/L-BU	6311	Cruise/ETC/TCC Brake Signal	I	—
14	0.5	WH/GY	459	A/C Compressor Clutch Relay Control	I	—
15	0.5	YE	5991	Powertrain Relay Coil Control	I	—
16	0.5	BN/WH	419	Check Engine Indicator Control	I	—
17	0.5	WH/BK	2366	Cooling Fan Control Relay Speed Signal	I	—
18 - 20	—	—	—	Not Occupied	—	—
21	0.5	BN/RD	1274	Accelerator Pedal Position 5V Reference 2	I	—
22	0.5	GN/WH	1162	Accelerator Pedal Position Signal 2	I	—
23	0.5	WH/RD	1164	Accelerator Pedal Position 5V Reference 1	I	—
24	0.5	L-BU/BK	7493	High Speed GMLAN Serial Data (+)3	I	—
25	0.5	WH/RD	5381	Brake Position Sensor 5V Reference	I	—
26	0.5	WH/GN	5380	Brake Position Sensor Signal	I	—
27	—	—	—	Not Occupied	—	—
28	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	I	—
29	0.5	WH/GY	1786	Transmission Park/Neutral Signal 1	I	—
30	0.5	GN/WH	492	Mass Air Flow Sensor Signal	I	—
31 - 37	—	—	—	Not Occupied	—	—
38	0.5	L-BU/WH	890	Fuel Tank Pressure Sensor Signal	I	—

39	0.5	BN/GY	4008	Humidity Sensor Signal	I	—
40 - 43	—	—	—	Not Occupied	—	—
44	0.5	BK/WH	2151	Signal Ground	I	—
45 - 46	—	—	—	Not Occupied	—	—
47	0.5	BN/RD	2700	A/C Pressure Sensor 5V Reference	I	—
48	—	—	—	Not Occupied	—	—
49	0.5	VT/L-BU	5292	Powertrain Main Relay Fused Supply 3	I	—
50	0.5	VT/L-BU	5291	Powertrain Main Relay Fused Supply 2	I	—
51	0.5	VT/YE	5985	Accessory Wakeup Serial Data	I	—
52	0.5	RD/WH	140	Battery Positive Voltage	I	—
53	—	—	—	Not Occupied	—	—
54	0.5	WH	1310	EVAP Canister Vent Solenoid Control	I	—
55 - 63	—	—	—	Not Occupied	—	—
64	0.5	L-BU/GY	636	Outside Ambient Air Temperature Sensor Signal	I	—
65 - 66	—	—	—	Not Occupied	—	—
67	0.5	GN	380	A/C Refrigerant Pressure Sensor Signal	I	—
68	—	—	—	Not Occupied	—	—
69	0.5	GN/GY	465	Fuel Pump Primary Relay Control	I	—
70	0.5	YE/BK	625	Starter Enable Relay Control	I	—

71	0.5	VT/GY	139	Run/Crank Ignition 1 Voltage	I	—
72	0.5	VT/L-BU	5290	Powertrain Main Relay Fused Supply 1	I	—
73	2	VT/L-BU	5290	Powertrain Main Relay Fused Supply 1	II	—

K20 Engine Control Module X1 (LGZ+ZR2)



Connector Part Information

Harness Type: Engine

OEM Connector: 34566-0303

Service Connector: 13574782

Description: 73-Way F 0.64, 2.8 Series, Sealed (BK with BU Terminal Position Assurance)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575812	J-35616-64B (LT BU)	J-38125-213	Not Available	Not Available	Not Available	Not Available
II	13576392	J-35616-4A (PU)	J-38125-11A	7116-4152-02	Yazaki 9	2	5

K20 Engine Control Module X1 (LGZ+ZR2)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 4	—	—	—	Not Occupied	—	—
5	0.5	BK/VT	1272	Accelerator Pedal Position Low Reference 2	I	—
6	0.5	YE/WH	1161	Accelerator Pedal Position Signal 1	I	—
7	0.5	BK/L-BU	1271	Accelerator Pedal Position Low Reference 1	I	—
8	0.5	WH	7494	High Speed GMLAN Serial Data (-)3	I	—
9	0.5	BK/YE	5382	Brake Position Sensor Low Reference	I	—
10 - 11	—	—	—	Not Occupied	—	—
12	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	I	—

13	0.5	WH/L-BU	6311	Cruise/ETC/TCC Brake Signal	I	—
14	0.5	WH/GY	459	A/C Compressor Clutch Relay Control	I	—
15	0.5	YE	5991	Powertrain Relay Coil Control	I	—
16	0.5	BN/WH	419	Check Engine Indicator Control	I	—
17	0.5	WH/BK	2366	Cooling Fan Control Relay Speed Signal	I	—
18 - 20	—	—	—	Not Occupied	—	—
21	0.5	BN/RD	1274	Accelerator Pedal Position 5V Reference 2	I	—
22	0.5	GN/WH	1162	Accelerator Pedal Position Signal 2	I	—
23	0.5	WH/RD	1164	Accelerator Pedal Position 5V Reference 1	I	—
24	0.5	L-BU/BK	7493	High Speed GMLAN Serial Data (+)3	I	—
25	0.5	WH/RD	5381	Brake Position Sensor 5V Reference	I	—
26	0.5	WH/GN	5380	Brake Position Sensor Signal	I	—
27	—	—	—	Not Occupied	—	—
28	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	I	—
29	0.5	WH/GY	1786	Transmission Park/Neutral Signal 1	I	—
30	0.5	GN/WH	492	Mass Air Flow Sensor Signal	I	—
31 - 37	—	—	—	Not Occupied	—	—
38	0.5	L-BU/WH	890	Fuel Tank Pressure Sensor Signal	I	—

39	0.5	BN/GY	4008	Humidity Sensor Signal	I	—
40 - 43	—	—	—	Not Occupied	—	—
44	0.5	BK/WH	2151	Signal Ground	I	—
45 - 46	—	—	—	Not Occupied	—	—
47	0.5	BN/RD	2700	A/C Pressure Sensor 5V Reference	I	—
48	—	—	—	Not Occupied	—	—
49	0.5	VT/L-BU	5292	Powertrain Main Relay Fused Supply 3	I	—
50	0.5	VT/L-BU	5291	Powertrain Main Relay Fused Supply 2	I	—
51	0.5	VT/YE	5985	Accessory Wakeup Serial Data	I	—
52	0.5	RD/WH	140	Battery Positive Voltage	I	—
53	—	—	—	Not Occupied	—	—
54	0.5	WH	1310	EVAP Canister Vent Solenoid Control	I	—
55 - 63	—	—	—	Not Occupied	—	—
64	0.5	L-BU/GY	636	Outside Ambient Air Temperature Sensor Signal	I	—
65 - 66	—	—	—	Not Occupied	—	—
67	0.5	GN	380	A/C Refrigerant Pressure Sensor Signal	I	—
68	—	—	—	Not Occupied	—	—
69	0.5	GN/GY	465	Fuel Pump Primary Relay Control	I	—
70	0.5	YE/BK	625	Starter Enable Relay Control	I	—

71	0.5	VT/GY	139	Run/Crank Ignition 1 Voltage	I	—
72	0.5	VT/L-BU	5290	Powertrain Main Relay Fused Supply 1	I	—
73	2	VT/L-BU	5290	Powertrain Main Relay Fused Supply 1	II	—

K20 Engine Control Module X1 (LWN)



Connector Part Information

Harness Type: Engine

OEM Connector: 13647470

Service Connector: 19181736

Description: 66-Way F 0.64, 2.8, 6.3 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13579752	J-35616-4A (PU)	J-38125-36	4-964286-1	Lear 16	E	1
II	13579752	J-35616-4A (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
III	13584448	J-35616-64B (LT BU)	J-38125-12A	1719532-5	Lear 7	J	J
IV	13584529	J-35616-42 (RD)	J-38125-11A	Not Available	Not Available	Not Available	Not Available
V	13584530	J-35616-4A (PU)	J-38125-36	4-964273-1	Yazaki 15	C	5
VI	13584530	J-35616-4A (PU)	J-38125-36	4-964273-1	Yazaki 15	E	1

K20 Engine Control Module X1 (LWN)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	2.5	VT/L-BU	5290	Powertrain Main Relay Fused Supply 1	V	—
2	0.75	VT/L-BU	5291	Powertrain Main Relay Fused Supply 2	I	—
3	1.5	VT/L-BU	5292	Powertrain Main Relay Fused Supply 3	VI	—
4	0.5	RD/WH	140	Battery Positive Voltage	II	—
5	6	BN/L-BU	104	Glow Plug Control	IV	—

6	6	BK/WH	451	Signal Ground	IV	—
7	0.5	VT/YE	5985	Accessory Wakeup Serial Data	III	—
8 - 10	—	—	—	Not Occupied	—	—
11	0.5	L-BU/YE	6861	Water In Fuel Sensor Signal	III	—
12	—	—	—	Not Occupied	—	—
13	0.5	WH/RD	1164	Accelerator Pedal Position 5V Reference 1	III	—
14	0.5	BN/RD	1274	Accelerator Pedal Position 5V Reference 2	III	—
15	0.5	GN/WH	1162	Accelerator Pedal Position Signal 2	III	—
16	0.5	BK/VT	1272	Accelerator Pedal Position Low Reference 2	III	—
17	0.5	WH/BK	2366	Cooling Fan Control Relay Speed Signal	III	—
18	0.5	BN/WH	419	Check Engine Indicator Control	III	—
19	0.5	GN/BN	507	Wait To Start Indicator Control	III	—
20	—	—	—	Not Occupied	—	—
21	0.5	YE	2928	Fuel Metering Valve High Control	III	—
22	0.5	VT/GY	139	Run/Crank Ignition 1 Voltage	III	—
23	0.5	WH/L-BU	6311	Cruise/ETC/TCC Brake Signal	III	—
24	0.5	WH/GY	1786	Transmission Park/Neutral Signal 1	III	—
25	0.5	GN/WH	492	Mass Air Flow Sensor Signal	III	—

26	0.5	L-BU/VT	2364	Cooling Fan Speed Signal	III	—
27	0.5	BK/L-BU	1271	Accelerator Pedal Position Low Reference 1	III	—
28	0.5	YE/WH	1161	Accelerator Pedal Position Signal 1	III	—
29	0.5	L-BU/RD	1688	5V Reference	III	—
30	0.5	VT/WH	821	Vehicle Speed Sensor Signal	III	—
31	0.5	BK/GN	822	Vehicle Speed Sensor Low Reference	III	—
32	—	—	—	Not Occupied	—	—
33	0.5	WH/GY	459	A/C Compressor Clutch Relay Control	III	—
34 - 35	—	—	—	Not Occupied	—	—
36	0.5	BN/BK	2929	Fuel Metering Valve Low Control	III	—
37 - 38	—	—	—	Not Occupied	—	—
39	0.5	WH	4499	High Speed GMLAN Serial Data (-) 7	III	—
40	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	III	—
41 - 42	—	—	—	Not Occupied	—	—
43	0.5	BK/YE	5382	Brake Position Sensor Low Reference	III	—
44	0.5	WH/RD	5381	Brake Position Sensor 5V Reference	III	—
45	0.5	WH/L-BU	6289	Induction Air Temperature Sensor Signal	III	—
46	0.5	BN/RD	2700	A/C Pressure Sensor 5V Reference	III	—

47	0.5	GN	380	A/C Refrigerant Pressure Sensor Signal	III	—
48	0.5	BK/BN	5514	A/C Refrigerant Pressure Sensor Low Reference	III	—
49	—	—	—	Not Occupied	—	—
50	0.5	GN/GY	465	Fuel Pump Primary Relay Control	III	—
51	0.5	YE	5991	Powertrain Relay Coil Control	III	—
52 - 53	—	—	—	Not Occupied	—	—
54	0.5	L-BU/BN	4498	High Speed GMLAN Serial Data (+) 7	III	—
55	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	III	—
56 - 58	—	—	—	Not Occupied	—	—
59	0.5	WH/GN	5380	Brake Position Sensor Signal	III	—
60	0.5	BK/VT	2760	Intake Air Temperature Sensor Low Reference	III	—
61 - 63	—	—	—	Not Occupied	—	—
64	0.5	VT/BN	2927	Hydrocarbon Injector Low Control	III	—
65	—	—	—	Not Occupied	—	—
66	0.5	VT/GY	6386	Starter Enable Relay (PPEI 3) Control	III	—

K20 Engine Control Module X2 (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 34566-0103

Service Connector: 88988931

Description: 73-Way F 0.64, 2.8 Series, Sealed (BK with BK Terminal Position Assurance)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575812	J-35616-64B (LT BU)	J-38125-213	Not Available	Not Available	Not Available	Not Available
II	13579770	J-35616-4A (PU)	J-38125-11A	7116-4152-02	Yazaki 9	A	5

K20 Engine Control Module X2 (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	—	—	—	Not Occupied	—	—
2	0.5	L-BU	410	Engine Coolant Temperature Sensor Signal	I	—
3	—	—	—	Not Occupied	—	—
4	0.5	BN/RD	7445	Fuel Line Pressure Sensor 5V Reference	I	—
5	0.5	GY/RD	2704	Manifold Absolute Pressure Sensor 5V Reference	I	—
6	0.5	GY/YE	5297	Camshaft Position Exhaust Sensor Control 1	I	—
7	0.5	GY/L-BU	5300	Camshaft Position Intake Sensor Control 1	I	—
8 - 11	—	—	—	Not Occupied	—	—
12	0.5	BN/RD	2701	Throttle Position Sensor 5V Reference	I	—

13	0.5	L-BU/WH	3630	Throttle Position Sensor (SENT1) Signal	I	—
14	0.5	WH/RD	2705	Oil Pressure Sensor 5V Reference	I	—
15	0.5	VT/L-BU	6270	Crankshaft 60X Sensor 5V Reference	I	—
16 - 19	—	—	—	Not Occupied	—	—
20	0.5	L-BU/WH	7446	Fuel Line Pressure Sensor Signal	I	—
21	0.5	BK/GN	469	Manifold Absolute Pressure Sensor Low Reference	I	—
22	0.5	BK/GY	5296	Camshaft Position Exhaust Sensor Low Reference 1	I	—
23	0.5	BK/GN	5301	Camshaft Position Intake Sensor Low Reference 1	I	—
24 - 27	—	—	—	Not Occupied	—	—
28	0.5	BK/BN	2752	Throttle Position Sensor Low Reference	I	—
29	0.5	YE/BN	331	Oil Pressure Sensor Signal	I	—
30	0.5	BK/VT	2755	Oil Pressure Sensor Low Reference	I	—
31	0.5	BK/VT	6272	Crankshaft 60X Sensor Low Reference	I	—
32	—	—	—	Not Occupied	—	—
33	0.5	WH/BK	3111	Heated Oxygen Sensor Low Signal Bank 1 Sensor 1	I	—
34	0.5	WH/YE	3121	Heated Oxygen Sensor Low Signal Bank 1 Sensor 2	I	—
35	—	—	—	Not Occupied	—	—
36	0.5	BK/VT	6754	Cam Phaser X Low Reference	I	—

37	0.5	BK/BN	6753	Cam Phaser W Low Reference	I	—
38	0.5	VT/BK	5273	Camshaft Position Exhaust Sensor 1	I	—
39	0.5	YE/VT	5275	Camshaft Position Intake Sensor 1	I	—
40	0.5	GN	6271	Crankshaft 60X Sensor Signal	I	—
41 - 42	—	—	—	Not Occupied	—	—
43	0.5	BK/BN	2761	Coolant Temperature Sensor Low Reference	I	—
44	0.5	BK/L-BU	2129	Ignition Control Low Reference Bank 1	I	—
45	0.5	GN/L-BU	2123	Ignition Control 3	I	—
46	0.5	L-BU/VT	2121	Ignition Control 1	I	—
47	—	—	—	Not Occupied	—	—
48	0.75	L-BU	4802	Direct Fuel Injector (DFI) High Voltage Control Cylinder 2	I	—
49	0.75	GY/L-BU	4804	Direct Fuel Injector (DFI) High Voltage Control Cylinder 4	I	—
50	0.75	GN	4803	Direct Fuel Injector (DFI) High Voltage Control Cylinder 3	I	—
51	0.75	BN	4801	Direct Fuel Injector (DFI) High Voltage Control Cylinder 1	I	—
52	0.5	YE	581	Throttle Actuator Control Open	I	—
53	0.5	VT/GY	3110	Heated Oxygen Sensor High Signal Bank 1 Sensor 1	I	—
54	0.5	VT/L-BU	3120	Heated Oxygen Sensor High Signal Bank 1 Sensor 2	I	—

55	—	—	—	Not Occupied	—	—
56	0.5	GY/L-BU	5282	Camshaft Phaser Exhaust Solenoid 1	I	—
57	0.5	VT/BN	5284	Camshaft Phaser Intake Solenoid 1	I	—
58 - 59	—	—	—	Not Occupied	—	—
60	0.5	GY/WH	3122	Heated Oxygen Sensor Heater Low Control Bank 1 Sensor 2	I	—
61	0.5	GY/WH	3113	Heated Oxygen Sensor Heater Low Control Bank 1 Sensor 1	I	—
62 - 63	—	—	—	Not Occupied	—	—
64	0.5	L-BU	179	Oil Pump Command Signal	I	—
65	0.5	L-BU/WH	2122	Ignition Control 2	I	—
66	0.5	YE/L-BU	2124	Ignition Control 4	I	—
67	—	—	—	Not Occupied	—	—
68	0.75	L-BU/GY	4902	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 2	I	—
69	0.75	L-BU/WH	4904	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 4	I	—
70	0.75	GN/GY	4903	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 3	I	—
71	0.75	BN/WH	4901	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 1	I	—
72	0.5	BN/WH	582	Throttle Actuator Control Close	I	—
73	2.5	BK/WH	1451	Signal Ground	II	—

K20 Engine Control Module X2 (LGZ)



Connector Part Information

Harness Type: Engine

OEM Connector: 34566-0103

Service Connector: 88988931

Description: 73-Way F 0.64, 2.8 Series, Sealed (BK with BK Terminal Position Assurance)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575812	J-35616-64B (LT BU)	J-38125-213	Not Available	Not Available	Not Available	Not Available
II	13576392	J-35616-4A (PU)	J-38125-11A	7116-4152-02	Yazaki 9	A	5

K20 Engine Control Module X2 (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/WH	3122	Heated Oxygen Sensor Heater Low Control Bank 1 Sensor 2	I	—
2	0.5	WH/BN	3223	Heated Oxygen Sensor Heater Low Control Bank 2 Sensor 2	I	—
3 - 6	—	—	—	Not Occupied	—	—
7	0.5	GY	3890	Aero Shutter Control 2	I	—
8	—	—	—	Not Occupied	—	—
9	0.5	BN/GN	1174	Oil Level Switch Signal	I	—
10	—	—	—	Not Occupied	—	—
11	0.5	YE/BN	331	Oil Pressure Sensor Signal	I	—
12	0.5	BK/BN	2761	Coolant Temperature Sensor Low Reference	I	—

13 - 16	—	—	—	Not Occupied	—	—
17	0.5	GY/WH	3113	Heated Oxygen Sensor Heater Low Control Bank 1 Sensor 1	I	—
18	0.5	GN/YE	3212	Heated Oxygen Sensor Heater Low Control Bank 2 Sensor 1	I	—
19 - 21	—	—	—	Not Occupied	—	—
22	0.5	L-BU/VT	1589	Primary Fuel Level Sensor Signal	I	—
23 - 26	—	—	—	Not Occupied	—	—
27	0.5	WH/RD	2705	Oil Pressure Sensor 5V Reference	I	—
28	0.5	VT/L-BU	5294	Powertrain Main Relay Fused Supply 5	I	—
29 - 34	—	—	—	Not Occupied	—	—
35	0.5	WH/BK	3111	Heated Oxygen Sensor Low Signal Bank 1 Sensor 1	I	—
36	0.5	YE/WH	3211	Heated Oxygen Sensor Low Signal Bank 2 Sensor 1	I	—
37	0.5	WH/YE	3121	Heated Oxygen Sensor Low Signal Bank 1 Sensor 2	I	—
38	0.5	YE/L-BU	3221	Heated Oxygen Sensor Low Signal Bank 2 Sensor 2	I	—
39	0.5	BK/YE	1716	Knock Sensor Low Reference 1	I	—
40	0.5	BK/GY	2303	Knock Sensor Low Reference 2	I	—
41	—	—	—	Not Occupied	—	—
42	0.5	YE/WH	3200	Throttle Inlet Absolute Pressure Sensor Signal	I	—
43	0.5	WH/RD	3201	Throttle Inlet Absolute Pressure Sensor 5V Reference	I	—
44	—	—	—	Not Occupied	—	—

44	—	—	—	Not Occupied	—	—
45	0.5	L-BU/RD	1688	5V Reference	I	—
46	0.5	YE/RD	2709	Fuel Tank Pressure Sensor 5V Reference	I	—
47	0.5	GY/RD	2704	Manifold Absolute Pressure Sensor 5V Reference	I	—
48	0.5	BK/GN	469	Manifold Absolute Pressure Sensor Low Reference	I	—
49 - 50	—	—	—	Not Occupied	—	—
51	0.5	BK/VT	2755	Oil Pressure Sensor Low Reference	I	—
52	0.5	BN/WH	582	Throttle Actuator Control Close	I	—
53 - 54	—	—	—	Not Occupied	—	—
55	0.5	VT/GY	3110	Heated Oxygen Sensor High Signal Bank 1 Sensor 1	I	—
56	0.5	VT/WH	3210	Heated Oxygen Sensor High Signal Bank 2 Sensor 1	I	—
57	0.5	VT/L-BU	3120	Heated Oxygen Sensor High Signal Bank 1 Sensor 2	I	—
58	0.5	VT/GN	3220	Heated Oxygen Sensor High Signal Bank 2 Sensor 2	I	—
59	0.5	VT/GY	496	Knock Sensor Signal 1	I	—
60	0.5	WH/GY	1876	Knock Sensor Signal 2	I	—
61 - 62	—	—	—	Not Occupied	—	—
63	0.5	BK/VT	2760	Intake Air Temperature Sensor Low Reference	I	—
64	—	—	—	Not Occupied	—	—
65	0.5	VT/WH	821	Vehicle Speed Sensor Signal	I	—

66	0.5	BK/GN	822	Vehicle Speed Sensor Low Reference	I	—
67	0.5	GN/WH	432	Manifold Absolute Pressure Sensor Signal	I	—
68 - 69	—	—	—	Not Occupied	—	—
70	0.5	WH/L-BU	6289	Induction Air Temperature Sensor Signal	I	—
71	—	—	—	Not Occupied	—	—
72	0.5	YE	581	Throttle Actuator Control Open	I	—
73	2.5	BK/WH	151	Signal Ground	II	—

K20 Engine Control Module X2 (LGZ+ZR2)



Connector Part Information

Harness Type: Engine

OEM Connector: 34566-0103

Service Connector: 88988931

Description: 73-Way F 0.64, 2.8 Series, Sealed (BK with BK Terminal Position Assurance)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575812	J-35616-64B (LT BU)	J-38125-213	Not Available	Not Available	Not Available	Not Available
II	13579770	J-35616-4A (PU)	J-38125-11A	7116-4152-02	Yazaki 9	A	5

K20 Engine Control Module X2 (LGZ+ZR2)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/WH	3122	Heated Oxygen Sensor Heater Low Control Bank 1 Sensor 2	I	—
2	0.5	WH/BN	3223	Heated Oxygen Sensor Heater Low Control Bank 2 Sensor 2	I	—
3 - 6	—	—	—	Not Occupied	—	—
7	0.5	GY	3890	Aero Shutter Control 2	I	—
8	—	—	—	Not Occupied	—	—
9	0.5	BN/GN	1174	Oil Level Switch Signal	I	—
10	—	—	—	Not Occupied	—	—
11	0.5	YE/BN	331	Oil Pressure Sensor Signal	I	—
12	0.5	BK/BN	2761	Coolant Temperature Sensor Low Reference	I	—

13 - 16	—	—	—	Not Occupied	—	—
17	0.5	GY/WH	3113	Heated Oxygen Sensor Heater Low Control Bank 1 Sensor 1	I	—
18	0.5	GN/YE	3212	Heated Oxygen Sensor Heater Low Control Bank 2 Sensor 1	I	—
19 - 21	—	—	—	Not Occupied	—	—
22	0.5	L-BU/VT	1589	Primary Fuel Level Sensor Signal	I	—
23 - 26	—	—	—	Not Occupied	—	—
27	0.5	WH/RD	2705	Oil Pressure Sensor 5V Reference	I	—
28	0.5	VT/L-BU	5294	Powertrain Main Relay Fused Supply 5	I	—
29 - 34	—	—	—	Not Occupied	—	—
35	0.5	WH/BK	3111	Heated Oxygen Sensor Low Signal Bank 1 Sensor 1	I	—
36	0.5	YE/WH	3211	Heated Oxygen Sensor Low Signal Bank 2 Sensor 1	I	—
37	0.5	WH/YE	3121	Heated Oxygen Sensor Low Signal Bank 1 Sensor 2	I	—
38	0.5	YE/L-BU	3221	Heated Oxygen Sensor Low Signal Bank 2 Sensor 2	I	—
39	0.5	BK/YE	1716	Knock Sensor Low Reference 1	I	—
40	0.5	BK/GY	2303	Knock Sensor Low Reference 2	I	—
41	—	—	—	Not Occupied	—	—
42	0.5	YE/WH	3200	Throttle Inlet Absolute Pressure Sensor Signal	I	—
43	0.5	WH/RD	3201	Throttle Inlet Absolute Pressure Sensor 5V Reference	I	—
44	—	—	—	Not Occupied	—	—

44	—	—	—	Not Occupied	—	—
45	0.5	L-BU/RD	1688	5V Reference	I	—
46	0.5	YE/RD	2709	Fuel Tank Pressure Sensor 5V Reference	I	—
47	0.5	GY/RD	2704	Manifold Absolute Pressure Sensor 5V Reference	I	—
48	0.5	BK/GN	469	Manifold Absolute Pressure Sensor Low Reference	I	—
49 - 50	—	—	—	Not Occupied	—	—
51	0.5	BK/VT	2755	Oil Pressure Sensor Low Reference	I	—
52	0.5	BN/WH	582	Throttle Actuator Control Close	I	—
53 - 54	—	—	—	Not Occupied	—	—
55	0.5	VT/GY	3110	Heated Oxygen Sensor High Signal Bank 1 Sensor 1	I	—
56	0.5	VT/WH	3210	Heated Oxygen Sensor High Signal Bank 2 Sensor 1	I	—
57	0.5	VT/L-BU	3120	Heated Oxygen Sensor High Signal Bank 1 Sensor 2	I	—
58	0.5	VT/GN	3220	Heated Oxygen Sensor High Signal Bank 2 Sensor 2	I	—
59	0.5	VT/GY	496	Knock Sensor Signal 1	I	—
60	0.5	WH/GY	1876	Knock Sensor Signal 2	I	—
61 - 62	—	—	—	Not Occupied	—	—
63	0.5	BK/VT	2760	Intake Air Temperature Sensor Low Reference	I	—
64	—	—	—	Not Occupied	—	—
65	0.5	VT/WH	821	Vehicle Speed Sensor Signal	I	—

66	0.5	BK/GN	822	Vehicle Speed Sensor Low Reference	I	—
67	0.5	GN/WH	432	Manifold Absolute Pressure Sensor Signal	I	—
68 - 69	—	—	—	Not Occupied	—	—
70	0.5	WH/L-BU	6289	Induction Air Temperature Sensor Signal	I	—
71	—	—	—	Not Occupied	—	—
72	0.5	YE	581	Throttle Actuator Control Open	I	—
73	2.5	BK/WH	151	Signal Ground	II	—

K20 Engine Control Module X2 (LWN)



Connector Part Information

Harness Type: Engine

OEM Connector: 12672831

Service Connector: 19354404

Description: 96-Way F 0.64 MTS-B, 2.8 ATS Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13584448	J-35616-64B (LT BU)	J-38125-12A	1719532-5	Lear 7	J	J
II	13584530	J-35616-4A (PU)	J-38125-36	4-964273-1	Yazaki 15	C	5
III	13584530	J-35616-4A (PU)	J-38125-36	4-964273-1	Yazaki 15	E	1

K20 Engine Control Module X2 (LWN)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1.5	L-BU/GY	4902	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 2	III	—
2	1.5	GN/GY	4903	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 3	III	—
3	1.5	L-BU/WH	4904	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 4	III	—
4	1.5	BN/WH	4901	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 1	III	—
5	1.5	L-BU	4802	Direct Fuel Injector (DFI) High Voltage Control Cylinder 2	III	—
6	1.5	GN	4803	Direct Fuel Injector (DFI) High Voltage Control Cylinder 3	III	—
7	1.5	GY/L-BU	4804	Direct Fuel Injector (DFI) High Voltage Control Cylinder 4	III	—

8	1.5	BN	4801	Direct Fuel Injector (DFI) High Voltage Control Cylinder 1	III	—
9 - 12	—	—	—	Not Occupied	—	—
13	2	GY/BN	1582	Glow Plug Control 2	II	—
14	2	GY/YE	1584	Glow Plug Control 4	II	—
15	2	GY/GN	1583	Glow Plug Control 3	II	—
16	2	GY/L-BU	1581	Glow Plug Control 1	II	—
17	0.5	BK/VT	2755	Oil Pressure Sensor Low Reference	I	—
18	0.5	YE/BN	331	Oil Pressure Sensor Signal	I	—
19	0.5	WH/RD	2705	Oil Pressure Sensor 5V Reference	I	—
20 - 25	—	—	—	Not Occupied	—	—
26	0.5	BN	7348	Induction Air Temperature Sensor 2 Signal	I	—
27	0.5	BN/GY	7072	Sensor Fuel Temperature 1 Signal	I	—
28 - 29	—	—	—	Not Occupied	—	—
30	0.5	L-BU	410	Engine Coolant Temperature Sensor Signal	I	—
31	0.5	BN	3681	Charge Air Cooler Outlet Temperature Sensor Signal	I	—
32	0.5	GN	3683	Charge Air Cooler Inlet Temperature Sensor Signal	I	—
33	—	—	—	Not Occupied	—	—
34	0.5	BN	25	Charge Indicator Control	I	—

35 - 37	—	—	—	Not Occupied	—	—
38	0.5	BN/YE	2161	Fuel Rail Pressure Sensor 2 Signal	I	—
39	—	—	—	Not Occupied	—	—
40	0.5	GY/L-BU	5300	Camshaft Position Intake Sensor Control 1	I	—
41	0.5	YE/VT	5275	Camshaft Position Intake Sensor 1	I	—
42	0.5	BK/GN	5301	Camshaft Position Intake Sensor Low Reference 1	I	—
43	0.5	BN/RD	2701	Throttle Position Sensor 5V Reference	I	—
44	0.5	L-BU/WH	3630	Throttle Position Sensor (SENT1) Signal	I	—
45	0.5	BK/BN	2752	Throttle Position Sensor Low Reference	I	—
46	—	—	—	Not Occupied	—	—
47	0.5	BN/WH	7073	Sensor Fuel Temperature 1 Low Reference	I	—
48 - 49	—	—	—	Not Occupied	—	—
50	0.5	BK/BN	2761	Coolant Temperature Sensor Low Reference	I	—
51	0.5	YE/L-BU	3680	Charge Air Cooler Outlet Temperature Sensor Low Reference	I	—
52	0.5	YE/BK	3682	Charge Air Cooler Inlet Temperature Sensor Low Reference	I	—
53 - 55	—	—	—	Not Occupied	—	—
56	0.5	BN/L-BU	2926	Hydrocarbon Injector High Control	I	—
57	0.5	BK/BN	2753	Exhaust Gas Recirculation Sensor Low Reference	I	—

58	0.5	BN/WH	5763	Exhaust Gas Recirculation Valve Sensor Signal	I	—
59	0.5	L-BU/RD	5047	Exhaust Gas Recirculation 5V Reference 1	I	—
60	0.5	BK/BN	6141	Cooling Fan Speed Low Reference	I	—
61	—	—	—	Not Occupied	—	—
62	0.5	GY/RD	2365	Cooling Fan Speed 5V Reference	I	—
63 - 66	—	—	—	Not Occupied	—	—
67	0.5	GY	23	Generator Field Duty Cycle Signal	I	—
68	—	—	—	Not Occupied	—	—
69	0.5	BK/GN	2919	Fuel Rail Pressure Sensor Low Reference	I	—
70	0.5	VT/BK	5746	Exhaust Gas Recirculation Valve Motor Low Signal	I	—
71	0.5	WH/VT	5764	Exhaust Gas Recirculation Valve Motor High Signal	I	—
72	0.5	GY/L-BU	5930	Variable Nozzle Turbo Solenoid High Signal	I	—
73	0.5	WH/BK	5931	Variable Nozzle Turbo Solenoid Low Signal	I	—
74 - 75	—	—	—	Not Occupied	—	—
76	0.5	BK/YE	2834	Fuel Rail Pressure Solenoid Low Reference	I	—
77 - 79	—	—	—	Not Occupied	—	—
80	0.5	BK/GN	469	Manifold Absolute Pressure Sensor Low Reference	I	—
81	0.5	GN/WH	432	Manifold Absolute Pressure Sensor Signal	I	—
82	0.5	GY/RD	2704	Manifold Absolute Pressure Sensor 5V Reference	I	—

83	0.5	VT/L-BU	6270	Crankshaft 60X Sensor 5V Reference	I	—
84	0.5	GN	6271	Crankshaft 60X Sensor Signal	I	—
85	0.5	BK/VT	6272	Crankshaft 60X Sensor Low Reference	I	—
86	0.5	BN/GN	1174	Oil Level Switch Signal	I	—
87	—	—	—	Not Occupied	—	—
88	0.5	L-BU/WH	2918	Fuel Rail Pressure Sensor Signal	I	—
89	0.5	BN/RD	2917	Fuel Rail Pressure Sensor 5V Reference	I	—
90	0.5	BN/WH	582	Throttle Actuator Control Close	I	—
91	0.5	YE	581	Throttle Actuator Control Open	I	—
92 - 93	—	—	—	Not Occupied	—	—
94	0.5	YE/L-BU	3231	Exhaust Gas Recirculation Cooler Bypass Solenoid Control	I	—
95	0.5	GY/L-BU	3230	Exhaust Gas Recirculation Cooler Bypass Solenoid Control	I	—
96	0.5	L-BU/WH	2530	Fuel Rail Pressure Solenoid Control	I	—

K20 Engine Control Module X3 (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 34566-0203

Service Connector: 88988372

Description: 73-Way F 0.64, 2.8 Series, Sealed (BK with GY Terminal Position Assurance)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575812	J-35616-64B (LT BU)	J-38125-213	Not Available	Not Available	Not Available	Not Available
II	13579770	J-35616-4A (PU)	J-38125-11A	7116-4152-02	Yazaki 9	A	5

K20 Engine Control Module X3 (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 3	—	—	—	Not Occupied	—	—
4	0.5	GN/L-BU	428	EVAP Canister Purge Solenoid Control	I	—
5	—	—	—	Not Occupied	—	—
6	0.5	BN/RD	2917	Fuel Rail Pressure Sensor 5V Reference	I	—
7	—	—	—	Not Occupied	—	—
8	0.5	YE/RD	2709	Fuel Tank Pressure Sensor 5V Reference	I	—
9 - 10	—	—	—	Not Occupied	—	—
11	0.5	L-BU/RD	1688	5V Reference	I	—
12 - 13	—	—	—	Not Occupied	—	—
14	0.5	WH/RD	3201	Throttle Inlet Absolute Pressure Sensor 5V Reference	I	—

15	—	—	—	Not Occupied	—	—
16	0.5	VT/L-BU	5294	Powertrain Main Relay Fused Supply 5	I	—
17	—	—	—	Not Occupied	—	—
18	0.5	L-BU/WH	225	Generator Turn On Signal	I	—
19	0.5	GY	23	Generator Field Duty Cycle Signal	I	—
20	0.5	BK/GN	6281	Fuel Level Sensor Low Reference	I	—
21	0.5	L-BU/WH	2918	Fuel Rail Pressure Sensor Signal	I	—
22	0.5	BK/GN	2919	Fuel Rail Pressure Sensor Low Reference	I	—
23 - 26	—	—	—	Not Occupied	—	—
27	0.5	BK/GN	822	Vehicle Speed Sensor Low Reference	I	—
28 - 39	—	—	—	Not Occupied	—	—
40	0.5	GN/WH	432	Manifold Absolute Pressure Sensor Signal	I	—
41	0.5	BN/GN	1174	Oil Level Switch Signal	I	—
42	—	—	—	Not Occupied	—	—
43	0.5	L-BU/VT	1589	Primary Fuel Level Sensor Signal	I	—
44 - 45	—	—	—	Not Occupied	—	—
46	0.5	YE/WH	3200	Throttle Inlet Absolute Pressure Sensor Signal	I	—
47 - 51	—	—	—	Not Occupied	—	—
52	0.5	VT/BK	7300	High Pressure Fuel Pump Actuator Low - Control	I	—
53 - 54	—	—	—	Not Occupied	—	—

53 - 54	—	—	—	Not Occupied	—	—
55	0.5	GY	3890	Aero Shutter Control 2	I	—
56 - 58	—	—	—	Not Occupied	—	—
59	0.5	BK/GY	2303	Knock Sensor Low Reference 2	I	—
60	0.5	WH/GY	1876	Knock Sensor Signal 2	I	—
61	0.5	BK/YE	1716	Knock Sensor Low Reference 1	I	—
62	0.5	VT/GY	496	Knock Sensor Signal 1	I	—
63	0.5	VT/WH	821	Vehicle Speed Sensor Signal	I	—
64 - 66	—	—	—	Not Occupied	—	—
67	0.5	GN/WH	5007	Reverse Switch Signal	I	—
68	0.5	L-BU/WH	890	Fuel Tank Pressure Sensor Signal	I	—
69 - 71	—	—	—	Not Occupied	—	—
72	0.5	YE	7301	High Pressure Fuel Pump Actuator High - Control	I	—
73	2.5	BK/WH	1451	Signal Ground	II	—

K20 Engine Control Module X3 (LGZ)



Connector Part Information

- Harness Type: Engine
- OEM Connector: 34566-0203
- Service Connector: 88988372
- Description: 73-Way F 0.64, 2.8 Series, Sealed (BK with GY Terminal Position Assurance)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575812	J-35616-64B (LT BU)	J-38125-213	Not Available	Not Available	Not Available	Not Available
II	13576392	J-35616-4A (PU)	J-38125-11A	7116-4152-02	Yazaki 9	A	5

K20 Engine Control Module X3 (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GN	5492	Cylinder Shutoff Solenoid Control 2	I	—
2	0.5	L-BU	5491	Cylinder Shutoff Solenoid Control 1	I	—
3	0.5	GN/BN	5298	Camshaft Position Exhaust Sensor Control 2	I	—
4	0.5	YE	5276	Camshaft Position Intake Sensor 2	I	—
5	0.5	WH/L-BU	5302	Camshaft Position Intake Sensor Control 2	I	—
6	0.5	VT/L-BU	6270	Crankshaft 60X Sensor 5V Reference	I	—
7	0.5	GN	6271	Crankshaft 60X Sensor Signal	I	—

8	0.5	BN/RD	2701	Throttle Position Sensor 5V Reference	I	—
9 - 11	—	—	—	Not Occupied	—	—
12	0.5	BN/L-BU	2126	Ignition Control 6	I	—
13	0.5	L-BU/GY	2125	Ignition Control 5	I	—
14	0.5	YE/L-BU	2124	Ignition Control 4	I	—
15	0.5	BK/GY	2130	Ignition Control Low Reference Bank 2	I	—
16	0.5	YE	7301	High Pressure Fuel Pump Actuator High - Control	I	—
17	0.5	YE/GN	4321	Park Phaser Lock Control	I	—
18	0.5	GY/GN	587	Skip/Shift Solenoid Control	I	—
19	0.5	BK/BN	5299	Camshaft Position Exhaust Sensor Low Reference 2	I	—
20	0.5	VT/L-BU	5274	Camshaft Position Exhaust Sensor 2	I	—
21	0.5	BK/VT	5303	Camshaft Position Intake Sensor Low Reference 2	I	—
22	0.5	BK/VT	6272	Crankshaft 60X Sensor Low Reference	I	—
23	0.5	L-BU/WH	3630	Throttle Position Sensor (SENT1) Signal	I	—
24	0.5	BK/BN	2752	Throttle Position Sensor Low Reference	I	—
25	—	—	—	Not Occupied	—	—
26	0.5	L-BU/WH	225	Generator Turn On Signal	I	—
27	—	—	—	Not Occupied	—	—

27	—	—	—	Not Occupied	—	—
28	0.5	GN/L-BU	2123	Ignition Control 3	I	—
29	0.5	L-BU/WH	2122	Ignition Control 2	I	—
30	0.5	L-BU/VT	2121	Ignition Control 1	I	—
31	0.5	BK/L-BU	2129	Ignition Control Low Reference Bank 1	I	—
32	0.5	VT/BK	7300	High Pressure Fuel Pump Actuator Low - Control	I	—
33	0.5	GN/L-BU	428	EVAP Canister Purge Solenoid Control	I	—
34	0.5	L-BU	179	Oil Pump Command Signal	I	—
35	0.5	GY/YE	5297	Camshaft Position Exhaust Sensor Control 1	I	—
36	0.5	VT/BK	5273	Camshaft Position Exhaust Sensor 1	I	—
37	0.5	BK/GY	5296	Camshaft Position Exhaust Sensor Low Reference 1	I	—
38	0.5	L-BU	410	Engine Coolant Temperature Sensor Signal	I	—
39	0.5	BN/RD	7445	Fuel Line Pressure Sensor 5V Reference	I	—
40	0.5	BN/RD	2917	Fuel Rail Pressure Sensor 5V Reference	I	—
41	0.5	BK/GN	2919	Fuel Rail Pressure Sensor Low Reference	I	—
42	—	—	—	Not Occupied	—	—
43	0.5	BK/L-BU	6755	Cam Phaser Y Low Reference	I	—

44	0.5	GN	5272	Camshaft Phaser Intake Solenoid 2	I	—
45	0.5	VT/BN	5284	Camshaft Phaser Intake Solenoid 1	I	—
46	0.5	BK/BN	6753	Cam Phaser W Low Reference	I	—
47	0.75	WH/GN	4805	Direct Fuel Injector (DFI) High Voltage Control Cylinder 5	I	—
48	0.75	L-BU	4802	Direct Fuel Injector (DFI) High Voltage Control Cylinder 2	I	—
49	0.75	BN	4801	Direct Fuel Injector (DFI) High Voltage Control Cylinder 1	I	—
50	0.75	GY/L-BU	4804	Direct Fuel Injector (DFI) High Voltage Control Cylinder 4	I	—
51	0.75	VT/GN	4806	Direct Fuel Injector (DFI) High Voltage Control Cylinder 6	I	—
52	0.75	GN	4803	Direct Fuel Injector (DFI) High Voltage Control Cylinder 3	I	—
53 - 54	—	—	—	Not Occupied	—	—
55	0.5	GY/L-BU	5300	Camshaft Position Intake Sensor Control 1	I	—
56	0.5	YE/VT	5275	Camshaft Position Intake Sensor 1	I	—
57	0.5	BK/GN	5301	Camshaft Position Intake Sensor Low Reference 1	I	—
58	—	—	—	Not Occupied	—	—
59	0.5	L-BU/WH	7446	Fuel Line Pressure Sensor Signal	I	—
60	0.5	L-BU/WH	2918	Fuel Rail Pressure Sensor Signal	I	—
61	0.5	GY	23	Generator Field Duty Cycle Signal	I	—
62	—	—	—	Not Occupied	—	—

62	—	—	—	Not Occupied	—	—
63	0.5	BK/GY	6756	Cam Phaser Z Low Reference	I	—
64	0.5	GN/BN	5283	Camshaft Phaser Exhaust Solenoid 2	I	—
65	0.5	GY/L-BU	5282	Camshaft Phaser Exhaust Solenoid 1	I	—
66	0.5	BK/VT	6754	Cam Phaser X Low Reference	I	—
67	0.75	GN/WH	4905	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 5	I	—
68	0.75	L-BU/GY	4902	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 2	I	—
69	0.75	BN/WH	4901	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 1	I	—
70	0.75	L-BU/WH	4904	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 4	I	—
71	0.75	VT/GY	4906	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 6	I	—
72	0.75	GN/GY	4903	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 3	I	—
73	2.5	BK/WH	151	Signal Ground	II	—

K20 Engine Control Module X3 (LGZ+ZR2)



Connector Part Information

Harness Type: Engine

OEM Connector: 34566-0203

Service Connector: 88988372

Description: 73-Way F 0.64, 2.8 Series, Sealed (BK with GY Terminal Position Assurance)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575812	J-35616-64B (LT BU)	J-38125-213	Not Available	Not Available	Not Available	Not Available
II	13579770	J-35616-4A (PU)	J-38125-11A	7116-4152-02	Yazaki 9	A	5

K20 Engine Control Module X3 (LGZ+ZR2)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GN	5492	Cylinder Shutoff Solenoid Control 2	I	—
2	0.5	L-BU	5491	Cylinder Shutoff Solenoid Control 1	I	—
3	0.5	GN/BN	5298	Camshaft Position Exhaust Sensor Control 2	I	—
4	0.5	YE	5276	Camshaft Position Intake Sensor 2	I	—
5	0.5	WH/L-BU	5302	Camshaft Position Intake Sensor Control 2	I	—
6	0.5	VT/L-BU	6270	Crankshaft 60X Sensor 5V Reference	I	—
7	0.5	GN	6271	Crankshaft 60X Sensor Signal	I	—

8	0.5	BN/RD	2701	Throttle Position Sensor 5V Reference	I	—
9 - 11	—	—	—	Not Occupied	—	—
12	0.5	BN/L-BU	2126	Ignition Control 6	I	—
13	0.5	L-BU/GY	2125	Ignition Control 5	I	—
14	0.5	YE/L-BU	2124	Ignition Control 4	I	—
15	0.5	BK/GY	2130	Ignition Control Low Reference Bank 2	I	—
16	0.5	YE	7301	High Pressure Fuel Pump Actuator High - Control	I	—
17	0.5	YE/GN	4321	Park Phaser Lock Control	I	—
18	0.5	GY/GN	587	Skip/Shift Solenoid Control	I	—
19	0.5	BK/BN	5299	Camshaft Position Exhaust Sensor Low Reference 2	I	—
20	0.5	VT/L-BU	5274	Camshaft Position Exhaust Sensor 2	I	—
21	0.5	BK/VT	5303	Camshaft Position Intake Sensor Low Reference 2	I	—
22	0.5	BK/VT	6272	Crankshaft 60X Sensor Low Reference	I	—
23	0.5	L-BU/WH	3630	Throttle Position Sensor (SENT1) Signal	I	—
24	0.5	BK/BN	2752	Throttle Position Sensor Low Reference	I	—
25	—	—	—	Not Occupied	—	—
26	0.5	L-BU/WH	225	Generator Turn On Signal	I	—
27	—	—	—	Not Occupied	—	—

27	—	—	—	Not Occupied	—	—
28	0.5	GN/L-BU	2123	Ignition Control 3	I	—
29	0.5	L-BU/WH	2122	Ignition Control 2	I	—
30	0.5	L-BU/VT	2121	Ignition Control 1	I	—
31	0.5	BK/L-BU	2129	Ignition Control Low Reference Bank 1	I	—
32	0.5	VT/BK	7300	High Pressure Fuel Pump Actuator Low - Control	I	—
33	0.5	GN/L-BU	428	EVAP Canister Purge Solenoid Control	I	—
34	0.5	L-BU	179	Oil Pump Command Signal	I	—
35	0.5	GY/YE	5297	Camshaft Position Exhaust Sensor Control 1	I	—
36	0.5	VT/BK	5273	Camshaft Position Exhaust Sensor 1	I	—
37	0.5	BK/GY	5296	Camshaft Position Exhaust Sensor Low Reference 1	I	—
38	0.5	L-BU	410	Engine Coolant Temperature Sensor Signal	I	—
39	0.5	BN/RD	7445	Fuel Line Pressure Sensor 5V Reference	I	—
40	0.5	BN/RD	2917	Fuel Rail Pressure Sensor 5V Reference	I	—
41	0.5	BK/GN	2919	Fuel Rail Pressure Sensor Low Reference	I	—
42	—	—	—	Not Occupied	—	—
43	0.5	BK/L-BU	6755	Cam Phaser Y Low Reference	I	—

44	0.5	GN	5272	Camshaft Phaser Intake Solenoid 2	I	—
45	0.5	VT/BN	5284	Camshaft Phaser Intake Solenoid 1	I	—
46	0.5	BK/BN	6753	Cam Phaser W Low Reference	I	—
47	0.75	WH/GN	4805	Direct Fuel Injector (DFI) High Voltage Control Cylinder 5	I	—
48	0.75	L-BU	4802	Direct Fuel Injector (DFI) High Voltage Control Cylinder 2	I	—
49	0.75	BN	4801	Direct Fuel Injector (DFI) High Voltage Control Cylinder 1	I	—
50	0.75	GY/L-BU	4804	Direct Fuel Injector (DFI) High Voltage Control Cylinder 4	I	—
51	0.75	VT/GN	4806	Direct Fuel Injector (DFI) High Voltage Control Cylinder 6	I	—
52	0.75	GN	4803	Direct Fuel Injector (DFI) High Voltage Control Cylinder 3	I	—
53 - 54	—	—	—	Not Occupied	—	—
55	0.5	GY/L-BU	5300	Camshaft Position Intake Sensor Control 1	I	—
56	0.5	YE/VT	5275	Camshaft Position Intake Sensor 1	I	—
57	0.5	BK/GN	5301	Camshaft Position Intake Sensor Low Reference 1	I	—
58	—	—	—	Not Occupied	—	—
59	0.5	L-BU/WH	7446	Fuel Line Pressure Sensor Signal	I	—
60	0.5	L-BU/WH	2918	Fuel Rail Pressure Sensor Signal	I	—
61	0.5	GY	23	Generator Field Duty Cycle Signal	I	—
62	—	—	—	Not Occupied	—	—

62	—	—	—	Not Occupied	—	—
63	0.5	BK/GY	6756	Cam Phaser Z Low Reference	I	—
64	0.5	GN/BN	5283	Camshaft Phaser Exhaust Solenoid 2	I	—
65	0.5	GY/L-BU	5282	Camshaft Phaser Exhaust Solenoid 1	I	—
66	0.5	BK/VT	6754	Cam Phaser X Low Reference	I	—
67	0.75	GN/WH	4905	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 5	I	—
68	0.75	L-BU/GY	4902	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 2	I	—
69	0.75	BN/WH	4901	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 1	I	—
70	0.75	L-BU/WH	4904	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 4	I	—
71	0.75	VT/GY	4906	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 6	I	—
72	0.75	GN/GY	4903	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 3	I	—
73	2.5	BK/WH	151	Signal Ground	II	—

K20 Engine Control Module X3 (LWN)



Connector Part Information

Harness Type: Engine

OEM Connector: 34576-0703

Service Connector: 88988373

Description: 56-Way F 0.64 Series, Sealed (BU with BU Terminal Position Assurance)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	19301532	J-35616-64B (LT BU)	J-38125-213	Not Available	Not Available	Not Available	Not Available

K20 Engine Control Module X3 (LWN)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BN/WH	3100	DEF Dosing Valve Low Control	I	—
2	—	—	—	Not Occupied	—	—
3	0.5	BK/GN	6281	Fuel Level Sensor Low Reference	I	—
4 - 5	—	—	—	Not Occupied	—	—
6	0.5	YE/WH	3200	Throttle Inlet Absolute Pressure Sensor Signal	I	—
7	0.5	WH/RD	3201	Throttle Inlet Absolute Pressure Sensor 5V Reference	I	—
8	0.5	BK/L-BU	61	Outside Ambient Temperature Sensor Low Reference	I	—
9	0.5	BK/VT	3661	Exhaust Gas Temperature Sensor 5 Low Reference	I	—
10	0.5	BK/L-BU	6274	Exhaust Gas Recirculation Temperature Sensor Low Reference	I	—

11	0.5	BK/GY	3659	Exhaust Gas Temperature Sensor 4 Low Reference	I	—
12	0.5	BK/GN	3657	Exhaust Gas Temperature Sensor 3 Low Reference	I	—
13	0.5	BK/L-BU	6783	Exhaust Gas Temperature Sensor 2 Low Reference	I	—
14	0.5	L-BU/WH	5277	Exhaust Gas Temperature Sensor 1	I	—
15	0.5	BN	3099	DEF Dosing Valve High Control	I	—
16 - 17	—	—	—	Not Occupied	—	—
18	0.5	L-BU/VT	1589	Primary Fuel Level Sensor Signal	I	—
19	0.5	BK/YE	6275	Exhaust Gas Recirculation Temperature Sensor 2 Low Reference	I	—
20	0.5	YE/GN	3236	Exhaust Gas Recirculation Temperature Sensor 2 Signal	I	—
21	0.5	GY/RD	5928	Variable Nozzle Turbo Position Sensor 5V Reference	I	—
22	0.5	L-BU/GY	636	Outside Ambient Air Temperature Sensor Signal	I	—
23	0.5	L-BU/GY	3660	Exhaust Gas Temperature Sensor 5 Signal	I	—
24	0.5	WH/BN	3237	Exhaust Gas Recirculation Temperature Sensor Signal	I	—
25	0.5	VT/BN	3658	Exhaust Gas Temperature Sensor 4 Signal	I	—
26	0.5	GY/GN	5378	Exhaust Gas Temperature Sensor 3	I	—
27	0.5	BK/BN	6782	Exhaust Gas Temperature Sensor 1 Low Reference	I	—

28	0.5	L-BU/GN	5377	Exhaust Gas Temperature Sensor 2	I	—
29	—	—	—	Not Occupied	—	—
30	0.5	YE/L-BU	1497	Crankcase Ventilation (Blowby) Heater Control Signal	I	—
31	—	—	—	Not Occupied	—	—
32	0.5	BN/GY	4008	Humidity Sensor Signal	I	—
33	0.5	BK/BN	5929	Variable Nozzle Turbo Position Sensor Low Reference	I	—
34 - 42	—	—	—	Not Occupied	—	—
43	0.5	GN/L-BU	3889	DEF Power Module Relay Control	I	—
44	—	—	—	Not Occupied	—	—
45	0.5	L-BU	3017	Fuel Heater Relay Control 1	I	—
46	0.5	VT/YE	5947	Variable Nozzle Turbo Position Sensor Signal	I	—
47 - 49	—	—	—	Not Occupied	—	—
50	0.5	WH/RD	6054	Exhaust Pressure Sensor 5V Reference 1	I	—
51	0.5	L-BU	6053	Exhaust Pressure Sensor Signal 1	I	—
52	0.5	BK/YE	6055	Exhaust Pressure Sensor Low Reference 1	I	—
53 - 56	—	—	—	Not Occupied	—	—

K22 Cooling Fan Control Module



Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 7287-1404-10

Service Connector: 19181808

Description: 4-Way F 1.5, 9.5 Series, Sealed (D-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-22 (RD)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required
III	Not Required	J-35616-42 (RD)	No Tool Required	Not Required	Not Required	Not Required	Not Required

K22 Cooling Fan Control Module

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	6	BK	1350	Ground	I	LCV
	10	BK	1350	Ground	III	LGZ
2	6	RD/GY	4840	Battery Positive Voltage	I	LCV
	10	RD/GY	4840	Battery Positive Voltage	III	LGZ
3	—	—	—	Not Occupied	—	—
4	0.5	WH/BK	2366	Cooling Fan Control Relay Speed Signal	II	—

K33 HVAC Control Module X1



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 31410-1203

Service Connector: 13576644

Description: 20-Way F 0.64 Series (GN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575845	J-35616-64B (LT BU)	J-38125-215A	SAIT-A03T-M064	Yazaki 14	P	P

K33 HVAC Control Module X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	—	—	—	Not Occupied	—	—
2	0.35	GY/GN	7565	Windscreen Temp Sensor Signal	I	—
3	—	—	—	Not Occupied	—	—
4	0.35	L-BU/WH	734	Inside Air Temperature Sensor Signal	I	—
5	0.35	YE/L-BU	3197	Humidity Temperature Sensor Signal	I	—
6	0.35	YE/RD	597	5V Reference	I	—
7	0.35	BK/L-BU	7566	Humidity/Windscreen Temp Sensor Low Reference	I	—
8 - 11	—	—	—	Not Occupied	—	—
12	0.35	GY/L-BU	7564	Humidity Sensor Signal	I	—
13	—	—	—	Not Occupied	—	—

13	—	—	—	Not Occupied	—	—
14	0.35	YE/VT	1783	Twilight Sentinel Delay Signal	I	—
15 - 17	—	—	—	Not Occupied	—	—
18	0.5	BN	518	Lower Left Air Temperature Sensor Signal	I	—
19 - 20	—	—	—	Not Occupied	—	—

K33 HVAC Control Module X2



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 31410-1202

Service Connector: 15126709

Description: 20-Way F 64 Series, Sealed (BN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575867	J-35616-64B (LT BU)	J-38125-215A	SAIT-A03T-M064	Yazaki 14	P	P

K33 HVAC Control Module X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	RD/VT	3340	Battery Positive Voltage	I	—
2	0.35	GN	5060	Low Speed GMLAN Serial Data	I	—
3	—	—	—	Not Occupied	—	—
4	0.35	GN/YE	7531	Local Interconnect Network Serial Data Bus 9	I	—
5 - 6	—	—	—	Not Occupied	—	—
7	0.5	VT	3195	Auxiliary Heater Control	I	—
8	0.5	BK	2050	Ground	I	—
9	0.35	VT/GY	539	Run/Crank Ignition 1 Voltage	I	—
10	0.5	L-BU/YE	7574	Electric Variable Displacement Control	I	—

11	0.5	L-BU/BN	7573	Electric Variable Displacement Supply	I	—
12 - 14	—	—	—	Not Occupied	—	—
15	0.35	L-BU/GY	754	Blower Motor Speed Control	I	—
16 - 17	—	—	—	Not Occupied	—	—
18	0.35	BK/YE	1791	Air Temperature Door Control Low Reference	I	—
19	0.35	BN/VT	193	Rear Defog Relay Control	I	—
20	—	—	—	Not Occupied	—	—

K33 HVAC Control Module X3



Connector Part Information

Harness Type: HVAC

OEM Connector: 31410-1200

Service Connector: Service by Harness - See Part Catalog

Description: 20-Way F 64 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

K33 HVAC Control Module X3

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	22	BN	516	Upper Left Air Temperature Sensor Signal	I	—
2	22	YE	3165	Mode Door Stepper Motor Control 1	I	—
3	22	WH/RD	3166	Mode Door Stepper Motor Control 2	I	—
4	22	GY/BN	3167	Mode Door Stepper Motor Control 3	I	—
5	22	D-GN/WH	3168	Mode Door Stepper Motor Control 4	I	—
6 - 8	—	—	—	Not Occupied	—	—
9	22	BK/YE	407	Sensor Low Reference	I	—
10	—	—	—	Not Occupied	—	—
11	22	D-GN	3169	Temp Door Stepper Motor Control 1	I	—

12	22	WH/PK	3170	Temp Door Stepper Motor Control 2	I	—
13	22	GY/RD	3171	Temp Door Stepper Motor Control 3	I	—
14	22	RD/BK	3172	Temp Door Stepper Motor Control 4	I	—
15	22	BK	7572	HVAC Motor Control	I	—
16	22	GY	3173	Air Inlet Door Stepper Motor Control 1	I	—
17	22	D-BU/WH	3174	Air Inlet Door Stepper Motor Control 2	I	—
18	22	BN/D-GN	3175	Air Inlet Door Stepper Motor Control 3	I	—
19	22	RD/D-GN	3176	Air Inlet Door Stepper Motor Control 4	I	—
20	22	GY	6137	EVAP Core Temperature Sensor Signal	I	—

K36 Inflatable Restraint Sensing and Diagnostic Module X1



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 2098923-7

Service Connector: 19299778

Description: 24-Way F 0.64 Series, Sealed (YE)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	19328872	J-35616-64B (LT BU)	J-38125-12A	Not Available	Not Available	Not Available	Not Available

K36 Inflatable Restraint Sensing and Diagnostic Module X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	OG/GN	3021	Steering Wheel Module Stage 1 High Control	I	—
2	0.35	WH/OG	3020	Steering Wheel Module Stage 1 Low Control	I	—
3	0.35	BN/OG	3022	Steering Wheel Module Stage 2 Low Control	I	—
4	0.35	OG/VT	3023	Steering Wheel Module Stage 2 High Control	I	—
5	0.35	YE/OG	3025	Passenger IP Module Stage 1 High Control	I	—
6	0.35	OG/WH	3024	Passenger IP Module Stage 1 Low Control	I	—
7	0.35	OG/VT	3026	Passenger IP Module Stage 2 Low Control	I	—
8	0.35	GY/OG	3027	Passenger IP Module Stage 2 High Control	I	—

9	0.5	RD/GN	4440	Battery Positive Voltage	I	—
10	0.35	VT/WH	5234	Passenger Seat Belt Indicator Control	I	—
11	0.35	L-BU	2307	Passenger Air Bag On Indicator Control	I	—
12	0.35	GN	2308	Passenger Air Bag Off Indicator Control	I	—
13 - 14	—	—	—	Not Occupied	—	—
15	0.5	GN	5060	Low Speed GMLAN Serial Data	I	—
16	—	—	—	Not Occupied	—	—
17	0.5	WH/L-BU	5986	Serial Data Communication Enable	I	—
18	0.5	L-BU/YE	6105	High Speed GMLAN Serial Data (+) 2	I	—
19	0.5	BK/WH	2251	Signal Ground	I	—
20	0.5	WH	6106	High Speed GMLAN Serial Data (-) 2	I	—
21 - 24	—	—	—	Not Occupied	—	—

K36 Inflatable Restraint Sensing and Diagnostic Module X2



Connector Part Information

Harness Type: Body

OEM Connector: 2098922-9

Service Connector: 19301526

Description: 54-Way F 0.64 Series, Sealed (YE)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	19328872	J-35616-64B (LT BU)	J-38125-12A	Not Available	Not Available	Not Available	Not Available

K36 Inflatable Restraint Sensing and Diagnostic Module X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 8	—	—	—	Not Occupied	—	—
9	0.35	OG/YE	3481	Driver Seat Belt Anchor Pretensioner High Control	I	—
10	0.35	YE/OG	3482	Driver Seat Belt Anchor Pretensioner Low Control	I	—
11	0.35	GY/OG	3480	Passenger Seat Belt Anchor Pretensioner Low Control	I	—
12	0.35	OG/BN	3479	Passenger Seat Belt Anchor Pretensioner High Control	I	—
13	0.35	OG/L-BU	3068	Driver Side Impact Module High Control	I	—
14	0.35	GN/OG	3069	Driver Side Impact Module Low Control	I	—
15	0.35	BN/OG	3067	Passenger Side Impact Module Low Control	I	—

16	0.35	OG/GY	3066	Passenger Side Impact Module High Control	I	—
17	0.5	OG/GN	5019	Left Front Head Curtain Module High Control	I	—
18	0.5	VT/OG	5020	Left Front Head Curtain Module Low Control	I	—
19	0.35	OG/GN	2132	Left Front Side Impact Sensing Module Signal	I	—
20	0.35	BK/OG	6628	Left Front Side Impact Sensing Module Low Reference	I	—
21	0.35	BK/OG	6629	Right Front Side Impact Sensing Module Low Reference	I	—
22	0.35	BN/OG	2134	Right Front Side Impact Sensing Module Signal	I	—
23	0.5	OG/YE	354	Left Front Discriminating Sensor Signal	I	—
24	0.5	BK/OG	5045	Left Front Discriminating Sensor Low Reference	I	—
25	0.5	BK/OG	5600	Right Front Discriminating Sensor Low Reference	I	—
26	0.5	OG/GN	1409	Right Front Discriminating Sensor Signal	I	—
27	0.35	OG/L-BU	6620	Left Middle Side Impact Sensing Module Signal	I	—
28	0.35	BK/OG	6621	Left Middle Side Impact Sensing Module Low Reference	I	—
29	0.35	BK/OG	6625	Right Middle Side Impact Sensing Module Low Reference	I	—
30	0.35	OG/VT	6624	Right Middle Side Impact Sensing Module Signal	I	—
31 - 36	—	—	—	Not Occupied	—	—
37	0.5	OG/WH	3477	Driver Seat Belt Retractor Pretensioner High Control	I	CREW CAB

	0.35	OG/WH	3477	Driver Seat Belt Retractor Pretensioner High Control	I	EXTENEDED CAB
38	0.5	GY/OG	3478	Driver Seat Belt Retractor Pretensioner Low Control	I	CREW CAB
	0.35	GY/OG	3478	Driver Seat Belt Retractor Pretensioner Low Control	I	EXTENEDED CAB
39	0.5	WH/OG	3476	Passenger Seat Belt Retractor Pretensioner Low Control	I	CREW CAB
	0.35	WH/OG	3476	Passenger Seat Belt Retractor Pretensioner Low Control	I	EXTENEDED CAB
40	0.5	OG/GN	3475	Passenger Seat Belt Retractor Pretensioner High Control	I	CREW CAB
	0.35	OG/GN	3475	Passenger Seat Belt Retractor Pretensioner High Control	I	EXTENEDED CAB
41	0.35	OG/BN	238	Driver Seat Belt Switch Signal	I	—
42	—	—	—	Not Occupied	—	—
43	0.35	BK/OG	1363	Driver Seat Belt Switch Low Reference	I	—
44	0.35	BK/OG	1361	Passenger Seat Belt Switch Low Reference	I	—
45	0.35	OG/VT	1362	Passenger Seat Belt Switch Signal	I	—
46 - 52	—	—	—	Not Occupied	—	—
53	0.5	OG/GY	5021	Right Front Head Curtain Module High Control	I	—
54	0.5	WH/OG	5022	Right Front Head Curtain Module Low Control	I	—

K38 Chassis Control Module (LCV)



Connector Part Information

Harness Type: Chassis

OEM Connector: 89047375

Service Connector: 19178089

Description: 38-Way F 0.64, 2.8 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13576407	J-35616-4A (PU)	J-38125-553	15304720	Delphi 19	4	5
II	13578924	J-35616-64B (LT BU)	J-38125-215A	SAITS-A03T-M064	Yazaki 14	9	9
III	13579766	J-35616-64B (LT BU)	J-38125-215A	SAITS-A03T-M064	Yazaki 14	9	9

K38 Chassis Control Module (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	2.5	RD/VT	1940	Battery Positive Voltage	I	—
2	—	—	—	Not Occupied	—	—
3	0.5	BN	3891	Aero Shutter Control	II	—
4	—	—	—	Not Occupied	—	—
5	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	II	—
6	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	II	—
7	—	—	—	Not Occupied	—	—
8	0.5	VT/YE	5985	Accessory Wakeup Serial Data	II	—
9	—	—	—	Not Occupied	—	—

9	—	—	—	Not Occupied	—	—
10	0.5	L-BU/WH	7446	Fuel Line Pressure Sensor Signal	II	—
11	—	—	—	Not Occupied	—	—
12	0.5	BN	3891	Aero Shutter Control	II	—
13	2.5	GY	120	Fuel Pump Control	I	—
14 - 16	—	—	—	Not Occupied	—	—
17	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	II	—
18	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	II	—
19	—	—	—	Not Occupied	—	—
20	0.5	GY	5660	Fuel Pump Controller Data Out Signal	II	—
21	0.75	VT/GY	139	Run/Crank Ignition 1 Voltage	III	—
22	0.5	BN/RD	7445	Fuel Line Pressure Sensor 5V Reference	II	—
23	0.5	BK/YE	7447	Fuel Line Pressure Sensor Low Reference	II	—
24	0.5	BK	7444	Fuel System Control Module Shield Ground	II	—
25	2.5	BK	650	Ground	I	—
26 - 37	—	—	—	Not Occupied	—	—
38	2.5	BK/GN	1580	Fuel Pump Low Reference	I	—

K38 Chassis Control Module (-LCV)



Connector Part Information

Harness Type: Chassis

OEM Connector: 15498534

Service Connector: 19329924

Description: 38-Way F 1.5 CTS, 2.8 MCP, 4.8 MCP Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	19119381	J-35616-14 (GN)	J-38125-215A	Not Available	Not Available	Not Available	Not Available
II	19119772	J-35616-35 (VT)	J-38125-557	1241388-1	Lear 17	E	C
III	19301757	J-35616-40 (BU)	J-38125-556	1241408-1	Lear 28	A	B

K38 Chassis Control Module (-LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	2.5	RD/VT	1940	Battery Positive Voltage	III	—
2	—	—	—	Not Occupied	—	—
3	0.5	YE/GN	7122	Axle Differential Lock Switch Signal	I	—
4	0.5	GN/RD	7119	Axle Differential Lock Mode Switch 5V Reference	I	—
5 - 6	—	—	—	Not Occupied	—	—
7	0.5	GN/BK	7118	Front Axle Differential Lock Low Reference	I	—
8 - 9	—	—	—	Not Occupied	—	—
10	0.5	VT/BK	7121	Rear Axle Differential Lock Low Reference	I	—

11	0.5	YE	7115	Rear Axle Differential Lock Indicator Control	I	—
12	0.5	VT/GY	7117	Front Axle Differential Lock Indicator Control	I	—
13	2.5	BK	650	Ground	III	—
14	0.5	VT/YE	5985	Accessory Wakeup Serial Data	I	—
15	0.5	L-BU/BK	7116	Front Axle Differential Lock Control	I	—
16	0.5	L-BU/RD	7632	Integrated Trailer Brake Controller Switch 5V Reference	I	—
17	0.5	L-BU/WH	7120	Rear Axle Differential Lock Control	I	—
18	0.5	BN	7634	Integrated Trailer Brake Controller Redundant Manual Apply Signal	I	—
19	0.5	BK/BN	7631	Integrated Trailer Brake Controller Switch Low Reference	I	—
20	0.5	YE	7635	Integrated Trailer Brake Controller Manual Apply Signal	I	—
21	0.5	GN/BK	7633	Integrated Trailer Brake Controller User Gain Signal	I	—
22	0.5	YE/BK	2224	Trailer Brake Enable Signal	I	—
23	0.5	WH/BK	2223	Trailer Brake Control Signal	I	—
24	—	—	—	Not Occupied	—	—
25	0.75	VT/GY	139	Run/Crank Ignition 1 Voltage	II	—
26	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	I	—
27	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	I	—

28	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	I	—
29	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	I	—
30	0.5	GN/VT	4114	Local Interconnect Network Serial Data Bus 14	I	—
31 - 33	—	—	—	Not Occupied	—	—
34	0.5	GN/BK	7118	Front Axle Differential Lock Low Reference	I	—
35	0.5	VT/BK	7121	Rear Axle Differential Lock Low Reference	I	—
36	0.5	L-BU/BK	7116	Front Axle Differential Lock Control	I	—
37	0.5	L-BU/WH	7120	Rear Axle Differential Lock Control	I	—
38	—	—	—	Not Occupied	—	—

K43 Power Steering Control Module X1



Connector Part Information

Harness Type: Power Steering

OEM Connector: 13678638

Service Connector: Service by Harness - See Part Catalog

Description: 12-Way F 1.2 OCS Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

K43 Power Steering Control Module X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	RD/BN	5940	Battery Positive Voltage	I	—
2	0.5	WH/L-BU	5986	Serial Data Communication Enable	I	—
3	0.5	L-BU/YE	6105	High Speed GMLAN Serial Data (+) 2	I	—
4	0.5	WH	6106	High Speed GMLAN Serial Data (-) 2	I	—
5	0.5	L-BU/YE	6105	High Speed GMLAN Serial Data (+) 2	I	—
6	0.5	WH	6106	High Speed GMLAN Serial Data (-) 2	I	—
7	0.5	BK	—	—	I	—
8	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	I	—

9	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	I	—
10	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	I	—
11	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	I	—
12	0.5	BK	—	—	I	—

K43 Power Steering Control Module X2



Connector Part Information

Harness Type: Power Steering

OEM Connector: 7287-1990-30

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F 9.5 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-42 (RD)	No Tool Required	Not Required	Not Required	Not Required	Not Required

K43 Power Steering Control Module X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	10	BK	1050	Ground	I	—
2	10	RD/VT	842	Battery Positive Voltage	I	—

K56 Serial Data Gateway Module X1



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 33104224

Service Connector: 13594065

Description: 16-Way F 0.64 OCS Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13587581	J-35616-64B (LT BU)	J-38616-12A	Not Available	Not Available	Not Available	Not Available

K56 Serial Data Gateway Module X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	RD/WH	6440	Battery Positive Voltage	I	—
2	—	—	—	Not Occupied	—	—
3	0.35	L-BU/GN	1304	High Speed GMLAN Serial Data (+)9	I	—
4	0.35	WH/GN	1305	High Speed GMLAN Serial Data (-)9	I	—
5	—	—	—	Not Occupied	—	—
6	0.35	BK/WH	2151	Signal Ground	I	—
7	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	I	—
8	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	I	—
9	—	—	—	Not Occupied	—	—

10	0.35	WH/L-BU	5986	Serial Data Communication Enable	I	—
11	0.35	L-BU/GN	1304	High Speed GMLAN Serial Data (+)9	I	—
12	0.35	WH/GN	1305	High Speed GMLAN Serial Data (-)9	I	—
13	0.35	L-BU/GN	1304	High Speed GMLAN Serial Data (+)9	I	—
14	0.35	WH/GN	1305	High Speed GMLAN Serial Data (-)9	I	—
15	0.5	GN	5060	Low Speed GMLAN Serial Data	I	—
16	—	—	—	Not Occupied	—	—

K56 Serial Data Gateway Module X2



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 33104225

Service Connector: 13594066

Description: 16-Way F 0.64 OCS Series (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13587581	J-35616-64B (LT BU)	J-38616-12A	Not Available	Not Available	Not Available	Not Available

K56 Serial Data Gateway Module X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	I	—
2	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	I	—
3 - 9	—	—	—	Not Occupied	—	—
10	0.5	GY/GN	1102	Low Speed GMLAN Serial Data #2	I	—
11	0.35	L-BU/GN	1304	High Speed GMLAN Serial Data (+)9	I	—
12	0.35	WH/GN	1305	High Speed GMLAN Serial Data (-)9	I	—
13 - 16	—	—	—	Not Occupied	—	—

K69 Transfer Case Control Module X1



Connector Part Information

Harness Type: Body

OEM Connector: 6098-5237

Service Connector: 88988778

Description: 16-Way F 1.5 Series (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575579	J-35616-2A (GY)	J-38125-553	8240-0127	Sumitomo 22	E	C
II	13575580	J-35616-2A (GY)	J-38125-553	8240-0128	Sumitomo 22	C	A

K69 Transfer Case Control Module X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	YE/BK	7478	Rotary Position Sensor Low Reference	I	—
2	0.5	WH/GN	7479	Rotary Position Sensor Signal	I	—
3	0.5	YE	7474	Incremental Encoder Direction Signal	I	—
4	0.5	GY/BK	1570	Front Axle Actuator Control	I	—
5	0.5	L-BU/GY	7473	Incremental Encoder Impulse Signal	I	—
6	0.35	GY/RD	6029	Four Wheel Drive Mode Switch 5V Reference	I	—
7	0.35	L-BU/YE	1693	Four Wheel Drive Switch Signal	I	—
8	—	—	—	Not Occupied	—	—

8	—	—	—	Not Occupied	—	—
9	0.5	WH/RD	7477	Rotary Position Sensor 5V Reference	I	—
10	0.5	WH/GN	7475	Incremental Encoder Sensor 8V Reference	I	—
11	0.5	VT	7476	Incremental Encoder Sensor Low Reference	I	—
12	0.5	YE/WH	1695	Four Wheel Drive Wheel Lock Indicator Control	I	—
13	1	YE/BN	1569	Transfer Case Lock Solenoid Control	II	—
14 - 16	—	—	—	Not Occupied	—	—

K69 Transfer Case Control Module X2



Connector Part Information

Harness Type: Body

OEM Connector: 6098-4611

Service Connector: 15134091

Description: 16-Way F 1.5 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575579	J-35616-2A (GY)	J-38125-553	8240-0127	Sumitomo 22	E	C

K69 Transfer Case Control Module X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 2	—	—	—	Not Occupied	—	—
3	0.35	VT/WH	1565	4 LO Indicator Control	I	—
4	0.35	VT/GN	1739	Run/Crank Ignition 1 Voltage	I	—
5	—	—	—	Not Occupied	—	—
6	0.35	VT/YE	5985	Accessory Wakeup Serial Data	I	—
7	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	I	—
8	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	I	—
9 - 10	—	—	—	Not Occupied	—	—
11	0.35	GY/GN	1561	AWD Indicator Control	I	—

12	0.35	BN	1560	Neutral Indicator Control	I	—
13	0.35	GN/BK	1563	2 HI Indicator Control	I	—
14	0.35	BN/BK	1566	4 HI Indicator Control	I	—
15	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	I	—
16	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	I	—

K69 Transfer Case Control Module X3



Connector Part Information

Harness Type: Body

OEM Connector: 15466671

Service Connector: 19149301

Description: 4-Way F 280 GT Series (L-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-4A (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

K69 Transfer Case Control Module X3

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	2.5	YE/VT	1553	Transfer Case Motor Counter Clockwise Control	I	—
B	2.5	YE/GY	1552	Transfer Case Motor Clockwise Control	I	—
C	2.5	RD/GY	1342	Battery Positive Voltage	I	—
D	2.5	BK	3250	Ground	I	—

K73 Telematics Communication Interface Control Module X1



Connector Part Information

Harness Type: Body

OEM Connector: 1456601-1

Service Connector: 19153138

Description: 16-Way F 040 Multilock II Series (WH)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575546	J-35616-16 (LT GN)	J-38125-559	15445905	Delphi 23	J	J
II	13575740	J-35616-16 (LT GN)	J-38125-559	15445905	Delphi 23	J	J

K73 Telematics Communication Interface Control Module X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/GN	1102	Low Speed GMLAN Serial Data #2	II	—
2	0.35	BN/WH	2517	Keypad Red LED Control	I	—
3	0.35	YE/VT	2516	Keypad Green LED Control	I	—
4 - 5	—	—	—	Not Occupied	—	—
6	0.35	GN/BK	2515	Keypad Control	I	—
7	0.5	BK/WH	2051	Signal Ground	II	—
8 - 9	—	—	—	Not Occupied	—	—
10	0.35	L-BU/GN	1304	High Speed GMLAN Serial Data (+)9	I	—

11	0.35	GN/WH	2514	Keypad Signal	I	—
12	0.35	WH/GN	1305	High Speed GMLAN Serial Data (-)9	I	—
13	0.5	BK/VT	5167	Battery Backup Low Reference	II	—
14	0.5	YE/VT	5235	Battery Backup Control	II	—
15	0.35	RD/L-BU	3240	Battery Positive Voltage	I	—
16	—	—	—	Not Occupied	—	—

K73 Telematics Communication Interface Control Module X2



Connector Part Information

Harness Type: Body

OEM Connector: 1456599-1

Service Connector: 88952886

Description: 12-Way F 040 Multilock II Series (WH)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575546	J-35616-16 (LT GN)	J-38125-559	15445905	Delphi 23	J	J
II	13575740	J-35616-16 (LT GN)	J-38125-559	15445905	Delphi 23	J	J

K73 Telematics Communication Interface Control Module X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	YE	658	Cellular Telephone Voice Signal	I	—
2	0.35	BK/YE	659	Cellular Telephone Voice Low Reference	I	—
3	0.35	L-BU/GN	1304	High Speed GMLAN Serial Data (+)9	I	—
4	0.35	WH/GN	1305	High Speed GMLAN Serial Data (-)9	I	—
5	0.5	BARE	1792	Low Reference	II	—
6	0.35	GY/YE	5149	Voice Recognition Audio Signal	I	—
7	0.35	WH/L-BU	5986	Serial Data Communication Enable	I	—

8	0.35	BARE	514	Low Reference	I	—
9	0.35	L-BU	655	Cellular Telephone Microphone Signal	I	—
10	0.35	BK/BN	654	Cellular Telephone Microphone Low Reference	I	—
11	—	—	—	Not Occupied	—	—
12	0.35	BK/GY	5152	Voice Recognition Audio Low Reference	I	—

K73 Telematics Communication Interface Control Module X5





Connector Part Information

Harness Type: Body

OEM Connector: 13581693

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way F Coax Type (VT)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

K73 Telematics Communication Interface Control Module X5

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	Coax	—	(Cell only) Coaxial Antenna Cell Phone Signal	I	—

K73 Telematics Communication Interface Control Module X7 (IO5+CV3)



Connector Part Information

Harness Type: Body

OEM Connector: 13585573

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way F Coax Type (BU)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

K73 Telematics Communication Interface Control Module X7 (IO5+CV3)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	Coax	—	(GPS only) Coaxial Antenna GPS Signal	I	—

K73 Telematics Communication Interface Control Module X7 (IO5-CV3)



Connector Part Information

Harness Type: Body

OEM Connector: 13581969

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way F Coax Type (BN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

K73 Telematics Communication Interface Control Module X7 (IO5-CV3)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	Coax	—	(GPS only) Coaxial Antenna GPS Signal	I	—



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 15136073

Service Connector: 15136073

Description: 16-Way F 0.64 Kaizen Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575845	J-35616-64B (LT BU)	J-38125-215A	SAIT-A03T-M064	Yazaki 14	P	P

K74 Human Machine Interface Control Module X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	GY/YE	5149	Voice Recognition Audio Signal	I	—
2	0.35	BK/GY	5152	Voice Recognition Audio Low Reference	I	—
3 - 4	—	—	—	Not Occupied	—	—
5	0.35	WH/L-BU	5986	Serial Data Communication Enable	I	—
6	—	—	—	Not Occupied	—	—
7	0.75	RD/VT	340	Battery Positive Voltage	I	—
8	0.75	BK/WH	2051	Signal Ground	I	—
9	0.5	GN/WH	7527	Local Interconnect Network Serial Data Bus 5	I	—
10	—	—	—	Not Occupied	—	—

11	0.35	L-BU/GN	1304	High Speed GMLAN Serial Data (+)9	I	—
12	0.35	WH/GN	1305	High Speed GMLAN Serial Data (-)9	I	—
13	0.35	L-BU/GN	1304	High Speed GMLAN Serial Data (+)9	I	—
14	0.35	WH/GN	1305	High Speed GMLAN Serial Data (-)9	I	—
15 - 16	—	—	—	Not Occupied	—	—

K74 Human Machine Interface Control Module X2



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 31410-1121

Service Connector: 19151154

Description: 12-Way F 64 Series, Sealed (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575845	J-35616-64B (LT BU)	J-38125-215A	SAIT-A03T-M064	Yazaki 14	P	P

K74 Human Machine Interface Control Module X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	WH/VT	3999	MOST Control	I	—
2	0.5	WH/GN	3997	MOST Serial Data (-)	I	—
3	0.5	GY/VT	3998	MOST Serial Data (+)	I	—
4	—	—	—	Not Occupied	—	—
5	0.35	GY/YE	6972	Camera Signal 2 +	I	—
6	0.35	WH/L-BU	6973	Camera Signal 2	I	—
7	—	—	—	Not Occupied	—	—
8	0.5	GY/VT	3998	MOST Serial Data (+)	I	—
9	0.5	WH/GN	3997	MOST Serial Data (-)	I	—

10 - 12	—	—	—	Not Occupied	—	—

K74 Human Machine Interface Control Module X3



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13581312

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 5-Way M 2.0 Mini-B USB Type (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

K74 Human Machine Interface Control Module X3

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	USB	—	USB Serial Data	I	—

K74 Human Machine Interface Control Module X4





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13581315

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 5-Way M 2.0 Mini-B USB Type (GN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

K74 Human Machine Interface Control Module X4

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	USB	—	USB Serial Data	I	—

K74 Human Machine Interface Control Module X5



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13581316

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 5-Way M 2.0 Mini-B USB Type (BU)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

K74 Human Machine Interface Control Module X5

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	USB	—	USB Serial Data	I	—

K74 Human Machine Interface Control Module X7



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13585574

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way F Coax Type (BU)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

K74 Human Machine Interface Control Module X7

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	Coax	—	(GPS only) Coaxial Antenna GPS Signal	I	—

K77 Remote Control Door Lock Receiver



Connector Part Information

Harness Type: Headliner

OEM Connector: 968943-1

Service Connector: 13576534

Description: 4-Way F 0.64 Micro-Quadlock Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

K77 Remote Control Door Lock Receiver

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	GY	3273	Remote Function Actuator Low Reference	I	—
2	0.35	YE/GN	3274	Remote Function Actuator Transmit Signal	I	—
3	0.35	L-BU/WH	3275	Remote Function Actuator Receive Signal	I	—
4	0.35	GY/WH	3272	Remote Function Actuator Control	I	—

K89 Immobilizer Control Module



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 4-1718346-1

Service Connector: 13576530

Description: 3-Way F 0.64 Micro-Quadlock Series (PU)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

K89 Immobilizer Control Module

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	GN/GY	3277	Vehicle Anti-Theft System Immobilizer Low Reference	I	—
2	0.35	GN/VT	7533	Local Interconnect Network Serial Data Bus 11	I	—
3	0.35	GY/BK	3276	Vehicle Anti-Theft System Immobilizer Control	I	—

K109 Frontview Camera Module



Connector Part Information

Harness Type: Headliner

OEM Connector: AIT2PB-10-1AK

Service Connector: 13576634

Description: 10-Way F 0.64 Kaizen Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575867	J-35616-64B (LT BU)	J-38125-215A	SAIT-A03T-M064	Yazaki 14	P	P

K109 Frontview Camera Module

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	BK	3450	Ground	I	—
2	—	—	—	Not Occupied	—	—
3	0.35	RD/GN	3140	Battery Positive Voltage	I	—
4	0.35	WH	3152	Lane Departure Warning Indicator Control	I	—
5 - 6	—	—	—	Not Occupied	—	—
7	0.5	GN	5060	Low Speed GMLAN Serial Data	I	—
8 - 9	—	—	—	Not Occupied	—	—
10	0.35	GY/WH	3153	Lane Departure Warning Disable Switch Signal	I	—

K111 Fuel Pump Driver Control Module (LCV)



Connector Part Information

Harness Type: Chassis

OEM Connector: 33476-4003

Service Connector: 13587961

Description: 16-Way F 1.5, 2.8 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13505803	J-35616-35 (VT)	J-38125-12A	1326030-8	Lear 17	4	D
II	13575868	J-35616-2A (GY)	J-38125-217	Not Available	Not Available	Not Available	Not Available
III	19300635	J-35616-2A (GY)	J-38125-217	Not Available	Not Available	Not Available	Not Available

K111 Fuel Pump Driver Control Module (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	2.5	RD/VT	1940	Battery Positive Voltage	I	—
2	0.5	GN/GY	465	Fuel Pump Primary Relay Control	II	LCV/LGZ
	0.5	GY	5660	Fuel Pump Controller Data Out Signal	II	LWN
3	—	—	—	Not Occupied	—	—
4	0.5	L-BU/BK	7493	High Speed GMLAN Serial Data (+)3	II	—
5	0.5	WH	7494	High Speed GMLAN Serial Data (-)3	II	—
6	0.75	VT/GY	139	Run/Crank Ignition 1 Voltage	III	—
7	0.5	VT/YE	5985	Accessory Wakeup Serial Data	II	—

7	0.5	VT/YE	5985	Accessory Wakeup Serial Data	II	—
8	2.5	GY	120	Fuel Pump Control	I	—
9	2.5	BK	650	Ground	I	—
10 - 14	—	—	—	Not Occupied	—	—
15	0.5	BK	7444	Fuel System Control Module Shield Ground	II	—
16	2.5	BK/GN	1580	Fuel Pump Low Reference	I	—

K111 Fuel Pump Driver Control Module (LFX)



Connector Part Information

Harness Type: Chassis

OEM Connector: 33476-4003

Service Connector: 13587961

Description: 16-Way F 1.5, 2.8 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13505803	J-35616-35 (VT)	J-38125-12A	1326030-8	Lear 17	4	D
II	13575868	J-35616-2A (GY)	J-38125-217	Not Available	Not Available	Not Available	Not Available
III	19300635	J-35616-2A (GY)	J-38125-217	Not Available	Not Available	Not Available	Not Available

K111 Fuel Pump Driver Control Module (LFX)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	2.5	RD/VT	1940	Battery Positive Voltage	I	—
2	0.5	GN/GY	465	Fuel Pump Primary Relay Control	II	—
3	—	—	—	Not Occupied	—	—
4	0.5	L-BU/BK	7493	High Speed GMLAN Serial Data (+)3	II	—
5	0.5	WH	7494	High Speed GMLAN Serial Data (-)3	II	—
6	0.75	VT/GY	139	Run/Crank Ignition 1 Voltage	III	—
7	0.5	VT/YE	5985	Accessory Wakeup Serial Data	II	—

8	2.5	GY	120	Fuel Pump Control	I	—
9	2.5	BK	650	Ground	I	—
10 - 14	—	—	—	Not Occupied	—	—
15	0.5	BK	7444	Fuel System Control Module Shield Ground	II	—
16	2.5	BK/GN	1580	Fuel Pump Low Reference	I	—

K111 Fuel Pump Driver Control Module (LGZ)



Connector Part Information

Harness Type: Chassis

OEM Connector: 33476-4003

Service Connector: 13587961

Description: 16-Way F 1.5, 2.8 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13505803	J-35616-35 (VT)	J-38125-12A	1326030-8	Lear 17	4	D
II	13575868	J-35616-2A (GY)	J-38125-217	Not Available	Not Available	Not Available	Not Available
III	19300635	J-35616-2A (GY)	J-38125-217	Not Available	Not Available	Not Available	Not Available

K111 Fuel Pump Driver Control Module (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	2.5	RD/VT	1940	Battery Positive Voltage	I	—
2	0.5	GN/GY	465	Fuel Pump Primary Relay Control	II	—
3	—	—	—	Not Occupied	—	—
4	0.5	L-BU/BK	7493	High Speed GMLAN Serial Data (+)3	II	—
5	0.5	WH	7494	High Speed GMLAN Serial Data (-)3	II	—
6	0.75	VT/GY	139	Run/Crank Ignition 1 Voltage	III	—
7	0.5	VT/YE	5985	Accessory Wakeup Serial Data	II	—

8	2.5	GY	120	Fuel Pump Control	I	—
9	2.5	BK	650	Ground	I	—
10 - 14	—	—	—	Not Occupied	—	—
15	0.5	BK	7444	Fuel System Control Module Shield Ground	II	—
16	2.5	BK/GN	1580	Fuel Pump Low Reference	I	—

K115 Reductant Control Module



Connector Part Information

Harness Type: Chassis

OEM Connector: 2109441-2

Service Connector: 19330153

Description: 8-Way F 2.8 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

K115 Reductant Control Module

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	RD/GN	2440	Battery Positive Voltage	I	—
2	0.5	WH	4499	High Speed GMLAN Serial Data (-) 7	I	—
3	0.5	L-BU/BN	4498	High Speed GMLAN Serial Data (+) 7	I	—
4	2.5	BK	650	Ground	I	—
5	0.5	VT/GN	4320	Selective Catalytic Reduction Power Module Wake-Up Signal	I	—
6	0.5	WH	4499	High Speed GMLAN Serial Data (-) 7	I	—
7	0.5	L-BU/BN	4498	High Speed GMLAN Serial Data (+) 7	I	—
8	2.5	L-BU	3921	DEF Heater Supply 1	I	—

K133 Trailer Brake Power Control Module



Connector Part Information

Harness Type: Chassis

OEM Connector: 33476-2170

Service Connector: 19329472

Description: 16-Way F 1.5, 2.8 Series, Sealed (D-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13505803	J-35616-35 (VT)	J-38125-12A	1326030-8	Lear 17	4	D
II	13575868	J-35616-2A (GY)	J-38125-217	Not Available	Not Available	Not Available	Not Available
III	19300635	J-35616-2A (GY)	J-38125-217	Not Available	Not Available	Not Available	Not Available

K133 Trailer Brake Power Control Module

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	2.5	RD/GN	242	Battery Positive Voltage	I	—
2	0.5	WH/BK	2223	Trailer Brake Control Signal	III	—
3 - 4	—	—	—	Not Occupied	—	—
5	0.5	YE/BK	2224	Trailer Brake Enable Signal	II	—
6 - 7	—	—	—	Not Occupied	—	—
8	2.5	L-BU	47	Trailer Auxiliary Control	I	—
9	2.5	BK	650	Ground	I	—
10 - 11	—	—	—	Not Occupied	—	—

12	0.5	GN/VT	4114	Local Interconnect Network Serial Data Bus 14	II	—
13 - 16	—	—	—	Not Occupied	—	—

M4 Air Inlet Door Actuator



Connector Part Information

Harness Type: HVAC

OEM Connector: 1519302

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way F Micro-Quadlock Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

M4 Air Inlet Door Actuator

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	22	GY	3173	Air Inlet Door Stepper Motor Control 1	I	—
2	22	BK	7572	HVAC Motor Control	I	—
3	22	D-BU/WH	3174	Air Inlet Door Stepper Motor Control 2	I	—
4	22	BN/D-GN	3175	Air Inlet Door Stepper Motor Control 3	I	—
5	—	—	—	Not Occupied	—	—
6	22	RD/D-GN	3176	Air Inlet Door Stepper Motor Control 4	I	—

M6 Air Temperature Door Actuator





Connector Part Information

Harness Type: HVAC

OEM Connector: 1519302

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way F Micro-Quadlock Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

M6 Air Temperature Door Actuator

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	22	D-GN	3169	Temp Door Stepper Motor Control 1	I	—
2	22	BK	7572	HVAC Motor Control	I	—
3	22	WH/PK	3170	Temp Door Stepper Motor Control 2	I	—
4	22	GY/RD	3171	Temp Door Stepper Motor Control 3	I	—
5	—	—	—	Not Occupied	—	—
6	22	RD/BK	3172	Temp Door Stepper Motor Control 4	I	—

M9 Brake Booster Pump Motor



Connector Part Information

Harness Type: Engine

OEM Connector: 7282-5575-10

Service Connector: 19115602

Description: 2-Way M 2.8 Series, Sealed (D-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-5 (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

M9 Brake Booster Pump Motor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	2.5	BN/VT	1470	Brake Booster Pump Motor Control	I	—
2	2.5	BK	1450	Ground	I	—

M26 Front Axle Engagement Actuator



Connector Part Information

Harness Type: Power Steering

OEM Connector: 1-1456426-5

Service Connector: Service by Harness - See Part Catalog

Description: 4-Way F 1.2 MCP Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

M26 Front Axle Engagement Actuator

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	VT/BK	2139	Run/Crank Ignition 1 Voltage	I	—
2	0.5	GY/BK	1570	Front Axle Actuator Control	I	—
3	0.5	YE/WH	1695	Four Wheel Drive Wheel Lock Indicator Control	I	—
4	0.75	BK	1450	Ground	I	—

M37 Mode Door Actuator



Connector Part Information

Harness Type: HVAC

OEM Connector: 1519302

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way F Micro-Quadlock Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

M37 Mode Door Actuator

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	22	YE	3165	Mode Door Stepper Motor Control 1	I	—
2	22	BK	7572	HVAC Motor Control	I	—
3	22	WH/RD	3166	Mode Door Stepper Motor Control 2	I	—
4	22	GY/BN	3167	Mode Door Stepper Motor Control 3	I	—
5	—	—	—	Not Occupied	—	—
6	22	D-GN/WH	3168	Mode Door Stepper Motor Control 4	I	—

M64 Starter Motor (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 2098198-9

Service Connector: 19300471

Description: 1-Way F 2.8 MCP Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

M64 Starter Motor (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	2.5	YE	6	Starter Solenoid Crank Ignition Voltage	I	—

M64 Starter Motor (LGZ)



Connector Part Information

Harness Type: Engine

OEM Connector: 2098198-5

Service Connector: 19300471

Description: 1-Way F 2.8 MCP Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

M64 Starter Motor (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	2.5	YE	6	Starter Solenoid Crank Ignition Voltage	I	—



Connector Part Information

Harness Type: Engine

OEM Connector: 2098198-5

Service Connector: 19300471

Description: 1-Way F 2.8 MCP Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

M64 Starter Motor (LWN)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	2	YE	6	Starter Solenoid Crank Ignition Voltage	I	—

M74D Window Motor - Driver



Connector Part Information

Harness Type: Driver Door

OEM Connector: 1732115-1

Service Connector: Service by Harness - See Part Catalog

Description: 7-Way F 0.64, 2.8 Kaizen Timer Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-4A (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

M74D Window Motor - Driver

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	2.5	BK	3550	Ground	I	—
2	2.5	RD/L-BU	1240	Battery Positive Voltage	I	—
3	0.35	GN/WH	1300	Power Window Master Switch Left Front Up Signal	II	—
4	0.5	GN/YE	6134	Local Interconnect Network Serial Data Bus 3	II	—
5	0.35	GN/VT	7628	Power Window Motor Left Front Express Control	II	—
6	0.35	GY	745	Left Front Door Ajar Switch Signal	II	—
7	0.35	GY	1136	Power Window Master Switch Left Front Down Signal	II	—

M74P Window Motor - Passenger



Connector Part Information

Harness Type: Passenger Door

OEM Connector: 54200220N

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F 2.8 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-4A (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

M74P Window Motor - Passenger

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	2.5	YE/L-BU	3388	Power Window Motor Passenger Down Control	I	—
2	2.5	GN/GY	3387	Power Window Motor Passenger Up Control	I	—

M75 Windshield Wiper Motor



Connector Part Information

Harness Type: Body

OEM Connector: 13147125

Service Connector: 13578531

Description: 4-Way F 2.8 Junior Power Timer Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-4A (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

M75 Windshield Wiper Motor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BN/GN	196	Windshield Wiper Motor Park Switch Signal	I	—
2	1.5	YE/BN	95	Windshield Wiper Motor Low Speed Control	I	—
3	1.5	BK	3150	Ground	I	—
4	1.5	WH	92	Windshield Wiper Motor High Speed Control	I	—

M93 Key Capture Solenoid Actuator



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: AIT2PB-02A-1AK

Service Connector: 13314093

Description: 2-Way F 0.64 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

M93 Key Capture Solenoid Actuator

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	VT/YE	143	Accessory Ignition Voltage	I	—
2	0.35	BK	2050	Ground	I	—

M103 Turbocharger Vane Position Actuator



Connector Part Information

Harness Type: Engine

OEM Connector: 09-4415-81

Service Connector: 19329390

Description: 5-Way F 2.8 SLK Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-4A (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

M103 Turbocharger Vane Position Actuator

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/L-BU	5930	Variable Nozzle Turbo Solenoid High Signal	I	—
2	0.5	WH/BK	5931	Variable Nozzle Turbo Solenoid Low Signal	I	—
3	0.5	BK/BN	5929	Variable Nozzle Turbo Position Sensor Low Reference	I	—
4	0.5	VT/YE	5947	Variable Nozzle Turbo Position Sensor Signal	I	—
5	0.5	GY/RD	5928	Variable Nozzle Turbo Position Sensor 5V Reference	I	—

P2 Transmission Shift Lever Position Indicator





Connector Part Information

Harness Type: Floor Console

OEM Connector: AIT2PB-03B-1AK

Service Connector: Service by Harness - See Part Catalog

Description: 3-Way F 0.64 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

P2 Transmission Shift Lever Position Indicator

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	VT	801	Retained Accessory Power Fuse Control	I	—
2	0.5	GN/L-BU	6133	Local Interconnect Network Serial Data Bus 2	I	—
3	0.35	BK	2050	Ground	I	—

P3 Backup Alarm (8S3)



Connector Part Information

Harness Type: Chassis

OEM Connector: 15300027

Service Connector: 12101855

Description: 2-Way F 280 Metri-Pack Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-4A (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

P3 Backup Alarm (8S3)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.75	GY	1624	Trailer Backup Lamp Control	I	8S3+Z82
	0.75	BK	22	Trailer Ground	I	8S3-Z82
B	0.75	BK	22	Trailer Ground	I	8S3+Z82
	0.75	GY	1624	Trailer Backup Lamp Control	I	8S3-Z82

P9 Driver Information Center Display X1



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 34824-2124

Service Connector: 19330348

Description: 12-Way F Mini 50 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575568	No Tool Required	J-38125-12A	Not Available	Not Available	Not Available	Not Available

P9 Driver Information Center Display X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	GY/BN	3761	Infotainment Regulated Control	I	—
2	0.35	BN/GN	3364	Navigation Display Reset Signal	I	—
3	0.35	GY/BN	3761	Infotainment Regulated Control	I	—
4	0.35	GN/BK	2515	Keypad Control	I	—
5	0.35	VT/GY	1381	LCD Dimming Signal	I	—
6	0.35	GY/L-BU	3989	Display Radio Bank Switch Dim Signal	I	—
7	0.35	BN/GN	4502	Video Display Request Signal	I	—
8	0.35	BK/GN	2804	Radio Display Backlight Low Reference	I	—

9	0.35	GN/BK	2515	Keypad Control	I	—
10	0.35	GN/BK	2515	Keypad Control	I	—
11	0.35	BK/BN	2518	Keypad Low Reference	I	—
12	0.35	GY/L-BU	3989	Display Radio Bank Switch Dim Signal	I	—

P9 Driver Information Center Display X2



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13580202

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 5-Way M 2.0 Mini-B USB Type (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

P9 Driver Information Center Display X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	USB	—	USB Serial Data	I	—

P13 Horn Assembly



Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 88988857

Service Connector: 13585854

Description: 2-Way F 150 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

P13 Horn Assembly

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	BK	1150	Ground	I	—
2	0.75	BN/GY	29	Horn Control	I	—

P14 Passenger Air Bag Disabled Indicator



Connector Part Information

Harness Type: Headliner

OEM Connector: HCMPB-C06-S

Service Connector: 19153174

Description: 6-Way F 0.64 HCM Series (NA)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

P14 Passenger Air Bag Disabled Indicator

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	L-BU	2307	Passenger Air Bag On Indicator Control	I	—
2	0.5	BK	3150	Ground	I	—
3	0.35	GN	2308	Passenger Air Bag Off Indicator Control	I	—
4	0.35	VT/WH	1139	Run/Crank Ignition 1 Voltage	I	—
5	0.35	VT/WH	5234	Passenger Seat Belt Indicator Control	I	—
6	—	—	—	Not Occupied	—	—

P16 Instrument Cluster (UDC)



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 90587345

Service Connector: 88988405

Description: 32-Way F 0.64 Micro-Quadlock Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575584	J-35616-64B (LT BU)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
II	13575859	J-35616-64B (LT BU)	J-38125-12A	Not Available	Not Available	Not Available	Not Available

P16 Instrument Cluster (UDC)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 2	—	—	—	Not Occupied	—	—
3	0.5	GY/GN	1102	Low Speed GMLAN Serial Data #2	II	—
4 - 6	—	—	—	Not Occupied	—	—
7	0.5	RD/GY	2840	Battery Positive Voltage	II	—
8	0.5	VT/BK	1639	Run/Crank Ignition 1 Voltage	II	—
9	0.35	GY/L-BU	893	Driver Information Center Select Menu Switch Signal	I	—
10 - 12	—	—	—	Not Occupied	—	—
13	0.35	BK/BN	897	Driver Information Center Switch Low Reference	I	—
14	0.35	GN/WH	1358	Driver Information Center Switch Signal	I	—

15	—	—	—	Not Occupied	—	—
16	0.35	BN/WH	419	Check Engine Indicator Control	I	—
17 - 18	—	—	—	Not Occupied	—	—
19	0.5	BK/WH	2151	Signal Ground	II	—
20	0.5	GN/BK	3894	Local Interconnect Network Serial Data Bus 12	II	—
21 - 31	—	—	—	Not Occupied	—	—
32	0.35	GN/BN	507	Wait To Start Indicator Control	I	—

P16 Instrument Cluster (UDD)



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 90587345

Service Connector: 88988405

Description: 32-Way F 0.64 Micro-Quadlock Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575584	J-35616-64B (LT BU)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
II	13575859	J-35616-64B (LT BU)	J-38125-12A	Not Available	Not Available	Not Available	Not Available

P16 Instrument Cluster (UDD)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	WH/GN	3997	MOST Serial Data (-)	II	—
2	0.5	GY/VT	3998	MOST Serial Data (+)	II	—
3	0.5	GY/GN	1102	Low Speed GMLAN Serial Data #2	II	—
4	—	—	—	Not Occupied	—	—
5	0.35	WH/VT	3999	MOST Control	I	—
6	—	—	—	Not Occupied	—	—
7	0.5	RD/GY	2840	Battery Positive Voltage	II	—
8	0.5	VT/BK	1639	Run/Crank Ignition 1 Voltage	II	—
9 - 11	—	—	—	Not Occupied	—	—

9 - 11	—	—	—	Not Occupied	—	—
12	0.35	GY/YE	3885	Forward Collision Alert LED Control	I	—
13 - 15	—	—	—	Not Occupied	—	—
16	0.35	BN/WH	419	Check Engine Indicator Control	I	—
17	0.5	GY/VT	3998	MOST Serial Data (+)	II	—
18	0.5	WH/GN	3997	MOST Serial Data (-)	II	—
19	0.5	BK/WH	2151	Signal Ground	II	—
20	0.5	GN/BK	3894	Local Interconnect Network Serial Data Bus 12	II	—
21 - 29	—	—	—	Not Occupied	—	—
30	0.35	WH/GN	3535	Reflected LED Display Dimming Control	I	—
31	—	—	—	Not Occupied	—	—
32	0.35	GN/BN	507	Wait To Start Indicator Control	I	—

P17 Info Display Module X1



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13577390

Service Connector: 13577390

Description: 10-Way F 0.64 Kaizen Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575867	J-35616-64B (LT BU)	J-38125-215A	SAIT-A03T-M064	Yazaki 14	P	P

P17 Info Display Module X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	RD/GY	2840	Battery Positive Voltage	I	—
2	—	—	—	Not Occupied	—	—
3	0.5	GY/GN	1102	Low Speed GMLAN Serial Data #2	I	—
4	—	—	—	Not Occupied	—	—
5	0.5	GN/L-BU	7532	Local Interconnect Network Serial Data Bus 10	I	—
6 - 7	—	—	—	Not Occupied	—	—
8	0.5	GN/WH	7527	Local Interconnect Network Serial Data Bus 5	I	—
9	—	—	—	Not Occupied	—	—
10	0.35	BK/WH	2051	Signal Ground	I	—

P17 Info Display Module X3



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13576692

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 5-Way M 2.0 Mini-B USB Type (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

P17 Info Display Module X3

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	USB	—	USB Serial Data	I	—

P19AG Speaker - Left Front Door



Connector Part Information

Harness Type: Driver Door

OEM Connector: R63461-005

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F 150 GT Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

P19AG Speaker - Left Front Door

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	BN/L-BU	118	Left Front Speaker Signal (-) 1	I	—
2	1	L-BU	201	Left Front Speaker Control (+) 1	I	—

P19AH Speaker - Right Front Door



Connector Part Information

Harness Type: Passenger Door

OEM Connector: R63461-005

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F 150 GT Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

P19AH Speaker - Right Front Door

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	YE/BK	117	Right Front Speaker Signal (-) 1	I	—
2	1	YE	200	Right Front Speaker Control (+) 1	I	—

P19AL Speaker - Left Rear Door



Connector Part Information

Harness Type: Left Rear Door

OEM Connector: R63461-005

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F 150 GT Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

P19AL Speaker - Left Rear Door

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	GN/BK	116	Left Rear Speaker Signal (-)	I	—
2	1	GN	199	Left Rear Speaker Control (+)	I	—

P19AM Speaker - Right Rear Door



Connector Part Information

Harness Type: Right Rear Door

OEM Connector: R63461-005

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way F 150 GT Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

P19AM Speaker - Right Rear Door

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	L-BU/BK	115	Right Rear Speaker Signal (-)	I	—
2	1	WH	46	Right Rear Speaker Control (+)	I	—

P19B Speaker - Center Instrument Panel





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 6098-5527

Service Connector: 13314097

Description: 2-Way F 1.5 Series (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

P19B Speaker - Center Instrument Panel

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	L-BU/YE	1960	Front Center Speaker (-) Low Reference	I	—
2	0.75	YE/WH	1860	Front Center Speaker Control (+)	I	—

P19H Speaker - Left Front Tweeter X1 (-UQA)





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 6098-5510

Service Connector: 13584097

Description: 2-Way F 1.5 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

P19H Speaker - Left Front Tweeter X1 (-UQA)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	BN/L-BU	118	Left Front Speaker Signal (-) 1	I	—
2	0.75	L-BU	201	Left Front Speaker Control (+) 1	I	—

P19H Speaker - Left Front Tweeter X2 (UQA)





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 6098-5527

Service Connector: 13314097

Description: 2-Way F 1.5 Series (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

P19H Speaker - Left Front Tweeter X2 (UQA)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	BN/L-BU	118	Left Front Speaker Signal (-) 1	I	—
2	0.75	L-BU	201	Left Front Speaker Control (+) 1	I	—

P19V Speaker - Right Front Tweeter X1 (UQA)



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 6098-5510

Service Connector: 13584097

Description: 2-Way F 1.5 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

P19V Speaker - Right Front Tweeter X1 (UQA)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	YE/BK	117	Right Front Speaker Signal (-) 1	I	—
2	0.75	YE	200	Right Front Speaker Control (+) 1	I	—

P19V Speaker - Right Front Tweeter X2 (-UQA)



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 6098-5527

Service Connector: 13314097

Description: 2-Way F 1.5 Series (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

P19V Speaker - Right Front Tweeter X2 (-UQA)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	YE/BK	117	Right Front Speaker Signal (-) 1	I	—
2	0.75	YE	200	Right Front Speaker Control (+) 1	I	—

P43 Collision Alert Indicators



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 0-936119-1

Service Connector: 13587297

Description: 4-Way F 0.64 Micro-Quadlock Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

P43 Collision Alert Indicators

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/BK	1639	Run/Crank Ignition 1 Voltage	I	—
2	0.35	GY/YE	3885	Forward Collision Alert LED Control	I	—
3	0.35	WH/GN	3535	Reflected LED Display Dimming Control	I	—
4	0.35	BK/WH	2151	Signal Ground	I	—

P46 Mobile Device Wireless Charger Indicators



Connector Part Information

Harness Type: Floor Console

OEM Connector: 1452142-1

Service Connector: Service by Harness - See Part Catalog

Description: 3-Way F 1.6 Micro-Timer Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

P46 Mobile Device Wireless Charger Indicators

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	WH	6816	Indicator Dimming Control	I	—
2	0.35	GN	4512	Wireless Charging System Charge Indicator Control	I	—
3	0.35	BN	4511	Wireless Charging System Fault Indicator Control	I	—

Q2 A/C Compressor Clutch



Connector Part Information

Harness Type: Engine

OEM Connector: 1-1823608-5

Service Connector: 19300402

Description: 2-Way F 1.2 MCP Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q2 A/C Compressor Clutch

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	BK	1450	Ground	I	—
2	0.75	BN/GN	59	A/C Compressor Clutch Control	I	—

Q6A Camshaft Position Actuator Solenoid Valve - Bank 1 Exhaust (LGZ)



Connector Part Information

Harness Type: Engine

OEM Connector: 7283-7526-30

Service Connector: 89047244

Description: 2-Way F 090 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-18 (BK)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q6A Camshaft Position Actuator Solenoid Valve - Bank 1 Exhaust (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/BU	5282	Camshaft Phaser Exhaust Solenoid 1	I	—
2	0.5	BK/VT	6754	Cam Phaser X Low Reference	I	—

Q6B Camshaft Position Actuator Solenoid Valve - Bank 1 Intake (LGZ)



Connector Part Information

Harness Type: Engine

OEM Connector: 7283-7526-30

Service Connector: 89047244

Description: 2-Way F 090 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-18 (BK)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q6B Camshaft Position Actuator Solenoid Valve - Bank 1 Intake (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/BN	5284	Camshaft Phaser Intake Solenoid 1	I	—
2	0.5	BK/BN	6753	Cam Phaser W Low Reference	I	—

Q6C Camshaft Position Actuator Solenoid Valve - Bank 2 Exhaust



Connector Part Information

Harness Type: Engine

OEM Connector: 10010338

Service Connector: 13587325

Description: 2-Way F 1.2 Multilock Series, Sealed (L-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q6C Camshaft Position Actuator Solenoid Valve - Bank 2 Exhaust

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GN/BN	5283	Camshaft Phaser Exhaust Solenoid 2	I	—
2	0.5	BK/GY	6756	Cam Phaser Z Low Reference	I	—

Q6D Camshaft Position Actuator Solenoid Valve - Bank 2 Intake



Connector Part Information

Harness Type: Engine

OEM Connector: 10010338

Service Connector: 13587325

Description: 2-Way F 1.2 Multilock Series, Sealed (L-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q6D Camshaft Position Actuator Solenoid Valve - Bank 2 Intake

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GN	5272	Camshaft Phaser Intake Solenoid 2	I	—
2	0.5	BK/L-BU	6755	Cam Phaser Y Low Reference	I	—

Q6E Camshaft Position Actuator Solenoid Valve - Exhaust (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 10010337

Service Connector: 13587326

Description: 2-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q6E Camshaft Position Actuator Solenoid Valve - Exhaust (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GY/L-BU	5282	Camshaft Phaser Exhaust Solenoid 1	I	—
2	0.5	BK/VT	6754	Cam Phaser X Low Reference	I	—

Q6F Camshaft Position Actuator Solenoid Valve - Intake



Connector Part Information

Harness Type: Engine

OEM Connector: 10010338

Service Connector: 13587325

Description: 2-Way F 1.2 Multilock Series, Sealed (L-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q6F Camshaft Position Actuator Solenoid Valve - Intake

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/BN	5284	Camshaft Phaser Intake Solenoid 1	I	—
2	0.5	BK/BN	6753	Cam Phaser W Low Reference	I	—

Q8 Control Solenoid Valve Assembly





Connector Part Information

Harness Type: Engine

OEM Connector: 9430734

Service Connector: 19303772

Description: 16-Way F 1.5 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13578934	J-35616-66 (YE)	J-38125-28	2 21 24 47220 0	Yazaki 12	E	1

Q8 Control Solenoid Valve Assembly

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 2	—	—	—	Not Occupied	—	—
3	0.5	WH/GY	1786	Transmission Park/Neutral Signal 1	I	—
4	0.75	RD/GN	1840	Battery Positive Voltage	I	—
5	0.75	BK/WH	1451	Signal Ground	I	—
6 - 8	—	—	—	Not Occupied	—	—
9	0.5	VT/YE	5985	Accessory Wakeup Serial Data	I	—
10	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	I	—
11	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	I	—
12	0.5	VT/BK	2139	Run/Crank Ignition 1 Voltage	I	—

13	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	I	—
14	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	I	—
15 - 16	—	—	—	Not Occupied	—	—

Q9F Differential Lock Actuator - Front



Connector Part Information

Harness Type: Chassis

OEM Connector: 1-2203312-1

Service Connector: 19330898

Description: 2-Way F 1.2 MCON Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q9F Differential Lock Actuator - Front

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	L-BU/BK	7116	Front Axle Differential Lock Control	I	—
2	1	GN/BK	7118	Front Axle Differential Lock Low Reference	I	—

Q9R Differential Lock Actuator - Rear





Connector Part Information

Harness Type: Chassis

OEM Connector: 1-2203312-1

Service Connector: 19330898

Description: 2-Way F 1.2 MCON Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q9R Differential Lock Actuator - Rear

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	L-BU/WH	7120	Rear Axle Differential Lock Control	I	—
2	1	VT/BK	7121	Rear Axle Differential Lock Low Reference	I	—

Q12 Evaporative Emission Purge Solenoid Valve



Connector Part Information

Harness Type: Engine

OEM Connector: 10010337

Service Connector: 13587326

Description: 2-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q12 Evaporative Emission Purge Solenoid Valve

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/L-BU	5293	Powertrain Main Relay Fused Supply 4	I	—
2	0.5	GN/L-BU	428	EVAP Canister Purge Solenoid Control	I	—

Q13 Evaporative Emission Vent Solenoid Valve



Connector Part Information

Harness Type: Chassis

OEM Connector: 34062-0028

Service Connector: 13579002

Description: 2-Way F 1.5 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q13 Evaporative Emission Vent Solenoid Valve

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	WH	1310	EVAP Canister Vent Solenoid Control	I	—
2	0.5	RD/GN	2440	Battery Positive Voltage	I	—

Q14 Exhaust Gas Recirculation Valve



Connector Part Information

Harness Type: Engine

OEM Connector: 284716-3

Service Connector: 13586128

Description: 6-Way F 1.6 Micro-Timer Series, Sealed (BN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q14 Exhaust Gas Recirculation Valve

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	WH/VT	5764	Exhaust Gas Recirculation Valve Motor High Signal	I	—
2	0.5	BN/WH	5763	Exhaust Gas Recirculation Valve Sensor Signal	I	—
3	—	—	—	Not Occupied	—	—
4	0.5	BK/BN	2753	Exhaust Gas Recirculation Sensor Low Reference	I	—
5	0.5	VT/BK	5746	Exhaust Gas Recirculation Valve Motor Low Signal	I	—
6	0.5	L-BU/RD	5047	Exhaust Gas Recirculation 5V Reference 1	I	—

Q17A Fuel Injector 1



Connector Part Information

Harness Type: Engine

OEM Connector: 6189-7138

Service Connector: 13407097

Description: 2-Way F (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-18 (BK)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q17A Fuel Injector 1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1.5	BN/WH	4901	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 1	I	—
2	1.5	BN	4801	Direct Fuel Injector (DFI) High Voltage Control Cylinder 1	I	—

Q17B Fuel Injector 2



Connector Part Information

Harness Type: Engine

OEM Connector: 6189-7138

Service Connector: 13407097

Description: 2-Way F (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-18 (BK)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q17B Fuel Injector 2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1.5	L-BU/GY	4902	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 2	I	—
2	1.5	L-BU	4802	Direct Fuel Injector (DFI) High Voltage Control Cylinder 2	I	—

Q17C Fuel Injector 3



Connector Part Information

Harness Type: Engine

OEM Connector: 6189-7138

Service Connector: 13407097

Description: 2-Way F (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-18 (BK)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q17C Fuel Injector 3

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1.5	GN/GY	4903	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 3	I	—
2	1.5	GN	4803	Direct Fuel Injector (DFI) High Voltage Control Cylinder 3	I	—

Q17D Fuel Injector 4



Connector Part Information

Harness Type: Engine

OEM Connector: 6189-7138

Service Connector: 13407097

Description: 2-Way F (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-18 (BK)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q17D Fuel Injector 4

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1.5	L-BU/WH	4904	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 4	I	—
2	1.5	GY/L-BU	4804	Direct Fuel Injector (DFI) High Voltage Control Cylinder 4	I	—

Q18A Fuel Pressure Regulator 1





Connector Part Information

Harness Type: Engine

OEM Connector: 1928405521

Service Connector: 13384371

Description: 2-Way F 2.8 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q18A Fuel Pressure Regulator 1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	YE	2928	Fuel Metering Valve High Control	I	—
2	0.5	BN/BK	2929	Fuel Metering Valve Low Control	I	—

Q18B Fuel Pressure Regulator 2





Connector Part Information

Harness Type: Engine

OEM Connector: 13580239

Service Connector: 19352404

Description: 2-Way F 1.5 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q18B Fuel Pressure Regulator 2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	L-BU/WH	2530	Fuel Rail Pressure Solenoid Control	I	—
2	0.5	BK/YE	2834	Fuel Rail Pressure Solenoid Low Reference	I	—

Q38 Throttle Body (JL1-LCV)





Connector Part Information

Harness Type: Engine

OEM Connector: 2272975-5

Service Connector: 19352911

Description: 6-Way F 1.2 MCON Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q38 Throttle Body (JL1-LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	YE	581	Throttle Actuator Control Open	I	—
2	0.5	BN/WH	582	Throttle Actuator Control Close	I	—
3	0.5	L-BU/WH	3630	Throttle Position Sensor (SENT1) Signal	I	—
4	0.5	BK/BN	2752	Throttle Position Sensor Low Reference	I	—
5	0.5	BN/RD	2701	Throttle Position Sensor 5V Reference	I	—
6	—	—	—	Not Occupied	—	—

Q38 Throttle Body (-LWN)



Connector Part Information

Harness Type: Engine

OEM Connector: 2138387-5

Service Connector: 19329736

Description: 6-Way F 1.2 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q38 Throttle Body (-LWN)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	YE	581	Throttle Actuator Control Open	I	—
2	0.5	BN/WH	582	Throttle Actuator Control Close	I	—
3	0.5	L-BU/WH	3630	Throttle Position Sensor (SENT1) Signal	I	—
4	0.5	BK/BN	2752	Throttle Position Sensor Low Reference	I	—
5	0.5	BN/RD	2701	Throttle Position Sensor 5V Reference	I	—
6	—	—	—	Not Occupied	—	—

Q44 Engine Oil Pressure Control Solenoid Valve (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 33471-0206

Service Connector: 13577534

Description: 2-Way F 1.5 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q44 Engine Oil Pressure Control Solenoid Valve (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/L-BU	5293	Powertrain Main Relay Fused Supply 4	I	—
2	0.5	L-BU	179	Oil Pump Command Signal	I	—

Q44 Engine Oil Pressure Control Solenoid Valve (LGZ)



Connector Part Information

Harness Type: Engine

OEM Connector: 10010337

Service Connector: 13587326

Description: 2-Way F 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q44 Engine Oil Pressure Control Solenoid Valve (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/L-BU	5293	Powertrain Main Relay Fused Supply 4	I	—
2	0.5	L-BU	179	Oil Pump Command Signal	I	—

Q46 A/C Compressor Solenoid Valve





Connector Part Information

Harness Type: Engine

OEM Connector: 2-1823608-5

Service Connector: 19299928

Description: 2-Way F 1.2 MCP Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q46 A/C Compressor Solenoid Valve

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	L-BU/YE	7574	Electric Variable Displacement Control	I	—
2	0.75	L-BU/BN	7573	Electric Variable Displacement Supply	I	—

Q47 Exhaust Gas Recirculation Cooler Bypass Solenoid Valve





Connector Part Information

Harness Type: Engine

OEM Connector: 1928405521

Service Connector: 13384371

Description: 2-Way F 2.8 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q47 Exhaust Gas Recirculation Cooler Bypass Solenoid Valve

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	YE/L-BU	3231	Exhaust Gas Recirculation Cooler Bypass Solenoid Control	I	—
2	0.5	GY/L-BU	3230	Exhaust Gas Recirculation Cooler Bypass Solenoid Control	I	—

Q61 Reductant Injector





Connector Part Information

Harness Type: Engine

OEM Connector: 13580239

Service Connector: 19352404

Description: 2-Way F 1.5 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q61 Reductant Injector

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	BN/WH	3100	DEF Dosing Valve Low Control	I	—
2	0.5	BN	3099	DEF Dosing Valve High Control	I	—

Q67 Exhaust Aftertreatment Fuel Injector





Connector Part Information

Harness Type: Chassis

OEM Connector: 34062-0025

Service Connector: 13580230

Description: 2-Way F 1.5 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q67 Exhaust Aftertreatment Fuel Injector

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/BN	2927	Hydrocarbon Injector Low Control	I	—
2	0.5	BN/L-BU	2926	Hydrocarbon Injector High Control	I	—

Q83A Valve Lifter Oil Solenoid Valve - Bank 1



Connector Part Information

Harness Type: Engine

OEM Connector: 10010338

Service Connector: 13587325

Description: 2-Way F 1.2 Multilock Series, Sealed (L-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q83A Valve Lifter Oil Solenoid Valve - Bank 1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/L-BU	5293	Powertrain Main Relay Fused Supply 4	I	—
2	0.5	L-BU	5491	Cylinder Shutoff Solenoid Control 1	I	—

Q83B Valve Lifter Oil Solenoid Valve - Bank 2



Connector Part Information

Harness Type: Engine

OEM Connector: 10010338

Service Connector: 13587325

Description: 2-Way F 1.2 Multilock Series, Sealed (L-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q83B Valve Lifter Oil Solenoid Valve - Bank 2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/L-BU	5293	Powertrain Main Relay Fused Supply 4	I	—
2	0.5	GN	5492	Cylinder Shutoff Solenoid Control 2	I	—

Q84A Camshaft Position Actuator Park Lock Solenoid Valve - Bank 1 Intake



Connector Part Information

Harness Type: Engine

OEM Connector: 10010338

Service Connector: 13587325

Description: 2-Way F 1.2 Multilock Series, Sealed (L-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q84A Camshaft Position Actuator Park Lock Solenoid Valve - Bank 1 Intake

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/L-BU	5293	Powertrain Main Relay Fused Supply 4	I	—
2	0.5	YE/GN	4321	Park Phaser Lock Control	I	—

Q84B Camshaft Position Actuator Park Lock Solenoid Valve - Bank 2 Intake



Connector Part Information

Harness Type: Engine

OEM Connector: 10010338

Service Connector: 13587325

Description: 2-Way F 1.2 Multilock Series, Sealed (L-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

Q84B Camshaft Position Actuator Park Lock Solenoid Valve - Bank 2 Intake

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/L-BU	5293	Powertrain Main Relay Fused Supply 4	I	—
2	0.5	GY/GN	587	Skip/Shift Solenoid Control	I	—

R6A Terminating Resistor - High Speed Bus



Connector Part Information

Harness Type: Chassis

OEM Connector: 13510085

Service Connector: 13580114

Description: 2-Way F 150 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

R6A Terminating Resistor - High Speed Bus

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	I	—
B	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	I	—

R10 Cooling Fan Resistor



Connector Part Information

Harness Type: Engine

OEM Connector: 13510085

Service Connector: 13580114

Description: 2-Way F 150 GT Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-14 (GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

R10 Cooling Fan Resistor

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	GY/RD	2365	Cooling Fan Speed 5V Reference	I	—
B	0.5	L-BU/VT	2364	Cooling Fan Speed Signal	I	—

S3 Transmission Shift Lever



Connector Part Information

Harness Type: Floor Console

OEM Connector: AIT2PB-06-1AK

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way F 0.64 Kaizen Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

S3 Transmission Shift Lever

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	—	—	—	Not Occupied	—	—
2	0.5	BK	2050	Ground	I	—
3	0.35	VT/YE	5526	Tap Up/Tap Down Switch Signal	I	—
4	0.5	VT/BK	7553	Park Lock Solenoid Control	I	—
5	—	—	—	Not Occupied	—	—
6	0.5	WH/VT	5905	Key Capture/Column Lock Shift Position Signal	I	—

S13D Door Lock Switch - Driver



Connector Part Information

Harness Type: Driver Door

OEM Connector: HCMPB-C06-K

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way F 0.64 HCM Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

S13D Door Lock Switch - Driver

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	—	—	—	Not Occupied	—	—
2	0.35	YE	6817	LED Backlight Dimming Control	I	—
3	0.35	BN/WH	781	Driver Door Lock Switch Unlock Signal	I	—
4	0.35	BN/YE	780	Driver Door Lock Switch Lock Signal	I	—
5	0.5	BK	3550	Ground	I	—
6	—	—	—	Not Occupied	—	—

S13P Door Lock Switch - Passenger



Connector Part Information

Harness Type: Passenger Door

OEM Connector: HCMPB-C06-K

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way F 0.64 HCM Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

S13P Door Lock Switch - Passenger

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	—	—	—	Not Occupied	—	—
2	0.35	YE	6817	LED Backlight Dimming Control	I	—
3	0.35	BN/VT	245	Passenger Door Lock Switch Unlock Control	I	—
4	0.35	YE/VT	244	Passenger Door Lock Switch Lock Control	I	—
5	0.35	BK	3650	Ground	I	—
6	—	—	—	Not Occupied	—	—

S30 Headlamp Switch



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 31410-1120

Service Connector: 89047364

Description: 12-Way F 0.64 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575845	J-35616-64B (LT BU)	J-38125-215A	SAIT-A03T-M064	Yazaki 14	P	P

S30 Headlamp Switch

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	WH/VT	103	Headlamp Switch On Signal	I	—
2	0.5	YE	6817	LED Backlight Dimming Control	I	—
3	0.35	GN/BN	306	Headlamp Switch Headlamps Off Signal Control	I	—
4	—	—	—	Not Occupied	—	—
5	0.35	GN/GY	13	Headlamp Switch Park Lamp Signal	I	—
6	—	—	—	Not Occupied	—	—
7	0.35	BK/YE	5005	Instrument Panel Lamp Dimmer Switch Low Reference	I	—
8	0.35	BK/WH	2151	Signal Ground	I	—
9	—	—	—	Not Occupied	—	—

10	0.35	L-BU/GY	192	Front Fog Lamp Switch Signal	I	—
11	0.35	YE/GY	44	Instrument Panel Lamp Dimmer Switch Signal	I	—
12	0.35	L-BU/RD	1688	5V Reference	I	—

S32D Seat Heating Switch - Driver



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 1379029-2

Service Connector: 13576536

Description: 4-Way F 0.64 Micro-Quadlock Series (WH)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

S32D Seat Heating Switch - Driver

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	BK	2050	Ground	I	—
2	—	—	—	Not Occupied	—	—
3	0.5	GN/WH	7527	Local Interconnect Network Serial Data Bus 5	I	—
4	0.5	RD/GY	2840	Battery Positive Voltage	I	—

S32P Seat Heating Switch - Passenger





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 1379029-6

Service Connector: 13587956

Description: 4-Way F 0.64 Micro-Quadlock Series (BN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

S32P Seat Heating Switch - Passenger

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	BK	2050	Ground	I	—
2	—	—	—	Not Occupied	—	—
3	0.5	GN/WH	7527	Local Interconnect Network Serial Data Bus 5	I	—
4	0.5	RD/GY	2840	Battery Positive Voltage	I	—

S39 Ignition Switch



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: HCMPB-C06-K

Service Connector: 19153174

Description: 6-Way F 0.64 HCM Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

S39 Ignition Switch

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/BK	3	Run/Crank Ignition 1 Voltage	I	—
2	0.5	RD/L-BU	540	Battery Positive Voltage	I	—
3	0.5	VT/YE	4	Accessory Ignition Voltage	I	—
4	0.5	WH/VT	1020	Off/Run/Crank Ignition Voltage	I	—
5	—	—	—	Not Occupied	—	—
6	0.5	WH/BK	1073	Ignition Key Resistor Signal	I	—

S48A Multifunction Switch - Instrument Panel





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 1379102-1

Service Connector: 13504129

Description: 18-Way F Micro-Quadlock Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575859	J-35616-64B (LT BU)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
II	19329754	J-35616-64B (LT BU)	J-38125-12A	Not Available	Not Available	Not Available	Not Available

S48A Multifunction Switch - Instrument Panel

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	YE	6817	LED Backlight Dimming Control	II	—
2	0.35	WH	6816	Indicator Dimming Control	II	—
3	0.5	GN/RD	7119	Axle Differential Lock Mode Switch 5V Reference	I	—
4	0.35	L-BU/YE	6844	ABS/TCS Hill Descent Control Switch Signal	II	—
5	0.35	WH	3152	Lane Departure Warning Indicator Control	II	—
6	0.5	VT/GY	7117	Front Axle Differential Lock Indicator Control	I	—
7	0.5	BN/WH	1429	Standing Lamp Relay Control	I	—

8	0.35	GY/WH	3153	Lane Departure Warning Disable Switch Signal	II	—
9	0.5	YE/GN	7122	Axle Differential Lock Switch Signal	I	—
10	0.35	GN/WH	111	Hazard Switch Signal	II	—
11	0.35	L-BU/GY	553	Shift Select Switch Performance Signal	II	—
12	0.5	YE	7115	Rear Axle Differential Lock Indicator Control	I	—
13	—	—	—	Not Occupied	—	—
14	0.35	BK	2050	Ground	II	—
15 - 16	—	—	—	Not Occupied	—	—
17	0.35	L-BU/VT	1788	Traction Control Switch Signal 1	II	—
18	0.35	GY	158	Cargo Lamp Switch Signal	II	—

S48D Multifunction Switch 2 - Instrument Panel (IOB)



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 34791-2180

Service Connector: 19333226

Description: 8-Way F Mini 50 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

S48D Multifunction Switch 2 - Instrument Panel (IOB)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	GY/BN	3761	Infotainment Regulated Control	I	—
2	0.35	GN/BK	2515	Keypad Control	I	—
3	0.35	BN/GN	3983	Display Radio Bank Switch Signal 2	I	—
4	0.35	GY	314	Radio On Signal	I	—
5	0.35	GY/L-BU	3989	Display Radio Bank Switch Dim Signal	I	—
6	0.35	L-BU	4315	Radio Volume Up Signal	I	—
7	0.35	GY/BN	4314	Radio Volume Down Signal	I	—
8	0.35	BK/BN	2518	Keypad Low Reference	I	—

S52 Outside Rearview Mirror Switch



Connector Part Information

Harness Type: Driver Door

OEM Connector: 31410-1121

Service Connector: Service by Harness - See Part Catalog

Description: 12-Way F 64 Series, Sealed (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

S52 Outside Rearview Mirror Switch

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	YE	6817	LED Backlight Dimming Control	I	—
2 - 4	—	—	—	Not Occupied	—	—
5	0.35	WH	3398	Passenger Mirror Motor Common Control	I	—
6	0.35	YE/BN	3391	Driver Mirror Motor Common Control	I	—
7	0.35	YE/VT	3397	Passenger Mirror Motor Up (+) Down (-) Control	I	—
8	0.35	VT/L-BU	3390	Driver Mirror Motor Up (+) Down (-) Control	I	—
9	0.35	GN/BK	3396	Passenger Mirror Motor Right (+) Left (-) Control	I	—
10	0.35	BN/BK	3389	Driver Mirror Motor Right (+) Left (-) Control	I	—

11	0.5	BK	3550	Ground	I	—
12	0.35	RD/VT	1940	Battery Positive Voltage	I	—

S76 Trailer Brake Control Switch



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 7283-9028-30

Service Connector: 13576542

Description: 8-Way F YESC Kaizen Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

S76 Trailer Brake Control Switch

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 2	—	—	—	Not Occupied	—	—
3	0.5	L-BU/RD	7632	Integrated Trailer Brake Controller Switch 5V Reference	I	—
4	0.5	YE	7635	Integrated Trailer Brake Controller Manual Apply Signal	I	—
5	0.5	BN	7634	Integrated Trailer Brake Controller Redundant Manual Apply Signal	I	—
6	0.5	GN/BK	7633	Integrated Trailer Brake Controller User Gain Signal	I	—
7	0.35	YE	6817	LED Backlight Dimming Control	I	—
8	0.5	BK/BN	7631	Integrated Trailer Brake Controller Switch Low Reference	I	—

S77 Transfer Case Shift Control Switch





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 31410-1121

Service Connector: 19151154

Description: 12-Way F 64 Series, Sealed (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575845	J-35616-64B (LT BU)	J-38125-215A	SAIT-A03T-M064	Yazaki 14	P	P

S77 Transfer Case Shift Control Switch

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	GY	5054	Sport Mode Switch Signal	I	—
2	0.5	VT/BN	300	Run Ignition 3 Voltage	I	—
3	0.35	BN	1560	Neutral Indicator Control	I	—
4	0.35	WH	6816	Indicator Dimming Control	I	—
5	0.35	YE	6817	LED Backlight Dimming Control	I	—
6	0.5	BK	2050	Ground	I	—
7	0.35	GY/GN	1561	AWD Indicator Control	I	—
8	0.35	GN/BK	1563	2 HI Indicator Control	I	—

9	0.35	BN/BK	1566	4 HI Indicator Control	I	—
10	0.35	VT/WH	1565	4 LO Indicator Control	I	—
11	0.35	GY/RD	6029	Four Wheel Drive Mode Switch 5V Reference	I	—
12	0.35	L-BU/YE	1693	Four Wheel Drive Switch Signal	I	—

S78 Turn Signal/Multifunction Switch



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: SHC2PB-12-2AK

Service Connector: 13576635

Description: 12-Way F 0.64 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575870	J-35616-64B (LT BU)	J-38125-12A	SNAC3-A021T-M0.64	Delphi 20	J	J

S78 Turn Signal/Multifunction Switch

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	WH/GN	663	Hazard Switch Left Turn Signal	I	—
2	0.35	WH	524	Headlamp Dimmer Switch High Beam Signal	I	—
3	0.35	BK/WH	2151	Signal Ground	I	—
4	0.35	YE/BN	307	Headlamp Switch Flash To Pass Signal	I	—
5	0.35	GY/L-BU	893	Driver Information Center Select Menu Switch Signal	I	—
6	0.35	BK/BN	897	Driver Information Center Switch Low Reference	I	—
7	0.35	VT/L-BU	664	Hazard Switch Right Turn Signal	I	—
8 - 11	—	—	—	Not Occupied	—	—

12	0.35	GN/WH	1358	Driver Information Center Switch Signal	I	—

S79D Window Switch - Driver



Connector Part Information

Harness Type: Driver Door

OEM Connector: 31410-1120

Service Connector: Service by Harness - See Part Catalog

Description: 12-Way F 0.64 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

S79D Window Switch - Driver

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	BK	3550	Ground	I	—
2	0.35	GN/VT	7628	Power Window Motor Left Front Express Control	I	—
3	0.35	GY	1136	Power Window Master Switch Left Front Down Signal	I	—
4	0.5	RD/VT	1940	Battery Positive Voltage	I	—
5	0.5	GN/YE	6134	Local Interconnect Network Serial Data Bus 3	I	—
6	0.35	GN/WH	1300	Power Window Master Switch Left Front Up Signal	I	—
7	0.35	WH/VT	3270	Driver Door Lock Motor Status Signal	I	—
8	0.35	L-BU/VT	1124	Door Lock Key Switch Unlock Signal	I	—

9	—	—	—	Not Occupied	—	—
10	0.35	YE/BN	3265	Child Security Lock Switch Signal	I	—
11	0.35	WH	6816	Indicator Dimming Control	I	—
12	0.35	GY	5697	Child Lockout Indicator Control	I	—

S79P Window Switch - Passenger



Connector Part Information

Harness Type: Passenger Door

OEM Connector: 6098-4713

Service Connector: Service by Harness - See Part Catalog

Description: 8-Way F 2.8 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

S79P Window Switch - Passenger

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	2.5	BK	3650	Ground	I	—
2	2.5	GN/GY	3387	Power Window Motor Passenger Up Control	I	—
3	2.5	YE/L-BU	3388	Power Window Motor Passenger Down Control	I	—
4	2.5	RD/WH	1340	Battery Positive Voltage	I	—
5	0.5	GN/YE	6134	Local Interconnect Network Serial Data Bus 3	I	—
6 - 7	—	—	—	Not Occupied	—	—
8	0.35	GY	746	Right Front Door Ajar Switch Signal	I	—

S82 Windshield Wiper/Washer Switch





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: HCMDPB-08-K

Service Connector: 13576541

Description: 8-Way F 1.2 HCM Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

S82 Windshield Wiper/Washer Switch

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	GY	1715	Windshield Wiper Switch High Signal	I	—
2	0.35	BK/GY	6009	Windshield Wiper Switch Low Reference	I	—
3	0.35	YE/L-BU	1714	Windshield Wiper Switch Low Signal	I	—
4	—	—	—	Not Occupied	—	—
5	0.35	WH/BK	94	Windshield Washer Switch Signal	I	—
6 - 8	—	—	—	Not Occupied	—	—

T2RR Antenna - Roof Rear



Connector Part Information

Harness Type: Body

OEM Connector: 13581687

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way F Coax Type (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

T2RR Antenna - Roof Rear

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	Coax	—	(AM/FM) Antenna RF Signal	I	—

T3 Audio Amplifier X1



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 6098-4713

Service Connector: 13580111

Description: 8-Way F 2.8 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-35 (VT)	No Tool Required	Not Required	Not Required	Not Required	Not Required

T3 Audio Amplifier X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	YE	200	Right Front Speaker Control (+) 1	I	—
2	—	—	—	Not Occupied	—	—
3	1	L-BU	201	Left Front Speaker Control (+) 1	I	—
4	2.5	RD/YE	3740	Battery Positive Voltage	I	—
5	1	YE/BK	117	Right Front Speaker Signal (-) 1	I	—
6	—	—	—	Not Occupied	—	—
7	1	BN/L-BU	118	Left Front Speaker Signal (-) 1	I	—
8	3	BK/WH	2251	Signal Ground	I	—

T3 Audio Amplifier X2



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 7283-6453-60

Service Connector: 89047090

Description: 16-Way F 1.5 Kaizen Series (GN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575829	J-35616-2A (GY)	J-38125-11A	Not Available	Not Available	Not Available	Not Available

T3 Audio Amplifier X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 2	—	—	—	Not Occupied	—	—
3	0.75	YE/WH	1860	Front Center Speaker Control (+)	I	—
4	0.75	YE	200	Right Front Speaker Control (+) 1	I	—
5	0.75	L-BU	201	Left Front Speaker Control (+) 1	I	—
6	1	WH	46	Right Rear Speaker Control (+)	I	—
7	1	GN	199	Left Rear Speaker Control (+)	I	—
8 - 10	—	—	—	Not Occupied	—	—
11	0.75	L-BU/YE	1960	Front Center Speaker (-) Low Reference	I	—
12	0.75	YE/BK	117	Right Front Speaker Signal (-) 1	I	—

13	0.75	BN/L-BU	118	Left Front Speaker Signal (-) 1	I	—
14	1	L-BU/BK	115	Right Rear Speaker Signal (-)	I	—
15	1	GN/BK	116	Left Rear Speaker Signal (-)	I	—
16	—	—	—	Not Occupied	—	—

T3 Audio Amplifier X3



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 15136073

Service Connector: 15136073

Description: 16-Way F 0.64 Kaizen Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575845	J-35616-64B (LT BU)	J-38125-215A	SAIT-A03T-M064	Yazaki 14	P	P

T3 Audio Amplifier X3

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.75	GY/GN	1102	Low Speed GMLAN Serial Data #2	I	—
2 - 16	—	—	—	Not Occupied	—	—

T3 Audio Amplifier X4



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 7283-9078-80

Service Connector: 15136074

Description: 16-Way F 0.64 Kaizen Series (BN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575845	J-35616-64B (LT BU)	J-38125-215A	SAIT-A03T-M064	Yazaki 14	P	P

T3 Audio Amplifier X4

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 2	—	—	—	Not Occupied	—	—
3	0.5	WH/GN	3997	MOST Serial Data (-)	I	—
4	0.5	GY/VT	3998	MOST Serial Data (+)	I	—
5	0.5	WH/GN	3997	MOST Serial Data (-)	I	—
6	0.5	GY/VT	3998	MOST Serial Data (+)	I	—
7 - 13	—	—	—	Not Occupied	—	—
14	0.35	WH/VT	3999	MOST Control	I	—
15 - 16	—	—	—	Not Occupied	—	—

T4G Cellular Phone, Navigation, and Digital Radio Antenna



Connector Part Information

Harness Type: Body

OEM Connector: 13583911

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 2-Way F Coax Type (PU)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

T4G Cellular Phone, Navigation, and Digital Radio Antenna

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	Coax	—	(GPS only) Coaxial Antenna GPS Signal	I	—

T4H Digital Radio Antenna



Connector Part Information

Harness Type: Body

OEM Connector: 13581975

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 2-Way F Coax Type (CU)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

T4H Digital Radio Antenna

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	Coax	—	(XM +/-HD) Coaxial Antenna XM Signal	I	—

T8A Ignition Coil 1 (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 33471-0461

Service Connector: 19299695

Description: 4-Way F 1.5 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

T8A Ignition Coil 1 (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	BK	1450	Ground	I	—
2	0.5	BK/L-BU	2129	Ignition Control Low Reference Bank 1	I	—
3	0.5	L-BU/VT	2121	Ignition Control 1	I	—
4	1	VT/L-BU	5291	Powertrain Main Relay Fused Supply 2	I	—

T8A Ignition Coil 1 (LGZ)



Connector Part Information

Harness Type: Engine

OEM Connector: 1-1456426-5

Service Connector: 19300397

Description: 4-Way F 1.2 MCP Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

T8A Ignition Coil 1 (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	BK	1450	Ground	I	—
2	0.5	BK/L-BU	2129	Ignition Control Low Reference Bank 1	I	—
3	0.5	L-BU/VT	2121	Ignition Control 1	I	—
4	1	VT/L-BU	5291	Powertrain Main Relay Fused Supply 2	I	—

T8B Ignition Coil 2 (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 33471-0461

Service Connector: 19299695

Description: 4-Way F 1.5 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

T8B Ignition Coil 2 (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	BK	1450	Ground	I	—
2	0.5	BK/L-BU	2129	Ignition Control Low Reference Bank 1	I	—
3	0.5	L-BU/WH	2122	Ignition Control 2	I	—
4	1	VT/L-BU	5291	Powertrain Main Relay Fused Supply 2	I	—

T8B Ignition Coil 2 (LGZ)



Connector Part Information

Harness Type: Engine

OEM Connector: 1-1456426-5

Service Connector: 19300397

Description: 4-Way F 1.2 MCP Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

T8B Ignition Coil 2 (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	BK	1550	Ground	I	—
2	0.5	BK/GY	2130	Ignition Control Low Reference Bank 2	I	—
3	0.5	L-BU/WH	2122	Ignition Control 2	I	—
4	1	VT/L-BU	5292	Powertrain Main Relay Fused Supply 3	I	—

T8C Ignition Coil 3 (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 33471-0461

Service Connector: 19299695

Description: 4-Way F 1.5 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

T8C Ignition Coil 3 (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	BK	1450	Ground	I	—
2	0.5	BK/L-BU	2129	Ignition Control Low Reference Bank 1	I	—
3	0.5	GN/L-BU	2123	Ignition Control 3	I	—
4	1	VT/L-BU	5291	Powertrain Main Relay Fused Supply 2	I	—

T8C Ignition Coil 3 (LGZ)



Connector Part Information

Harness Type: Engine

OEM Connector: 1-1456426-5

Service Connector: 19300397

Description: 4-Way F 1.2 MCP Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

T8C Ignition Coil 3 (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	BK	1450	Ground	I	—
2	0.5	BK/L-BU	2129	Ignition Control Low Reference Bank 1	I	—
3	0.5	GN/L-BU	2123	Ignition Control 3	I	—
4	1	VT/L-BU	5291	Powertrain Main Relay Fused Supply 2	I	—

T8D Ignition Coil 4 (LCV)



Connector Part Information

Harness Type: Engine

OEM Connector: 33471-0461

Service Connector: 19299695

Description: 4-Way F 1.5 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

T8D Ignition Coil 4 (LCV)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	BK	1450	Ground	I	—
2	0.5	BK/L-BU	2129	Ignition Control Low Reference Bank 1	I	—
3	0.5	YE/L-BU	2124	Ignition Control 4	I	—
4	1	VT/L-BU	5291	Powertrain Main Relay Fused Supply 2	I	—

T8D Ignition Coil 4 (LGZ)



Connector Part Information

Harness Type: Engine

OEM Connector: 1-1456426-5

Service Connector: 19300397

Description: 4-Way F 1.2 MCP Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

T8D Ignition Coil 4 (LGZ)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	BK	1550	Ground	I	—
2	0.5	BK/GY	2130	Ignition Control Low Reference Bank 2	I	—
3	0.5	YE/L-BU	2124	Ignition Control 4	I	—
4	1	VT/L-BU	5292	Powertrain Main Relay Fused Supply 3	I	—

T8E Ignition Coil 5



Connector Part Information

Harness Type: Engine

OEM Connector: 1-1456426-5

Service Connector: 19300397

Description: 4-Way F 1.2 MCP Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

T8E Ignition Coil 5

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	BK	1450	Ground	I	—
2	0.5	BK/L-BU	2129	Ignition Control Low Reference Bank 1	I	—
3	0.5	L-BU/GY	2125	Ignition Control 5	I	—
4	1	VT/L-BU	5291	Powertrain Main Relay Fused Supply 2	I	—

T8F Ignition Coil 6



Connector Part Information

Harness Type: Engine

OEM Connector: 1-1456426-5

Service Connector: 19300397

Description: 4-Way F 1.2 MCP Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required

T8F Ignition Coil 6

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	1	BK	1550	Ground	I	—
2	0.5	BK/GY	2130	Ignition Control Low Reference Bank 2	I	—
3	0.5	BN/L-BU	2126	Ignition Control 6	I	—
4	1	VT/L-BU	5292	Powertrain Main Relay Fused Supply 3	I	—

T12 Automatic Transmission Assembly X1



Connector Part Information

Harness Type: Engine

OEM Connector: 34822-0013

Service Connector: 19329822

Description: 66-Way F 0.64, 2.8 Series, Sealed (BK with BK Terminal Position Assurance)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575812	J-35616-64B (LT BU)	J-38125-213	Not Available	Not Available	Not Available	Not Available
II	13579765	J-35616-4A (PU)	J-38125-11A	Not Available	Not Available	Not Available	Not Available

T12 Automatic Transmission Assembly X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	WH/L-BU	4507	Transmission Clutch H Control	I	—
2	0.5	L-BU	6401	Clutch B Control	I	—
3	0.5	GY/GN	6403	Clutch D Control	I	—
4 - 6	—	—	—	Not Occupied	—	—
7	0.5	YE/GN	4170	Transmission Position Sensor B 9V Reference	I	—
8	0.5	YE/L-BU	4171	Transmission Position Sensor A 9V Reference	I	—
9 - 12	—	—	—	Not Occupied	—	—
13	0.5	GN/VT	4510	Transmission Intermediate Speed Signal	I	—

14	0.5	GY/L-BU	6358	Output Speed Signal	I	—
15	0.5	GN/YE	6353	Input Speed Signal	I	—
16	—	—	—	Not Occupied	—	—
17	0.5	WH	4508	Transmission Clutch G Control	I	—
18	0.5	BN	6400	Clutch A Control	I	—
19	0.5	GY	6402	Clutch C Control	I	—
20	0.5	YE/BN	6404	Clutch E Control	I	—
21	0.5	GN/WH	6380	TCC On/Off Solenoid A Control	I	—
22	0.5	YE/BN	6210	TCC On/Off Solenoid B Control	I	—
23 - 24	—	—	—	Not Occupied	—	—
25	0.5	BK/GY	3927	IMS Mode Switch Low Reference	I	—
26 - 27	—	—	—	Not Occupied	—	—
28	0.5	BK/BN	586	Transmission Oil Temperature Sensor Low Reference	I	—
29 - 32	—	—	—	Not Occupied	—	—
33	0.75	GN/GY	6387	Transmission High Side Driver 1 Signal Driver	I	—
34	—	—	—	Not Occupied	—	—
35	0.5	VT/BK	2139	Run/Crank Ignition 1 Voltage	I	—
36	—	—	—	Not Occupied	—	—
37	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	I	—

38	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	I	—
39 - 46	—	—	—	Not Occupied	—	—
47	0.5	GY/YE	4169	PRNDL S Signal	I	—
48	—	—	—	Not Occupied	—	—
49	0.75	GY/BN	6388	Transmission High Side Driver 2 Signal	I	—
50	—	—	—	Not Occupied	—	—
51	0.5	VT/YE	5985	Accessory Wakeup Serial Data	I	—
52	—	—	—	Not Occupied	—	—
53	0.5	L-BU	2500	High Speed GMLAN Serial Data (+) 1	I	—
54	0.5	WH	2501	High Speed GMLAN Serial Data (-) 1	I	—
55 - 58	—	—	—	Not Occupied	—	—
59	0.5	GY/WH	4168	PRNDL P Signal	I	—
60	0.5	WH/BK	5983	PRNDL C Signal	I	—
61	0.5	GY/BN	5982	PRNDL B Signal	I	—
62	0.5	VT/WH	5981	PRNDL A Signal	I	—
63	0.5	BN/WH	585	Transmission Oil Temperature Sensor Signal	I	—
64	—	—	—	Not Occupied	—	—
65	0.75 0.75	BK/WH BK/WH	1451 1451	Signal Ground Signal Ground	II I	— —

66	0.75	RD/GN	1840	Battery Positive Voltage	I	—

T15 Navigation Antenna Signal Splitter X1



Connector Part Information

Harness Type: Body

OEM Connector: 13585423

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way F Coax Type (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

T15 Navigation Antenna Signal Splitter X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	Coax	—	(GPS only) Coaxial Antenna GPS Signal	I	—

T15 Navigation Antenna Signal Splitter X2





Connector Part Information

Harness Type: Body

OEM Connector: 13581697

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way F Coax Type (VT)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

T15 Navigation Antenna Signal Splitter X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	Coax	—	(GPS only) Coaxial Antenna GPS Signal	I	—

T15 Navigation Antenna Signal Splitter X3





Connector Part Information

Harness Type: Body

OEM Connector: 13585573

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way F Coax Type (BU)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

T15 Navigation Antenna Signal Splitter X3

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	Coax	—	(GPS only) Coaxial Antenna GPS Signal	I	—

T22 Mobile Device Wireless Charger Module



Connector Part Information

Harness Type: Floor Console

OEM Connector: AIT2PB-06-1FS

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way F 0.64 Series (NA)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

T22 Mobile Device Wireless Charger Module

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT	4601	Retained Accessory Power Fused Control	I	—
2	0.5	BK	2050	Ground	I	—
3	0.35	GN	4512	Wireless Charging System Charge Indicator Control	I	—
4	0.35	BN	4511	Wireless Charging System Fault Indicator Control	I	—
5 - 6	—	—	—	Not Occupied	—	—

X80A Accessory Power Receptacle - Center Console 1



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 12176836

Service Connector: 19257374

Description: 3-Way F 280 Metri-Pack Series (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-4A (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X80A Accessory Power Receptacle - Center Console 1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	1.5	VT	1701	Retained Accessory Power Ignition	I	—
B	—	—	—	Not Occupied	—	—
C	1.5	BK	2050	Ground	I	—

X80B Accessory Power Receptacle - Center Console 2



Connector Part Information

Harness Type: Floor Console

OEM Connector: 12176836

Service Connector: Service by Harness - See Part Catalog

Description: 3-Way F 280 Metri-Pack Series (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-4A (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X80B Accessory Power Receptacle - Center Console 2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	1.5	VT	2101	Retained Accessory Power Fuse Ignition	I	—
B	—	—	—	Not Occupied	—	—
C	1.5	BK	2050	Ground	I	—

X83 Auxiliary Audio Input X1 ((IO3)(MYB))



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: AIT2PB-06-1AK

Service Connector: 19167753

Description: 6-Way F 0.64 Kaizen Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X83 Auxiliary Audio Input X1 ((IO3)(MYB))

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	GY	5839	Left Auxiliary Audio Signal 2	I	—
2	0.35	GN	5841	Right Auxiliary Audio Signal 2	I	—
3	0.35	VT	5843	Auxiliary Audio Common Signal	I	—
4	0.35	BK/WH	2051	Signal Ground	I	—
5	0.35	L-BU	2060	Auxiliary Detection Signal	I	—
6	0.5	RD/VT	340	Battery Positive Voltage	I	—

X83 Auxiliary Audio Input X1 ((IO4/IO5/IO6)(MYB))



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: AIT2PB-06-1AK

Service Connector: 19167753

Description: 6-Way F 0.64 Kaizen Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X83 Auxiliary Audio Input X1 ((IO4/IO5/IO6)(MYB))

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	GY	5839	Left Auxiliary Audio Signal 2	I	—
2	0.35	GN	5841	Right Auxiliary Audio Signal 2	I	—
3	0.35	VT	5843	Auxiliary Audio Common Signal	I	—
4	0.35	BK/WH	2051	Signal Ground	I	—
5	0.35	L-BU	2060	Auxiliary Detection Signal	I	—
6	0.5	RD/VT	340	Battery Positive Voltage	I	—

X83 Auxiliary Audio Input X2 ((IO3)(MYB))



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13584747

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 5-Way M 2.0 Mini-B USB Type (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

X83 Auxiliary Audio Input X2 ((IO3)(MYB))

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	USB	—	USB Serial Data	I	—

X83 Auxiliary Audio Input X2 ((IO4/IO5/IO6)(MYB))



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13584747

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 5-Way M 2.0 Mini-B USB Type (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

X83 Auxiliary Audio Input X2 ((IO4/IO5/IO6)(MYB))

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	USB	—	USB Serial Data	I	—

X83R Auxiliary Audio Input - Rear X1 (IO5/IO6)



Connector Part Information

Harness Type: Floor Console

OEM Connector: AIT2PB-06-1AK

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way F 0.64 Kaizen Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X83R Auxiliary Audio Input - Rear X1 (IO5/IO6)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1 - 3	—	—	—	Not Occupied	—	—
4	0.35	BK/WH	2051	Signal Ground	I	—
5	—	—	—	Not Occupied	—	—
6	0.5	RD/VT	340	Battery Positive Voltage	I	—

X83R Auxiliary Audio Input - Rear X2 (IO5/IO6)



Connector Part Information

Harness Type: Floor Console

OEM Connector: 13580213

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 5-Way M 2.0 Mini-B USB Type (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

X83R Auxiliary Audio Input - Rear X2 (IO5/IO6)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	USB	—	USB Serial Data	I	—

X83R Auxiliary Audio Input - Rear X3 (IO5/IO6)





Connector Part Information

Harness Type: Floor Console

OEM Connector: 13580212

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 5-Way M 2.0 Mini-B USB Type (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

X83R Auxiliary Audio Input - Rear X3 (IO5/IO6)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	USB	—	USB Serial Data	I	—

X84 Data Link Connector



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 12110250

Service Connector: 12110250

Description: 16-Way F 150 Metri-Pack Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575725	J-35616-14 (GN)	J-38125-12A	12129484	Delphi 19	E	A
II	13575725	J-35616-14 (GN)	J-38125-12A	12129484	Delphi 19	E	C

X84 Data Link Connector

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	GN	5060	Low Speed GMLAN Serial Data	II	—
2 - 3	—	—	—	Not Occupied	—	—
4	0.5	BK	2050	Ground	II	—
5	0.75	BK/WH	2151	Signal Ground	I	—
6	0.35	L-BU	2500	High Speed GMLAN Serial Data (+) 1	II	—
7 - 11	—	—	—	Not Occupied	—	—
12	0.5	L-BU/YE	6105	High Speed GMLAN Serial Data (+) 2	II	—
13	0.5	WH	6106	High Speed GMLAN Serial Data (-) 2	II	—

14	0.35	WH	2501	High Speed GMLAN Serial Data (-) 1	II	—
15	—	—	—	Not Occupied	—	—
16	0.5	RD/WH	640	Battery Positive Voltage	II	—

X85 Steering Wheel Air Bag Coil X1



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 1563190-1

Service Connector: 13574780

Description: 2-Way M 1.6 Timer Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-34 (YE)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X85 Steering Wheel Air Bag Coil X1

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.5	VT/WH	1139	Run/Crank Ignition 1 Voltage	I	—
2	0.5	BK	2050	Ground	I	—

X85 Steering Wheel Air Bag Coil X2



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: AIT2PB-10-1AK

Service Connector: 13576634

Description: 10-Way F 0.64 Kaizen Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575867	J-35616-64B (LT BU)	J-38125-215A	SAIT-A03T-M064	Yazaki 14	P	P

X85 Steering Wheel Air Bag Coil X2

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	GN/WH	3287	Horn Switch Signal	I	—
2	0.5	BK	2050	Ground	I	—
3	0.35	BN/GN	1884	Cruise Control Set/Coast/Resume/Accelerate Switch Signal	I	—
4	0.35	GN	6818	Steering Wheel Resistor Ladder Signal 1	I	—
5	0.35	WH/RD	1444	12V Reference	I	—
6	0.35	BN	6136	Control	I	—
7	0.35	GY/GN	5737	Adaptive Cruise Control Gap Up/Down Switch Signal	I	—
8	—	—	—	Not Occupied	—	—

9	0.5	GN/BK	3894	Local Interconnect Network Serial Data Bus 12	I	—
10	0.35	RD/YE	3040	Battery Positive Voltage	I	—

X85 Steering Wheel Air Bag Coil X3



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 15393421

Service Connector: 13580115

Description: 4-Way F 0.64 Micro-Pack Series (YE)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-64B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X85 Steering Wheel Air Bag Coil X3

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
1	0.35	WH/OG	3020	Steering Wheel Module Stage 1 Low Control	I	—
2	0.35	OG/GN	3021	Steering Wheel Module Stage 1 High Control	I	—
3	0.35	BN/OG	3022	Steering Wheel Module Stage 2 Low Control	I	—
4	0.35	OG/VT	3023	Steering Wheel Module Stage 2 High Control	I	—

X88 Trailer Connector



Connector Part Information

Harness Type: Chassis

OEM Connector: 13857223

Service Connector: 13583927

Description: 7-Way F 280, 630 Metri-Pack Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-42 (RD)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-4A (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X88 Trailer Connector

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.75	GY	1624	Trailer Backup Lamp Control	II	—
B	6	BK	22	Trailer Ground	I	—
C	2.5	L-BU	47	Trailer Auxiliary Control	II	—
D	0.75	GN	1619	Right Rear Trailer Stop/Turn Lamp Control	II	—
E	4	OG	742	Battery Positive Voltage	II	—
F	1.5	BN	2109	Trailer Park Lamp Control	II	—
G	0.75	YE	1618	Left Rear Trailer Stop/Turn Lamp Control	II	—

X92 USB Receptacle (IO5/IO6)



Connector Part Information

Harness Type: Floor Console

OEM Connector: 13584747

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 5-Way M 2.0 Mini-B USB Type (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

X92 USB Receptacle (IO5/IO6)

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
—	—	USB	—	USB Serial Data	I	—

JX200 Splice Pack



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 15305291

Service Connector: 15305291

Description: 12-Way F 280 Metri-Pack Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575721	J-35616-4A (PU)	J-38125-553	12110844	Delphi 4	E	4
II	13575721	J-35616-4A (PU)	J-38125-553	12110844	Delphi 4	E	A

JX200 Splice Pack

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	GN	5060	Low Speed GMLAN Serial Data	II	—
B	—	—	—	Not Occupied	—	—
C	0.5	GN	5060	Low Speed GMLAN Serial Data	II	—
D	—	—	—	Not Occupied	—	—
E	0.35	GN	5060	Low Speed GMLAN Serial Data	I	—
F - H	—	—	—	Not Occupied	—	—
J	0.5	GN	5060	Low Speed GMLAN Serial Data	II	—
K	0.35	GN	5060	Low Speed GMLAN Serial Data	I	—
L	0.5	GN	5060	Low Speed GMLAN Serial Data	II	—

M	—	—	—	Not Occupied	—	—

JX201 Splice Pack



Connector Part Information

Harness Type: Body

OEM Connector: 15305291

Service Connector: 15305291

Description: 12-Way F 280 Metri-Pack Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575721	J-35616-4A (PU)	J-38125-553	12110844	Delphi 4	E	4
II	13575721	J-35616-4A (PU)	J-38125-553	12110844	Delphi 4	E	A

JX201 Splice Pack

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	GN	5060	Low Speed GMLAN Serial Data	II	—
B - E	—	—	—	Not Occupied	—	—
F	0.35	GN	5060	Low Speed GMLAN Serial Data	I	—
G - H	—	—	—	Not Occupied	—	—
J	0.5	GN	5060	Low Speed GMLAN Serial Data	II	—
K - M	—	—	—	Not Occupied	—	—

JX202 Splice Pack



Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 12176461

Service Connector: 15305914

Description: 12-Way F 150 GT Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575735	J-35616-14 (GN)	J-38125-553	12191812	Delphi 19	C	A
II	13575735	J-35616-14 (GN)	J-38125-553	12191812	Delphi 19	E	C

JX202 Splice Pack

Pin	Size	Color	Circuit	Function	Terminal Type ID	Option
A	0.5	GY/GN	1102	Low Speed GMLAN Serial Data #2	II	—
B	0.35	GY/GN	1102	Low Speed GMLAN Serial Data #2	II	IOB
	0.5	GY/GN	1102	Low Speed GMLAN Serial Data #2	II	-IOB
C	—	—	—	Not Occupied	—	—
D	0.5	GY/GN	1102	Low Speed GMLAN Serial Data #2	II	—
E	0.5	GY/GN	1102	Low Speed GMLAN Serial Data #2	II	—
F	—	—	—	Not Occupied	—	—
G	0.5	GY/GN	1102	Low Speed GMLAN Serial Data #2	II	—
H - J	—	—	—	Not Occupied	—	—

K	0.75	GY/GN	1102	Low Speed GMLAN Serial Data #2	I	—
L - M	—	—	—	Not Occupied	—	—

X100 Battery Negative Harness to Power Steering Harness

—



Connector Part Information

Harness Type: Battery Negative

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 4-Way F

Connector Part Information

Harness Type: Power Steering

OEM Connector: 7286-1399-80

Service Connector: Service by Harness - See Part Catalog

Description: 4-Way M 1.5, 9.5 Series, Sealed (BN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-21 (RD)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X100 Battery Negative Harness to Power Steering Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	10	RD/VT	842	I	—	Battery Positive Voltage	1	10	RD/VT	842	II	—
2	10	BK	1050	I	—	Ground	2	10	BK	1050	II	—

X101 Engine Harness to Body Harness (NQ6+LCV/LWN)





Connector Part Information

Harness Type: Engine

OEM Connector: 15509585

Service Connector: 19329744

Description: 48-Way F 1.5 MCP, 2.8 JPT, 6.3 MCP Series, Sealed (BK)

Connector Part Information

Harness Type: Body

OEM Connector: 15513438

Service Connector: 19329745

Description: 48-Way M 1.6, 2.8, 5.8 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13579921	J-35616-40 (BU)	J-38125-556	Not Available	Not Available	Not Available	Not Available
II	13579986	J-35616-4A (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
III	13580821	J-35616-4A (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
IV	13580830	J-35616-35 (VT)	J-38125-36	Not Available	Not Available	Not Available	Not Available
V	13580830	J-35616-4A (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
VI	19119381	J-35616-14 (GN)	J-38125-215A	Not Available	Not Available	Not Available	Not Available
VII	19301757	J-35616-40 (BU)	J-38125-556	1241408-1	Lear 28	A	B
VIII	13327190	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available
IX	13575574	J-35616-5 (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
X	13581368	J-35616-5 (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available

X	[illegible]	[illegible]	[illegible]	Not Available	Not Available	Not Available	Not Available
XI	19119926	J-35616-43 (RD)	J-38125-36	Not Available	Not Available	Not Available	Not Available
XII	19301750	J-35616-32 (OR)	J-38125-36	Not Available	Not Available	Not Available	Not Available

X101 Engine Harness to Body Harness (NQ6+LCV/LWN)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	2.5	YE/VT	1553	VII	—	Transfer Case Motor Counter Clockwise Control	1	2.5	YE/VT	1553	XI	—
2	0.75	VT/GY	139	V	—	Run/Crank Ignition 1 Voltage	2	0.75	VT/GY	139	X	—
3	0.75	VT/GY	139	VI	—	Run/Crank Ignition 1 Voltage	3	0.75	VT/GY	139	VIII	—
4	0.5	WH/GN	7475	VI	—	Incremental Encoder Sensor 8V Reference	4	0.5	WH/GN	7475	VIII	—
5	0.5	WH/L-BU	6311	VI	—	Cruise/ETC/TCC Brake Signal	5	0.5	WH/L-BU	6311	VIII	—
6	0.5	BK/VT	1272	VI	—	Accelerator Pedal Position Low Reference 2	6	0.5	BK/VT	1272	VIII	—
7	0.5	BN/WH	419	VI	—	Check Engine Indicator Control	7	0.5	BN/WH	419	VIII	—
8	0.5	BN/RD	1274	VI	—	Accelerator Pedal Position 5V Reference 2	8	0.5	BN/RD	1274	VIII	—
9	0.5	YE	7474	VI	—	Incremental Encoder Direction Signal	9	0.5	YE	7474	VIII	—
		L-BU/BN	7573	VI	—	Electric Variable			L-BU/BN	7573	VIII	—

10	0.75	L-BU/BN	7573	VI	—	Electric Variable Displacement Supply	10	0.5	L-BU/BN	7573	VIII	—
11	0.75	BK	1450	I	—	Ground	11	0.75	BK	1450	XII	—
12	0.5	BK	1782	VI	—	Low Reference	12	0.5	BK	1782	VIII	—
13	0.5	GN/GY	465	VI	—	Fuel Pump Primary Relay Control	13	0.5	GN/GY	465	VIII	—
14	0.5	WH/BK	2366	VI	—	Cooling Fan Control Relay Speed Signal	14	0.5	WH/BK	2366	VIII	—
15	0.5	L-BU/WH	890	VI	—	Fuel Tank Pressure Sensor Signal	15	0.5	L-BU/WH	890	VIII	—
16	0.5	YE/RD	2709	VI	—	Fuel Tank Pressure Sensor 5V Reference	16	0.5	YE/RD	2709	VIII	—
17	0.5	BK/GN	6281	VI	—	Fuel Level Sensor Low Reference	17	0.5	BK/GN	6281	VIII	—
18	0.5	L-BU/VT	1589	VI	—	Primary Fuel Level Sensor Signal	18	0.5	L-BU/VT	1589	VIII	—
19	0.75	L-BU/YE	7574	VI	—	Electric Variable Displacement Control	19	0.5	L-BU/YE	7574	VIII	—
20	2.5	YE/BN	1569	III	—	Transfer Case Lock Solenoid Control	20	2.5	YE/BN	1569	IX	—
		GN/BN	507	VI	LWN	Wait To Start Indicator			GN/BN	507	VIII	LWN

21	0.5 0.5	GN/BN BK/YE	507 7447	VI VI	LWN -LWN	Wait To Start Indicator Control Fuel Line Pressure Sensor Low Reference	21	0.5 0.5	GN/BN BK/YE	507 7447	VIII VIII	LWN -LWN
22	0.5	L-BU/GY	7473	VI	—	Incremental Encoder Impulse Signal	22	0.5	L-BU/GY	7473	VIII	—
23	0.5	GN/WH	1162	VI	—	Accelerator Pedal Position Signal 2	23	0.5	GN/WH	1162	VIII	—
24	0.5	BK/L-BU	1271	VI	—	Accelerator Pedal Position Low Reference 1	24	0.5	BK/L-BU	1271	VIII	—
25	0.5	WH/RD	1164	VI	—	Accelerator Pedal Position 5V Reference 1	25	0.5	WH/RD	1164	VIII	—
26	0.5	WH	1310	VI	—	EVAP Canister Vent Solenoid Control	26	0.5	WH	1310	VIII	—
27	0.5	WH/RD	7477	VI	—	Rotary Position Sensor 5V Reference	27	0.5	WH/RD	7477	VIII	—
28	0.5 0.5	BN WH/GN	6305 7479	VI VI	LGZ NQ6+LCV/LWN	Brake Vacuum Switch Signal Rotary Position Sensor Signal	28	0.5 0.5	BN WH/GN	6305 7479	VIII VIII	LGZ NQ6+LCV/LWN
29	2.5 0.5	BN/VT YE/BK	1470 7478	II IV	LGZ NQ6+LCV/LWN	Brake Booster Pump Motor Control Rotary Position Sensor Low Reference	29	2.5 0.5	BN/VT YE/BK	1470 7478	X X	LGZ NQ6+LCV/LWN

30	0.5	BK/L-BU	61	VI	—	Outside Ambient Temperature Sensor Low Reference	30	0.5	BK/L-BU	61	VIII	—
31	0.5	L-BU/GY	636	VI	—	Outside Ambient Air Temperature Sensor Signal	31	0.5	L-BU/GY	636	VIII	—
32	0.5	YE/WH	1161	VI	—	Accelerator Pedal Position Signal 1	32	0.5	YE/WH	1161	VIII	—
33	0.5 0.5	BK/YE BK/GY	5382 6110	VI VI	MYB N8D	Brake Position Sensor Low Reference Clutch Apply Sensor Low Reference	33	0.5 0.5	BK/YE BK/GY	5382 6110	VIII VIII	MYB N8D
34	0.5 0.5	WH/GN YE	5380 6111	VI VI	MYB N8D	Brake Position Sensor Signal Clutch Apply Sensor Signal	34	0.5 0.5	WH/GN YE	5380 6111	VIII VIII	MYB N8D
35	0.5 0.5	WH/RD GY/RD	5381 6109	VI VI	MYB/M5T N8D	Brake Position Sensor 5V Reference Clutch Apply Sensor 5V Reference	35	0.5 0.5	WH/RD GY/RD	5381 6109	VIII VIII	MYB N8D
36	0.5	L-BU/BK	7493	VI	—	High Speed GMLAN Serial Data (+)3	36	0.5	L-BU/BK	7493	VIII	—
37	0.5	WH	7494	VI	—	High Speed GMLAN Serial Data (-)3	37	0.5	WH	7494	VIII	—

38	2.5	YE/GY	1552	VII	—	Transfer Case Motor Clockwise Control	38	2.5	YE/GY	1552	XI	—
39	2.5	RD/GY	1342	III	—	Battery Positive Voltage	39	2.5	RD/GY	1342	IX	—
40	0.5	BK/L-BU	6813	VI	—	Coolant Temperature Sensor 2 Low Reference	40	0.5	BK/L-BU	6813	VIII	—
41	0.5 0.5	L-BU/BK YE/BK	7116 3000	VI VI	BPH LCV	Front Axle Differential Lock Control Coolant Temperature Sensor 2 Signal	41	0.5 0.5	L-BU/BK YE/BK	7116 3000	VIII VIII	BPH LCV
42	0.5	VT/YE	5985	VI	—	Accessory Wakeup Serial Data	42	0.5	VT/YE	5985	VIII	—
43	0.5	VT	7476	VI	—	Incremental Encoder Sensor Low Reference	43	0.5	VT	7476	VIII	—
44	0.5	L-BU/WH	7446	VI	—	Fuel Line Pressure Sensor Signal	44	0.5	L-BU/WH	7446	VIII	—
45	0.5	GY	3890	VI	—	Aero Shutter Control 2	45	0.5	GY	3890	VIII	—
46	0.5	L-BU	2500	VI	—	High Speed GMLAN Serial Data (+) 1	46	0.5	L-BU	2500	VIII	—
47	0.5	WH	2501	VI	—	High Speed GMLAN Serial Data (-) 1	47	0.5	WH	2501	VIII	—

48	0.5	BN/RD	7445	I	—	Fuel Line Pressure Sensor 5V Reference	48	0.5	BN/RD	7445	XII	—
29A	—	—	—	—	—	Brake Booster Pump Motor Control	29A	2.5	BN/VT	1470	IX	—

X102 Forward Lamp Harness to Body Harness





Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 15509588

Service Connector: 19329766

Description: 48-Way F 1.5 MCP, 2.8 JPT, 6.3 MCP Series, Sealed (YE)

Connector Part Information

Harness Type: Body

OEM Connector: 15513436

Service Connector: 19301796

Description: 48-Way M 1.6, 2.8, 5.8 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13580830	J-35616-4A (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
II	19119381	J-35616-14 (GN)	J-38125-215A	Not Available	Not Available	Not Available	Not Available
III	19301757	J-35616-40 (BU)	J-38125-556	1241408-1	Lear 28	A	B
IV	19301757	J-35616-40 (BU)	J-38125-556	1241408-1	Lear 28	C	A
V	19329757	J-35616-14 (GN)	J-38125-215A	Not Available	Not Available	Not Available	Not Available
VI	19330701	J-35616-14 (GN)	J-38125-215A	Not Available	Not Available	Not Available	Not Available
VII	13327190	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available
VIII	13581368	J-35616-5 (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
IX	19119926	J-35616-43 (RD)	J-38125-36	Not Available	Not Available	Not Available	Not Available
X	19331731	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available

X102 Forward Lamp Harness to Body Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	2.5	BN/VT	1470	III	—	Brake Booster Pump Motor Control	1	2.5	BN/VT	1470	IX	—
2	—	—	—	—	—	Not Occupied	2	—	—	—	—	—
3	0.75	WH/VT	1430	II	—	Exterior Courtesy Lamp Control	3	0.75	WH/VT	1430	VII	—
4 - 5	—	—	—	—	—	Not Occupied	4 - 5	—	—	—	—	—
6	0.75	VT/GY	709	II	—	Left Park Lamp Control	6	0.5	VT/GY	709	VII	—
7	—	—	—	—	—	Not Occupied	7	—	—	—	—	—
8	0.75	GY/BN	309	II	—	Right Park Lamp Control	8	0.5	GY/BN	309	VII	—
9	—	—	—	—	—	Not Occupied	9	—	—	—	—	—
10	1.5	WH	92	VI	—	Windshield Wiper Motor High Speed Control	10	1.5	WH	92	X	—
11	1.5	YE/BN	95	IV	—	Windshield Wiper Motor Low Speed Control	11	1.5	YE/BN	95	IX	—
12	—	—	—	—	—	Not Occupied	12	—	—	—	—	—
13	0.5	OG/YE	354	V	—	Left Front Discriminating Sensor Signal	13	0.5	OG/YE	354	X	—
14	0.5	BK/OG	5045	V	—	Left Front Discriminating Sensor Low Reference	14	0.5	BK/OG	5045	X	—
		BN/GN	109	II	—	Hood Ajar Switch Signal			BN/GN	109	VII	—

15	0.5	BN/GN	109	II	—	Hood Ajar Switch Signal	15	0.5	BN/GN	109	VII	—
16	—	—	—	—	—	Not Occupied	16	—	—	—	—	—
17	0.5	VT/GY	1054	III	—	Stop Lamp Control	17	0.5	VT/GY	1054	VII	—
18	—	—	—	—	—	Not Occupied	18	—	—	—	—	—
19	1.5	YE	312	VI	—	Right Headlamp Low Beam Control	19	1.5	YE	312	X	—
20	—	—	—	—	—	Not Occupied	20	—	—	—	—	—
21	0.5	OG/GN	1409	V	—	Right Front Discriminating Sensor Signal	21	0.5	OG/GN	1409	X	—
22	0.5	BK/OG	5600	V	—	Right Front Discriminating Sensor Low Reference	22	0.5	BK/OG	5600	X	—
23	—	—	—	—	—	Not Occupied	23	—	—	—	—	—
24	0.5	WH/BK	2366	II	—	Cooling Fan Control Relay Speed Signal	24	0.5	WH/BK	2366	VII	—
25	—	—	—	—	—	Not Occupied	25	—	—	—	—	—
26	0.5	L-BU/GY	636	II	—	Outside Ambient Air Temperature Sensor Signal	26	0.5	L-BU/GY	636	VII	—
27	0.5	BK/L-BU	61	II	—	Outside Ambient Temperature Sensor Low Reference	27	0.5	BK/L-BU	61	VII	—
28	—	—	—	—	—	Not Occupied	28	—	—	—	—	—
29	0.75	GN/VT	1315	I	—	Right Front Turn Signal Lamp Control	29	0.75	GN/VT	1315	VIII	—
30	—	—	—	—	—	Not Occupied	30	—	—	—	—	—

31	0.5	BN	6305	II	—	Brake Vacuum Switch Signal	31	—	—	—	—	—
32 - 33	—	—	—	—	—	Not Occupied	32 - 33	—	—	—	—	—
34	0.5	BN	3891	II	—	Aero Shutter Control	34	—	—	—	—	—
35	0.5	GY	3890	II	—	Aero Shutter Control 2	35	0.5	GY	3890	VII	—
36	—	—	—	—	—	Not Occupied	36	—	—	—	—	—
37	1.5	YE	712	VI	—	Left Headlamp Low Beam Control	37	1.5	YE	712	X	—
38	1.5	BK	3150	IV	—	Ground	38	1.5	BK	3150	IX	—
39	—	—	—	—	—	Not Occupied	39	—	—	—	—	—
40	1	L-BU/BK	7116	VI	—	Front Axle Differential Lock Control	40	1	L-BU/BK	7116	X	—
41	1	L-BU/WH	7120	VI	—	Rear Axle Differential Lock Control	41	1	L-BU/WH	7120	X	—
42 - 43	—	—	—	—	—	Not Occupied	42 - 43	—	—	—	—	—
44	0.5 0.5	L-BU/WH YE/BK	7120 3000	V II	BPH LCV	Rear Axle Differential Lock Control Coolant Temperature Sensor 2 Signal	44	0.5 0.5	L-BU/WH YE/BK	7120 3000	VII VII	BPH LCV
45	0.5	BK/L-BU	6813	II	—	Coolant Temperature Sensor 2 Low Reference	45	0.5	BK/L-BU	6813	VII	—

						Reference						
46	—	—	—	—	—	Not Occupied	46	—	—	—	—	—
47	0.75	L-BU/WH	1314	II	—	Left Front Turn Signal Lamp Control	47	0.75	L-BU/WH	1314	VII	—
48	1.5	BN	2109	IV	—	Trailer Park Lamp Control	48	1.5	BN	2109	IX	—

X103 Chassis Harness to Power Steering Harness





Connector Part Information

Harness Type: Chassis

OEM Connector: 33472-1606

Service Connector: 13584788

Description: 16-Way F 150 MX Series, Sealed (BK)

Connector Part Information

Harness Type: Power Steering

OEM Connector: 33482-1643

Service Connector: Service by Harness - See Part Catalog

Description: 16-Way M 150 MX Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575868	J-35616-2A (GY)	J-38125-217	Not Available	Not Available	Not Available	Not Available
II	19300635	J-35616-2A (GY)	J-38125-217	Not Available	Not Available	Not Available	Not Available
III	Not Required	J-35616-3 (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X103 Chassis Harness to Power Steering Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.75	VT/BK	2139	II	—	Run/Crank Ignition 1 Voltage	1	0.75	VT/BK	2139	III	—
2	0.5	WH	2501	I	—	High Speed GMLAN	2	0.5	WH	2501	III	—

2	0.5					Serial Data (-) 1	2	0.5			
3	0.5	L-BU	2500	I	—	High Speed GMLAN Serial Data (+) 1	3	0.5	L-BU	2500	III	—
4	0.5	WH	6106	I	—	High Speed GMLAN Serial Data (-) 2	4	0.5	WH	6106	III	—
5	0.5	L-BU/YE	6105	I	—	High Speed GMLAN Serial Data (+) 2	5	0.5	L-BU/YE	6105	III	—
6	0.5	GY/BK	1570	I	—	Front Axle Actuator Control	6	0.5	GY/BK	1570	III	—
7	0.5	RD/BN	5940	I	—	Battery Positive Voltage	7	0.5	RD/BN	5940	III	—
8	0.5	WH/L-BU	5986	I	—	Serial Data Communication Enable	8	0.5	WH/L-BU	5986	III	—
9	0.5	WH	2501	I	—	High Speed GMLAN Serial Data (-) 1	9	0.5	WH	2501	III	—
10	0.5	L-BU	2500	I	—	High Speed GMLAN Serial Data (+) 1	10	0.5	L-BU	2500	III	—
11	0.5	WH	6106	I	—	High Speed GMLAN Serial Data (-) 2	11	0.5	WH	6106	III	—
12	0.5	L-BU/YE	6105	I	—	High Speed GMLAN Serial Data (+) 2	12	0.5	L-BU/YE	6105	III	—
		BK	1450	II	—	Ground			BK	1450	III	—

13	0.75						13	0.75				
14	0.5	YE/WH	1695	I	—	Four Wheel Drive Wheel Lock Indicator Control	14	0.5	YE/WH	1695	III	—
15 - 16	—	—	—	—	—	Not Occupied	15 - 16	—	—	—	—	—

X104 Forward Lamp Harness to Forward Lamp Extension Harness





Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 34062-0038

Service Connector: 19329741

Description: 2-Way F 1.5 Series, Sealed (BK)

Connector Part Information

Harness Type: Forward Lamp Extension

OEM Connector: 34675-0001

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way M 1.5 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-3 (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X104 Forward Lamp Harness to Forward Lamp Extension Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.5	YE/BK	3000	I	—	Coolant Temperature Sensor 2 Signal	1	0.5	YE/BK	3000	II	—
2	0.5	BK/L-BU	6813	I	—	Coolant Temperature Sensor 2 Low Reference	2	0.5	BK/L-BU	6813	II	—

X105 Forward Lamp Harness to Ambient Temperature Sensor Extension Harness (LCV)



—

Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 33472-0607

Service Connector: 19301527

Description: 6-Way F 150 MX Series, Sealed (GY)

Connector Part Information

Harness Type: Ambient Temperature Sensor Extension

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way M

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required

X105 Forward Lamp Harness to Ambient Temperature Sensor Extension Harness (LCV)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.75	BK	1250	I	—	Ground	1	0.75	BK	1250	II	—
2	0.5	WH/VT	4333	I	—	Aero Shutter Actuator Control	2	0.5	WH/VT	4333	II	—
3	0.5	GY	3890	I	—	Aero Shutter Control 2	3	0.5	GY	3890	II	—
4	—	—	—	—	—	Not Occupied	4	—	—	—	—	—
5	0.5	L-BU/GY	636	I	—	Outside Ambient Air Temperature Sensor	5	0.5	L-BU/GY	636	II	—

						Temperature Sensor Signal					
6	0.5	BK/L-BU	61	I	—	Outside Ambient Temperature Sensor Low Reference	6	0.5	BK/L-BU	61	II	—

X105 Forward Lamp Harness to Ambient Temperature Sensor Extension Harness (LGZ)



—

Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 33471-0606

Service Connector: 19303226

Description: 6-Way F 1.5 Series, Sealed (BK)

Connector Part Information

Harness Type: Ambient Temperature Sensor Extension

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way M

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required

X105 Forward Lamp Harness to Ambient Temperature Sensor Extension Harness (LGZ)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.75	BK	1250	I	—	Ground	1	0.75	BK	1250	II	—
2	0.5	WH/VT	4333	I	—	Aero Shutter Actuator Control	2	0.5	WH/VT	4333	II	—
3	0.5	BN	3891	I	—	Aero Shutter Control	3	0.5	BN	3891	II	—
4	—	—	—	—	—	Not Occupied	4	—	—	—	—	—
5	0.5	L-BU/GY	636	I	—	Outside Ambient Air Temperature Sensor	5	0.5	L-BU/GY	636	II	—

						Signal						
6	0.5	BK/L-BU	61	I	—	Outside Ambient Temperature Sensor Low Reference	6	0.5	BK/L-BU	61	II	—

X105 Forward Lamp Harness to Ambient Temperature Sensor Extension Harness (LWN)



—

Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 33472-0607

Service Connector: 19301527

Description: 6-Way F 150 MX Series, Sealed (GY)

Connector Part Information

Harness Type: Ambient Temperature Sensor Extension

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way M

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required

X105 Forward Lamp Harness to Ambient Temperature Sensor Extension Harness (LWN)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1 - 4	—	—	—	—	—	Not Occupied	1 - 4	—	—	—	—	—
5	0.5	L-BU/GY	636	I	—	Outside Ambient Air Temperature Sensor Signal	5	0.5	L-BU/GY	636	II	—
6	0.5	BK/L-BU	61	I	—	Outside Ambient Temperature Sensor Low Reference	6	0.5	BK/L-BU	61	II	—

X106 Body Harness to Chassis Harness (LWN)





Connector Part Information

Harness Type: Body

OEM Connector: 15509587

Service Connector: 19119963

Description: 48-Way F 1.5 MCP, 2.8 JPT, 6.3 MCP Series, Sealed (GY)

Connector Part Information

Harness Type: Chassis

OEM Connector: 15513437

Service Connector: 13586850

Description: 48-Way M 1.6, 2.8, 5.8 Series, Sealed (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13579921	J-35616-40 (BU)	J-38125-556	Not Available	Not Available	Not Available	Not Available
II	13580821	J-35616-4A (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
III	19119381	J-35616-14 (GN)	J-38125-215A	Not Available	Not Available	Not Available	Not Available
IV	19301757	J-35616-40 (BU)	J-38125-556	1241408-1	Lear 28	A	B
V	19301757	J-35616-40 (BU)	J-38125-556	1241408-1	Lear 28	B	G
VI	19301757	J-35616-40 (BU)	J-38125-556	Not Available	Not Available	Not Available	Not Available
VII	19330701	J-35616-14 (GN)	J-38125-215A	Not Available	Not Available	Not Available	Not Available
VIII	19353349	J-35616-40 (BU)	J-38125-556	1241408-1	Lear 28	B	G
IX	13327190	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available
X	13575376	J-35616-43 (RD)	J-38125-557	Not Available	Not Available	Not Available	Not Available

X	[illegible]	[illegible]	[illegible]	Not Available	Not Available	Not Available	Not Available
XI	13575574	J-35616-5 (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
XII	19119926	J-35616-43 (RD)	J-38125-36	Not Available	Not Available	Not Available	Not Available
XIII	19301750	J-35616-32 (OR)	J-38125-36	Not Available	Not Available	Not Available	Not Available
XIV	19331731	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available

X106 Body Harness to Chassis Harness (LWN)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	4	RD/GY	1042	V	—	Battery Positive Voltage	1	4	RD/GY	1042	X	—
2	2.5	RD/YE	442	II	—	Battery Positive Voltage	2	2.5	RD/YE	442	XI	—
3	0.75	GY	1624	III	—	Trailer Backup Lamp Control	3	0.75	GY	1624	IX	—
4	0.75	GN	1619	III	—	Right Rear Trailer Stop/Turn Lamp Control	4	0.75	GN	1619	IX	—
5	0.75	YE	1618	III	—	Left Rear Trailer Stop/Turn Lamp Control	5	0.75	YE	1618	IX	—
6	0.5	BN/GY	2609	III	—	Right Rear Park Lamp Control	6	1.5	BN/GY	2609	XIV	—
7	0.5	GN/WH	24	III	—	Backup Lamp Control	7	0.5	GN/WH	24	IX	—
8	0.5	GN/YE	6846	III	—	Rear License Lamp Control	8	0.5	GN/YE	6846	IX	—
9	0.5	GN/BK	7633	III	LWB	Integrated Trailer Brake Controller User Gain Signal	9	0.5	GN/BK	7633	IX	LWB

	0.5	VT/YE	5985	III	SWB	Signal Accessory Wakeup Serial Data		0.5	VT/YE	5985	IX	SWB
10	0.75	VT/BK	2139	III	—	Run/Crank Ignition 1 Voltage	10	0.75	VT/BK	2139	IX	—
11	0.75	BK	1450	I	—	Ground	11	0.75	BK	1450	XIII	—
12	1.5	GY/YE	7542	VII	—	Left Rear Stop Lamp Control	12	1.5	GY/YE	7542	XIV	—
13	0.5	VT/GN	1739	III	—	Run/Crank Ignition 1 Voltage	13	0.5	VT/GN	1739	IX	—
14	0.5	BN/L-BU	2509	III	—	Left Rear Park Lamp Control	14	1.5	BN/L-BU	2509	XIV	—
15	1.5	WH/YE	7541	VII	—	Right Rear Stop Lamp Control	15	1.5	WH/YE	7541	XIV	—
16	0.75	VT/GY	139	III	—	Run/Crank Ignition 1 Voltage	16	0.75	VT/GY	139	IX	—
17	0.5 0.75	L-BU/RD VT/GY	7632 139	III III	LWB SWB	Integrated Trailer Brake Controller Switch 5V Reference Run/Crank Ignition 1 Voltage	17	0.5	L-BU/RD	7632	IX	LWB
18	0.5	YE	7635	III	—	Integrated Trailer Brake Controller Manual Apply Signal	18	0.5	YE	7635	IX	—

19	0.5	WH	2501	III	—	High Speed GMLAN Serial Data (-) 1	19	0.5	WH	2501	IX	—
20	2.5	RD/VT	1940	II	—	Battery Positive Voltage	20	2.5	RD/VT	1940	XI	—
21	0.5	RD/BN	5940	III	—	Battery Positive Voltage	21	0.5	RD/BN	5940	IX	—
22	0.5	BK/GN	6281	III	—	Fuel Level Sensor Low Reference	22	0.5	BK/GN	6281	IX	SWB
23	0.5 0.5	L-BU/VT L-BU/WH	1589 890	III III	LWB SWB	Primary Fuel Level Sensor Signal Fuel Tank Pressure Sensor Signal	23	0.5 0.5	L-BU/VT L-BU/WH	1589 890	IX IX	LWB SWB
24	0.5 0.5	RD/GN YE/RD	2440 2709	III III	LWB SWB	Battery Positive Voltage Fuel Tank Pressure Sensor 5V Reference	24	0.5 0.5	RD/GN YE/RD	2440 2709	IX IX	LWB SWB
25	0.5 0.5 0.5	BK/GN BN BN	6281 6305 7634	III III III	LCV LWB LWN	Fuel Level Sensor Low Reference Brake Vacuum Switch Signal Integrated Trailer Brake Controller Redundant Manual Apply Signal	25	0.5 0.5 0.5	BK/GN BN BN	6281 6305 7634	IX IX IX	LCV LWB LWN
26	0.5	WH/L-BU	5986	III	—	Serial Data Communication Enable	26	0.5	WH/L-BU	5986	IX	—

26	0.5					Communication Enable	26	0.5				
27	0.5 0.5	BK/BN GN/GY	7631 465	III III	LWB SWB	Integrated Trailer Brake Controller Switch Low Reference Fuel Pump Primary Relay Control	27	0.5	BK/BN	7631	IX	LWB
28	0.5	L-BU	2500	III	—	High Speed GMLAN Serial Data (+) 1	28	0.5	L-BU	2500	IX	—
29	2.5	RD/GN	242	II	—	Battery Positive Voltage	29	2.5	RD/GN	242	XI	—
30	0.5	GY/BK	1570	III	—	Front Axle Actuator Control	30	0.5	GY/BK	1570	IX	—
31	0.5	YE/WH	1695	III	—	Four Wheel Drive Wheel Lock Indicator Control	31	0.5	YE/WH	1695	IX	—
32	0.5 0.5	L-BU/VT VT/BK	1589 7121	III III	LCV/LGZ LWN	Primary Fuel Level Sensor Signal Rear Axle Differential Lock Low Reference	32	0.5	L-BU/VT	1589	IX	—
33	0.5 0.5	RD/GN VT/YE	2440 5985	III III	LCV/LGZ LWN	Battery Positive Voltage Accessory Wakeup Serial Data	33	0.5 0.5	RD/GN VT/YE	2440 5985	IX IX	LCV/LGZ LWN
34	0.5	WH L-BU/WH	1310 7120	VI VI	LCV/LGZ LWN	EVAP Canister Vent Solenoid Control	34	0.5	WH	1310	IX	—

	0.5	L-BU/WH	7120	VI	LWN	Rear Axle Differential Lock Control						
35	0.5 0.5	L-BU/BK GN/BK	7493 7118	III III	LCV/LGZ LWN	High Speed GMLAN Serial Data (+)3 Front Axle Differential Lock Low Reference	35	0.5	L-BU/BK	7493	IX	—
36	0.5 0.5	WH L-BU/BK	7494 7116	III III	LCV/LGZ LWN	High Speed GMLAN Serial Data (-)3 Front Axle Differential Lock Control	36	0.5	WH	7494	IX	—
37	0.5	L-BU/YE	6105	III	—	High Speed GMLAN Serial Data (+) 2	37	0.5	L-BU/YE	6105	IX	—
38	4	OG	742	VIII	—	Battery Positive Voltage	38	4	OG	742	X	—
39	1.5	BN	2109	II	—	Trailer Park Lamp Control	39	1.5	BN	2109	XI	—
40	0.5	GN	6974	III	—	Camera Low Reference	40	0.5	GN	6974	IX	—
41	0.5	GY/YE	6972	III	—	Camera Signal 2 +	41	0.5	GY/YE	6972	IX	—
42	0.5	WH/L-BU	6973	III	—	Camera Signal 2	42	0.5	WH/L-BU	6973	IX	—
		BK/YE	7447	III	LCV/LGZ	Fuel Line Pressure			BK/YE	7447	IX	—

43	0.5 0.5	BK/YE VT/GY	7447 7117	III III	LCV/LGZ LWN	Fuel Line Pressure Sensor Low Reference Front Axle Differential Lock Indicator Control	43	0.5	BK/YE	7447	IX	—
44	0.5 0.5	L-BU/WH YE/GN	7446 7122	III III	LCV/LGZ LWN	Fuel Line Pressure Sensor Signal Axle Differential Lock Switch Signal	44	0.5	L-BU/WH	7446	IX	—
45	0.5 0.5	BN/RD GN/RD	7445 7119	III III	LCV/LGZ LWN	Fuel Line Pressure Sensor 5V Reference Axle Differential Lock Mode Switch 5V Reference	45	0.5	BN/RD	7445	IX	—
46	0.5	WH	6106	III	—	High Speed GMLAN Serial Data (-) 2	46	0.5	WH	6106	IX	—
47	0.5 0.75	YE WH/VT	7115 1430	III III	LWN SOY	Rear Axle Differential Lock Indicator Control Exterior Courtesy Lamp Control	47	0.75	WH/VT	1430	IX	—
48	2.5 2.5 2.5	L-BU RD/VT GY	47 1940 120	IV IV IV	LCV LGZ LWN	Trailer Auxiliary Control Battery Positive Voltage Fuel Pump Control	48	2.5 2.5	L-BU GY	47 120	XII XII	LCV LWN

X106 Body Harness to Chassis Harness (SWB)





Connector Part Information

Harness Type: Body

OEM Connector: 15509587

Service Connector: 19119963

Description: 48-Way F 1.5 MCP, 2.8 JPT, 6.3 MCP Series, Sealed (GY)

Connector Part Information

Harness Type: Chassis

OEM Connector: 13586850

Service Connector: 13586850

Description: 48-Way M 1.6, 2.8, 5.8 Series, Sealed (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13579921	J-35616-40 (BU)	J-38125-556	Not Available	Not Available	Not Available	Not Available
II	13580821	J-35616-4A (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
III	19119381	J-35616-14 (GN)	J-38125-215A	Not Available	Not Available	Not Available	Not Available
IV	19301757	J-35616-40 (BU)	J-38125-556	1241408-1	Lear 28	A	B
V	19330701	J-35616-14 (GN)	J-38125-215A	Not Available	Not Available	Not Available	Not Available
VI	19353349	J-35616-40 (BU)	J-38125-556	1241408-1	Lear 28	B	G
VII	13327190	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available
VIII	13575376	J-35616-43 (RD)	J-38125-557	Not Available	Not Available	Not Available	Not Available
IX	13575574	J-35616-5 (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
X	19119926	J-35616-43 (RD)	J-38125-36	Not Available	Not Available	Not Available	Not Available

X	[illegible]	[illegible]	[illegible]	Not Available	Not Available	Not Available	Not Available
XI	19301750	J-35616-32 (OR)	J-38125-36	Not Available	Not Available	Not Available	Not Available
XII	19331731	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available

X106 Body Harness to Chassis Harness (SWB)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	4	RD/GY	1042	VI	—	Battery Positive Voltage	1	4	RD/GY	1042	VIII	—
2	2.5	RD/YE	442	II	—	Battery Positive Voltage	2	2.5	RD/YE	442	IX	—
3	0.75	GY	1624	III	—	Trailer Backup Lamp Control	3	0.75	GY	1624	VII	—
4	0.75	GN	1619	III	—	Right Rear Trailer Stop/Turn Lamp Control	4	0.75	GN	1619	VII	—
5	0.75	YE	1618	III	—	Left Rear Trailer Stop/Turn Lamp Control	5	0.75	YE	1618	VII	—
6	0.5	BN/GY	2609	III	—	Right Rear Park Lamp Control	6	1.5	BN/GY	2609	XII	—
7	0.5	GN/WH	24	III	—	Backup Lamp Control	7	0.5	GN/WH	24	VII	—
8	0.5	GN/YE	6846	III	—	Rear License Lamp Control	8	0.5	GN/YE	6846	VII	—
9	0.5 0.5	VT/YE GN/BK	5985 7633	III III	LCV/LGZ LWN	Accessory Wakeup Serial Data Integrated Trailer Brake Controller User Gain Signal	9	0.5 0.5	VT/YE GN/BK	5985 7633	VII VII	LCV/LGZ LWN

	0.5					Signal		0.5				
10	0.75	VT/BK	2139	III	—	Run/Crank Ignition 1 Voltage	10	0.75	VT/BK	2139	VII	—
11	0.75	BK	1450	I	—	Ground	11	0.75	BK	1450	XI	—
12	1.5	GY/YE	7542	V	—	Left Rear Stop Lamp Control	12	1.5	GY/YE	7542	XII	—
13	0.5	VT/GN	1739	III	—	Run/Crank Ignition 1 Voltage	13	0.5	VT/GN	1739	VII	—
14	0.5	BN/L-BU	2509	III	—	Left Rear Park Lamp Control	14	1.5	BN/L-BU	2509	XII	—
15	1.5	WH/YE	7541	V	—	Right Rear Stop Lamp Control	15	1.5	WH/YE	7541	XII	—
16	0.75	VT/GY	139	III	—	Run/Crank Ignition 1 Voltage	16	0.75	VT/GY	139	VII	—
17	0.75 0.5	VT/GY L-BU/RD	139 7632	III III	LGZ-BPH LWN	Run/Crank Ignition 1 Voltage Integrated Trailer Brake Controller Switch 5V Reference	17	0.75 0.5	VT/GY L-BU/RD	139 7632	VII VII	LGZ-BPH LWN
18	0.5	YE	7635	III	—	Integrated Trailer Brake Controller Manual Apply Signal	18	0.5	YE	7635	VII	—
19	0.5	WH	2501	III	—	High Speed GMLAN Serial Data (-) 1	19	0.5	WH	2501	VII	—

20	2.5	RD/VT	1940	II	—	Battery Positive Voltage	20	2.5	RD/VT	1940	IX	—
21	0.5	RD/BN	5940	III	—	Battery Positive Voltage	21	0.5	RD/BN	5940	VII	—
22	0.5	BK/GN	6281	III	—	Fuel Level Sensor Low Reference	22	0.5	BK/GN	6281	VII	—
23	0.5 0.5	L-BU/VT L-BU/WH	1589 890	III III	— —	Primary Fuel Level Sensor Signal Fuel Tank Pressure Sensor Signal	23	0.5 0.5	L-BU/VT L-BU/WH	1589 890	VII VII	— —
24	0.5 0.5	RD/GN YE/RD	2440 2709	III III	— —	Battery Positive Voltage Fuel Tank Pressure Sensor 5V Reference	24	0.5 0.5	RD/GN YE/RD	2440 2709	VII VII	— —
25	0.5 0.5	BK BN	6305 7634	III III	— —	Brake Vacuum Switch Signal Integrated Trailer Brake Controller Redundant Manual Apply Signal	25	0.5 0.5	BN BN	6305 7634	VII VII	— —
26	0.5	WH/L-BU	5986	III	—	Serial Data Communication Enable	26	0.5	WH/L-BU	5986	VII	—
27	0.5	GN/GY BK/BN	465 7631	III III	— —	Fuel Pump Primary Relay Control Integrated Trailer Brake	27	0.5	GN/GY BK/BN	465 7631	VII VII	— —

	0.5					Integrated Trailer Brake Controller Switch Low Reference		0.5			
28	0.5	L-BU	2500	III	—	High Speed GMLAN Serial Data (+) 1	28	0.5	L-BU	2500	VII
29	2.5	RD/GN	242	II	—	Battery Positive Voltage	29	2.5	RD/GN	242	IX
30	0.5	GY/BK	1570	III	—	Front Axle Actuator Control	30	0.5	GY/BK	1570	VII
31	0.5	YE/WH	1695	III	—	Four Wheel Drive Wheel Lock Indicator Control	31	0.5	YE/WH	1695	VII
32	0.5	L-BU/VT	1589	III	—	Primary Fuel Level Sensor Signal	32	0.5 0.5	VT/BK L-BU/VT	7121 1589	VII VII
33	0.5 0.5	RD/GN VT/YE	2440 5985	III III	— —	Battery Positive Voltage Accessory Wakeup Serial Data	33	0.5 0.5	RD/GN VT/YE	2440 5985	VII VII
34	0.5	WH	1310	III	—	EVAP Canister Vent Solenoid Control	34	0.5 0.5	WH L-BU/WH	1310 7120	VII VII
35	0.5	L-BU/BK	7493	III	—	High Speed GMLAN Serial Data (+)3	35	0.5	L-BU/BK	7493	VII

								0.5	GN/BK	7118	VII	—
36	0.5	WH	7494	III	—	Front Axle Differential Lock Control High Speed GMLAN Serial Data (-)3	36	0.5 0.5	L-BU/BK WH	7116 7494	VII VII	— —
37	0.5	L-BU/YE	6105	III	—	High Speed GMLAN Serial Data (+) 2	37	0.5	L-BU/YE	6105	VII	—
38	4	OG	742	VI	—	Battery Positive Voltage	38	4	OG	742	VIII	—
39	1.5	BN	2109	II	—	Trailer Park Lamp Control	39	1.5	BN	2109	IX	—
40	0.5	GN	6974	III	—	Camera Low Reference	40	0.5	GN	6974	VII	—
41	0.5	GY/YE	6972	III	—	Camera Signal 2 +	41	0.5	GY/YE	6972	VII	—
42	0.5	WH/L-BU	6973	III	—	Camera Signal 2	42	0.5	WH/L-BU	6973	VII	—
43	0.5	BK/YE	7447	III	—	Fuel Line Pressure Sensor Low Reference	43	0.5 0.5	BK/YE VT/GY	7447 7117	VII VII	— —

44	0.5	L-BU/WH	7446	III	—	Fuel Line Pressure Sensor Signal	44	0.5 0.5	YE/GN L-BU/WH	7122 7446	VII VII	— —
45	0.5	BN/RD	7445	III	—	Axle Differential Lock Mode Switch 5V Reference Fuel Line Pressure Sensor 5V Reference	45	0.5 0.5	GN/RD BN/RD	7119 7445	VII VII	— —
46	0.5	WH	6106	III	—	High Speed GMLAN Serial Data (-) 2	46	0.5	WH	6106	VII	—
47	0.75	WH/VT	1430	III	—	Rear Axle Differential Lock Indicator Control Exterior Courtesy Lamp Control	47	0.5 0.75	YE WH/VT	7115 1430	VII VII	— —
48	2.5 2.5 2.5	GY RD/VT L-BU	120 1940 47	IV IV IV	— — —	Fuel Pump Control Battery Positive Voltage Trailer Auxiliary Control	48	2.5 2.5 2.5	GY RD/VT L-BU	120 1940 47	X X X	— — —

X107 Engine Harness to Chassis Harness





Connector Part Information

Harness Type: Engine

OEM Connector: 15509585

Service Connector: 19329744

Description: 48-Way F 1.5 MCP, 2.8 JPT, 6.3 MCP Series, Sealed (BK)

Connector Part Information

Harness Type: Chassis

OEM Connector: 13937571

Service Connector: 19329745

Description: 48-Way M 1.6, 2.8, 5.8 Series, Sealed (YE)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13579921	J-35616-40 (BU)	J-38125-556	Not Available	Not Available	Not Available	Not Available
II	13579986	J-35616-4A (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
III	13580830	J-35616-35 (VT)	J-38125-36	Not Available	Not Available	Not Available	Not Available
IV	19119381	J-35616-14 (GN)	J-38125-215A	Not Available	Not Available	Not Available	Not Available
V	19301757	J-35616-40 (BU)	J-38125-556	1241408-1	Lear 28	C	A
VI	19330701	J-35616-14 (GN)	J-38125-215A	Not Available	Not Available	Not Available	Not Available
VII	19353349	J-35616-40 (BU)	J-38125-556	1241408-1	Lear 28	B	G
VIII	13327190	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available
IX	13575376	J-35616-43 (RD)	J-38125-557	Not Available	Not Available	Not Available	Not Available
X	13575574	J-35616-5 (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available

X	[illegible]	[illegible]	[illegible]	Not Available	Not Available	Not Available	Not Available
XI	13581368	J-35616-5 (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
XII	19119926	J-35616-43 (RD)	J-38125-36	Not Available	Not Available	Not Available	Not Available
XIII	19301750	J-35616-32 (OR)	J-38125-36	Not Available	Not Available	Not Available	Not Available
XIV	19331731	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available

X107 Engine Harness to Chassis Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	1.5	VT/L-BU	3674	V	—	NOx Sensor 1 Control	1	1.5	VT/L-BU	3674	XII	—
2	0.5	BN/L-BU	2926	III	—	Hydrocarbon Injector High Control	2	0.5	BN/L-BU	2926	XI	—
3	0.5	VT/BN	2927	IV	—	Hydrocarbon Injector Low Control	3	0.5	VT/BN	2927	VIII	—
4	—	—	—	—	—	Not Occupied	4	—	—	—	—	—
5	0.75	VT/GY	139	IV	—	Run/Crank Ignition 1 Voltage	5	0.75	VT/GY	139	VIII	—
6	0.5	L-BU/YE	6861	IV	—	Water In Fuel Sensor Signal	6	0.5	L-BU/YE	6861	VIII	—
7	1.5	VT/L-BU	3674	VI	—	NOx Sensor 1 Control	7	1.5	VT/L-BU	3674	XIV	—
8 - 9	—	—	—	—	—	Not Occupied	8 - 9	—	—	—	—	—
10	0.5	WH/RD	6054	IV	—	Exhaust Pressure Sensor 5V Reference 1	10	0.5	WH/RD	6054	VIII	—
11	0.5	BK/YE	6055	I	—	Exhaust Pressure Sensor Low Reference 1	11	0.5	BK/YE	6055	XIII	—

12	0.5	L-BU	6053	IV	—	Exhaust Pressure Sensor Signal 1	12	0.5	L-BU	6053	VIII	—
13	0.5	VT/GN	4320	IV	—	Selective Catalytic Reduction Power Module Wake-Up Signal	13	0.5	VT/GN	4320	VIII	—
14	0.5	BK/L-BU	6783	IV	—	Exhaust Gas Temperature Sensor 2 Low Reference	14	0.5	BK/L-BU	6783	VIII	—
15	0.5	L-BU/GN	5377	IV	—	Exhaust Gas Temperature Sensor 2	15	0.5	L-BU/GN	5377	VIII	—
16 - 17	—	—	—	—	—	Not Occupied	16 - 17	—	—	—	—	—
18	0.5	BK/GN	3657	IV	—	Exhaust Gas Temperature Sensor 3 Low Reference	18	0.5	BK/GN	3657	VIII	—
19	0.5	GY/GN	5378	IV	—	Exhaust Gas Temperature Sensor 3	19	0.5	GY/GN	5378	VIII	—
20	0.5	BK/GY	3659	III	—	Exhaust Gas Temperature Sensor 4 Low Reference	20	0.5	BK/GY	3659	XI	—
21	0.5	VT/BN	3658	IV	—	Exhaust Gas Temperature Sensor 4 Signal	21	0.5	VT/BN	3658	VIII	—
22	0.5	BK/VT	3661	IV	—	Exhaust Gas Temperature Sensor 5 Low Reference	22	0.5	BK/VT	3661	VIII	—
23	0.5	L-BU/GY	3660	IV	—	Exhaust Gas Temperature Sensor 5 Signal	23	0.5	L-BU/GY	3660	VIII	—
24 - 27	—	—	—	—	—	Not Occupied	24 - 27	—	—	—	—	—

28	0.5	L-BU/BN	4498	IV	—	High Speed GMLAN Serial Data (+) 7	28	0.5	L-BU/BN	4498	VIII	—
29	0.5	WH	4499	III	—	High Speed GMLAN Serial Data (-) 7	29	0.5	WH	4499	XI	—
30	0.5	BN/GY	7072	IV	—	Sensor Fuel Temperature 1 Signal	30	0.5	BN/GY	7072	VIII	—
31	0.5	BN/WH	7073	IV	—	Sensor Fuel Temperature 1 Low Reference	31	0.5	BN/WH	7073	VIII	—
32 - 37	—	—	—	—	—	Not Occupied	32 - 37	—	—	—	—	—
38	4	L-BU	3921	VII	—	DEF Heater Supply 1	38	4	L-BU	3921	IX	—
39	2.5	L-BU/GN	7071	II	—	Heater Fuel Control	39	2.5	L-BU/GN	7071	X	—
40 - 48	—	—	—	—	—	Not Occupied	40 - 48	—	—	—	—	—

X108 Engine Harness to Cooling Fan Harness (LWN)



—

Connector Part Information

Harness Type: Engine

OEM Connector: 33472-0606

Service Connector: 13585853

Description: 6-Way F 150 MX Series, Sealed (BK)

Connector Part Information

Harness Type: Cooling Fan

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way M

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required

X108 Engine Harness to Cooling Fan Harness (LWN)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	—	—	—	—	—	Not Occupied	1	—	—	—	—	—
2	0.5	WH	2368	I	—	Cooling Fan Control Signal	2	0.5	WH	2368	II	—
3	0.5	GY/RD	2365	I	—	Cooling Fan Speed 5V Reference	3	0.5	GY/RD	2365	II	—
4	0.5	L-BU/VT	2364	I	—	Cooling Fan Speed Signal	4	0.5	L-BU/VT	2364	II	—
5	0.5	BK/BN	6141	I	—	Cooling Fan Speed Low Reference	5	0.5	BK/BN	6141	II	—

[illegible]	0.5					Reference	[illegible]	0.5			
6	0.5	BK	550	I	—	Ground	6	0.5	BK	550	II	—

X109 Engine Harness to Forward Lamp Harness





Connector Part Information

Harness Type: Engine

OEM Connector: 7283-3108-10

Service Connector: 13501883

Description: 4-Way F 6.3 Series, Sealed (D-GY)

Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 7282-5595-10

Service Connector: 13585864

Description: 4-Way M 6.3 Series, Sealed (D-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-42 (RD)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-43 (RD)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X109 Engine Harness to Forward Lamp Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	6	BN/L-BU	104	I	—	Glow Plug Control	1	4	BN/L-BU	104	II	—
2	4	L-BU	3921	I	—	DEF Heater Supply 1	2	4	L-BU	3921	II	—

3	2.5	L-BU/GN	7071	I	—	Heater Fuel Control	3	2.5	L-BU/GN	7071	II	—
4	—	—	—	—	—	Not Occupied	4	—	—	—	—	—

X110 Forward Lamp Harness to Left Front Lamp Harness



—

Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 33472-0606

Service Connector: 13585853

Description: 6-Way F 150 MX Series, Sealed (BK)

Connector Part Information

Harness Type: Left Front Lamp

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way M

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required

X110 Forward Lamp Harness to Left Front Lamp Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	1.5	BK	1150	I	—	Ground	1	1.5	BK	1150	II	—
2	1.5	YE	712	I	—	Left Headlamp Low Beam Control	2	1.5	YE	712	II	—
3	0.5	WH	711	I	—	Left Headlamp High Beam Control	3	0.5	WH	711	II	—
4	0.75	VT/GY	709	I	—	Left Park Lamp Control	4	0.75	VT/GY	709	II	—

5	0.75	L-BU/WH	1314	I	—	Left Front Turn Signal Lamp Control	5	0.75	L-BU/WH	1314	II	—
6	—	—	—	—	—	Not Occupied	6	—	—	—	—	—

X111 Engine Harness to Glow Plug Harness (LWN)



—

Connector Part Information

Harness Type: Engine

OEM Connector: 184248-1

Service Connector: 13587793

Description: 4-Way F SSC Series (BK)

Connector Part Information

Harness Type: Glow Plug

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 4-Way M

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-33 (YE)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required

X111 Engine Harness to Glow Plug Harness (LWN)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	2	GY/L-BU	1581	I	—	Glow Plug Control 1	1	2	GY/L-BU	1581	II	—
2	2	GY/BN	1582	I	—	Glow Plug Control 2	2	2	GY/BN	1582	II	—
3	2	GY/GN	1583	I	—	Glow Plug Control 3	3	2	GY/L-GN	1583	II	—
4	2	GY/YE	1584	I	—	Glow Plug Control 4	4	2	GY/YE	1584	II	—

X114 Engine Harness to Coolant Temp Sensor Jumper Harness





—

Connector Part Information

Harness Type: Engine

OEM Connector: 1-2203312-1

Service Connector: 19330898

Description: 2-Way F 1.2 MCON Series, Sealed (BK)

Connector Part Information

Harness Type: Coolant Temp Sensor Jumper

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way M

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required

X114 Engine Harness to Coolant Temp Sensor Jumper Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.5	L-BU	410	I	—	Engine Coolant Temperature Sensor Signal	1	0.5	L-BU	410	II	—
2	0.5	BK/BN	2761	I	—	Coolant Temperature Sensor Low Reference	2	0.5	BK/BN	2761	II	—

X119 Engine Harness to Body Harness (NQ6+LGZ)





Connector Part Information

Harness Type: Engine

OEM Connector: 10010346

Service Connector: 13587299

Description: 4-Way F 1.2 Multilock Series, Sealed (BK)

Connector Part Information

Harness Type: Body

OEM Connector: 10013906

Service Connector: 19354931

Description: 4-Way M 1.2 Multilock Series (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-13 (BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X119 Engine Harness to Body Harness (NQ6+LGZ)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.5	WH/RD	7477	I	—	Rotary Position Sensor 5V Reference	1	0.5	WH/RD	7477	II	—
2	0.5	WH/GN	7479	I	—	Rotary Position Sensor Signal	2	0.5	WH/GN	7479	II	—

3	0.5	YE/BK	7478	I	—	Rotary Position Sensor Low Reference	3	0.5	YE/BK	7478	II	—
4	—	—	—	—	—	Not Occupied	4	—	—	—	—	—

X120 Forward Lamp Harness to Right Front Lamp Harness



—

Connector Part Information

Harness Type: Forward Lamp

OEM Connector: 33472-0606

Service Connector: 13585853

Description: 6-Way F 150 MX Series, Sealed (BK)

Connector Part Information

Harness Type: Right Front Lamp

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way M

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required

X120 Forward Lamp Harness to Right Front Lamp Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	1.5	BK	1250	I	—	Ground	1	1.5	BK	1250	II	—
2	1.5	YE	312	I	—	Right Headlamp Low Beam Control	2	1.5	YE	312	II	—
3	0.75	WH	311	I	—	Right Headlamp High Beam Control	3	0.75	WH	311	II	—
4	0.75	GY/BN	309	I	—	Right Park Lamp Control	4	0.75	GY/BN	309	II	—

5	0.75	GN/VT	1315	I	—	Right Front Turn Signal Lamp Control	5	0.75	L-GN/VT	1315	II	—
6	—	—	—	—	—	Not Occupied	6	—	—	—	—	—

X122 Body Harness to Chassis Harness (LWN)





Connector Part Information

Harness Type: Body

OEM Connector: 0-1452327-1

Service Connector: 19332889

Description: 6-Way F 2.8 Junior Power Timer Series, Sealed (BK)

Connector Part Information

Harness Type: Chassis

OEM Connector: 1452324-1

Service Connector: 93185233

Description: 6-Way M 2.8 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-17 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-5 (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X122 Body Harness to Chassis Harness (LWN)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	1	VT/BK	7121	I	—	Rear Axle Differential Lock Low Reference	1	1	VT/BK	7121	II	—
2	1	L-BU/WH	7120	I	—	Rear Axle Differential Lock Control	2	1	L-BU/WH	7120	II	—

3	—	—	—	—	—	Not Occupied	3	—	—	—	—	—
4	1	GN/BK	7118	I	—	Front Axle Differential Lock Low Reference	4	1	GN/BK	7118	II	—
5	1	L-BU/BK	7116	I	—	Front Axle Differential Lock Control	5	1	L-BU/BK	7116	II	—
6	0.75	WH/VT	1430	I	—	Exterior Courtesy Lamp Control	6	0.75	WH/VT	1430	II	—

X123 Chassis Harness to Body Harness (JL1)





Connector Part Information

Harness Type: Chassis

OEM Connector: 34900-6010

Service Connector: 19330684

Description: 6-Way F 1.2 MCON Series, Sealed (YE)

Connector Part Information

Harness Type: Body

OEM Connector: 34899-6010

Service Connector: 19354932

Description: 6-Way M 1.2 MCON Series, Sealed (YE)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-13 (BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X123 Chassis Harness to Body Harness (JL1)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.5	L-BU/RD	7632	I	—	Integrated Trailer Brake Controller Switch 5V Reference	1	0.5	L-BU/RD	7632	II	—
2	0.5	BK/BN	7631	I	—	Integrated Trailer Brake Controller Switch Low Reference	2	0.5	BK/BN	7631	II	—

3	0.5	GN/BK	7633	I	—	Integrated Trailer Brake Controller User Gain Signal	3	0.5	GN/BK	7633	II	—
4	0.5	BN	7634	I	—	Integrated Trailer Brake Controller Redundant Manual Apply Signal	4	0.5	BN	7634	II	—
5	0.5	VT/YE	5985	I	—	Accessory Wakeup Serial Data	5	0.5	VT/YE	5985	II	—
6	—	—	—	—	—	Not Occupied	6	—	—	—	—	—

X124 Body Harness to Chassis Harness (BPH)





Connector Part Information

Harness Type: Body

OEM Connector: 13674800

Service Connector: 19300480

Description: 23-Way F 1.5 DSQ, 2.8 AST Series, Sealed (BK)

Connector Part Information

Harness Type: Chassis

OEM Connector: 13674783

Service Connector: 19303858

Description: 23-Way M 1.5 DSQ, 2.8 AST Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13576369	J-35616-14 (GN)	J-38125-560	Not Available	Not Available	Not Available	Not Available
II	13580830	J-35616-4A (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
III	13580834	J-35616-14 (GN)	J-38125-560	60000641	AFL 21	2	5
IV	19329758	J-35616-16 (LT GN)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
V	13327190	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available
VI	13581368	J-35616-5 (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
VII	19331731	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available

X124 Body Harness to Chassis Harness (BPH)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option

1	1	L-BU/WH	7120	II	—	Rear Axle Differential Lock Control	1	1	L-BU/WH	7120	VI	—
2	—	—	—	—	—	Not Occupied	2	—	—	—	—	—
3	0.5	L-BU/WH	7120	I	—	Rear Axle Differential Lock Control	3	0.5	L-BU/WH	7120	V	—
4	0.5	VT/BK	7121	I	—	Rear Axle Differential Lock Low Reference	4	0.5	VT/BK	7121	V	—
5	—	—	—	—	—	Not Occupied	5	—	—	—	—	—
6	0.5	L-BU/RD	7632	I	—	Integrated Trailer Brake Controller Switch 5V Reference	6	0.5	L-BU/RD	7632	V	—
7	0.5	GN/BK	7633	I	—	Integrated Trailer Brake Controller User Gain Signal	7	0.5	GN/BK	7633	V	—
8	0.5	BN	7634	I	—	Integrated Trailer Brake Controller Redundant Manual Apply Signal	8	0.5	BN	7634	V	—
9	1	VT/BK	7121	III	—	Rear Axle Differential Lock Low Reference	9	1	VT/BK	7121	VII	—
10	—	—	—	—	—	Not Occupied	10	—	—	—	—	—
11	0.5	L-BU/BK	7116	I	—	Front Axle Differential Lock Control	11	0.5	L-BU/BK	7116	V	—
12	0.5	GN/BK	7118	I	—	Front Axle Differential Lock Low Reference	12	0.5	GN/BK	7118	V	—
13	0.5	GN/RD	7119	I	—	Axle Differential Lock Mode Switch 5V Reference	13	0.5	GN/BK	7119	V	—

14	0.5	VT/YE	5985	I	—	Accessory Wakeup Serial Data	14	0.5	VT/YE	5985	V	—
15	0.5	BK/BN	7631	I	—	Integrated Trailer Brake Controller Switch Low Reference	15	0.5	BK/BN	7631	V	—
16	1	L-BU/BK	7116	II	—	Front Axle Differential Lock Control	16	1	L-BU/BK	7116	VI	—
17	1	GN/BK	7118	III	—	Front Axle Differential Lock Low Reference	17	1	GN/BK	7118	VII	—
18 - 20	—	—	—	—	—	Not Occupied	18 - 20	—	—	—	—	—
21	0.5	YE/GN	7122	I	—	Axle Differential Lock Switch Signal	21	0.5	YE/GN	7122	V	—
22	0.5	YE	7115	I	—	Rear Axle Differential Lock Indicator Control	22	0.5	YE	7115	V	—
23	0.5	VT/GY	7117	IV	—	Front Axle Differential Lock Indicator Control	23	0.5	VT/GY	7117	V	—

X160 Engine Harness to Fuel Injector Harness (LCV)



—

Connector Part Information

Harness Type: Engine

OEM Connector: 33472-1216

Service Connector: 19150019

Description: 12-Way F 150 MX Series, Sealed (BK)

Connector Part Information

Harness Type: Fuel Injector

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 12-Way M

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	19300635	J-35616-2A (GY)	J-38125-217	Not Available	Not Available	Not Available	Not Available
II	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required

X160 Engine Harness to Fuel Injector Harness (LCV)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.75	BN	4801	I	—	Direct Fuel Injector (DFI) High Voltage Control Cylinder 1	1	0.75	BN	4801	II	—
2	0.75	L-BU	4802	I	—	Direct Fuel Injector (DFI) High Voltage Control Cylinder 2	2	0.75	L-BU	4802	II	—
3	0.75	GN	4803	I	—	Direct Fuel Injector (DFI) High Voltage Control Cylinder 3	3	0.75	L-GN	4803	II	—
4	0.75	GY/L-BU	4804	I	—	Direct Fuel Injector (DFI) High Voltage Control Cylinder 4	4	0.75	GY/L-BU	4804	II	—

5	0.5	BK/GN	2919	I	—	Fuel Rail Pressure Sensor Low Reference	5	0.5	BK/L-GN	2919	II	—
6	—	—	—	—	—	Not Occupied	6	—	—	—	—	—
7	0.75	BN/WH	4901	I	—	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 1	7	0.75	BN/WH	4901	II	—
8	0.75	L-BU/GY	4902	I	—	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 2	8	0.75	L-BU/GY	4902	II	—
9	0.75	GN/GY	4903	I	—	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 3	9	0.75	L-GN/GY	4903	II	—
10	0.75	L-BU/WH	4904	I	—	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 4	10	0.75	L-BU/WH	4904	II	—
11	0.5	BN/RD	2917	I	—	Fuel Rail Pressure Sensor 5V Reference	11	0.5	BN/RD	2917	II	—
12	0.5	L-BU/WH	2918	I	—	Fuel Rail Pressure Sensor Signal	12	0.5	L-BU/WH	2918	II	—

X160 Engine Harness to Fuel Injector - Odd Harness (LGZ)



—

Connector Part Information

Harness Type: Engine

OEM Connector: 33472-0606

Service Connector: 13585853

Description: 6-Way F 150 MX Series, Sealed (BK)

Connector Part Information

Harness Type: Fuel Injector - Odd

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way M

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required

X160 Engine Harness to Fuel Injector - Odd Harness (LGZ)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.75	BN	4801	I	—	Direct Fuel Injector (DFI) High Voltage Control Cylinder 1	1	0.75	BN	4801	II	—
2	0.75	BN/WH	4901	I	—	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 1	2	0.75	BN/WH	4901	II	—
3	0.75	GN	4803	I	—	Direct Fuel Injector (DFI) High Voltage Control Cylinder 3	3	0.75	L-GN	4803	II	—
4	0.75	GN/GY	4903	I	—	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 3	4	0.75	L-GN/GY	4903	II	—

5	0.75	WH/GN	4805	I	—	Direct Fuel Injector (DFI) High Voltage Control Cylinder 5	5	0.75	WH/L-GN	4805	II	—
6	0.75	GN/WH	4905	I	—	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 5	6	0.75	L-GN/WH	4905	II	—

X161 Engine Harness to Fuel Injector - Even Harness (LGZ)



—

Connector Part Information

Harness Type: Engine

OEM Connector: 33472-1236

Service Connector: 19178148

Description: 12-Way F 150 MX Series, Sealed (BK)

Connector Part Information

Harness Type: Fuel Injector - Even

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 12-Way M

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13578813	J-35616-2A (GY)	J-38125-217	Not Available	Not Available	Not Available	Not Available
II	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required

X161 Engine Harness to Fuel Injector - Even Harness (LGZ)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	—	—	—	—	—	Not Occupied	1	—	—	—	—	—
2	0.75	L-BU	4802	I	—	Direct Fuel Injector (DFI) High Voltage Control Cylinder 2	2	0.75	L-BU	4802	II	—
3	0.75	GY/L-BU	4804	I	—	Direct Fuel Injector (DFI) High Voltage Control Cylinder 4	3	0.75	GY/L-BU	4804	II	—
4	0.75	VT/GN	4806	I	—	Direct Fuel Injector (DFI) High Voltage Control Cylinder 6	4	0.75	VT/L-GN	4806	II	—
5	0.5	BK/GN	2919	I	—	Fuel Rail Pressure Sensor Low Reference	5	0.5	BK/L-GN	2919	II	—

6 - 7	—	—	—	—	—	Not Occupied	6 - 7	—	—	—	—	—
8	0.75	L-BU/GY	4902	I	—	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 2	8	0.75	L-BU/GY	4902	II	—
9	0.75	L-BU/WH	4904	I	—	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 4	9	0.75	L-BU/WH	4904	II	—
10	0.75	VT/GY	4906	I	—	Direct Fuel Injector (DFI) High Voltage Supply Cylinder 6	10	0.75	VT/GY	4906	II	—
11	0.5	BN/RD	2917	I	—	Fuel Rail Pressure Sensor 5V Reference	11	0.5	BN/RD	2917	II	—
12	0.5	L-BU/WH	2918	I	—	Fuel Rail Pressure Sensor Signal	12	0.5	L-BU/WH	2918	II	—

X175 Engine Harness to Transmission Harness



—

Connector Part Information

Harness Type: Engine

OEM Connector: 2138314-7

Service Connector: 19332681

Description: 36-Way F 1.2 MCON-CB, 2.8 MCP Series, Sealed (BK)

Connector Part Information

Harness Type: Transmission

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 36-Way M

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	19119772	J-35616-35 (VT)	J-38125-557	1241388-1	Lear 17	E	C
II	19300445	J-35616-16 (LT GN)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
III	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required

X175 Engine Harness to Transmission Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.5	GN/WH	6380	II	—	TCC On/Off Solenoid A Control	1	0.5	L-GN/WH	6380	III	—
2	—	—	—	—	—	Not Occupied	2	—	—	—	—	—
3	0.5	YE/BN	6404	II	—	Clutch E Control	3	0.5	YE/BN	6404	III	—
4	0.5	GY/GN	6403	II	—	Clutch D Control	4	0.5	GY/L-GN	6403	III	—

5	0.5	BN	6400	II	—	Clutch A Control	5	0.5	BN	6400	III	—
6	0.5	L-BU	6401	II	—	Clutch B Control	6	0.5	L-BU	6401	III	—
7	0.5	YE/BN	6210	II	—	TCC On/Off Solenoid B Control	7	0.5	YE/BN	6210	III	—
8 - 9	—	—	—	—	—	Not Occupied	8 - 9	—	—	—	—	—
10	0.5	GY	6402	II	—	Clutch C Control	10	0.5	GY	6402	III	—
11	0.5	BK/BN	586	II	—	Transmission Oil Temperature Sensor Low Reference	11	0.5	BK/BN	586	III	—
12	0.5	BN/WH	585	II	—	Transmission Oil Temperature Sensor Signal	12	0.5	BN/WH	585	III	—
13	0.5	WH	4508	II	—	Transmission Clutch G Control	13	0.5	WH	4508	III	—
14	0.5	WH/L-BU	4507	II	—	Transmission Clutch H Control	14	0.5	WH/L-BU	4507	III	—
15 - 17	—	—	—	—	—	Not Occupied	15 - 17	—	—	—	—	—
18	0.75	GN/GY	6387	I	—	Transmission High Side Driver 1 Signal Driver	18	0.75	L-GN/GY	6387	III	—
19	0.75	GY/BN	6388	I	—	Transmission High Side Driver 2 Signal	19	0.75	GY/BN	6388	III	—
20	—	—	—	—	—	Not Occupied	20	—	—	—	—	—

21	0.5	WH/BK	5983	II	—	PRNDL C Signal	21	0.5	WH/BK	5983	III	—
22	0.5	VT/WH	5981	II	—	PRNDL A Signal	22	0.5	VT/WH	5981	III	—
23	0.5	GY/WH	4168	II	—	PRNDL P Signal	23	0.5	GY/WH	4168	III	—
24	0.5	GY/L-BU	6358	II	—	Output Speed Signal	24	0.5	GY/L-BU	6358	III	—
25	0.5	YE/GN	4170	II	—	Transmission Position Sensor B 9V Reference	25	0.5	YE/L-GN	4170	III	—
26	0.5	GN/YE	6353	II	—	Input Speed Signal	26	0.5	L-GN/YE	6353	III	—
27	0.5	YE/L-BU	4171	II	—	Transmission Position Sensor A 9V Reference	27	0.5	YE/L-BU	4171	III	—
28	0.5	GY/BN	5982	II	—	PRNDL B Signal	28	0.5	GY/BN	5982	III	—
29	0.5	YE/L-BU	4171	II	—	Transmission Position Sensor A 9V Reference	29	0.5	YE/L-BU	4171	III	—
30	0.5	BK/GY	3927	II	—	IMS Mode Switch Low Reference	30	0.5	BK/GY	3927	III	—
31	0.5	YE/GN	4170	II	—	Transmission Position Sensor B 9V Reference	31	0.5	YE/L-GN	4170	III	—

32	0.5	GN/VT	4510	II	—	Transmission Intermediate Speed Signal	32	0.5	L-GN/VT	4510	III	—
33	—	—	—	—	—	Not Occupied	33	—	—	—	—	—
34	0.5	GY/YE	4169	II	—	PRNDL S Signal	34	0.5	GY/YE	4169	III	—
35	0.5	WH/GY	1786	II	—	Transmission Park/Neutral Signal 1	35	0.5	WH/GY	1786	III	—
36	—	—	—	—	—	Not Occupied	36	—	—	—	—	—

X200 Body Harness to Instrument Panel Harness





Connector Part Information

Harness Type: Body

OEM Connector: 2109452-2

Service Connector: 19329739

Description: 48-Way F 1.2 MCON, 2.8 MCP Series (BK)

Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 5-2109455-2

Service Connector: 19329740

Description: 48-Way M 1.2 MCON, 2.8 MCP Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	19119592	J-35616-35 (VT)	J-38125-557	Not Available	Not Available	Not Available	Not Available
II	19329758	J-35616-16 (LT GN)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
III	13575529	J-35616-5 (PU)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
IV	13575574	J-35616-5 (PU)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
V	13575574	J-35616-5 (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
VI	19329749	J-35616-13 (BU)	J-38125-12A	Not Available	Not Available	Not Available	Not Available

X200 Body Harness to Instrument Panel Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
		RD/VT	542	I	—	Battery Positive Voltage			RD/VT	542	V	—

1	2.5						1	2.5				
2	—	—	—	—	—	Not Occupied	2	—	—	—	—	—
3	0.5	GN/BN	507	I	—	Wait To Start Indicator Control	3	0.35	GN/BN	507	III	—
4	0.5	L-BU/YE	6105	II	—	High Speed GMLAN Serial Data (+) 2 High Speed GMLAN Serial Data (+) 2	4	0.5	L-BU/YE	6105	VI	—
5	0.5	WH	6106	II	—	High Speed GMLAN Serial Data (-) 2 High Speed GMLAN Serial Data (-) 2	5	0.5	WH	6106	VI	—
6	0.5	L-BU/BN	7573	II	—	Electric Variable Displacement Supply	6	0.5	L-BU/BN	7573	VI	—
7	0.5	L-BU/YE	7574	II	—	Electric Variable Displacement Control	7	0.5	L-BU/YE	7574	VI	—
8 - 9	—	—	—	—	—	Not Occupied	8 - 9	—	—	—	—	—
10	0.5	RD/GN	4440	II	—	Battery Positive Voltage	10	0.5	RD/GN	4440	VI	—
11 - 13	—	—	—	—	—	Not Occupied	11 - 13	—	—	—	—	—
14	1	L-BU	201	I	—	Left Front Speaker Control (+) 1 Left Front Speaker Control (+) 1	14	0.75 1	L-BU L-BU	201 201	IV IV	UQ3+IOB UQA
		BN/L-BU	118	I	—	Left Front Speaker			BN/L-BU	118	IV	UQ3+IOB

15	1					Signal (-) 1 Left Front Speaker Signal (-) 1	15	0.75 1	BN/L-BU	118	IV	UQA
16 - 17	—	—	—	—	—	Not Occupied	16 - 17	—	—	—	—	—
18	0.5	GY	158	II	—	Cargo Lamp Switch Signal	18	0.35	GY	158	VI	—
19	0.5	BN/WH	1429	II	—	Standing Lamp Relay Control	19	0.5	BN/WH	1429	VI	—
20	—	—	—	—	—	Not Occupied	20	—	—	—	—	—
21	0.35	WH	6816	II	—	Indicator Dimming Control	21	0.35	WH	6816	VI	—
22	0.5	YE	6817	II	—	LED Backlight Dimming Control	22	0.5	YE	6817	VI	—
23	0.35	YE/BN	3265	II	—	Child Security Lock Switch Signal	23	0.35	YE/BN	3265	VI	—
24	0.35	GY	5697	II	—	Child Lockout Indicator Control	24	0.35	GY	5697	VI	—
25	—	—	—	—	—	Not Occupied	25	—	—	—	—	—
26	1	GN/BK	116	I	—	Left Rear Speaker Signal (-) Left Rear Speaker Signal (-)	26	0.75 1	GN/BK GN/BK	116 116	IV IV	UQ3+IOB UQA
27	1	GN	199	I	—	Left Rear Speaker Control (+)	27	0.75	GN	199	IV	UQ3+IOB

						Left Rear Speaker Control (+)		1	GN	199	IV	UQA
28 - 29	—	—	—	—	—	Not Occupied	28 - 29	—	—	—	—	—
30	0.5	BN/WH	419	II	—	Check Engine Indicator Control	30	0.35	BN/WH	419	VI	—
31	0.35	BN/YE	780	II	—	Driver Door Lock Switch Lock Signal	31	0.35	BN/YE	780	VI	—
32	0.35	BN/WH	781	II	—	Driver Door Lock Switch Unlock Signal	32	0.35	BN/WH	781	VI	—
33	0.5	WH	5359	II	—	Brake Apply Sensor Control	33	0.35	WH	5359	VI	—
34	0.5	L-BU/YE	5361	II	—	Brake Apply Sensor Signal	34	0.35	L-BU/YE	5361	VI	—
35	0.5	BK/BN	5360	II	—	Brake Apply Sensor Low Reference	35	0.35	BK/BN	5360	VI	—
36	0.5	BARE	6974	II	—	Camera Low Reference	36	0.35	BARE	6974	VI	—
37	2.5	RD/GN	242	I	—	Battery Positive Voltage	37	2.5	RD/GN	242	V	—
38 - 41	—	—	—	—	—	Not Occupied	38 - 41	—	—	—	—	—
42	0.5	BK/WH	2251	II	—	Signal Ground	42	0.5	BK/WH	2251	VI	—

43	0.5	WH/L-BU	5986	II	—	Serial Data Communication Enable	43	0.5	WH/L-BU	5986	VI	—
44	—	—	—	—	—	Not Occupied	44	—	—	—	—	—
45	0.5	BN/VT	193	II	—	Rear Defog Relay Control	45	0.35	BN/VT	193	VI	—
46	0.35	GN/GY	6135	II	CREW CAB	Local Interconnect Network Serial Data Bus 4	46	0.5	GN/GY	6135	VI	—
	0.5	GN/GY	6135	II	EXTENDED CAB	Local Interconnect Network Serial Data Bus 4						
47	0.5	GY/YE	6972	II	—	Camera Signal 2 +	47	0.35	GY/YE	6972	VI	—
48	0.5	WH/L-BU	6973	II	—	Camera Signal 2	48	0.35	WH/L-BU	6973	VI	—

X202 Body Harness to Instrument Panel Harness





Connector Part Information

Harness Type: Body

OEM Connector: 1-2109452-3

Service Connector: 19329737

Description: 48-Way F 1.2 MCON, 2.8 MCP Series (GY)

Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 1-2109455-3

Service Connector: 19329738

Description: 48-Way M 1.2 MCON, 2.8 MCP Series

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	19119592	J-35616-35 (VT)	J-38125-557	Not Available	Not Available	Not Available	Not Available
II	19329758	J-35616-16 (LT GN)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
III	13575574	J-35616-5 (PU)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
IV	13575574	J-35616-5 (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
V	19329749	J-35616-13 (BU)	J-38125-12A	Not Available	Not Available	Not Available	Not Available

X202 Body Harness to Instrument Panel Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1 - 3	—	—	—	—	—	Not Occupied	1 - 3	—	—	—	—	—
		RD/GY	2140	II	—	Battery Positive Voltage			RD/GY	2140	V	—

4	0.5						4	0.75			
5	0.5	VT	4601	II	—	Retained Accessory Power Fused Control	5	0.5	VT	4601	V	—
6	0.35	RD/YE	3040	II	—	Battery Positive Voltage	6	0.35	RD/YE	3040	V	—
7	0.75	RD/BN	2240	II	—	Battery Positive Voltage	7	0.75	RD/BN	2240	V	—
8	0.35	VT	801	II	—	Retained Accessory Power Fuse Control	8	0.35	VT	801	V	—
9	0.5	RD/GY	2840	II	—	Battery Positive Voltage	9	0.5	RD/GY	2840	V	—
10	0.5	VT/BN	300	II	—	Run Ignition 3 Voltage	10	0.5	VT/BN	300	V	—
11	0.5	VT/GY	139	II	—	Run/Crank Ignition 1 Voltage	11	0.5	VT/GY	139	V	—
12	0.5	YE	5991	II	—	Powertrain Relay Coil Control	12	0.5	YE	5991	V	—
13	—	—	—	—	—	Not Occupied	13	—	—	—	—	—
14	2.5	L-BU	47	I	—	Trailer Auxiliary Control	14	2.5	L-BU	47	IV	—
15	0.5	YE	5991	I	—	Powertrain Relay Coil Control	15	0.5	YE	5991	V	—

16	0.35	GY/WH	3272	II	—	Remote Function Actuator Control	16	0.35	GY/WH	3272	V	—
17	0.35	YE/GN	3274	II	—	Remote Function Actuator Transmit Signal	17	0.35	YE/GN	3274	V	—
18	0.35	L-BU/WH	3275	II	—	Remote Function Actuator Receive Signal	18	0.35	L-BU/WH	3275	V	—
19	0.35	GY	3273	II	—	Remote Function Actuator Low Reference	19	0.35	GY	3273	V	—
20	0.35	GY/GN	328	II	—	Interior Lamp Defeat Switch Signal	20	0.35	GY/GN	328	V	—
21	0.5	GY	157	II	—	Interior Lamp Control	21	0.5	GY	157	V	—
22	0.5	YE	6817	II	—	LED Backlight Dimming Control	22	0.5	YE	6817	V	—
23	0.5	VT/GY	7117	II	—	Front Axle Differential Lock Indicator Control	23	0.5	VT/GY	7117	V	—
24	0.5	YE	7115	II	—	Rear Axle Differential Lock Indicator Control	24	0.5	YE	7115	V	—
25	2.5	RD/YE	2340	I	—	Battery Positive Voltage	25	2.5	RD/YE	2340	IV	—
26	—	—	—	—	—	Not Occupied	26	—	—	—	—	—
27	0.5	YE/GN	7122	I	—	Axle Differential Lock Switch Signal	27	0.5	YE/GN	7122	V	—

28	0.35	GN/BK	1563	II	—	2 HI Indicator Control	28	0.35	GN/BK	1563	V	—
29	0.35	GY/GN	1561	II	—	AWD Indicator Control	29	0.35	GY/GN	1561	V	—
30	0.35	BN/BK	1566	II	—	4 HI Indicator Control	30	0.35	BN/BK	1566	V	—
31	0.35	VT/WH	1565	II	—	4 LO Indicator Control	31	0.35	VT/WH	1565	V	—
32	0.35	BN	1560	II	—	Neutral Indicator Control	32	0.35	BN	1560	V	—
33	0.35	GY/RD	6029	II	—	Four Wheel Drive Mode Switch 5V Reference	33	0.35	GY/RD	6029	V	—
34	0.35	L-BU/YE	1693	II	—	Four Wheel Drive Switch Signal	34	0.35	L-BU/YE	1693	V	—
35	0.5	GN/BK	7633	II	—	Integrated Trailer Brake Controller User Gain Signal	35	0.5	GN/BK	7633	V	—
36	0.5	YE	7635	II	—	Integrated Trailer Brake Controller Manual Apply Signal	36	0.5	YE	7635	V	—
37	0.5	L-BU/RD	7632	I	—	Integrated Trailer Brake Controller Switch 5V Reference	37	0.5	L-BU/RD	7632	III	—
38	0.5	BN	7634	I	—	Integrated Trailer Brake Controller Redundant Manual Apply Signal	38	0.5	BN	7634	III	—

39	0.5	BK/BN	7631	I	—	Integrated Trailer Brake Controller Switch Low Reference	39	0.5	BK/BN	7631	III	—
40	0.5	GN/RD	7119	II	—	Axle Differential Lock Mode Switch 5V Reference	40	0.5	GN/RD	7119	V	—
41	0.5	WH/VT	5905	II	—	Key Capture/Column Lock Shift Position Signal	41	0.5	WH/VT	5905	V	—
42	0.5	GN/L-BU	6133	II	—	Local Interconnect Network Serial Data Bus 2	42	0.5	GN/L-BU	6133	V	—
43	0.5	WH/L-BU	3691	II	—	Trailer Brake Apply Signal	43	0.5	WH/L-BU	3691	V	—
44	0.5	VT/BK	7553	II	—	Park Lock Solenoid Control	44	0.5	VT/BK	7553	V	—
45 - 48	—	—	—	—	—	Not Occupied	45 - 48	—	—	—	—	—

X203 Body Harness to Instrument Panel Harness





Connector Part Information

Harness Type: Body

OEM Connector: 2109452-2

Service Connector: 19329739

Description: 48-Way F 1.2 MCON, 2.8 MCP Series (BK)

Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 5-2109455-2

Service Connector: 19329740

Description: 48-Way M 1.2 MCON, 2.8 MCP Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	19119592	J-35616-35 (VT)	J-38125-557	Not Available	Not Available	Not Available	Not Available
II	19329758	J-35616-16 (LT GN)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
III	13575529	J-35616-5 (PU)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
IV	13575574	J-35616-5 (PU)	J-38125-12A	Not Available	Not Available	Not Available	Not Available
V	13575574	J-35616-5 (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
VI	19329749	J-35616-13 (BU)	J-38125-12A	Not Available	Not Available	Not Available	Not Available

X203 Body Harness to Instrument Panel Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
		RD/YE	3740	I	—	Battery Positive Voltage			RD/YE	3740	V	—

1	2.5						1	2.5				
2	1	YE/BK	117	I	—	Right Front Speaker Signal (-) 1 Right Front Speaker Signal (-) 1	2	0.75 1	YE/BK YE/BK	117 117	IV IV	UE3+IOB UE3-IOB
3	1	YE	200	I	—	Right Front Speaker Control (+) 1 Right Front Speaker Control (+) 1	3	0.75 1	YE YE	200 200	IV IV	UE3+IOB UE3-IOB
4	0.35	YE/RD	597	II	—	5V Reference	4	0.35	YE/RD	597	VI	—
5	0.35	BK/L-BU	7566	II	—	Humidity/Windscreen Temp Sensor Low Reference	5	0.35	BK/L-BU	7566	VI	—
6	0.35	GY/GN	7565	II	—	Windscreen Temp Sensor Signal	6	0.35	GY/GN	7565	VI	—
7	0.35	GY/L-BU	7564	II	—	Humidity Sensor Signal	7	0.35	GY/L-BU	7564	VI	—
8	0.35	YE/L-BU	3197	II	—	Humidity Temperature Sensor Signal	8	0.35	YE/L-BU	3197	VI	—
9	0.35	YE	6817	II	—	LED Backlight Dimming Control	9	0.35	YE	6817	VI	—
10	0.35	BN	6136	II	—	Control	10	0.35	BN	6136	VI	—

11	0.5	RD/L-BU	540	II	—	Battery Positive Voltage	11	0.5	RD/L-BU	540	VI	—
12	0.5	VT/WH	1139	II	—	Run/Crank Ignition 1 Voltage Run/Crank Ignition 1 Voltage	12	0.5	VT/WH	1139	VI	—
13	2.5	RD/VT	4040	I	—	Battery Positive Voltage	13	2.5	RD/VT	4040	V	—
14	1	L-BU/BK	115	I	—	Right Rear Speaker Signal (-) Right Rear Speaker Signal (-)	14	0.75 1	L-BU/BK L-BU/BK	115 115	IV IV	UE3-IOB UQ3+IOB
15	1	WH	46	I	—	Right Rear Speaker Control (+) Right Rear Speaker Control (+)	15	0.75 1	WH WH	46 46	IV IV	UE3-IOB UQ3+IOB
16	0.35	VT/WH	5234	II	—	Passenger Seat Belt Indicator Control	16	0.35	VT/WH	5234	VI	—
17	0.35	L-BU	2307	II	—	Passenger Air Bag On Indicator Control	17	0.35	L-BU	2307	VI	—
18	0.35	GN	2308	II	—	Passenger Air Bag Off Indicator Control	18	0.35	GN	2308	VI	—
		BARE	1792	II	—	Low Reference			BARE	1792	VI	—

19	0.5						19	0.5				
20	0.35 0.35	BK/BN BK/GY	654 5152	II II	IO5/IO6-UE1 UE1+IO5/IO6	Cellular Telephone Microphone Low Reference Voice Recognition Audio Low Reference	20	0.35	BK/GY	5152	VI	—
21	0.35 0.35	L-BU GY/YE	655 5149	II II	IO5/IO6-UE1 UE1+IO5/IO6	Cellular Telephone Microphone Signal Voice Recognition Audio Signal	21	0.35	GY/YE	5149	VI	—
22	—	—	—	—	—	Not Occupied	22	—	—	—	—	—
23	0.35	GY/WH	3153	II	—	Lane Departure Warning Disable Switch Signal	23	0.35	GY/WH	3153	VI	—
24	0.35	WH	3152	II	—	Lane Departure Warning Indicator Control	24	0.35	WH	3152	VI	—
25	0.35	RD/WH	6440	I	—	Battery Positive Voltage	25	0.35	RD/WH	6440	III	—
26	1.5	VT	2101	I	—	Retained Accessory Power Fuse Ignition	26	1.5	VT	2101	V	—
27	2.5	RD/GN	2440	I	—	Battery Positive Voltage	27	2.5	RD/GN	2440	V	—
28	0.35	BARE	514	II	—	Low Reference	28	0.35	BARE	514	VI	—
		YE	658	II	—	Cellular Telephone			YE	658	VI	—

29	0.35	YE	658	II	—	Cellular Telephone Voice Signal	29	0.35	YE	658	VI	—
30	0.35	BK/YE	659	II	—	Cellular Telephone Voice Low Reference	30	0.35	BK/YE	659	VI	—
31	0.35	L-BU/GN	1304	II	—	High Speed GMLAN Serial Data (+)9	31	0.35	L-BU/GN	1304	VI	—
32	0.35	WH/GN	1305	II	—	High Speed GMLAN Serial Data (-)9	32	0.35	WH/GN	1305	VI	—
33	0.5	GY/GN	1102	II	—	Low Speed GMLAN Serial Data #2	33	0.5	GY/GN	1102	VI	—
34	—	—	—	—	—	Not Occupied	34	—	—	—	—	—
35	1	RD/VT	340	II	—	Battery Positive Voltage	35	1	RD/VT	340	VI	—
36	0.5	VT/BK	1639	II	—	Run/Crank Ignition 1 Voltage	36	0.5	VT/BK	1639	VI	—
37	1.5	VT	1701	I	—	Retained Accessory Power Ignition	37	1.5	VT	1701	V	—
38	0.5	RD/VT	340	I	—	Battery Positive Voltage	38	0.5	RD/VT	340	IV	—
39	0.75	BK	2050	I	—	Ground	39	0.75	BK	2050	IV	—
40	0.5	L-BU	2500	II	—	High Speed GMLAN Serial Data (+) 1	40	0.5	L-BU	2500	VI	—

41	0.5	WH	2501	II	—	High Speed GMLAN Serial Data (-) 1	41	0.5	WH	2501	VI	—
42	0.35	L-BU/GN	1304	II	—	High Speed GMLAN Serial Data (+)9	42	0.35	L-BU/GN	1304	VI	—
43	0.35	WH/GN	1305	II	—	High Speed GMLAN Serial Data (-)9	43	0.35	WH/GN	1305	VI	—
44 - 45	—	—	—	—	—	Not Occupied	44 - 45	—	—	—	—	—
46	0.5	RD/VT	3340	II	—	Battery Positive Voltage	46	0.5	RD/VT	3340	VI	—
47	0.35	VT/GY	539	II	—	Run/Crank Ignition 1 Voltage	47	0.35	VT/GY	539	VI	—
48	0.5	RD/WH	640	II	—	Battery Positive Voltage	48	0.5	RD/WH	640	VI	—

X206 Instrument Panel Harness to HVAC Harness





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13668003

Service Connector: 13587145

Description: 2-Way F 150 GT FBT Series (BK)

Connector Part Information

Harness Type: HVAC

OEM Connector: 15332130

Service Connector: Service by Harness - See Part Catalog

Description: 2-Way M 150 GT Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-3 (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X206 Instrument Panel Harness to HVAC Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
A	—	—	—	—	—	Not Occupied	A	—	—	—	—	—
B	0.5	BN	518	I	—	Lower Left Air Temperature Sensor Signal	B	20	BN	518	II	—

X218 Instrument Panel Harness to Body Harness (UK2)





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13581975

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 2-Way F Coax Type (CU)

Connector Part Information

Harness Type: Body

OEM Connector: 13581974

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 2-Way M Coax Type (CU)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

X218 Instrument Panel Harness to Body Harness (UK2)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
—	—	Coax	—	I	—	(XM +/-HD) Coaxial Antenna XM Signal	—	—	Coax	—	I	—

X219 Instrument Panel Harness to Body Harness









Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13581687

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way F Coax Type (BK)

Connector Part Information

Harness Type: Body

OEM Connector: 13581674

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way M Coax Type (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

X219 Instrument Panel Harness to Body Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
—	—	Coax	—	I	—	(AM/FM) Antenna RF Signal	—	—	Coax	—	I	—

X220 Instrument Panel Harness to Body Harness (IO6)





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13581685

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way F Coax Type (BK)

Connector Part Information

Harness Type: Body

OEM Connector: 13581673

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 1-Way M Coax Type (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

X220 Instrument Panel Harness to Body Harness (IO6)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
—	—	Coax	—	I	—	(GPS only) Coaxial Antenna GPS Signal	—	—	Coax	—	I	—

X299 Instrument Panel Harness to Instrument Panel Harness





Connector Part Information

- Harness Type: Instrument Panel
- OEM Connector: 7283-6443-40
- Service Connector: 88988504
- Description: 2-Way F 1.5 YESC Series (L-GY)

Connector Part Information

- Harness Type: Instrument Panel
- OEM Connector: 7282-6443-40
- Service Connector: 88988503
- Description: 2-Way M 1.5 Series (L-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-3 (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X299 Instrument Panel Harness to Instrument Panel Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.5	GY/VT	3998	I	—	MOST Serial Data (+)	1	0.5	GY/VT	3998	II	—
2	0.5	WH/GN	3997	I	—	MOST Serial Data (-)	2	0.5	WH/GN	3997	II	—

X300 Headliner Harness to Body Harness





Connector Part Information

Harness Type: Headliner

OEM Connector: 7283-6453-60

Service Connector: 89047090

Description: 16-Way F 1.5 Kaizen Series (GN)

Connector Part Information

Harness Type: Body

OEM Connector: 7282-6453-60

Service Connector: 89047072

Description: 16-Way M 1.5 Kaizen Series (GN)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13578891	J-35616-2A (GY)	J-38125-11A	Not Available	Not Available	Not Available	Not Available
II	13575818	J-35616-3 (GY)	J-38125-553	Not Available	Not Available	Not Available	Not Available

X300 Headliner Harness to Body Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.35	BK/BN	654	I	—	Cellular Telephone Microphone Low Reference	1	0.35	BK/BN	654	II	—
2	0.35	GN/BK	2515	I	—	Keypad Control	2	0.35	GN/BK	2515	II	—

3	0.35	GN/WH	2514	I	—	Keypad Signal	3	0.35	GN/WH	2514	II	—
4	0.35	YE/VT	2516	I	—	Keypad Green LED Control	4	0.35	YE/VT	2516	II	—
5	0.35	BN/WH	2517	I	—	Keypad Red LED Control	5	0.35	BN/WH	2517	II	—
6	0.35	YE/RD	597	I	—	5V Reference	6	0.35	YE/RD	597	II	—
7	0.35	BK/L-BU	7566	I	—	Humidity/Windscreen Temp Sensor Low Reference	7	0.35	BK/L-BU	7566	II	—
8	0.35	GY/GN	7565	I	—	Windscreen Temp Sensor Signal	8	0.35	GY/GN	7565	II	—
9	0.35	L-BU	655	I	—	Cellular Telephone Microphone Signal	9	0.35	L-BU	655	II	—
10	0.35	RD/GN	3140	I	—	Battery Positive Voltage	10	0.35	RD/GN	3140	II	—
11	0.35	BK	3450	I	—	Ground	11	0.35	BK/WH	3451	II	—
12	0.35	WH	3152	I	—	Lane Departure Warning Indicator Control	12	0.35	WH	3152	II	—
13	0.35	GY/WH	3153	I	—	Lane Departure Warning Disable Switch Signal	13	0.35	GY/WH	3153	II	—

14	0.35	GY/L-BU	7564	I	—	Humidity Sensor Signal	14	0.35	GY/L-BU	7564	II	—
15	0.35	YE/L-BU	3197	I	—	Humidity Temperature Sensor Signal	15	0.35	YE/L-BU	3197	II	—
16	—	—	—	—	—	Not Occupied	16	—	—	—	—	—

X301 Headliner Harness to Body Harness





Connector Part Information

Harness Type: Headliner

OEM Connector: AIT2PB-22-2AK

Service Connector: 13504097

Description: 22-Way F 0.64 Kaizen Series (BK)

Connector Part Information

Harness Type: Body

OEM Connector: 13892299

Service Connector: 13505628

Description: 22-Way M 0.64 Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575867	J-35616-64B (LT BU)	J-38125-215A	SAIT-A03T-M064	Yazaki 14	P	P
II	19299859	J-35616-65B (LT BU)	J-38125-215A	Not Available	Not Available	Not Available	Not Available
III	19299859	J-35616-65B (LT BU)	J-38125-215A	SAITW-A03T-064	Delphi 20	J	J

X301 Headliner Harness to Body Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.35	GY/WH	3272	I	—	Remote Function Actuator Control	1	0.35	GY/WH	3272	III	—
2	0.35	YE/GN	3274	I	—	Remote Function	2	0.35	YE/GN	3274	III	—

2	0.35					Actuator Transmit Signal	2	0.35				
3	0.35	L-BU/WH	3275	I	—	Remote Function Actuator Receive Signal	3	0.35	L-BU/WH	3275	III	—
4	0.35	GY	3273	I	—	Remote Function Actuator Low Reference	4	0.35	GY	3273	III	—
5	0.5	YE	6817	I	—	LED Backlight Dimming Control	5	0.5	YE	6817	III	—
6	0.5	WH/BN	6815	I	—	Inadvertent Power Control	6	0.75	WH/BN	6815	II	—
7	0.5	GY	157	I	—	Interior Lamp Control	7	0.5	GY	157	III	—
8	0.35	GY/GN	328	I	—	Interior Lamp Defeat Switch Signal	8	0.35	GY/GN	328	III	—
9	0.35	GY	156	I	—	Courtesy Lamp Switch Signal	9	0.35	GY	156	III	—
10	0.5	VT/GN	1739	I	—	Run/Crank Ignition 1 Voltage	10	0.5	VT/GN	1739	III	—
11	0.5	GN/WH	24	I	—	Backup Lamp Control	11	0.5	GN/WH	24	III	—
12	0.75	BK	2050	I	—	Ground	12	0.75	BK	3150	II	—
13	—	—	—	—	—	Not Occupied	13	—	—	—	—	—

14	0.35	VT/WH	5234	I	—	Passenger Seat Belt Indicator Control	14	0.35	VT/WH	5234	III	—
15	0.35	L-BU	2307	I	—	Passenger Air Bag On Indicator Control	15	0.35	L-BU	2307	III	—
16	0.35	GN	2308	I	—	Passenger Air Bag Off Indicator Control	16	0.35	GN	2308	III	—
17	0.5	GN	5060	I	—	Low Speed GMLAN Serial Data	17	0.5	GN	5060	III	—
18	—	—	—	—	—	Local Interconnect Network Serial Data Bus 1	18	0.5	GN/BN	6132	III	—
19	0.35	VT/WH	1139	I	—	Run/Crank Ignition 1 Voltage	19	0.35	VT/WH	1139	III	—
20 - 22	—	—	—	—	—	Not Occupied	20 - 22	—	—	—	—	—

X302 Floor Console Harness to Instrument Panel Harness





Connector Part Information

Harness Type: Floor Console

OEM Connector: 13584760

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 5-Way F 2.0 Mini-B USB Type (BK)

Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 13584746

Service Connector: Service by Cable Assembly — See Part Catalog

Description: 5-Way M 2.0 Mini-B USB Type (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	No Tool Required	No Tool Required	Not Required	Not Required	Not Required	Not Required

X302 Floor Console Harness to Instrument Panel Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
—	—	USB	—	I	—	USB Serial Data	—	—	USB	—	I	—

X303 Body Harness to CHMSL Harness



—

Connector Part Information

Harness Type: Body

OEM Connector: 7283-3440-40

Service Connector: 19149536

Description: 3-Way F 1.5 Kaizen Series (L-GY)

Connector Part Information

Harness Type: CHMSL

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 3-Way M

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required

X303 Body Harness to CHMSL Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.75	WH/VT	1430	I	—	Exterior Courtesy Lamp Control	1	0.75	WH/VT	1430	II	—
2	0.5	VT/GY	1054	I	—	Stop Lamp Control	2	0.5	VT/GY	1054	II	—
3	0.75	BK	3150	I	—	Ground	3	0.75	BK	3150	II	—

X305 Instrument Panel Harness to Floor Console Harness





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 7283-6447-40

Service Connector: 88956524

Description: 14-Way F 1.5, 2.8 Series (L-GY)

Connector Part Information

Harness Type: Floor Console

OEM Connector: 89047433

Service Connector: Service by Harness - See Part Catalog

Description: 14-Way M 1.5, 2.8 Series (L-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575839	J-35616-35 (VT)	J-38125-11A	Not Available	Not Available	Not Available	Not Available
II	13575850	J-35616-2A (GY)	J-38125-11A	Not Available	Not Available	Not Available	Not Available
III	Not Required	J-35616-3 (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required
IV	Not Required	J-35616-5 (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X305 Instrument Panel Harness to Floor Console Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	1.5	BK	2050	I	—	Ground	1	—	—	—	—	—

2	0.35	BK/WH	2051	II	—	Signal Ground	2	0.35	BK/WH	2051	III	—
3 - 5	—	—	—	—	—	Not Occupied	3 - 5	—	—	—	—	—
6	0.5	RD/VT	340	II	—	Battery Positive Voltage	6	0.5	RD/VT	340	III	—
7	1.5	VT	1701	I	—	Retained Accessory Power Ignition	7	—	—	—	—	—
8	1.5	BK	2050	I	—	Ground	8	1.5	BK	2050	IV	—
9	0.35	GN	5841	II	—	Right Auxiliary Audio Signal 2	9	—	—	—	—	—
10	0.35	GY	5839	II	—	Left Auxiliary Audio Signal 2	10	—	—	—	—	—
11	0.35	VT	5843	II	—	Auxiliary Audio Common Signal	11	—	—	—	—	—
12	0.5	BK	5842	II	—	Auxiliary Audio Screen 2	12	—	—	—	—	—
13	0.35	L-BU	2060	II	—	Auxiliary Detection Signal	13	—	—	—	—	—
14	1.5	VT	2101	I	—	Retained Accessory Power Fuse Ignition	14	1.5	VT	2101	IV	—

X306 Instrument Panel Harness to Floor Console Harness





Connector Part Information

Harness Type: Instrument Panel

OEM Connector: 7283-3441-40

Service Connector: 19153166

Description: 8-Way F 1.5 YESC Kaizen Series (L-GY)

Connector Part Information

Harness Type: Floor Console

OEM Connector: 7282-3441-40

Service Connector: Service by Harness - See Part Catalog

Description: 8-Way M 1.5 YESC Kaizen Series (L-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-3 (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X306 Instrument Panel Harness to Floor Console Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.35	VT	801	I	—	Retained Accessory Power Fuse Control	1	0.35	VT	801	II	—
2	0.5	GN/L-BU	6133	I	—	Local Interconnect Network Serial Data Bus 2	2	0.5	GN/L-BU	6133	II	—

3	0.75	BK	2050	I	—	Ground Ground	3	0.5 0.35	BK BK	2050 2050	II II	M5T/MYB KA1
4	0.5	VT	4601	I	—	Retained Accessory Power Fused Control	4	0.5	VT	4601	II	—
5	0.35	WH	6816	I	—	Indicator Dimming Control	5	0.35	WH	6816	II	—
6	0.35	VT/YE	5526	I	—	Tap Up/Tap Down Switch Signal	6	0.35	VT/YE	5526	II	—
7	0.5	VT/BK	7553	I	—	Park Lock Solenoid Control	7	0.5	VT/BK	7553	II	—
8	0.5	WH/VT	5905	I	—	Key Capture/Column Lock Shift Position Signal	8	0.5	WH/VT	5905	II	—

X310 Driver Seat Cushion Harness to Body Harness

—



Connector Part Information

Harness Type: Driver Seat Cushion

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 23-Way F

Connector Part Information

Harness Type: Body

OEM Connector: 13750010

Service Connector: 19332380

Description: 23-Way M 1.5 DSQ, 2.8 AST Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required
II	13327190	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available
III	13575574	J-35616-5 (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
IV	13578882	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available
V	19353142	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available

X310 Driver Seat Cushion Harness to Body Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	2.5	RD/YE	5040	I	—	Battery Positive Voltage	1	2.5	RD/YE	5040	III	—
2	0.75	BK/YE	2080	I	—	Driver Heated Seat NTC Low Reference	2	0.75	BK/YE	2080	II	—
7	0.35	YE/OG	3482	I	—	Driver Seat Belt Anchor Pretensioner Low Control	7	0.35	YE/OG	3482	V	—

8	0.35	OG/YE	3481	I	—	Driver Seat Belt Anchor Pretensioner High Control	8	0.35	OG/YE	3481	V	—
10	0.75	VT/BK	2424	I	—	Driver Heated Back Element Low Reference	10	0.75	VT/BK	2424	II	—
11	0.35	OG/BN	238	I	—	Driver Seat Belt Switch Signal	11	0.35	OG/BN	238	IV	—
12	0.35	L-GN/VT	5906	I	—	Driver Seat Vent Motor Control 1	12	0.35	GN/VT	5906	IV	—
13	0.75	L-BU	2425	I	—	Driver Heated Back NTC Signal	13	0.75	L-BU	2425	II	—
15	0.35	L-GN/OG	3069	I	—	Driver Side Impact Module Low Control	15	0.35	GN/OG	3069	V	—
16	2.5	BK	3750	I	—	Ground	16	2.5	BK	3750	III	—
17	0.75	YE/GY	2079	I	—	Driver Heated Seat NTC Signal	17	0.75	YE/GY	2079	II	—
19	0.35	BK/OG	1363	I	—	Driver Seat Belt Switch Low Reference	19	0.35	BK/OG	1363	V	—
20	0.75	VT/BK	1239	I	—	Run/Crank Ignition 1 Voltage	20	0.75	VT/BK	1239	II	—
21	0.75	BN/VT	2077	I	—	Driver Heated Seat Element Control	21	0.75	BN/VT	2077	II	—

22	0.75	BN	2432	I	—	Driver Heated Back Element Control	22	0.75	BN	2432	II	—
23	0.35	OG/L-BU	3068	I	—	Driver Side Impact Module High Control	23	0.35	OG/L-BU	3068	V	—

X320 Passenger Seat Cushion Harness to Body Harness





Connector Part Information

Harness Type: Passenger Seat Cushion

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 23-Way F

Connector Part Information

Harness Type: Body

OEM Connector: 13750010

Service Connector: 19332380

Description: 23-Way M 1.5 DSQ, 2.8 AST Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	Not Available	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	13327190	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available
III	13575574	J-35616-5 (PU)	J-38125-36	Not Available	Not Available	Not Available	Not Available
IV	13578882	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available
V	19331731	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available
VI	19353142	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available

X320 Passenger Seat Cushion Harness to Body Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
		RD/BN	1440	I	—	Battery Positive Voltage			RD/BN	1440	III	—

1	2.5						1	2.5				
2	0.75	BK/YE	2080	I	—	Driver Heated Seat NTC Low Reference	2	0.75	BK/YE	2080	II	—
3	0.75	RD/L-GN	5140	I	—	Battery Positive Voltage	3	0.75	RD/GN	5140	II	—
4	—	—	—	—	—	Not Occupied	4	—	—	—	—	—
5	0.5	BK/WH	2251	I	—	Signal Ground	5	0.5	BK/WH	2251	V	—
6	0.35	L-GN	5060	I	—	Low Speed GMLAN Serial Data	6	0.35	GN	5060	IV	—
7	0.35	GY/OG	3480	I	—	Passenger Seat Belt Anchor Pretensioner Low Control	7	0.35	GY/OG	3480	VI	—
8	0.35	OG/BN	3479	I	—	Passenger Seat Belt Anchor Pretensioner High Control	8	0.35	OG/BN	3479	VI	—
9	0.75	RD/L-GN	6140	I	—	Battery Positive Voltage	9	0.75	RD/GN	6140	II	—
10	0.75	VT/BK	2424	I	—	Driver Heated Back Element Low Reference	10	0.75	VT/BK	2424	II	—
11	0.35	OG/VT	1362	I	—	Passenger Seat Belt Switch Signal	11	0.35	OG/VT	1362	VI	—
12	0.35	RD/L-GN	4440	I	—	Battery Positive Voltage	12	0.35	RD/GN	4440	VI	—

13	0.75	L-BU	2425	I	—	Driver Heated Back NTC Signal	13	0.75	L-BU	2425	II	—
14	0.35	L-GN/VT	5906	I	—	Driver Seat Vent Motor Control 1	14	0.35	GN/VT	5906	IV	—
15	0.35	BN/OG	3067	I	—	Passenger Side Impact Module Low Control	15	0.35	BN/OG	3067	VI	—
16	2.5	BK	3850	I	—	Ground	16	2.5	BK	3850	III	—
17	0.75	YE/GY	2079	I	—	Driver Heated Seat NTC Signal	17	0.75	YE/GY	2079	II	—
18	0.5	L-GN/L-BU	6133	I	—	Local Interconnect Network Serial Data Bus 2	18	0.5	GN/L-BU	6133	II	—
19	0.35	BK/OG	1361	I	—	Passenger Seat Belt Switch Low Reference	19	0.35	BK/OG	1361	VI	—
20	0.75	VT/BK	1239	I	—	Run/Crank Ignition 1 Voltage	20	0.75	VT/BK	1239	II	—
21	0.75	BN/VT	2077	I	—	Driver Heated Seat Element Control	21	0.75	BN/VT	2077	II	—
22	0.75	BN	2432	I	—	Driver Heated Back Element Control	22	0.75	BN	2432	II	—
23	0.35	OG/GY	3066	I	—	Passenger Side Impact Module High Control	23	0.35	OG/GY	3066	VI	—

X400 Chassis Harness to License Lamp Harness (X88/Z88)





Connector Part Information

Harness Type: Chassis

OEM Connector: 493577-2

Service Connector: 19301910

Description: 10-Way F 2.8 Junior Power Timer Series, Sealed (BK)

Connector Part Information

Harness Type: License Lamp

OEM Connector: 1718167-1

Service Connector: Service by Harness - See Part Catalog

Description: 10-Way M 2.8 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13578866	J-35616-4A (PU)	J-38125-36	964280-2	Yazaki 15	E	C
II	Not Required	J-35616-5 (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X400 Chassis Harness to License Lamp Harness (X88/Z88)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.5	GN/YE	6846	I	—	Rear License Lamp Control	1	0.5	GN/YE	6846	II	—
2	0.5	BK	750	I	—	Ground	2	0.5	BK	750	II	—

3	—	—	—	—	—	—	3	0.5	GN/YE	—	II	—
4	—	—	—	—	—	—	4	0.5	BK	—	II	—
5	0.5	WH/L-BU	6973	I	—	Camera Signal 2	5	0.5	WH/L-BU	6973	II	—
6	0.5	GY/YE	6972	I	—	Camera Signal 2 +	6	0.5	GY/YE	6972	II	—
7	0.5	GN	6974	I	—	Camera Low Reference	7	0.5	GN	6974	II	—
8	0.5	BK/WH	751	I	—	Signal Ground	8	0.5	BK/WH	751	II	—
9	0.5	VT/GN	1739	I	—	Run/Crank Ignition 1 Voltage	9	0.5	VT/GN	1739	II	—
10	0.5	GN/WH	24	I	—	Backup Lamp Control	10	0.5	GN/WH	24	II	—

X401 Cargo Lamp Harness to Chassis Harness





Connector Part Information

Harness Type: Chassis

OEM Connector: 1-1823608-5

Service Connector: 19300402

Description: 2-Way F 1.2 MCP Series, Sealed (BK)

Connector Part Information

Harness Type: Chassis

OEM Connector: 2203314-1

Service Connector: 19332631

Description: 2-Way M 1.2 Multilock Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-16 (LT GN)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-13 (BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X401 Cargo Lamp Harness to Chassis Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.75	WH/VT	1430	I	—	Exterior Courtesy Lamp Control	1	0.75	WH/VT	1430	II	—
2	0.75	BK/WH	751	I	—	Signal Ground	2	0.75	BK/WH	751	II	—

X410 Tail Lamp - Left Harness to Chassis Harness

—



Connector Part Information

Harness Type: Tail Lamp - Left

OEM Connector: Not Available

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way F

Connector Part Information

Harness Type: Chassis

OEM Connector: 33482-0601

Service Connector: 13395395

Description: 6-Way M 150 MX Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-3 (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X410 Tail Lamp - Left Harness to Chassis Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	1.5	L-GN/WH	24	I	—	Backup Lamp Control	1	1.5	GN/WH	24	II	—
2	1.5	BN/L-BU	2509	I	—	Left Rear Park Lamp Control	2	1.5	BN/L-BU	2509	II	—
3	1.5	GY/YE	7542	I	—	Left Rear Stop Lamp Control	3	1.5	GY/YE	7542	II	—
4	1.5	BK	750	I	—	Ground	4	1.5	BK	750	II	—

X420 Tail Lamp - Right Harness to Chassis Harness

—



Connector Part Information

Harness Type: Tail Lamp - Right

OEM Connector: Not Available

Service Connector: Service by Harness - See Part Catalog

Description: 6-Way F

Connector Part Information

Harness Type: Chassis

OEM Connector: 33482-0601

Service Connector: 13395395

Description: 6-Way M 150 MX Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-3 (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X420 Tail Lamp - Right Harness to Chassis Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	1.5	L-GN/WH	24	I	—	Backup Lamp Control	1	1.5	GN/WH	24	II	—
2	1.5	BN/GY	2609	I	—	Right Rear Park Lamp Control	2	1.5	BN/GY	2609	II	—
3	1.5	WH/YE	7541	I	—	Right Rear Stop Lamp Control	3	1.5	WH/YE	7541	II	—
4	1.5	BK	850	I	—	Ground	4	1.5	BK	850	II	—

X500 Body Harness to Driver Door Harness





Connector Part Information

Harness Type: Body

OEM Connector: 30432411

Service Connector: 19300485

Description: 34-Way F 1.5, 2.8 Series, Sealed (BK)

Connector Part Information

Harness Type: Driver Door

OEM Connector: 3 053 06 11

Service Connector: Service by Harness - See Part Catalog

Description: 34-Way M 1.5, 2.8 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575357	J-35616-2A (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available
II	13575377	J-35616-35 (VT)	J-38125-557	Not Available	Not Available	Not Available	Not Available
III	13578884	J-35616-14 (GN)	J-38125-560	Not Available	Not Available	Not Available	Not Available
IV	Not Required	J-35616-19 (BK)	No Tool Required	Not Required	Not Required	Not Required	Not Required
V	Not Required	J-35616-5 (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X500 Body Harness to Driver Door Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	2.5	RD/L-BU	1240	II	—	Battery Positive Voltage	1	2.5	RD/L-BU	1240	V	—

2	2.5	BK	3550	II	—	Ground	2	2.5	BK	3550	V	—
3	0.35	WH	3398	I	—	Passenger Mirror Motor Common Control	3	0.35	WH	3398	IV	—
4	0.5	BN/YE	2267	III	—	Mirror Heating Element Control	4	0.5	BN/YE	2267	IV	—
5	0.35	YE/VT	3397	I	—	Passenger Mirror Motor Up (+) Down (-) Control	5	0.35	YE/VT	3397	IV	—
6	0.35	GN/BK	3396	I	—	Passenger Mirror Motor Right (+) Left (-) Control	6	0.35	GN/BK	3396	IV	—
7 - 8	—	—	—	—	—	Not Occupied	7 - 8	—	—	—	—	—
9	1	BN/L-BU	118	III	—	Left Front Speaker Signal (-) 1	9	1	BN/L-BU	118	IV	—
10	1	L-BU	201	III	—	Left Front Speaker Control (+) 1	10	1	L-BU	201	IV	—
11	—	—	—	—	—	Not Occupied	11	—	—	—	—	—
12	0.35	WH	6816	I	—	Indicator Dimming Control	12	0.35	WH	6816	IV	—
13	—	—	—	—	—	Not Occupied	13	—	—	—	—	—
14	0.35	OG/GN	2132	I	—	Left Front Side Impact Sensing Module Signal	14	0.35	OG/GN	2132	IV	—
15	0.35	BK/OG	6628	I	—	Left Front Side Impact Sensing Module Low Reference	15	0.35	BK/OG	6628	IV	—

16	0.35	RD/VT	1940	I	—	Battery Positive Voltage	16	0.5	RD/VT	1940	IV	AXG+DL6/DL9
						Battery Positive Voltage		0.35	RD/VT	1940	IV	DL6/DL9
17	0.35	BN/WH	781	I	—	Driver Door Lock Switch Unlock Signal	17	0.35	BN/WH	781	IV	—
18	0.35	BN/YE	780	I	—	Driver Door Lock Switch Lock Signal	18	0.35	BN/YE	780	IV	—
19	0.75	BN/YE	294	III	—	Door Lock Actuator Unlock Control	19	0.75	BN/YE	294	IV	—
20	0.75	GY	5911	III	—	Door Lock Actuator Lock Control 2	20	0.75	GY	5911	IV	—
21 - 25	—	—	—	—	—	Not Occupied	21 - 25	—	—	—	—	—
26	0.35	YE	6817	I	—	LED Backlight Dimming Control	26	0.35	YE	6817	IV	—
27 - 31	—	—	—	—	—	Not Occupied	27 - 31	—	—	—	—	—
32	0.35	GY	5697	I	—	Child Lockout Indicator Control	32	0.35	GY	5697	IV	—
33	0.5	GN/YE	6134	III	—	Local Interconnect Network Serial Data Bus 3	33	0.5	GN/YE	6134	IV	—
34	0.35	YE/BN	3265	I	—	Child Security Lock Switch Signal	34	0.35	YE/BN	3265	IV	—

X510 OSRVM Harness to Driver Door Harness

—



Connector Part Information

Harness Type: OSRVM

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 10-Way F

Connector Part Information

Harness Type: Driver Door

OEM Connector: AIT2WSB-10A-2AK

Service Connector: Service by Harness - See Part Catalog

Description: 10-Way M 0.64 Kaizen Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-65B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X510 OSRVM Harness to Driver Door Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.35	YE/BN	3391	I	—	Driver Mirror Motor Common Control	1	0.35	YE/BN	3391	II	—
2	0.35	VT/L-BU	3390	I	—	Driver Mirror Motor Up (+) Down (-) Control	2	0.35	VT/L-BU	3390	II	—
3	0.35	BN/BK	3389	I	—	Driver Mirror Motor Right (+) Left (-) Control	3	0.35	BN/BK	3389	II	—
4	0.5	BN/YE	2267	I	—	Mirror Heating Element Control	4	0.5	BN/YE	2267	II	—

5	0.5	BK	3550	I	—	Ground	5	0.5	BK	3550	II	—

X600 Body Harness to Passenger Door Harness





Connector Part Information

Harness Type: Body

OEM Connector: 30432411

Service Connector: 19300485

Description: 34-Way F 1.5, 2.8 Series, Sealed (BK)

Connector Part Information

Harness Type: Passenger Door

OEM Connector: 3 053 06 11

Service Connector: Service by Harness - See Part Catalog

Description: 34-Way M 1.5, 2.8 Series, Sealed (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	13575357	J-35616-2A (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available
II	13575377	J-35616-35 (VT)	J-38125-557	Not Available	Not Available	Not Available	Not Available
III	13578884	J-35616-14 (GN)	J-38125-560	Not Available	Not Available	Not Available	Not Available
IV	Not Required	J-35616-19 (BK)	No Tool Required	Not Required	Not Required	Not Required	Not Required
V	Not Required	J-35616-5 (PU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X600 Body Harness to Passenger Door Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	2.5	RD/WH	1340	II	—	Battery Positive Voltage	1	2.5	RD/WH	1340	V	—

2	2.5	BK	3650	II	—	Ground	2	2.5	BK	3650	V	—
3	0.35	WH	3398	I	—	Passenger Mirror Motor Common Control	3	0.35	WH	3398	IV	—
4	0.5	BN/YE	2267	III	—	Mirror Heating Element Control	4	0.5	BN/YE	2267	IV	—
5	0.35	YE/VT	3397	I	—	Passenger Mirror Motor Up (+) Down (-) Control	5	0.35	YE/VT	3397	IV	—
6	0.35	GN/BK	3396	I	—	Passenger Mirror Motor Right (+) Left (-) Control	6	0.35	GN/BK	3396	IV	—
7 - 8	—	—	—	—	—	Not Occupied	7 - 8	—	—	—	—	—
9	1	YE/BK	117	III	—	Right Front Speaker Signal (-) 1	9	1	YE/BK	117	IV	—
10	1	YE	200	III	—	Right Front Speaker Control (+) 1	10	1	YE	200	IV	—
11 - 13	—	—	—	—	—	Not Occupied	11 - 13	—	—	—	—	—
14	0.35	BN/OG	2134	I	—	Right Front Side Impact Sensing Module Signal	14	0.35	BN/OG	2134	IV	—
15	0.35	BK/OG	6629	I	—	Right Front Side Impact Sensing Module Low Reference	15	0.35	BK/OG	6629	IV	—
16	—	—	—	—	—	Not Occupied	16	—	—	—	—	—
17	0.35	BN/VT	245	I	—	Passenger Door Lock Switch Unlock Control	17	0.35	BN/VT	245	IV	—

18	0.35	YE/VT	244	I	—	Passenger Door Lock Switch Lock Control	18	0.35	YE/VT	244	IV	—
19	0.75	BN/YE	294	III	—	Door Lock Actuator Unlock Control	19	0.75	BN/YE	294	IV	—
20	0.75	GY	295	III	—	Door Lock Actuator Lock Control	20	0.75	GY	295	IV	—
21 - 25	—	—	—	—	—	Not Occupied	21 - 25	—	—	—	—	—
26	0.35	YE	6817	I	—	LED Backlight Dimming Control	26	0.35	YE	6817	IV	—
27 - 32	—	—	—	—	—	Not Occupied	27 - 32	—	—	—	—	—
33	0.5	GN/YE	6134	I	—	Local Interconnect Network Serial Data Bus 3	33	0.5	GN/YE	6134	IV	—
34	—	—	—	—	—	Not Occupied	34	—	—	—	—	—

X610 OSRVM Harness to Passenger Door Harness

—



Connector Part Information

Harness Type: OSRVM

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 10-Way F

Connector Part Information

Harness Type: Passenger Door

OEM Connector: AIT2WSB-10A-2AK

Service Connector: Service by Harness - See Part Catalog

Description: 10-Way M 0.64 Kaizen Series (BK)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required
II	Not Required	J-35616-65B (LT BU)	No Tool Required	Not Required	Not Required	Not Required	Not Required

X610 OSRVM Harness to Passenger Door Harness

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	0.35	WH	3398	I	—	Passenger Mirror Motor Common Control	1	0.35	WH	3398	II	—
2	0.35	YE/VT	3397	I	—	Passenger Mirror Motor Up (+) Down (-) Control	2	0.35	YE/VT	3397	II	—
3	0.35	L-GN/BK	3396	I	—	Passenger Mirror Motor Right (+) Left (-) Control	3	0.35	GN/BK	3396	II	—
4	0.5	BN/YE	2267	I	—	Mirror Heating Element Control	4	0.5	BN/YE	2267	II	—

5	0.5	BK	3650	I	—	Ground	5	0.5	BK	3650	II	—

X700 Left Rear Door Harness to Body Harness (AXG)





Connector Part Information

Harness Type: Left Rear Door

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 20-Way F

Connector Part Information

Harness Type: Body

OEM Connector: 13680032

Service Connector: 13577518

Description: 20-Way M 1.5, 2.8 DSQ Series (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required
II	13575556	J-35616-34 (YE)	J-38125-560	Not Available	Not Available	Not Available	Not Available
III	13575706	J-35616-32 (OR)	J-38125-36	Not Available	Not Available	Not Available	Not Available
IV	13575775	J-35616-34 (YE)	J-38125-560	Not Available	Not Available	Not Available	Not Available
V	13575776	J-35616-34 (YE)	J-38125-560	964265-2	Lear 28	E	2
VI	13575776	J-35616-34 (YE)	J-38125-560	964265-2	Lear 28	E	C

X700 Left Rear Door Harness to Body Harness (AXG)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
		RD/L-BU	1240	I	—	Battery Positive Voltage			RD/L-BU	1240	III	—

1	2.5						1	2.5				
2	2.5	BK	3350	I	—	Ground	2	2.5	BK	3350	III	—
3 - 6	—	—	—	—	—	Not Occupied	3 - 6	—	—	—	—	—
7	1	L-GN	199	I	—	Left Rear Speaker Control (+)	7	1	GN	199	II	—
8	—	—	—	—	—	Not Occupied	8	—	—	—	—	—
9	0.75	WH/L-BU	3266	I	—	Child Security Lock Motor Lock Control	9	0.75	WH/L-BU	3266	VI	—
10	0.75	BN/YE	294	I	—	Door Lock Actuator Unlock Control	10	0.75	BN/YE	294	VI	—
11	0.75	GY	295	I	—	Door Lock Actuator Lock Control	11	0.75	GY	295	VI	—
12 - 15	—	—	—	—	—	Not Occupied	12 - 15	—	—	—	—	—
16	1	L-GN/BK	116	I	—	Left Rear Speaker Signal (-)	16	1	GN/BK	116	II	—
17 - 18	—	—	—	—	—	Not Occupied	17 - 18	—	—	—	—	—
19	0.35	BN/WH	3269	I	—	Child Security Lock Motor Status Signal Left Rear	19	0.35	BN/WH	3269	IV	—
20	0.35	L-GN/GY	6135	I	CREW CAB	Local Interconnect Network Serial Data Bus 4	20	0.35	GN/GY	6135	IV	CREW CAB
		L-GN/GY	6135	I	EXTENDED CAB				GN/GY	6135	V	EXTENDED CAB
	0.5					Local Interconnect Network Serial Data Bus 4		0.5				

X700 Left Rear Door Harness to Body Harness (UQA)





Connector Part Information

Harness Type: Left Rear Door

OEM Connector: 7283-3442-40

Service Connector: Service by Harness - See Part Catalog

Description: 12-Way F YESC Kaizen Series (L-GY)

Connector Part Information

Harness Type: Body

OEM Connector: 7282-3442-40

Service Connector: 88988266

Description: 12-Way M 1.5 Series (L-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	13575818	J-35616-3 (GY)	J-38125-553	Not Available	Not Available	Not Available	Not Available
III	19329753	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available

X700 Left Rear Door Harness to Body Harness (UQA)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	—	—	—	—	—	Not Occupied	1	—	—	—	—	—
2	0.5	OG/YE	3481	I	—	Driver Seat Belt Anchor Pretensioner High Control	2	0.35	OG/YE	3481	III	—

3	0.5	OG/WH	3477	I	—	Driver Seat Belt Retractor Pretensioner High Control	3	0.35	OG/WH	3477	III	—
4	1	GN/BK	116	I	—	Left Rear Speaker Signal (-)	4	1	GN/BK	116	II	—
5	0.35	GY	747	I	—	Left Rear Door Ajar Switch Signal	5	0.35	GY	747	II	—
6 - 7	—	—	—	—	—	Not Occupied	6 - 7	—	—	—	—	—
8	0.5	YE/OG	3482	I	—	Driver Seat Belt Anchor Pretensioner Low Control	8	0.35	YE/OG	3482	III	—
9	0.5	GY/OG	3478	I	—	Driver Seat Belt Retractor Pretensioner Low Control	9	0.35	GY/OG	3478	III	—
10	1	GN	199	I	—	Left Rear Speaker Control (+)	10	1	GN	199	II	—
11	0.35	BK	3350	I	—	Ground	11	0.5	BK	3350	II	—
12	—	—	—	—	—	Not Occupied	12	—	—	—	—	—

X800 Right Rear Door Harness to Body Harness (AXG)





Connector Part Information

Harness Type: Right Rear Door

OEM Connector: —

Service Connector: Service by Harness - See Part Catalog

Description: 20-Way F

Connector Part Information

Harness Type: Body

OEM Connector: 13680032

Service Connector: 13577518

Description: 20-Way M 1.5, 2.8 DSQ Series (GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Available	No Tool Required	Not Available	Not Required	Not Required	Not Required	Not Required
II	13575556	J-35616-34 (YE)	J-38125-560	Not Available	Not Available	Not Available	Not Available
III	13575706	J-35616-32 (OR)	J-38125-36	Not Available	Not Available	Not Available	Not Available
IV	13575775	J-35616-34 (YE)	J-38125-560	Not Available	Not Available	Not Available	Not Available
V	13575776	J-35616-34 (YE)	J-38125-560	964265-2	Lear 28	E	2
VI	13575776	J-35616-34 (YE)	J-38125-560	964265-2	Lear 28	E	C

X800 Right Rear Door Harness to Body Harness (AXG)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
		RD/WH	1340	I	—	Battery Positive Voltage			RD/WH	1340	III	—

1	2.5						1	2.5				
2	2.5	BK	3450	I	—	Ground	2	2.5	BK	3450	III	—
3 - 6	—	—	—	—	—	Not Occupied	3 - 6	—	—	—	—	—
7	1	WH	46	I	—	Right Rear Speaker Control (+)	7	1	WH	46	II	—
8	—	—	—	—	—	Not Occupied	8	—	—	—	—	—
9	0.75	WH/L-BU	3266	I	—	Child Security Lock Motor Lock Control	9	0.75	WH/L-BU	3266	VI	—
10	0.75	BN/YE	294	I	—	Door Lock Actuator Unlock Control	10	0.75	BN/YE	294	VI	—
11	0.75	GY	295	I	—	Door Lock Actuator Lock Control	11	0.75	GY	295	VI	—
12 - 15	—	—	—	—	—	Not Occupied	12 - 15	—	—	—	—	—
16	1	L-BU/BK	115	I	—	Right Rear Speaker Signal (-)	16	1	L-BU/BK	115	II	—
17 - 18	—	—	—	—	—	Not Occupied	17 - 18	—	—	—	—	—
19	0.35	GY/BK	3268	I	—	Child Security Lock Motor Status Signal Right Rear	19	0.35	GY/BK	3268	IV	—
20	0.35 0.5	L-GN/GY L-GN/GY	6135 6135	I I	CREW CAB EXTENDED CAB	Local Interconnect Network Serial Data Bus 4 Local Interconnect Network Serial Data Bus 4	20	0.35 0.5	GN/GY GN/GY	6135 6135	IV V	CREW CAB EXTENDED CAB

X800 Right Rear Door Harness to Body Harness (UQA)





Connector Part Information

Harness Type: Right Rear Door

OEM Connector: 7283-3442-40

Service Connector: Service by Harness - See Part Catalog

Description: 12-Way F YESC Kaizen Series (L-GY)

Connector Part Information

Harness Type: Body

OEM Connector: 7282-3442-40

Service Connector: 88988266

Description: 12-Way M 1.5 Series (L-GY)

Terminal Part Information

Terminal Type ID	Terminated Lead	Diagnostic Test Probe	Terminal Removal Tool	Service Terminal	Tray Name	Core Crimp	Insulation Crimp
I	Not Required	J-35616-2A (GY)	No Tool Required	Not Required	Not Required	Not Required	Not Required
II	13575818	J-35616-3 (GY)	J-38125-553	Not Available	Not Available	Not Available	Not Available
III	19329753	J-35616-3 (GY)	J-38125-560	Not Available	Not Available	Not Available	Not Available

X800 Right Rear Door Harness to Body Harness (UQA)

Pin	Size	Color	Circuit	Terminal Type ID	Option	Function	Pin	Size	Color	Circuit	Terminal Type ID	Option
1	—	—	—	—	—	Not Occupied	1	—	—	—	—	—
2	0.5	OG/BN	3479	I	—	Passenger Seat Belt Anchor Pretensioner High Control	2	0.35	OG/BN	3479	III	—

3	0.5	OG/GN	3475	I	—	Passenger Seat Belt Retractor Pretensioner High Control	3	0.35	OG/GN	3475	III	—
4	1	L-BU/BK	115	I	—	Right Rear Speaker Signal (-)	4	1	L-BU/BK	115	II	—
5	0.35	GY	748	I	—	Right Rear Door Ajar Switch Signal	5	0.35	GY	748	II	—
6 - 7	—	—	—	—	—	Not Occupied	6 - 7	—	—	—	—	—
8	0.5	GY/OG	3480	I	—	Passenger Seat Belt Anchor Pretensioner Low Control	8	0.35	GY/OG	3480	III	—
9	0.5	WH/OG	3476	I	—	Passenger Seat Belt Retractor Pretensioner Low Control	9	0.35	WH/OG	3476	III	—
10	1	WH	46	I	—	Right Rear Speaker Control (+)	10	1	WH	46	II	—
11	0.35	BK	3450	I	—	Ground	11	0.5	BK	3450	II	—
12	—	—	—	—	—	Not Occupied	12	—	—	—	—	—

Description and Operation

Electronic Park Lock Description and Operation

If the vehicle is equipped with automatic transmission and a floor mounted console gear shift, it has an electronic park lock system (EPL). The EPL system purpose is to prevent the ignition key from being turned to the OFF position when the transmission is in any position other than PARK and the vehicle may still be moving. The EPL system consists of an ignition lock cylinder solenoid, and a park position switch that is located in the A/T shift lock control switch. The ignition lock cylinder solenoid contains a pin that is spring loaded to mechanically prevent the ignition key cylinder from being turned to the lock position when the vehicle transmission is not in the PARK position. If vehicle power is lost, and/or the transmission is not in the Park position the operator will not be able to turn the ignition key to the lock position and will not be able to remove the ignition key from the column.

Power Mode Description and Operation

Power Moding D&O Block Diagram



Serial Data Power Mode Master

Power to many of this vehicles circuits is controlled by the module that is designated the power mode master. This vehicles power mode master is the body control module (BCM). The BCM has multiple B+ circuits that feed into it. Each of those circuits are partitioned within the controller to drive certain outputs of the vehicle's body functions. An open or short in any one of the B+ circuits may induce multiple codes/or a section of non-functionality within the BCM with the rest of the BCM functioning normally. In this case it is useful to refer to the power distribution schematics to determine if the non-functional partition of the controller shares a common B+ circuit. The ignition switch is a low current switch with multiple discrete ignition switch signals to the power mode master for determination of the power mode that will be sent over the serial data circuits to the other modules that need this information. The power mode master will also activate relays and other direct outputs of the power mode master as needed. The power mode master determines which power mode (Off, Accessory, Run, Crank Request) is required, and reports this information to other modules via serial data. Modules which have switched voltage inputs may operate in a default mode if the power mode serial data message does not match what the individual module can see from its own connections.

The power mode master receives ignition switch or ignition mode switch signals to identify the operators desired power mode. The Power Mode Parameter tables below illustrate the correct state of these input parameters (circuits) in correspondence to the ignition switch position or ignition mode switch with the transmitter to vehicle range:

Power Mode Parameters

Ignition Switch Position	Power Mode Transmitted	Ign. Off/Run/Crank (Off/Run Crank Voltage Circuit)	Ignition Accessory/Run (Accessory Voltage Circuit)	Ignition Run/Crank (Ignition 1 Voltage Circuit)
Off Key Out	Off	Key Out / ACC	Inactive	Inactive
Off Key IN	Off	Key In / Off	Inactive	Inactive
Accessory	Accessory	Key Out / ACC	Active	Inactive

Run	Run	Run	Active	Active
Start	Crank Request	Crank	Inactive	Active

Relay Controlled Power Mode

The BCM uses the discrete ignition switch inputs Off/Run/Crank Voltage, Accessory Voltage, and Ignition 1 Voltage, to distinguish the correct power mode. The BCM, after determining the desired power mode, will activate the appropriate relays for that power mode.

The accessory relay remains on for a timed period after the Ignition key is removed. Refer to Retained Accessory Power Description and Operation for more information on the retained accessory power function.

Battery Saver Mode (Transport Mode)

Battery saver mode (transport mode) reduces the parasitic load of some modules during overseas shipment or during vehicle storage conditions. This improves the drain time on the battery (up to 70 days without the battery going dead). When a vehicle is in transport/storage, some features may have reduced functionality while in the battery saver mode, such as disabling keyless entry, afterblow, and content theft features. Battery saver mode is initiated by turning on the hazard flashers, applying the brake pedal, and then turning the ignition key to the start position or pushing the ignition mode switch with the foot on the brake for greater than 15 seconds. The mode is disengaged by repeating the previous process. The driver information center (if equipped) will display Transport Mode is On when battery saver mode is enabled and Transport Mode is Off when battery saver mode is disabled. For vehicles not equipped with a driver information center, the battery indicator light will constantly flash on the Instrument Cluster when battery saver mode is enabled. This feature can be used as many times as necessary if the vehicle is to be stored for an extended period of time.

BCM Awake/Sleep States

The BCM is able to control or perform all of the BCM functions in the awake state. The BCM enters the sleep state when active control or normal monitoring of system functions has stopped and a time limit has passed. The BCM must detect certain wake-up inputs before entering the awake state. The BCM monitors for these inputs during the sleep state.

The BCM will enter the awake state if any of the following wake-up inputs are detected:

- Activity on the serial data line
- Detection of a battery reconnect
- Any door open signal
- Headlamps ON
- Key-in-ignition
- Ignition ON
- Park lamps ON
- Keyless entry or remote start message

The BCM will enter a sleep state when all of the following conditions exist:

- The ignition switch is OFF, key out.
- Ignition OFF, transmitter is out of range
- No activity exists on the serial data line.
- No outputs are commanded.
- No delay timers are actively counting.
- No wake-up inputs are present.

If all these conditions are met, the BCM will enter a low power or sleep condition.

Retained Accessory Power Description and Operation

RAP Description and Operation Block Diagram



Retained Accessory Power

The body control module (BCM) monitors the ignition switch position, battery condition, and each door ajar/open switch status to determine whether the retained accessory power should be initiated or terminated. Retained accessory power is controlled by two different methods; relay control and serial data. Some modules receive a retained accessory power message from the BCM over the serial data circuits. Serial data controlled retained accessory power is deactivated as required by their modules retained accessory power mode operation. Other subsystems are activated directly by the BCM through a relay. Components and systems that are active in retained accessory power are also activated anytime the ignition is any position other than OFF regardless of the door switch signals.

Relay Controlled Retained Accessory Power

The BCM keeps the relay energized during all power modes, except Off-Awake and Crank. The relay is also energized for approximately 10 minutes after shutting the ignition OFF and removing the key, providing no door is opened.

Relay controlled retained accessory power will end when one of the following conditions is met:

- The BCM receives an input from any door ajar or open switch indicating the opening of any door after the ignition key is out of the ignition.

  Note: If the BCM is receiving any door ajar or open signal from those switches when the ignition key is turned OFF, retained accessory power will not initiate.

- The BCM internal timer for the retained accessory power expires after approximately 10 minutes.
- The BCM detects a decrease in battery capacity below a prescribed limit.

Systems powered by the retained accessory power relay during the retained accessory power mode are as follows:

Note: The vehicle may not be equipped with all components as listed below.

- Accessory Power Receptacle
- Cigarette Lighter Receptacle

- Window Switches
- Sunroof Control Module
- Sunroof Switch
- Mobile Device Wireless Charger Module
- Mobile Telephone Control Module
- Traffic Data Receiver
- Transmission Shift Lever Position Indicator (w/floor mounted console gear shift)
- Seat Heating Control Module

Serial Data Controlled Retained Accessory Power

Retained accessory power systems controlled by serial data are as follows:

Radio

Radio retained accessory power activation / termination is the same as relay operation with one exception; the only door switch that will turn off the radio during retained accessory power is the driver door open switch.

Vehicle Communication Interface Module (VCIM) (Onstar®) (If Equipped)

VCIM RAP activation/termination is the same as radio operation with 1 exception; if there is an active call when the ignition key is turned off the VCIM will remain in RAP mode, and keep the radio in RAP mode until the call is terminated.

Safety and Security

Immobilizer

Schematic and Routing Diagrams

Immobilizer Schematics

Immobilizer


K89
Immobilizer
Control
Module
3
3276
GY/BK
2
7533
L-GN/VT
1
3277
L-GN/GY
P16
Instrument
Cluster
A90
Logic
K20
Engine
Control
Module
X3
3
2
1
K9
Body
Control
Module
X4
24
UTJ
109
BN/L-GN
Hood Latch
Schematics

Description and Operation

Immobilizer Description and Operation



The immobilizer system functions are provided by the body control module (BCM) and the engine control module (ECM), as well as any control modules which store and report the environment identifier.

When an ignition key is inserted into the ignition lock cylinder and the ignition is switched ON, the transponder in the key is energized by the immobilizer coil surrounding the ignition lock cylinder. This immobilizer coil is part of the immobilizer control module. The transponder transmits a signal that contains its unique value, which is received by the BCM through the immobilizer coil. The BCM then compares this value to a value stored in memory. The BCM also monitors various control modules to determine if the stored environment identifiers match.

If both the environment identifier and the value received from the transponder match, the BCM will send the prerelease password via serial data to the ECM. If the encrypted code's unique value is incorrect or the environment identifier does not match, the BCM will send the start disable message to the ECM which will prevent the vehicle starter and fuel pump from operating.

When the ECM receives the BCM prerelease password, the ECM will challenge the password. The ECM sends this challenge to the BCM via serial data. Both the ECM and BCM perform a calculation on this challenge. If the BCM calculated response to the challenge equals the calculation performed by the ECM, the ECM will allow vehicle starting.

The components of the theft system are as follows:

- BCM
- ECM
- Immobilizer control module
- Ignition key
- Security indicator
- Various control modules which store and report the environment identifier

Body Control Module (BCM)

The immobilizer system is an integral part of the BCM and is controlled internally within the BCM. The BCM can learn up to 8 keys (transponder values).

The BCM uses the following inputs:

- Environment identifier exchange with various modules
- Encrypted code from the vehicle key, received by the immobilizer control module

The BCM uses the following outputs:

- Prerelease password communication with ECM
- Challenge/response with ECM

When an ignition key is inserted into the ignition lock cylinder and the ignition is switched ON, the encrypted code in the key is energized by the immobilizer control module surrounding the ignition lock cylinder. The energized transponder transmits a signal that contains its unique value, which is received by the BCM. The BCM then compares this value to the learned key code stored in memory. The BCM then performs one of the following functions:

- If the encrypted code value matches the values stored in the BCM memory, the BCM will send the prerelease password to the ECM via serial data.
- If the encrypted code unique value does not match the value stored in the BCM, the BCM will send the start disable message to the ECM via serial data.
- If the BCM is unable to measure the ignition key encrypted code value, the BCM will not send any messages to the ECM.

Engine Control Module (ECM)

When the ECM receives the BCM prerelease password, the ECM will challenge the password. The ECM sends this challenge to the BCM via the serial data circuit. Both the ECM and BCM perform a calculation on this challenge. If the calculated response from the BCM equals the calculation performed by the ECM, the ECM will allow vehicle starting.

The ECM will disable vehicle starting if any of the following immobilization conditions occur:

- The prerelease password is invalid.
- The start disable password is sent by the BCM.
- No passwords are received. There is no communication with the BCM.
- The BCM calculated response to the challenge does not equal the calculation performed by the ECM.

Immobilizer Control Module

The immobilizer control module contains an immobilizer coil which surrounds the ignition cylinder. The coil passively powers the transponder located in the ignition key when the key is in the ignition. When powered, the key transmits its unique value to the immobilizer control module, which is then relayed to the BCM via a discrete serial data circuit. The immobilizer control module also receives B+ and ground from the BCM.

The immobilizer control module is used to:

1. Learn keys
2. To start the vehicle

Ignition Key

Each ignition key contains a transponder with a unique encrypted value. The transponder's encrypted value is fixed and unable to be changed. The immobilizer system uses the ignition key transponder value to determine if a valid ignition key is being used to start the vehicle.

Environment Identifier

Various modules throughout the vehicle learn a specific environment identifier during the module programming process. The environment identifier is learned by each individual module and matches the environment identifier stored in the BCM. Prior to starting after a battery disconnect, each of the modules which store a environment identifier will compare their identifier to that of the identifier stored in the BCM. If all the identifiers match, the engine starting process will continue. If the environment identifiers do not match, engine starting will be disabled.

Security Indicator

The BCM will command the instrument cluster to illuminate the security indicator when the ignition is in the ON position to indicate a fault has occurred within the immobilizer system and when the engine starting is disabled.

Safety and Security

Object Detection and Pedestrian Protection

Schematic and Routing Diagrams

Object Detection Schematics

Rear Camera (IO3)


X51A
Fuse
Block -
Instrument
Panel
KR73
Ignition
Main
Relay
F29DA
10A
X2 38
1739
VT/L-GN
F15DA
K9
Body
Control
Module
X7 3
24
L-GN/WH
J200
24
L-GN/WH
24
L-GN/WH
Inside
Rearview
Mirror
Schematics
A11
Radio
X2 5
6
6972
GY/YE
9
6973
WH/L-BU
W7
Blunt Cut - Shield
6974
BARE
X200 47
48
36
6972
GY/YE
9
6973
WH/L-BU
6974
BARE
J102
6974
L-GN
40
X106 13
7
41
42
1739
VT/L-GN
24
L-GN/WH
6972
GY/YE
6973
WH/L-BU
6974
L-GN
J105
6974
BARE
J400
6974
L-GN
7
X400 9
10
6
5
1739
VT/L-GN
24
L-GN/WH
6972
GY/YE
6973
WH/L-BU
6974
L-GN
J406
6974
BARE
J409
6974
L-GN
J402
24
L-GN/WH
24
L-GN/WH
Exterior
Lights
Schematics
751
BK/WH
5
751
BK/WH
3
1739
RD
1
24
WH
2
6972
YE
6
6973
BK
4
6974
BN
IGN
R
B87
Rearview
Camera
G401

Rear Camera (IO4/IO5/IO6)


X51A
Fuse
Block -
Instrument
Panel
KR73
Ignition
Main
Relay
F29DA
10A
X2 38
1739
VT/L-GN
F15DA
K9
Body
Control
Module
X7 3
24
L-GN/WH
J200
24
L-GN/WH
24
L-GN/WH
Inside
Rearview
Mirror
Schematics
K74
Human Machine Interface
Control Module
X2 5
6
6972
GY/YE
9
6973
WH/L-BU
W7
Blunt Cut - Shield
6974
BARE
X200 47
48
36
6972
GY/YE
9
6973
WH/L-BU
6974
BARE
J102
6974
L-GN
X106 13
7
41
42
40
1739
VT/L-GN
24
L-GN/WH
6972
GY/YE
6973
WH/L-BU
6974
L-GN
J105
6974
BARE
J400
6974
L-GN
X400 9
10
6
5
7
1739
VT/L-GN
24
L-GN/WH
6972
GY/YE
6973
WH/L-BU
6974
L-GN
J406
J402
24
L-GN/WH
24
L-GN/WH
Exterior
Lights
Schematics
6974
BARE
J409
6974
L-GN
751
BK/WH
5
751
BK/WH
3
1739
RD
1
24
WH
2
6972
YE
6
6973
BK
4
6974
BN
IGN
R
B87
Rearview
Camera
G401

Lane Departure Warning and Forward Collision Alert (UEU/UFL)


B+
X51A Fuse Block - Instrument Panel
KR73 Ignition Main Relay
F31DA 10A
F28DA 10A
X3 12
X2 28
3140 RD/L-GN
1639 VT/BK
Interior Lights Dimming Schematics
6816 WH
2
S48A Multifunction Switch - Instrument Panel
14
8
5
2050 BK
3153 GY/WH
3152 WH
X203 23
24
X300 13
12
3153 GY/WH
3152 WH
10
4
X300 10
Instrument Cluster Schematics
1639 VT/BK
X203 36
1639 VT/BK
3140 RD/L-GN
5060 L-GN
3
7
B+
K109 Frontview Camera Module
1
3450 BK
1
IGN
P43 Collision Alert Indicators
3
2
4
3535 WH/L-GN
3885 GY/YE
2151 BK/WH
30
12
P16 Instrument Cluster
A90 Logic
A11 Radio
K9 Body Control Module
X3 4
16
1444 WH/RD
5737 GY/L-GN
X2 5
7
X85 Steering Wheel Air Bag Coil
X1 6
4
1444 WH
J234
1444 WH
1444 WH
5737 GY/OG
9
3
Steering Wheel Secondary/Configurable Control Schematics
S70L Steering Wheel Controls Switch - Left
Cruise Control Schematics
G300
G304
G307
LOC
DESC

Description and Operation

Lane Departure Warning Description and Operation

Lane Departure Warning Block Diagram


S48C
Multifunction
Switch 1 -
Instrument
Panel
K109
Frontview
Camera
Module
A11
Radio
P16
Instrument
Cluster
K40
Seat
Memory
Control
Module
P45RR
Seat
Haptic
Movement
Motor -
Driver
Right Rear
P45LR
Seat
Haptic
Movement
Motor -
Driver Left
Rear

The lane departure warning system is a convenience feature of the front view camera that issues a warning when the system detects that the vehicle has unintentionally crossed a lane marking. The front view camera is located behind the windshield, looking out at the road ahead and detecting any lane markings. When the vehicle unintentionally leaves a detected lane, a visual and audible or haptic (pulses the seat, if equipped) alerts are given to the driver. The visual alert cannot be changed, but the driver can select between audible or haptic alerts in the vehicle personalization menus. See the user's manual for more detailed information on vehicle personalization.

The lane departure warning system is made up of the following components:

- Front view camera module
- Lane departure warning switch / control indicator
- Instrument cluster / Vehicle Direction Display
- Radio
- Safety Alert Seat, if equipped

Front View Camera Module

The camera detects visual queues such as lane markings. When it is determined that the vehicle has unintentionally moved outside of the lane, visual, and audible or haptic warning is given to the driver. The front view camera module receives an input from the lane departure warning switch and controls the lane departure warning switch indicator output. The front view camera module also communicates via serial data with the instrument cluster, radio, and memory seat module to request visual, and audible or haptic alerts.

Lane Departure Warning Switch

The lane departure warning switch provides an input to the front view camera module to turn the lane departure warning system ON and OFF. The front view camera module provides a signal voltage to the normally open momentary switch. When the switch is pressed, the signal circuit is pulled to ground, indicating to the front view camera module that the system has been requested to turn ON or OFF. The lane departure warning switch also contains the lane departure warning switch indicator, which is controlled by the front view camera module to indicate the ON and OFF status of the lane departure warning system. When the system has been enabled by the lane departure warning switch, the front view camera module applies ground to the switch indicator and illuminates the LED. The location of the lane departure warning switch can vary with different vehicles. For the exact location please refer to the user's manual.

Instrument Cluster

The vehicle direction display contains green and amber lane departure warning indicators. These indicate to the driver the current status of the lane departure warning system and are controlled via serial data by the front view camera module. When the vehicle speed is above 56 km/h (35 MPH) and the system has detected the required lane markings and is ready to assist, the green indicator will be illuminated on the vehicle direction display. If the vehicle has unintentionally left the lane, the amber indicator will flash.

Radio

The radio controls the audible alert for the lane departure warning. If the vehicle has unintentionally left the lane, the radio will command three beeps as an audible alert to the driver.

Safety Alert Seat

The memory seat module controls the haptic alert provided by the seats. If the vehicle has unintentionally left the lane, the memory seat module will command three pulses to the left or right side of the seat, depending on the lane departure direction.

Lane Departure Warning Operation

System operation can be described by the following modes:

- Off State: The system has been turned off by the driver using the lane departure warning switch. The lane departure warning indicator will not be illuminated.
- Not Ready To Assist: The system is enabled and the lane departure warning indicator is illuminated, but not ready to assist when any of the following conditions is true:
  - Vehicle speed is less than 56 km/h (35 MPH). The system is designed to function at speeds greater than 56 km/h (35 MPH).
  - The system cannot detect lane markings. This may be because there are no lane markings, as on a country road or that the lane markings cannot be determined due to snow, rain, or other driving conditions.
  - The windshield area in front of the camera or the camera lens is blocked by fog, dirt, damage to the windshield or other elements that may prevent the camera from detecting lane markings.
- Ready To Assist: The system is enabled and ready to warn of the unintentional lane crossing. The system is ready to assist when the green lane departure warning indicator is illuminated on the vehicle direction display.

Lane Crossing Alerts

- When one of the following conditions are met, the system will not give alerts:
  - The correct turn signal is activated. An activated turn signal is interpreted as an intentional lane crossing.
  - The operator makes an intentional steering maneuver.
  - The operator makes an intentional accelerating maneuver.
  - The operator makes an intentional braking maneuver.
- Lane crossing alert consists of the following:
  - The amber lane departure warning indicator will flash.
  - Three chimes are activated through the radio.
  - or if equipped, three pulses to the left or right side of the seat.

Lane Departure Warning System Driver Information Center Messages

The front view camera module can command the driver information center to display the various messages to alert the driver of a system concern or status information. For detailed information about the possible messages please refer to the user's manual.

Forward Collision Alert Description and Operation

Forward Collision Alert Block Diagram


S70L
Steering Wheel Controls Switch - Left
K9
Body Control Module
K109
Frontview Camera Module
A11
Radio
P16
Instrument Cluster
K40
Seat Memory Control Module
P43
Collision Alert Indicators
P45RR
Seat Haptic Movement Motor - Driver Right Rear
P45LR
Seat Haptic Movement Motor - Driver Left Rear

The forward collision alert system is a convenience feature of the front view camera that issues a warning to the driver when a potential collision risk exists. The front view camera is located behind the windshield, looking out at the road ahead and detecting vehicles directly ahead, within a distance of approximately 60 meters (197 ft). The forward collision alert system operates at speeds above 40 kph (25 mph). When the system detects a vehicle in the path ahead, the green vehicle ahead indicator in the vehicle direction display is illuminated. When approaching another vehicle too rapidly, the collision alert symbol will flash in the head-up display (if equipped) or a series of red LEDs in the vehicle direction display. Simultaneously an audible alert can sound or the Safety Alert Seat pulses. The visual alert cannot be changed, but the driver can select between audible or haptic alerts in the vehicle personalization menus. The forward collision alert system can also be turned on or off through the vehicle personalization menus. See the user’s manual for more detailed information on vehicle personalization.

Forward collision alert does not warn the driver of any objects that are not detected as a vehicle, like e.g. pedestrians, animals, signs, guard rails, bridges, construction barrels or other stationary or slow moving objects. The forward collision alert timing sensitivity to control the distance to the vehicle ahead can be set using the forward collision alert switch in the left steering wheel controls.

In some cases the camera may detect a vehicle that is not in the path ahead, or the system may occasionally provide unrealistic alerts. This could respond to a turning vehicle ahead, guard rails, traffic signs, or other stationary objects. This is normal operation, the vehicle does not need service. Forward collision alert may sometimes set unnecessary alerts to turning vehicles, vehicles in other lanes, objects that are not vehicles, or shadows. These alerts are normal operation and the vehicle does not need service.

The forward collision alert system is made up of the following components:

- Front view camera module
- Forward collision alert switch
- Instrument cluster / Vehicle direction display
- Radio
- Memory Seat Module and Safety Alert Seat, if equipped

Front View Camera Module

The camera detects vehicles in front of the host vehicle. The front view camera module requests the green vehicle ahead alert indicator in the vehicle direction display ON via serial data when the front view camera system has detected a vehicle in the driving path ahead. The front view camera module also communicates via serial data with the driver information center, radio, and memory seat module to request visual, and audible or haptic alerts.

Forward Collision Alert Switch

The forward collision alert switch provides an input to the front view camera module to select the alert timing sensitivity when approaching another vehicle too rapidly. The front view camera module provides a signal voltage to the normally open switch. When the switch is pressed, the signal circuit is pulled to ground, indicating to the front view camera module that the system has been requested to change the alert timing sensitivity. The first button press shows the current alert timing setting on the driver information center. With every button press, the alert timing sensitivity is changed. The current alert timing setting will be maintained until it is changed. The preset alert timing setting is displayed in the top line of the driver information center. The position of the forward collision alert switch can vary with different vehicles. For the exact position of the switch and possible user settings, please refer to the user's manual.

Instrument Cluster

The Vehicle direction display contains the green vehicle ahead indicator, which indicates to the driver that the Front View Camera system has detected a vehicle in the driving path ahead and is controlled via serial data. When approaching another vehicle too rapidly, the collision alert symbol will flash in the Vehicle direction display. The red Front collision alert display will stay continuously illuminated if the vehicle ahead remains much too close. The vehicle ahead indicator will display amber when following too close to the vehicle ahead.

Radio

The radio controls the audible alert for the forward collision alert system. If the host vehicle is approaching another vehicle too rapidly, the radio will command eight beeps as an audible alert to the driver.

Safety Alert Seat

The memory seat module controls the haptic alert provided by the seats. If the vehicle is approaching another vehicle too quickly, the memory seat module will command five pulses to both sides of the seat.

Forward Collision Alert System Driver Information Center Messages

The front view camera module can command the driver information center to display the various messages to alert the driver of a system concern or status information. For detailed information about the possible messages please refer to the user's manual.

Rear Vision Camera Description and Operation

Rear Vision Camera System Operation

The rear vision camera system consists of a video camera/module located at the rear of the vehicle and the infotainment display.

When the transmission is placed into REVERSE, a 12 volt signal is sent to the rear vision camera by the body control module (BCM). This signal indicates to the camera that the vehicle is in reverse and image display is requested. The rear vision camera receives ignition voltage and a constant ground to power the camera. Video signal + and video signal – circuits carry the video image from the rear vision camera to the infotainment display. Additionally, the video signal circuits are shielded to prevent any interference which may lead to a loss of video signal resolution and a degraded video image. The shield is provided a ground path by the rear vision camera.

The following conditions may cause a degraded rear vision camera image:

- Ice, snow, or mud has built up on the rear vision camera
- Dark conditions
- Extreme light conditions, such as glare from the sun or the headlights of another vehicle
- Damage to the rear of the vehicle
- Extreme high temperatures or extreme temperature changes

If a malfunction is detected in the system, Service Rear Vision Camera may be displayed on the infotainment display as an indicator to the customer that a problem exists that requires service.

Safety and Security

Remote Functions

Schematic and Routing Diagrams

Remote Function Schematics

Keyless Entry



K77
Remote
Control
Door Lock
Receiver
T2
Antenna
A90
Logic
12V
4
3
2
1
3272
GY/WH
3275
D-BU/WH
3274
YE/L-GN
3273
GY
X301
1
3
2
4
3272
GY/WH
3275
D-BU/WH
3274
YE/L-GN
3273
GY
X202
16
18
17
19
3272
GY/WH
3275
D-BU/WH
3274
YE/L-GN
3273
GY
X2
25
X1
26
X2
27
16
12V
K9
Body
Control
Module

Description and Operation

Garage Door Opener Description and Operation

The garage door opener is fixed and rolling code capable. Rolling code is a system that allows the code that the customers receiver receives from the garage door opener to change every time the garage door opener is used within operating range of the receiver. Rolling code programming requires the customer to push a learn/program button on the garage door opener receiver at their home. This button is usually located on the receiver unit under a cover (light cover) on one end of the unit. The customer must follow the garage door opener manufacturers instructions to program/learn the receiver to accept the Universal Home Remote System as an authorized opener for their unit . When the receiver and the garage door opener are initially programmed together, a code is established and a new code is created for every new transmission. The software in the receiver recognizes the garage door opener and accepts the new code.

The garage door opener is compatible with most, but not all types and brands of transmitters.

The garage door opener is a transmitter operating between 288–434 MHz. The power and range of the transmitter is limited to comply with laws governing the generation of radio frequency interference. The transmitter is programmed by the user to accept the signal generated by the user's transmitters.

The garage door opener has 3 buttons that may be programmed for individual transmitter/receiver combinations to control up to 3 garage door openers, security gates, lighting systems, etc. Each button represents a transmitter code section of the transmitter, which operates separately from any other button, and may be considered a separate transmitter. Operation consists of simply pressing a button to activate the corresponding transmitter.

Note: Do not use the garage door opener (GDO) with any garage door opener that does not have the stop and reverse safety feature. This includes any garage door opener model manufactured before April 1, 1982.

Keyless Entry System Description and Operation

The keyless entry system is a vehicle entry device. The keyless entry system is used in conjunction with the door locks to unlock the vehicle. Keyless entry will lock/unlock the vehicle doors or open the rear compartment lid when a corresponding button on the keyless entry transmitter is pressed. This is accomplished by the transmitter sending a radio frequency to the Remote Control Door Lock Receiver antenna that has a direct link to the Body Control Module (BCM). The BCM interprets the signal and activates the requested function or request the appropriate control module to activate the function via a serial data message. A low transmitter battery or radio frequency interference from aftermarket devices, such as 2-way radios, power inverters, computers, etc., may cause a system malfunction. High radio frequency traffic areas, such as gas stations that use pay-at-the-pump radio frequency transponders, may also cause interference that could lead to a malfunction. Keyless entry allows you to operate the following features:

- Door lock/unlock
- Vehicle locator/Panic alarm
- Remote vehicle starting, if equipped

The keyless entry system has the following components:

- Keyless entry transmitters
- Body Control Module
- Remote Control Door Lock Receiver

Keyless Entry Transmitters

Note: When the vehicle key is in the ignition, keyless entry functions from all keyless entry transmitter are disabled.

The keyless entry transmitters are used to perform various entry functions while away from the immediate are of the vehicle. Keyless entry functions may work at up to 20 m (65 ft) away from the vehicle. Ambient conditions may affect the performance of the keyless entry transmitter and reduce the range at which keyless entry functions operate. Up to eight transmitters may be programmed to a single vehicle.

OnStar® Remote Link (if equipped)

A vehicle operator may have the ability to perform some of the keyless entry functions using applications on personal devices such as a smart phone. Unwanted or inadvertent door lock/unlock activation may be requested by the OnStar® Remote Link app. It is possible that a customer may be unaware of account usage, result in an unwanted or phantom door lock/unlock. If normal system diagnosis does results in an inability to verify the customer’s concern, contact Technical Assistance Center (TAC).

Body Control Module (BCM)

The BCM is a multifunction module that operates the keyless entry system. When an radio frequency message is received from a keyless entry transmitter, the BCM interprets this signal and performs the specific function, i.e. door lock, door unlock, or vehicle locate.

Remote Control Door Lock Receiver

The Remote Control Door Lock Receiver acts as an antenna for the keyless entry system and communicates with the BCM through a dedicated serial data link. When a button is pressed on a keyless entry transmitter, the Remote Control Door Lock Receiver receives this signal and sends the request to the BCM. The BCM interprets the signal and performs the specific function, i.e. door lock, door unlock, or vehicle locate.

Unlock Doors

Momentarily press the transmitter UNLOCK button in order to perform the following functions:

- Unlock only the driver door or all doors and liftgate (if equipped); this is customized through the DIC.
- Illuminate the interior lamps for a determined length of time or until the ignition is turned ON.
- Flash the exterior lights; this is customized through the DIC.
- Disarm the content theft deterrent system, if equipped.
- Deactivate the content theft deterrent system when in the alarm mode.

Lock All Doors

Press the transmitter LOCK button to perform the following functions:

- Lock all vehicle doors.
- Immediately turn OFF the interior lamps.
- Flash the exterior lights and/or sound the horn; this is customized through the DIC.
- Arm the content theft deterrent system.

Vehicle Locator/Panic Alarm

A single press of the panic button performs the following functions. Some functions may be dependent on personalization settings:

- Pulse the horn three times.
- Flash the exterior lamps three times.

A press and hold of the panic button performs the following functions:

- Illuminate the interior lamps.
- Pulse the horn and flash the exterior lamps for 30 seconds or until the following conditions occur:

  - The panic button is pressed.
  - The ignition switch is turned to the RUN position with a valid key.

Remote Vehicle Start, if equipped

The remote vehicle start function allows engine starting while not in the vehicle. It also allows the vehicle HVAC system and other vehicle systems to enable, providing a comfortable vehicle upon entry. The remote vehicle start sequence begins by pressing and releasing the lock button and then pressing and holding the remote vehicle start buttons on the keyless entry transmitter. The turn signal lamps will illuminate to indicate the vehicle has received the remote start request. Each time an remote vehicle start is performed, the vehicle doors are locked, however they may then be unlocked/locked with the transmitter or vehicle key at any time. Once activated, the engine is allowed to run for 10 minutes. The remote vehicle start time may be extended by an additional 10 minutes by again pressing and releasing the lock button and then pressing and holding the remote vehicle start buttons on the transmitter. This feature is called a remote vehicle start continue and allows a maximum of 20 minutes of engine running. If the remote vehicle start continue is performed at seven minutes into the initial 10 minute time-out, a total of 17 minutes of engine running would occur. The remote vehicle start event may be suspended at any time by pressing only the remote vehicle start button on the transmitter or by entering the vehicle and pressing the hazard lamp switch.

In between ignition cycles, only two remote vehicle start events may occur or be attempted. Once two events or attempts have been made, future remote vehicle start events will be suspended until the vehicle is started using the ignition.

Enable/Disable Remote Vehicle Start

Using the driver information center, remote vehicle start may be enabled or disabled as a part of vehicle personalization. Refer to the vehicle owners manual for more information.

Hood Ajar Switch

The hood switch provides status of the hood to the BCM for remote vehicle start purposes. The switch is integrated into the hood latch assembly.

Remote Vehicle Start Circuit Description

The BCM receives a signal from the keyless entry transmitter indicating a remote vehicle start request. A message is then sent to the BCM which determines if a crank request message will be sent to the ECM to allow engine starting. To determine if conditions are correct for an remote vehicle start event, the BCM will ensure the following conditions are met:

- A valid hood ajar switch closed signal is present.
- The doors are locked.
- The hazard switch is OFF.
- The vehicle power mode is correct.
- No content theft deterrent alarm triggers are present.

When the BCM determines all conditions meet those required for an remote vehicle start event, a message is sent via serial data to the ECM. The ECM relies on the remote vehicle start message from BCM to enable remote vehicle start when the crank request signal is received. If the ECM does not receive a valid remote vehicle start message, it will not attempt to start the engine. While the ECM is in remote vehicle start mode it will suspend engine operation if any of the following additional conditions occur:

- Vehicle speed is greater than 0.
- Transmission is not in PARK.
- Excessive engine coolant temperature
- Low oil pressure
- The malfunction indicator lamp (MIL) is commanded ON.
- Engine crank time is greater than 30 seconds.
- Excessive engine speed
- Accelerator pedal position too high
- Remote start timer equals 0.
- Immobilizer system indicates tamper

Keyless Entry Personalization

Vehicle lock/unlock functions and remote vehicle start remote vehicle start settings may be personalized. For functional descriptions and personalization instructions, refer to the vehicle owners manual.

Safety and Security

Seat Belts

Schematic and Routing Diagrams

Seat Belt Schematics

Seat Belts


P16
Instrument
Cluster
A90
Logic
L O C
D E S C
K36
Inflatable
Restraint
Sensing
and
Diagnostic
Module
X2
43
41
45
44
X1
10
1363
BK/OG
238
OG/BN
1362
OG/VT
1361
BK/OG
5234
VT/WH
X310
19
11
X320
11
19
X203
16
1363
BK/OG
238
OG/BN
1362
OG/VT
1361
BK/OG
5234
VT/WH
2
2
X301
14
B153D
Seat Belt
Buckle -
Driver
B88D
Seat Belt Switch -
Driver
B153P
Seat Belt
Buckle -
Passenger
B88P
Seat Belt Switch -
Passenger
5234
VT/WH
5
P14
Passenger
Air Bag
Disabled
Indicator
SIR
Schematics
2
1
1
2
3150
BK
G301

Description and Operation

Seat Belt System Description and Operation

Seat Belt Block Diagram


B153D Seat Belt Buckle - Driver
B153P Seat Belt Buckle - Passenger
K85 Passenger Presence Module
K36 Inflatable Restraint Sensing and Diagnostic Module
A11 Radio
P16 Instrument Cluster
S48A Multifunction Switch - Instrument Panel

Restraint System

Note: If the vehicle has been in a collision, refer to CELL Link Error - Link target cell (cell ID 69000) is invalid for this publication.

The vehicle has front and rear seat belts that are the primary means of occupant restraint. Seat belts help to keep the occupants inside the passenger compartment and to gradually reduce the impact forces during the following events:

- Frontal impact type crashes
- Rear impact type crashes
- Side impact type crashes
- Roll-over type crashes

All seat belt retractors have emergency locks. The retractors remain unlocked during normal operation and under normal driving conditions. The retractors remain unlocked during normal conditions in order to allow free movement of the upper body of each occupant. A pendulum locks the seat belt webbing into position. The pendulum causes a locking bar to engage a cog on the spool of the retractor mechanism when the following conditions occur:

- A rapid extraction of the seat belt webbing from the retractor
- An abrupt change in vehicle speed
- An abrupt change in vehicle direction
- Operation of the vehicle on a steep upgrade
- Operation of the vehicle on a downgrade

The seat belts have an automatic locking (cinch) feature. The cinch feature is activated when the seat belt webbing is completely extended from the retractor. The cinch feature prevents the webbing from extending beyond the position from which it is allowed to retract. Use of the cinch feature is recommended for securing a child seat. The cinch feature may be cancelled by allowing the webbing to wind back completely into the retractor. After the cinch feature is cancelled, the webbing is unlocked. After the cinch feature is cancelled, the webbing will extend from the retractor. This vehicle is also equipped with a supplemental inflatable restraint (SIR) system. Refer to CELL Link Error - Link target cell (cell ID 62350) is invalid for this publication.

Front Seat Belt System

The front seat belt system includes a driver and passenger seat belt retractor pretensioner. Both front seat belt pretensioners includes a seat belt switch in the seat buckle which controls a reminder lamp and a tone alarm.

Note: The front passenger seat is equipped with a passenger presence sensor, which detects an occupant. If the passenger presence sensor detects an empty front passenger seat, then the passenger fasten safety belt indicator will be disabled.

- When the driver seat belt is buckled and the ignition switch is turned ON, the following events will occur:
  - The tone alarm will not operate.
  - The reminder lamp will not operate.
- When the passenger seat belt is buckled with an occupant sitting in the passenger front seat, then the ignition switch is turned ON, the following events will occur:
  - The tone alarm will not operate.
  - The reminder lamp, which is located within the Instrument Panel Multifunction Switch, will not be turned ON.
- When the driver seat belt is not buckled and the ignition switch is in the ON position, the following events will occur:
  - The tone alarm will operate for 4–8 seconds and then go OFF.
  - The fasten safety belt indicator will turn ON for 20 seconds, until the driver seat belt is buckled.
- When the passenger seat belt is not buckled with an occupant sitting in the passenger front seat, then the ignition switch is turned ON, the following events will occur:
  - The tone alarm will operate for 4–8 seconds and then go OFF.
  - The reminder lamp, which is located within the Instrument Panel Multifunction Switch, will be turned ON.

Rear Seat Belt System

The Rear Seat Belt System includes the following components:

- The rear seat belt retractor is located at the wheelhouse panel and attached to the floor panel by the rear seat shoulder belt retractor bracket.
- The rear seat belt buckles and the center seat belt buckle are attached to each seat.

Child Seat Restraint System

Warning: A child in a rear-facing child restraint can be seriously injured if the right-front passengers air bag inflates. This is because the back of a rear-facing child restraint would be very close to the inflating air bag. NEVER use a rear-facing child restraint in this vehicle. If a forward-facing child restraint is suitable for your child, ALWAYS move the front passenger seat as far back as it will go and then install the child restraint. Be sure the child restraint position does not conflict with any additional requirements provided by the manufacturer. For more information, refer to the vehicle owners manual and the instruction that came with the child restraint.

A child in a rear-facing child restraint can be seriously injured if the right-front passengers air bag inflates. This is because the back of a rear-facing child restraint would be very close to the inflating air bag. NEVER use a rear-facing child restraint in this vehicle. If a forward-facing child restraint is suitable for your child, ALWAYS move the front passenger seat as far back as it will go and then install the child restraint. Be sure the child restraint position does not conflict with any additional requirements provided by the manufacturer. For more information, refer to the vehicle owners manual and the instruction that came with the child restraint.

The child seat may only be used in a forward facing seating location. The child seat should be installed and secured according to the manufacturer's directions. If the child seat has a top strap, the seat will need to be anchored. Passengers should not be allowed to sit at locations where the seat belts are being used to secure the child seat.

All vehicles are equipped with a dual-mode type retractor with emergency and automatic locking features. The automatic locking feature is for restraint of a child seat. The child seat can be secured by pulling the seat belt all the way out to lock it. Then tighten the seat belt around the child seat.

If a child seat is to be used in the second seat position, a special dealer-installed anchor must be used in order to anchor the child seat top strap. This only applies to the seats designed with the top strap provision and for the vehicles sold in Canada. In order to ensure the correct top strap angle, the child seat is only to be used at the seating position for which the top strap anchor is installed.

Fasten Safety Belt Indicators

There are two fasten safety belt indicators for this vehicle. The driver fasten safety belt reminder is displayed in the instrument cluster, and the passenger fasten safety belt reminder is displayed in the Instrument Panel Multifunction Switch. The fasten safety belt indicator may only be ON during RUN. The fasten safety belt indicator illuminates under the following conditions:

- During the bulb check
- The inflatable restraint sensing and diagnostic module (SDM) sends the status of the driver seat belt to the instrument cluster via serial data. The passenger seat belt status is sent to the Instrument Panel Multifunction Switch via a hard wire. If any of the seat belts are unfastened, the instrument cluster will send a message requesting a chime sound to be turned ON after a bulb check.

Seats

Power Seats

Schematic and Routing Diagrams

Driver Seat Schematics

Power Seat


B+
X51A
Fuse
Block -
Instrument
Panel
F43DA
30A
X1
27
5040
RD/YE
X310
1
5040
RD/YE
J309
AL9
5040
RD/YE
X1
D
5040
RD/YE
X2
E
S64D
Seat
Adjuster
Switch -
Driver
X1
C
F
H
A
B
X2
A
D
H
285
YE/L-BU
284
GY/L-GN
283
GY/L-BU
282
YE
3750
BK
610
VT
611
L-BU
3750
BK
1
M
M51D
Seat
Horizontal
Motor -
Driver
3
1
M
M55D
Seat Rear
Vertical
Motor -
Driver
3
A
M
M52D
Seat
Lumbar
Support
Horizontal
Motor -
Driver
B
G302
G302
LOC
DESC

Passenger Seat Schematics

Power Seat

LOC

DESC



B+
X51A Fuse Block - Instrument Panel
F46DA 30A
X1 36
1440 RD/BN
X320 1
5040 RD/BN
J310
AT9
5040 RD/BN
5040 RD/BN
X1 D
X2 E
S64P Seat Adjuster Switch - Passenger
X1 C
F
H
A
B
X2 A
D
H
290 YE/L-BU
296 YE/WH
289 L-BU/WH
288 L-GN/WH
3850 BK
210 VT
211 L-BU
3850 BK
3
M
M51P Seat Horizontal Motor - Passenger
1
3
M
M55P Seat Rear Vertical Motor - Passenger
1
A
M
M52P Seat Lumbar Support Horizontal Motor - Passenger
B
G302
G302

Description and Operation

Lumbar Support Description and Operation

Lumbar Support Components

The power seat lumbar support systems consist of the following components:

- Seat lumbar support switch
- Seat lumbar support horizontal motor

The seat lumbar support switch provides both power and ground to the lumbar support motor. The switch is closed to the switch ground circuit while it is in an inactive state.

The lumbar support motor contains an electronic circuit breaker (PTC) that will reset only after voltage has been removed from the motor. The motor moves the lumbar support horizontally forward and rearward.

The motor is reversible, for example, when the lumbar forward switch is pressed to move the lumbar support forward, battery voltage is applied through the switch contacts and the lumbar motor forward control circuit to the motor. With the lumbar motor rearward switch contacts closed to the switch ground circuit, the motor runs in order to drive the lumbar support forward toward the occupants back until the switch is released. Moving the lumbar support rearward works similarly to moving the lumbar support forward, except that battery positive voltage and ground are applied on opposite circuits causing the motor to run in the opposite direction.

Power Seats System Description and Operation

The power seat system consists of the following components:

- Seat adjuster switch
- Seat horizontal motor
- Seat rear vertical motor

The seat adjuster switches provide both power and ground to the selected seat motors. The switches are closed to the switch ground circuit while they are in an inactive state.

The seat motors operate independently of each other. Each motor contains an electronic circuit breaker (PTC) that opens in the event of a circuit overload and will reset only after voltage has been removed from the circuit. There are two seat position motors. They are the horizontal motor and the rear vertical motor. The horizontal motor moves the entire seat forward and rearward while the seat rear vertical motor moves the entire seat up and down.

The motors are reversible, for example, when the seat horizontal forward switch is pressed to move the entire seat forward, battery voltage is applied through the switch contacts and the seat horizontal motor forward control circuit to the motor. With the horizontal motor rearward switch contacts closed to the switch ground circuit, the motor runs in order to drive the entire seat forward until the switch is released. Moving the entire seat rearward works similarly to moving the entire seat forward, except that battery voltage and ground are applied on opposite circuits causing the motor to run in the opposite direction. The seat rear vertical motor is also powered this way.

Seats

Seat Heating and Cooling

Schematic and Routing Diagrams

Heated/Cooled Seat Schematics

Power, Ground, Serial Data and Switches (KA1)


B+
B+
X50A
Fuse Block - Underhood
F32UA
15A
F30UA
15A
X2
68
56
X51A
Fuse Block - Instrument Panel
F9DA
10A
X2
2
2840
RD/GY
X202
9
2840
RD/GY
J221
2840
RD/GY
4
2840
RD/GY
4
S32D
Seat Heating Switch - Driver
S32P
Seat Heating Switch - Passenger
B+
B+
3
1
3
1
7527
L-GN/WH
7527
L-GN/WH
J217
7527
L-GN/WH
X3
19
K9
Body Control Module
X6
9
Data Communication Schematics
6133
L-GN/L-BU
MYB
6133
L-GN/L-BU
J208
6140
RD/L-GN
5140
RD/L-GN
2050
BK
2050
BK
6133
L-GN/L-BU
X320
9
6140
RD/L-GN
3
5140
RD/L-GN
18
6133
L-GN/L-BU
X1
7
10
X2
8
B+
B+
K29
Seat Heating Control Module
X1
8
3850
BK
G302
G300

Heating Elements (KA1)


K29 Seat Heating Control Module
5V
12V
X2 1
6
X1 6
4
5
X2 3
2
5
X1 2
3
1
X2 4
12
2080 BK
2079 BN
2077 BN/VT
2424 VT/BK
2432 BN
2425 BN
2435 GY/BK
2434 WH/GY
2479 BN/L-BU
2480 GY/BK
2481 WH/BN
2436 WH/L-BU
2482 BK/L-GN
X320 2
17
21
10
22
13
2080 BK
2079 RD
2077 YE
2424 VT/BK
2432 BN
2425 BK/RD
X310 2
17
21
10
22
13
2080 BK
2079 YE/BN
2077 BN/VT
2424 VT/BK
2432 BN
2425 L-BU
2
1
1
2
2
1
1
2
E14B Seat Heating Element - Driver Cushion
E14A Seat Heating Element - Driver Back
E14D Seat Heating Element - Passenger Cushion
E14C Seat Heating Element - Passenger Back
3
4
4
3
3
4
4
3
2080 BK
2424 VT/BK
2424 VT/BK
2080 BK/YE
2480 GY/BK
2480 BK
J314
J315
J316

Vented Seat - Driver (KU1)


K29F
Seat Heating
Control
Module -
Front
X2
9
IGN II/III
X53A
Fuse
Block -
Rear
Body
F19RA
10A
X1
10
5906
GN/VT
X320
25
739
VT/BK
5906
GN/VT
X310
26
25
739
VT/BK
5906
GN/VT
J381
J380
739
VT/BK
5906
GN/VT
739
VT/BK
5906
GN/VT
1
2
1
2
739
RD
5906
WH
739
RD
5906
WH
M73C
Seat
Blower
Motor -
Driver
Cushion
M73A
Seat
Blower
Motor -
Driver
Back
M
M
IGN
A90
Logic
IGN
A90
Logic
2150
BK
3
2150
BK
2150
BK
3
2150
BK
G301

Vented Seat - Passenger (KU1)


K29F Seat Heating Control Module - Front
X2
10
IGN II/III
X53A Fuse Block - Rear Body
F19RA 10A
X1
11
739 VT/BK
5908 VT/WH
X320
12
J386
J385
1
2
739 RD
5908 WH
M73D Seat Blower Motor - Passenger Cushion
M73B Seat Blower Motor - Passenger Back
M
IGN
A90 Logic
2250 BK
3
G302

Description and Operation

Heated/Vented Seat Description and Operation

Heated/Vented Seat Components

The heated/vented seat system consists of the following components:

- Heated and vented seat switches
- Body control module
- Seat heating control module
- Driver seat cushion heating element
- Driver seat cushion temperature sensor
- Driver seat back heating element
- Driver seat back temperature sensor
- Driver seat temperature control module
- Driver seat cushion blower motor
- Driver seat back blower motor
- Passenger seat cushion heating element
- Passenger seat cushion temperature sensor
- Passenger seat back heating element
- Passenger seat back temperature sensor
- Passenger seat temperature control module
- Passenger seat cushion blower motor
- Passenger seat back blower motor

Heated/Vented Seat Switches

The driver and passenger heated and vented seats are controlled by separate heated/vented seat switches located on the center stack near the HVAC controls. To operate the engine must be running. The BCM is the heated and vented seat system master. It monitors heated/vented seat switch activations to determine user requested operating mode. Based on the requested operating mode, the BCM sends a LIN Bus serial data message to the Seat Heating Control Module how to drive the self-regulated heating pads or ventilation motors. The BCM also controls the indicators used to provide the operator with feedback as to the operating status of the system. With each press of the switch, the system will cycle through High, Medium, Low, and then back to Off again. The BCM also controls the seat temperature and mode indicators, via the serial data line, used to provide the operator with feedback as to the operating status of the system.

Heated Seat Operation

The seat heating control module controls heated seat operation for the driver and passenger seats. There are two modes for heated seat operation; seat back and cushion heat mode and seat back only heat mode. When active, power is applied to the seat cushion and back heater elements through individual pulse width modulated (PWM) voltage supply control circuits. Each individual heater element is switched to ground by the module through a common low side drive control circuit.

When inactive the seat heating control module connects the heating element low side outputs to a common reference point internal to the module which is biased to approximately 3.5 V. The module uses this biased voltage in order to check the high side and low side control circuits for a short to battery or ground before enabling the driver and passenger seat heating elements. During heated seat operation, the seat heating control module interrupts control of the heating elements every 10 s for approximately 10 ms to make this biased voltage check.

With both the seat cushion and seat back heater elements disconnected, if the high side output of the module is measured it will display a low current 12 V bleed off voltage. This bleed off voltage does not have a meaningful diagnostic purpose. With the heater element connected you would just see the 3.5 V biased voltage from this circuit.

Temperature Regulation

The seat back and cushion temperature sensors (thermistors) are packaged with the seat heating elements located just under the seat covers. The seat heating control module supplies each temperature sensor with a 5 V reference signal circuit and a low reference circuit. The module monitors the voltage from the signal circuit to determine the temperature of the seat.

The temperature sensor varies in resistance based on the temperature of the heating element causing the signal voltage to change. Once the module senses the seat reached the set temperature, it will then begin regulate the current flow through the heater elements in order to maintain the desired seat temperature based on the feedback voltage from the sensor.

If the heated seats are on high, the temperature level may automatically be lowered after approximately 30 min of operation.

Vented Seat Operation

Each vented seat system consists of 2 blower motors; one in the seat back and one in the seat cushion. During vented seat operation, the vented seat blower motors move cabin air through channels in the foam pad and small holes in the seat covers causing a cooling effect to the occupant.

Battery voltage is supplied to the blower motors through a 15 A fuse located in the left instrument panel fuse block. Ground for each blower motor is provided through separate ground circuits and a common ground connection.

When the seat heating control module receives a ventilation seat command, it sends a low side drive pulse width modulation (PWM) signal through the blower motor control circuit to each blower motor indicating the seat ventilation command. The logic in the blower motors interprets this signal then sets the blower speed to the switch set point. The blower motors run causing a cooling effect to the occupant.

Heated and Vented Seat Operation During Remote Start

Refer to Vehicle Personalization in the Owner’s Manual for Remote Start Auto Heated and Ventilation Seats.

During remote start, the heated seats will turn ON when the ambient temperature is below 10° C (50° F).

During remote start, the seat ventilation system will turn ON when the ambient temperature is above 27° C (80° F).

Load Shed Management

The electrical power management function is designed to monitor the vehicle electrical load and determine when the battery is potentially in a high discharge condition. The heated seat system is one of the vehicle loads that is subject to reduction during a battery discharge condition. For more information on load management refer to Electrical Power Management Description and Operation.

Transmission

Shift Lock Control

Schematic and Routing Diagrams

Shift Lock Control Schematics

MYB


K9
Body
Control
Module
F5DA
X7
6
7553
VT/BK
X202
44
7553
VT/BK
X306
7
7553
VT/BK
4
7553
RD
S3
Transmission
Shift Lever
M7
Transmission Shift Lock
Control Solenoid Actuator
2050
BK
2
2050
BK
G300

Description and Operation

Automatic Transmission Shift Lock Control Description and Operation

The automatic transmission park lock control system is a safety device that prevents an inadvertent shift out of PARK. The driver must press the brake pedal before moving the park lever out of the PARK position. The system consists of the following components:

- The automatic transmission park lock solenoid (serviced as the automatic transmission shift lock actuator), is located within the floor shift control assembly.
- The body control module, which controls the voltage supply circuit of the park lock control solenoid.
- The engine control module.

The body control module controls the voltage to the park lock control solenoid through the park lock control solenoid controlled voltage circuit. The following conditions must be met before the body control module will supply voltage to the park lock solenoid:

- The ignition is in the ON position.
- The engine control module sends an input via GMLAN serial data to the body control module indicating the transmission is in the PARK position.
- The body control module determines the brake pedal is applied according the brake pedal position.

Since the park lock control solenoid is permanently grounded, the body control module supplies voltage to the automatic transmission park lock control solenoid, unlocking the park lever allowing the driver to move the park lever out of the PARK position as the solenoid energizes. When the brake pedal is not applied, the body control module turns the control voltage output of the park lock control solenoid OFF, de-energizing the park lock control solenoid. The de-energized solenoid mechanically locks the park lever in the PARK position.

Automatic Transmission Shift Lock Control Description and Operation (RPO T4Z)

The automatic transmission park lock control system is a safety device that prevents an inadvertent shift out of PARK. Vehicles equipped with the Safety Belt Assurance System (RPO T4Z), the driver must press the brake pedal and have the driver and if present, the front outboard passenger safety belt(s) buckled before moving the park lever out of the PARK position. The system consists of the following components:

- The automatic transmission park lock solenoid (serviced as the automatic transmission shift lock actuator), is located within the floor shift control assembly.
- The body control module, which controls the voltage supply circuit of the park lock control solenoid.
- The engine control module.
- The inflatable restraint sensing and diagnostic module.

The body control module controls the voltage to the park lock control solenoid through the park lock control solenoid controlled voltage circuit. The following conditions must be met before the body control module will supply voltage to the park lock solenoid:

- The ignition is in the ON position.
- The engine control module sends an input via GMLAN serial data to the body control module indicating the transmission is in the PARK position.
- The body control module determines the brake pedal is applied according the brake pedal position.
- The inflatable restraint sensing and diagnostic module determines if the occupied driver and front outboard passenger, if present, have their safety belt(s) buckled.

Since the park lock control solenoid is permanently grounded, the body control module supplies voltage to the automatic transmission park lock control solenoid, unlocking the park lever allowing the driver to move the park lever out of the PARK position as the solenoid energizes. When the brake pedal is not applied, the body control module turns the control voltage output of the park lock control solenoid OFF, de-energizing the park lock control solenoid. The de-energized solenoid mechanically locks the park lever in the PARK position.

Vehicles with the Safety Belt Assurance System, will display the following message “Shift Locked, Buckle Seatbelt” if the driver and front outboard passenger, if present, do not have safety belt(s) buckled. The vehicle will not shift out of PARK. Buckle the safety belt(s) to unlock the shifter.

This system may not allow the vehicle to shift out of PARK if an object such as a briefcase, handbag, grocery bag, laptop, or other electronic devices is on the front outboard passenger seat. If this happens, remove the object from the seat or buckle the safety belt.

Vehicles with the Safety Belt Assurance System, will display the following message “Shift Unlocked, Brake To Shift” if the system times out and allows the vehicle to be shifted out of PARK after 30 s following brake applied.

The Safety Belt Assurance System can be disabled with a calibration file update in the K36 Inflatable Restraint Sensing and Diagnostic Module using SPS. This procedure should only be done to help resolve a customer dissatisfaction issue.